

EXTRALINK OLT RAPTOR, PREDATOR

A short guide showing how to launch the **web interface**

To meet the expectations of our customers, we've added the ability of management via www in Extralink OLTs.

The following guide shows in a few steps how update the firmware of EXTRALINK OLTs, RAPTOR and PREDATOR to start management via the web interface.

It's worth mentioning that in a new firmware (V2.3.1) we've two addresses for OLT management unlike in the previous version where there was only one address:

- 1. Prior to the update, the default OLT's address is 192.168.1.100 but after updating to V2.3.1:**

- OLT uplink port manage IP address: 192.168.8.100
- OLT AUX/MGMT port manage IP address: 192.168.1.100

- 2. If the default OLT's address was changed before the update to 192.168.1.X (excluding 192.168.1.100) then after updating to V2.3.1:**

- OLT uplink port manage IP address: 192.168.1.X
- OLT UX/MGMT port manage IP address: 192.168.2.100


- 3. If the default OLT's address was changed before the update to completely different than 192.168.1.X, then after updating to V2.3.1:**

- OLT uplink port manage IP address: the same as before update
- OLT AUX / MGMT port manage IP address: 192.168.1.100

Let's get to the point ... firstly, we must prepare our work station

III. Launch the TFTP program to download a new firmware. Configure the TFTP Server as follows:

- 1) Specify a path to the software you want to update
- 2) Specify the IP address of the server (in this case it's the PC address)



IV. Now you can proceed to OLT update

Epon # system update firmware <firmware name> tftp-server <tftp-ip>

where:

(1) <firmware name>: FD1108S_V2.4.02_170421_X000.img,
<tftp-ip>: 192.168.1.111


(2) If you have typed the command correctly, you will see that the image of a firmware is being properly imported to OLT

```
192.168.1.100 - PuTTY

.....
Command Line Interface for EPON System
Hardware Ver: V3.1
Software Ver: 2.2.10_000
Created Time: Oct 10 2016 10:50:24
Copyright (c) 2006-2015 All rights reserved.
.....
Username:admin
Password:*****

Entry level 3(administrator) successfully!

epon# show system ipconfig
ip       : 192.168.1.100
netmask  : 255.255.255.0
gateway  : 192.168.1.1
MNGMT-VID : 1
epon#
epon#
epon#
epon# system update firmware FD1108S_V2.4.02_170421_X000.img tftp-server 192.168.1.111
Transferring the Image file, please wait...
```



- (3) After the correct update, type "y" to restart the OLT.
OLT needs to be restarted to load a new version of the software.

```
192.168.1.100 - PuTTY

*****
Command Line Interface for EPON System
Hardware Ver: V3.1
Software Ver: 2.2.10_000
Created Time: Oct 10 2016 10:50:24
Copyright (c) 2006-2015 All rights reserved.
*****
Username:admin
Password:*****

Entry level 3(administrator) successfully!

epon# show system ipconfig
ip       : 192.168.1.100
netmask  : 255.255.255.0
gateway  : 192.168.1.1
MNGMT-VID : 1
epon#
epon#
epon#
epon#
epon# system update firmware FD1108S_V2.4.02_170421_X000.img tftp-server 192.168.1.111
Transferring the Image file, please wait...
Erasing flash, please wait...
Upgrading image, please wait.....OK!

Reboot the system now<y/n>?
```


- V. Next step is to install an image of the software analogously. It'll launch the web access.

epon# **system update web-server <firmware name> tftp-server <tftp-ip>**

where:

(1) <firmware name>: FD1108S_WEB_V1.0.0_170421_1831.img,
<tftp-ip>: 192.168.1.111


(2) In order to check whether everything has been successfully installed, type in the command: epon# **show system infor**




```
192.168.1.100 - PuTTY
*****
Command Line Interface for EPON System
Hardware Ver: V3.1
Software Ver: 2.2.10_000
Created Time: Apr 21 2017 18:25:38
Copyright (c) 2006-2015 All rights reserved.
*****
Username:admin
Password:
epon# system update web-server FD1108S_WEB_V1.0.0_170421_1831.img tftp-server 192.168.1.111
Transferring the Web Server file, please wait...
Upgrading Web Server ...
Restarting Web Server ...
OK!
epon# show system infor

-----
Software Version : 2.2.10_000(Apr 21 2017)
Hardware Version : V3.1
MAC : e0-67-b3-00-96-ec
Serial Number : AF1101-1610000017
System Time : 2000/01/01 04:49:53 +08:00
Contact : pawel
-----
Web Server
Version : V1.0.0
BuildTime : 17-04-21 18:31:25
Administrator : admin
Password : admin
-----
System Temperature : 38.0C
FAN[1] : Normal
FAN[2] : Normal
FAN[3] : Normal
-----
epon# █
```

If everything is ok you can finally login to your OLT via the web interface without rebooting the device. Simply type in <http://192.168.1.100> (by default) and log in using the password: **admin**



It's worth mentioning that the OLT web interface is very clear which is best illustrated by the following screenshots of some of the settings:



Topology

- FD1108S
 - Main Board
 - Switching Board
 - PON Board
 - PON1
 - PON2
 - PON3
 - PON4
 - PON5
 - PON6
 - PON7
 - PON8

PATH:FD1108S>Switching Board>VLAN Manage

- Switching Board
 - Switch-Config
 - Net Interface
 - Port Status
 - Port Property
 - Packet Suppress
 - VLAN Manage
 - TRUNK
 - RSTP
 - Port Mirror
 - IGMP Snooping

VLAN Manage

VLANEnable : disable

VALNID	Tagged Port	Untagged Port	vlan-edit	vlan-clear
1		ge1;ge2;ge3;ge4;ge5;ge6;ge7;ge8;pon1;pon2;pon3;pon4;pon5;pon6;pon7;pon8;	edit	delete

refresh add set First Next

xPON OLT | Version: V1.0.0 | Language: English ▾ | Exit

Topology

- FD1108S
 - Main Board
 - Switching Board
 - PON Board
 - PON1
 - PON2
 - PON3
 - PON4
 - PON5
 - PON6
 - PON7
 - PON8

PATH:FD1108S>PON Board>BaseInfo

PON Board

- BaseInfo
- Port Property
- ONU Authority

BaseInfo

Firmware version :

operation Times : 0 days 1 hours 31 minutes 15 seconds

Operating status : normal

refresh Reboot Save Config Default

All rights reserved

We highly recommend firmware update.

All the necessary files at:

www.anteny24.com

Author: Leszek Błaszczyk

Translation: Łukasz Sikora