

# NETGEAR®


## M4100 Series ProSAFE Managed Switches

CLI Command Reference Manual

Software Version 10.0.2

April 2015  
202-11166-04

350 East Plumeria Drive  
San Jose, CA 95134  
USA



### Support

Thank you for selecting NETGEAR products.

After installing your device, locate the serial number on the label of your product and use it to register your product at <https://my.netgear.com>. You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website.

For product updates and web support, visit <http://support.netgear.com>.

Phone (US & Canada only): 1-888-NETGEAR.

Phone (Other Countries): Check the list of phone numbers at <http://support.netgear.com/general/contact/default.aspx>.

### Compliance

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory>.

See the regulatory compliance document before connecting the power supply.

### Trademarks

© NETGEAR, Inc. NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

### Revision History

Publication Part Number	Publish Date	Comments
202-11166-03	March 2015	First publication.

# Contents

## Chapter 1 Using the Command-Line Interface

Command Syntax .....	8
Command Conventions .....	8
Common Parameter Values .....	9
Slot/Port Naming Convention .....	10
Using a Command's "No" Form .....	10
Managed Switch Modules .....	11
Command Modes .....	11
Command Completion and Abbreviation .....	14
CLI Error Messages .....	14
CLI Line-Editing Conventions .....	14
Using CLI Help .....	15
Accessing the CLI .....	16

## Chapter 2 Switching Commands

Port Configuration Commands .....	19
Loopback Interface Commands .....	26
Spanning Tree Protocol (STP) Commands .....	27
VLAN Commands .....	46
Switch Port Commands .....	59
Double VLAN Commands .....	63
Voice VLAN Commands .....	65
Provisioning (IEEE 802.1p) Commands .....	67
Protected Ports Commands .....	68
Private VLAN Commands .....	70
GARP Commands .....	74
GVRP Commands .....	76
GMRP Commands .....	78
Port-Based Network Access Control Commands .....	80
802.1X Supplicant Commands .....	94
Storm-Control Commands .....	97
Flow Control Commands .....	107
Port-Channel/LAG (802.3ad) Commands .....	109
Port Mirroring Commands .....	125
Static MAC Filtering Commands .....	129
DHCP L2 Relay Agent Commands .....	133
DHCP Client Commands .....	137
DHCP Snooping Configuration Commands .....	138
Dynamic ARP Inspection Commands .....	147

IGMP Snooping Configuration Commands .....	154
IGMP Snooping Querier Commands .....	164
MLD Snooping Commands .....	168
MLD Snooping Querier Commands .....	175
Port Security Commands .....	178
LLDP (802.1AB) Commands .....	182
LLDP-MED Commands .....	191
Denial of Service Commands .....	201
MAC Database Commands .....	211
ISDP Commands .....	213

### Chapter 3 Multicast VLAN Registration Commands

About MVR .....	220
MVR Commands .....	220

### Chapter 4 Routing Commands

Address Resolution Protocol (ARP) Commands .....	228
IP Routing Commands .....	234
Virtual LAN Routing Commands .....	251
DHCP and BOOTP Relay Commands .....	252
IP Helper Commands .....	254
ICMP Throttling Commands .....	260

### Chapter 5 Quality of Service Commands

Class of Service (CoS) Commands .....	263
Differentiated Services (DiffServ) Commands .....	270
DiffServ Class Commands .....	272
DiffServ Policy Commands .....	280
DiffServ Service Commands .....	286
DiffServ Show Commands .....	287
MAC Access Control List (ACL) Commands .....	293
IP Access Control List (ACL) Commands .....	297
IPv6 Access Control List (ACL) Commands .....	305
Time Range Commands for Time-Based ACLs .....	309
AutoVoIP Commands .....	312

### Chapter 6 Power over Ethernet Commands

About PoE .....	318
PoE Commands .....	318

### Chapter 7 Utility Commands

Auto Install Commands .....	329
Dual Image Commands .....	331
System Information and Statistics Commands .....	333

Logging Commands	353
Email Alerting and Mail Server Commands	358
System Utility and Clear Commands	365
Simple Network Time Protocol (SNTP) Commands	375
DHCP Server Commands	382
DNS Client Commands	395
Packet Capture Commands	400
Serviceability Packet Tracing Commands	403
Cable Test Command	425
sFlow Commands	425
IP Address Conflict Commands	431
RMON Stats and History Commands	432
UniDirectional Link Detection Commands	438
USB Commands	440

## Chapter 8 Management Commands

Switch Management CPU Commands	444
Management Interface Commands	446
Console Port Access Commands	449
Telnet Commands	452
Secure Shell (SSH) Commands	457
Management Security Commands	459
Hypertext Transfer Protocol (HTTP) Commands	460
Access Commands	467
User Account Commands	468
SNMP Commands	491
RADIUS Commands	501
TACACS+ Commands	514
Configuration Scripting Commands	518
Pre-Login Banner and System Prompt Commands	520

## Chapter 9 Green Ethernet Commands

Green Feature Support	523
Energy-Detect Mode	523
Energy Efficient Ethernet (EEE)	524
Green Ethernet Commands	524

## Chapter 10 Log Messages

Core	533
Utilities	535
Management	537
Switching	541
QoS	547
Routing/IPv6 Routing	548
Multicast	551
Stacking	553

Technologies.....	554
O/S Support.....	556

**Command List**

# Using the Command-Line Interface

---

# 1

The command-line interface (CLI) is a text-based way to manage and monitor the system. You can access the CLI by using a direct serial connection or by using a remote logical connection with telnet or SSH.

This chapter describes the CLI syntax, conventions, and modes. It contains the following sections:

- *Command Syntax*
- *Command Conventions*
- *Common Parameter Values*
- *Slot/Port Naming Convention*
- *Using a Command's "No" Form*
- *Managed Switch Modules*
- *Command Modes*
- *Command Completion and Abbreviation*
- *CLI Error Messages*
- *CLI Line-Editing Conventions*
- *Using CLI Help*
- *Accessing the CLI*

---

**Note:** For more information about the topics covered in this manual, visit the support website at [support.netgear.com](http://support.netgear.com).

---

---

**Note:** Firmware updates with new features and bug fixes are made available from time to time at [downloadcenter.netgear.com](http://downloadcenter.netgear.com). Some products can regularly check the site and download new firmware, or you can check for and download new firmware manually. If the features or behavior of your product does not match what is described in this guide, you might need to update your firmware.

---

## Command Syntax

A command is one or more words that might be followed by one or more parameters. Parameters can be required or optional values.

Some commands, such as **show network** and **clear vlan**, do not require parameters. Other commands, such as **network parms**, require that you supply a value after the command. You must type the parameter values in a specific order, and optional parameters follow required parameters. The following example describes the **network parms** command syntax:

Format	<code>network parms &lt;ipaddr&gt; &lt;netmask&gt; [gateway]</code>
--------	---

- **network parms** is the command name.
- *<ipaddr>* and *<netmask>* are parameters and represent required values that you must enter after you type the command keywords.
- [**gateway**] is an optional keyword, so you are not required to enter a value in place of the keyword.

This command line reference manual lists each command by the command name and provides a brief description of the command. Each command reference also contains the following information:

- Format shows the command keywords and the required and optional parameters.
- Mode identifies the command mode you must be in to access the command.
- Default shows the default value, if any, of a configurable setting on the device.

The **show** commands also contain a description of the information that the command shows.

## Command Conventions

In this document, the command name is in **bold** font. Parameters are in *<italic font>* between angle brackets. You must replace the parameter name with an appropriate value, which might be a name or number. Parameters are order-dependent. Keyword choices are in **bold** font.

The parameters for a command might include mandatory values, optional values, or keyword choices. The following table describes the conventions this document uses to distinguish between value types.

**Table 1. Parameter Conventions**

Symbol	Example	Description
<i>italic font</i> in angle brackets	<i>&lt;value&gt;</i> or [ <i>&lt;value&gt;</i> ]	Indicates a variable value. You must replace the italicized text within angle brackets with a name or number.
[ ] square brackets	[keyword]	Indicates an optional parameter.



**Table 1. Parameter Conventions (continued)**

Symbol	Example	Description
{ } curly braces	{choice1   choice2}	Indicates that you must select a parameter from the list of choices.
Vertical bars	choice1   choice2	Separates the mutually exclusive choices.
[{ }] Braces within square brackets	[[choice1   choice2]]	Indicates a choice within an optional element. This format is used mainly for complicated commands

## Common Parameter Values

Parameter values might be names (strings) or numbers. To use spaces as part of a name parameter, enclose the name value in double quotes. For example, the expression “System Name with Spaces” forces the system to accept the spaces. Empty strings (“”) are not valid user-defined strings. The following table describes common parameter values and value formatting.

**Table 2. Parameter Descriptions**

Parameter	Description
ipaddr	<p>This parameter is a valid IPv4 address. You can enter the IP address in the following formats:</p> <ul style="list-style-type: none"> <li>• a (32 bits)</li> <li>• a.b (8.24 bits)</li> <li>• a.b.c (8.8.16 bits)</li> <li>• a.b.c.d (8.8.8.8)</li> </ul> <p>In addition to these formats, the CLI accepts decimal, hexadecimal and octal formats through the following input formats (where <i>n</i> is any valid hexadecimal, octal or decimal number):</p> <ul style="list-style-type: none"> <li>• 0xn (CLI assumes hexadecimal format.)</li> <li>• 0n (CLI assumes octal format with leading zeros.)</li> <li>• n (CLI assumes decimal format.)</li> </ul>
ipv6-address	<p>This parameter is a valid IPv6 address. You can enter the IP address in the following formats:</p> <ul style="list-style-type: none"> <li>• FE80:0000:0000:0000:020F:24FF:FEBF:DCB</li> <li>• FE80:0:0:0:20F:24FF:FEBF:DCB</li> <li>• FE80::20F24FF:FEBF:DCB</li> <li>• FE80:0:0:0:20F:24FF:128:141:49:32</li> </ul> <p>For additional information, refer to RFC 3513.</p>
Interface or <i>slot/port</i>	Valid slot and port number separated by forward slashes. For example, 0/1 represents slot number 0 and port number 1.
Logical Interface	Represents a logical slot and port number. This is applicable in the case of a port-channel (LAG). You can use the logical slot/port to configure the port-channel.
Character strings	Use double quotation marks to identify character strings, for example, “System Name with Spaces”. An empty string (“”) is not valid.

## Slot/Port Naming Convention

Managed switch software references physical entities such as cards and ports by using a slot/port naming convention. The software also uses this convention to identify certain logical entities, such as port-channel interfaces.

The slot number has two uses. In the case of physical ports, it identifies the card containing the ports. In the case of logical and CPU ports it also identifies the type of interface or port.

**Table 3. Type of slots**

Slot Type	Description
Physical slot numbers	Physical slot numbers begin with zero, and are allocated up to the maximum number of physical slots.
Logical slot numbers	Logical slots immediately follow physical slots and identify port-channel (LAG) or router interfaces.
CPU slot numbers	The CPU slots immediately follow the logical slots.

The port identifies the specific physical port or logical interface being managed on a slot.

**Table 4. Type of ports**

Port Type	Description
Physical Ports	The physical ports for each slot are numbered sequentially starting from zero.
Logical Interfaces	Port-channel or link aggregation group (LAG) interfaces are logical interfaces that are only used for bridging functions. VLAN routing interfaces are only used for routing functions. Loopback interfaces are logical interfaces that are always up. Tunnel interfaces are logical point-to-point links that carry encapsulated packets.
CPU ports	CPU ports are handled by the driver as one or more physical entities located on physical slots.

---

**Note:** In the CLI, loopback and tunnel interfaces do not use the slot/port format. To specify a loopback interface, you use the loopback ID. To specify a tunnel interface, you use the tunnel ID.

---

## Using a Command's "No" Form

The `no` keyword is a specific form of an existing command and does not represent a new or distinct command. Almost every configuration command has a `no` form. In general, use the `no` form to reverse the action of a command or reset a value back to the default. For example, the `no shutdown` configuration command reverses the shutdown of an interface. Use the

command without the keyword `no` to reenable a disabled feature or to enable a feature that is disabled by default. Only the configuration commands are available in the `no` form.

## Managed Switch Modules

Managed switch software consists of flexible modules that can be applied in various combinations to develop advanced Layer 2/3/4+ products. The commands and command modes available on your switch depend on the installed modules. Additionally, for some `show` commands, the output fields might change based on the modules included in the software.

The software suite includes the following modules:

- Switching (Layer 2)
- Routing (Layer 3)
- Quality of Service
- Management (CLI, web UI, and SNMP)

## Command Modes

The CLI groups commands into modes according to the command function. Each of the command modes supports specific software commands. The commands in one mode are not available until you switch to that particular mode, except for the User EXEC mode commands. You can execute the User EXEC mode commands in the Privileged EXEC mode.

The command prompt changes in each command mode to help you identify the current mode. The following table describes the command modes and the prompts visible in that mode.

---

**Note:** The command modes available on your switch depend on the software modules that are installed. For example, a switch that does not support BGPv4 does not provide the Router BGPv4 Command Mode.

---

**Table 5. CLI Command Modes**

Command Mode	Prompt	Mode Description
User EXEC	Switch>	Contains a limited set of commands to view basic system information.
Privileged EXEC	Switch#	Allows you to issue any EXEC command, enter the VLAN mode, or enter the Global Configuration mode.

Table 5. CLI Command Modes (continued)

Command Mode	Prompt	Mode Description
Global Config	Switch (Config)#	Groups general setup commands and permits you to make modifications to the running configuration.
VLAN Config	Switch (Vlan)#	Groups all the VLAN commands.
Interface Config	Switch (Interface <slot/port>)# Switch (Interface Loopback <id>)# Switch (Interface Tunnel <id>)#	Manages the operation of an interface and provides access to the router interface configuration commands. Use this mode to set up a physical port for a specific logical connection operation.
Line Config	Switch (line)#	Contains commands to configure outbound telnet settings and console interface settings.
Policy Map Config	Switch (Config-policy-map)#	Contains the QoS Policy-Map configuration commands.
Policy Class Config	Switch (Config-policy-class-map)#	Consists of class creation, deletion, and matching commands. The class match commands specify Layer 2, Layer 3, and general match criteria.
Class Map Config	Switch (Config-class-map)#	Contains the QoS class map configuration commands for IPv4.
Ipv6_Class-Map Config	Switch (Config-class-map)#	Contains the QoS class map configuration commands for IPv6.
MAC Access-list Config	Switch (Config-mac-access-list)#	Allows you to create a MAC Access-List and to enter the mode containing MAC Access-List configuration commands.
TACACS Config	Switch (Tacacs)#	Contains commands to configure properties for the TACACS servers.
DHCP Pool Config	Switch (Config dhcp-pool)#	Contains the DHCP server IP address pool configuration commands.
ARP Access-List Config Mode	Switch (Config-arp-access-list)#	Contains commands to add ARP ACL rules in an ARP Access List.

The following table explains how to enter or exit each mode.

Table 6. CLI Mode Access and Exit

Command Mode	Access Method	Exit or Access Previous Mode
User EXEC	This is the first level of access.	To exit, enter <code>logout</code> .
Privileged EXEC	From the User EXEC mode, enter <code>enable</code> .	To exit to the User EXEC mode, enter <code>exit</code> or press <code>Ctrl-Z</code> .

Table 6. CLI Mode Access and Exit (continued)

Command Mode	Access Method	Exit or Access Previous Mode
Global Config	From the Privileged EXEC mode, enter <code>configure</code> .	To exit to the Privileged EXEC mode, enter <code>exit</code> , or press <code>Ctrl-Z</code> .
VLAN Config	From the Privileged EXEC mode, enter <code>vlan database</code> .	To exit to the Privileged EXEC mode, enter <code>exit</code> , or press <code>Ctrl-Z</code> .
Interface Config	From the Global Config mode, enter <code>interface &lt;slot/port&gt;</code> or <code>interface loopback &lt;id&gt;</code> or <code>interface tunnel &lt;id&gt;</code>	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
Line Config	From the Global Config mode, enter <code>lineconfig</code> .	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
Policy-Map Config	From the Global Config mode, enter <code>policy-map &lt;name&gt;</code> .	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
Policy-Class-Map Config	From the Policy Map mode enter <code>class</code> .	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
Class-Map Config	From the Global Config mode, enter <code>class-map</code> , and specify the optional keyword <code>ipv4</code> to specify the Layer 3 protocol for this class. See <a href="#">class-map</a> on page 272 for more information.	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
Ipv6-Class-Map Config	From the Global Config mode, enter <code>class-map</code> and specify the optional keyword <code>ipv6</code> to specify the Layer 3 protocol for this class. See <a href="#">class-map</a> on page 272 for more information.	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
MAC Access-list Config	From the Global Config mode, enter <code>mac access-list extended &lt;name&gt;</code> .	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
TACACS Config	From the Global Config mode, enter <code>tacacs-server host &lt;ip-addr&gt;</code> , in which <code>&lt;ip-addr&gt;</code> is the IP address of the TACACS server on your network.	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
DHCP Pool Config	From the Global Config mode, enter <code>ip dhcp pool &lt;pool-name&gt;</code> .	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .
ARP Access-List Config Mode	From the Global Config mode, enter <code>arp access-list</code> .	To exit to the Global Config mode, enter <code>exit</code> . To return to the Privileged EXEC mode, enter <code>Ctrl-Z</code> .

## Command Completion and Abbreviation

Command completion finishes spelling the command when you type enough letters of a command to uniquely identify the command keyword. Once you have entered enough letters, press the SPACEBAR or TAB key to complete the word.

Command abbreviation allows you to execute a command when you have entered there are enough letters to uniquely identify the command. You must enter all of the required keywords and parameters before you enter the command.

## CLI Error Messages

If you enter a command and the system is unable to execute it, an error message appears. The following table describes the most common CLI error messages.

**Table 7. CLI Error Messages**

Message Text	Description
% Invalid input detected at '^' marker.	Indicates that you entered an incorrect or unavailable command. The carat (^) shows where the invalid text is detected. This message also appears if any of the parameters or values are not recognized.
Command not found / Incomplete command. Use a question mark (?) to list commands.	Indicates that you did not enter the required keywords or values.
Ambiguous command	Indicates that you did not enter enough letters to uniquely identify the command.

## CLI Line-Editing Conventions

The following table describes the key combinations you can use to edit commands or increase the speed of command entry. You can access this list from the CLI by entering `help` from the User or Privileged EXEC modes.

**Table 8. CLI Editing Conventions**

Key Sequence	Description
DEL or Backspace	Delete previous character
Ctrl-A	Go to beginning of line
Ctrl-E	Go to end of line
Ctrl-F	Go forward one character
Ctrl-B	Go backward one character

Table 8. CLI Editing Conventions (continued)

Key Sequence	Description
Ctrl-D	Delete current character
Ctrl-U, X	Delete to beginning of line
Ctrl-K	Delete to end of line
Ctrl-W	Delete previous word
Ctrl-T	Transpose previous character
Ctrl-P	Go to previous line in history buffer
Ctrl-R	Rewrites or pastes the line
Ctrl-N	Go to next line in history buffer
Ctrl-Y	Prints last deleted character
Ctrl-Q	Enables serial flow
Ctrl-S	Disables serial flow
Ctrl-Z	Return to root command prompt
Tab, <SPACE>	Command-line completion
Exit	Go to next lower command prompt
?	List available commands, keywords, or parameters

## Using CLI Help

Enter a question mark (?) at the command prompt to display the commands available in the current mode.

```
(NETGEAR Switch) >?
```

```
enable          Enter into user privilege mode.
help            Display help for various special keys.
logout         Exit this session. Any unsaved changes are lost.
ping           Send ICMP echo packets to a specified IP address.
quit          Exit this session. Any unsaved changes are lost.
show          Display Switch Options and Settings.
telnet        Telnet to a remote host.
```

Enter a question mark (?) after each word you enter to display available command keywords or parameters.

```
(NETGEAR Switch) #network ?
```

```
javamode          Enable/Disable.
mgmt_vlan         Configure the Management VLAN ID of the switch.
parms             Configure Network Parameters of the router.
protocol          Select DHCP, BootP, or None as the network config
                  protocol.
```

If the help output shows a parameter in angle brackets, you must replace the parameter with a value.

```
(NETGEAR Switch) #network parms ?
```

```
<ipaddr>         Enter the IP address.
```

If there are no additional command keywords or parameters, or if more parameters are optional, the following message appears in the output:

```
<cr>             Press Enter to execute the command
```

You can also enter a question mark (?) after typing one or more characters of a word to list the available command or parameters that begin with the letters, as shown in the following example:

```
(NETGEAR Switch) #show m?
```

```
mac-addr-table   mac-address-table   monitor
```

## Accessing the CLI

You can access the CLI by using a direct console connection or by using a telnet or SSH connection from a remote management host.

For the initial connection, you must use a direct connection to the console port. You cannot access the system remotely until the system has an IP address, subnet mask, and default gateway. You can set the network configuration information manually, or you can configure the system to accept these settings from a BOOTP or DHCP server on your network. For more information, see [Management Interface Commands](#) on page 446.



## 2. Switching Commands

---

This chapter describes the switching commands available in the managed switch CLI.

The chapter contains the following sections:

- *Port Configuration Commands*
- *Loopback Interface Commands*
- *Spanning Tree Protocol (STP) Commands*
- *VLAN Commands*
- *Switch Port Commands*
- *Double VLAN Commands*
- *Voice VLAN Commands*
- *Provisioning (IEEE 802.1p) Commands*
- *Protected Ports Commands*
- *Private VLAN Commands*
- *GARP Commands*
- *GVRP Commands*
- *GMRP Commands*
- *Port-Based Network Access Control Commands*
- *802.1X Supplicant Commands*
- *Storm-Control Commands*
- *Flow Control Commands*
- *Port Mirroring Commands*
- *Static MAC Filtering Commands*
- *DHCP L2 Relay Agent Commands*
- *DHCP Client Commands*
- *DHCP Snooping Configuration Commands*
- *Dynamic ARP Inspection Commands*
- *IGMP Snooping Configuration Commands*
- *IGMP Snooping Querier Commands*
- *MLD Snooping Commands*

- *MLD Snooping Querier Commands*
- *Port Security Commands*
- *LLDP (802.1AB) Commands*
- *LLDP-MED Commands*
- *Denial of Service Commands*
- *MAC Database Commands*
- *ISDP Commands*

The commands in this chapter are in three functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. Every switch command has a show command that displays the configuration setting.
- Clear commands clear some or all of the settings to factory defaults.

## Port Configuration Commands

This section describes the commands you use to view and configure port settings.

### interface

This command gives you access to the Interface Config mode, which allows you to enable or modify the operation of an interface (port).

Format	<code>interface &lt;slot/port&gt;</code>
Mode	Global Config

### interface vlan

This command gives you access to the vlan virtual interface mode, which allows certain port configurations (for example, the IP address) to be applied to the VLAN interface. Type a question mark (?) after entering the interface configuration mode to see the available options.

Format	<code>interface vlan &lt;vlan id&gt;</code>
Mode	Global Config

### interface lag

This command gives you access to the LAG (link aggregation, or port channel) virtual interface, which allows certain port configurations to be applied to the LAG interface. Type a question mark (?) after entering the interface configuration mode to see the available options.

---

**Note:** The IP address cannot be assigned to a LAG virtual interface. The interface must be put under a VLAN group and an IP address assigned to the VLAN group.

---

Format	<code>interface lag &lt;lag id&gt;</code>
Mode	Global Config

### auto-negotiate

This command enables automatic negotiation on a port.

Default	enabled
Format	<code>auto-negotiate</code>
Mode	Interface Config

**no auto-negotiate**

This command disables automatic negotiation on a port.

---

**Note:** Automatic sensing is disabled when automatic negotiation is disabled.

---

**auto-negotiate all**

This command enables automatic negotiation on all ports.

Default	enabled
Format	auto-negotiate all
Mode	Global Config

**no auto-negotiate all**

This command disables automatic negotiation on all ports.

Format	no auto-negotiate all
Mode	Global Config

**description**

Use this command to create an alpha-numeric description of the port.

Format	description <description>
Mode	Interface Config

**mtu**

Use the **mtu** command to set the maximum transmission unit (MTU) size, in bytes, for frames that ingress or egress the interface. You can use the **mtu** command to configure jumbo frame support for physical and port-channel (LAG) interfaces. The MTU size is a valid integer between 1522–9216 for tagged packets and a valid integer between 1518–9216 for untagged packets.

---

**Note:** To receive and process packets, the Ethernet MTU must include any extra bytes that Layer-2 headers might require. To configure the IP MTU size, which is the maximum size of the IP packet (IP Header + IP payload), see *ip mtu* on page 239.

---

Default	1518 (untagged)
Format	mtu <1518-9216>
Mode	Interface Config

**no mtu**

This command sets the default MTU size (in bytes) for the interface.

Format	no mtu
Mode	Interface Config

**shutdown**

This command disables a port.

---

**Note:** You can use the `shutdown` command on physical and port-channel (LAG) interfaces, but not on VLAN routing interfaces.

---

Format	shutdown
Mode	Interface Config

**no shutdown**

This command enables a port.

Format	no shutdown
Mode	Interface Config

**shutdown all**

This command disables all ports.

---

**Note:** You can use the `shutdown all` command on physical and port-channel (LAG) interfaces, but not on VLAN routing interfaces.

---

Format	shutdown all
Mode	Global Config

### no shutdown all

This command enables all ports.

Format	no shutdown all
Mode	Global Config

### speed

This command sets the speed and duplex setting for the interface.

Format	speed [auto] [{<100   10   10G> {<half-duplex   full-duplex>}}]
Mode	Interface Config

Acceptable Values	Definition
100h	100BASE-T half duplex
100f	100BASE-T full duplex
10h	10BASE-T half duplex
10f	10BASE-T full duplex
10Gh	10GBase-T full duplex
10Gf	10Gbase-T half duplex

### speed all

This command sets the speed and duplex setting for all interfaces.

Format	speed all [auto] [{<100   10> {<half-duplex   full-duplex>}}]
Mode	Global Config

Acceptable Values	Definition
100h	100BASE-T half duplex
100f	100BASE-T full duplex
10h	10BASE-T half duplex

Acceptable Values	Definition
10f	10BASE-T full duplex
10Gh	10GBase-T full duplex
10Gf	10Gbase-T half duplex

## show port advertise

Use this command to display the local administrative link advertisement configuration, local operational link advertisement, and the link partner advertisement for an interface. It also displays priority Resolution for speed and duplex as per 802.3 Annex 28B.3. It displays the autonegotiation state, Phy Master/Slave Clock configuration, and Link state of the port.

If the link is down, the Clock is displayed as *No Link*, and a dash is displayed against the Oper Peer advertisement, and Priority Resolution. If autonegotiation is disabled, the admin Local Link advertisement, operational local link advertisement, operational peer advertisement, and Priority resolution fields are not displayed.

If this command is executed without the optional slot/port parameter, it displays the autonegotiation state and operational Local link advertisement for all the ports. Operational link advertisement will display speed only if it is supported by both local as well as link partner. If autonegotiation is disabled, operational local link advertisement is not displayed.

Format	show port advertise [ <i>slot/port</i> ]
Mode	Privileged EXEC

### Command example:

The following commands show the command output with and without the optional parameter:

```
(NETGEAR Switch)#show port advertise 0/1
```

```
Port: 0/1
```

```
Type: Gigabit - Level
```

```
Link State: Down
```

```
Auto Negotiation: Enabled
```

```
Clock: Auto
```

```

                                1000f 1000h 100f 100h 10f 10h
                                -----
Admin Local Link Advertisement no    no    yes  no   yes no
Oper Local Link Advertisement no    no    yes  no   yes no
Oper Peer Advertisement       no    no    yes  yes  yes yes
Priority Resolution            -    -    yes  -    -   -

```

```
(NETGEAR Switch)#show port advertise
```

Port	Type	Neg	Operational Link Advertisement
0/1	Gigabit - Level	Enabled	1000f, 100f, 100h, 10f, 10h
0/2	Gigabit - Level	Enabled	1000f, 100f, 100h, 10f, 10h
0/3	Gigabit - Level	Enabled	1000f, 100f, 100h, 10f, 10h

### show port

This command displays port information.

Format	show port {<slot/port>   all}
Mode	Privileged EXEC

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
Type	If not blank, this field indicates that this port is a special type of port. The possible values are: <ul style="list-style-type: none"> <li>• <b>Mirror.</b> This port is a monitoring port. For more information, see <a href="#">Port Mirroring Commands</a> on page 125.</li> <li>• <b>PC Mbr.</b> This port is a member of a port-channel (LAG).</li> <li>• <b>Probe.</b> This port is a probe port.</li> </ul>
Admin Mode	The Port control administration state. The port must be enabled in order for it to be allowed into the network. - May be enabled or disabled. The factory default is enabled.
Physical Mode	The desired port speed and duplex mode. If autonegotiation support is selected, the duplex mode and speed is set from the auto-negotiation process. Note that the maximum capability of the port (full-duplex -100M) is advertised. Otherwise, this object determines the port's duplex mode and transmission rate. The factory default is Auto.
Physical Status	The port speed and duplex mode.
Link Status	The Link is up or down.
Link Trap	This object determines whether to send a trap when link status changes. The factory default is enabled.
LACP Mode	LACP is enabled or disabled on this port.

### show port protocol

This command displays the Protocol-Based VLAN information for either the entire system, or for the indicated group.

Format	show port protocol {<groupid>   all}
Mode	Privileged EXEC



Term	Definition
Group Name	The group name of an entry in the Protocol-based VLAN table.
Group ID	The group identifier of the protocol group.
Protocol(s)	The type of protocol(s) for this group.
VLAN	The VLAN associated with this Protocol Group.
Interface(s)	Lists the slot/port interface(s) that are associated with this Protocol Group.

### show port description

This command displays the port description for every port.

Format	<code>show port description &lt;slot/port&gt;</code>
Mode	Privileged EXEC

Term	Definition
Interface	Valid slot and port number separated by forward slashes
Description	Shows the port description configured via the “description” command

### show port status

This command displays the Protocol-Based VLAN information for either the entire system, or for the indicated group.

Format	<code>show port status {&lt;slot/port&gt;   all}</code>
Mode	Privileged EXEC

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
Media Type	“Copper” or “Fiber” for combo port.
STP Mode	Indicate the spanning tree mode of the port.
Physical Mode	Either “Auto” or fixed speed and duplex mode.
Physical Status	The actual speed and duplex mode.
Link Status	Whether the link is Up or Down.
Loop Status	Whether the port is in loop state or not.
Partner Flow Control	Whether the remote side is using flow control or not.

## Loopback Interface Commands

The commands in this section describe how to create, delete, and manage loopback interfaces. A loopback interface is always expected to be up. This interface can provide the source address for sent packets and can receive both local and remote packets. The loopback interface is typically used by routing protocols.

To assign an IP address to the loopback interface, see [ip address](#) on page 234.

### interface loopback

Use this command to enter the Interface Config mode for a loopback interface. The range of the loopback ID is 0–7.

Format	<code>interface loopback &lt;loopback-id&gt;</code>
Mode	Global Config

### no interface loopback

This command removes the loopback interface and associated configuration parameters for the specified loopback interface.

Format	<code>no interface loopback &lt;loopback-id&gt;</code>
Mode	Global Config

### show interface loopback

This command displays information about configured loopback interfaces.

Format	<code>show interface loopback [&lt;loopback-id&gt;]</code>
Mode	Privileged EXEC

If you do not specify a loopback ID, the following information appears for each loopback interface on the system:

Term	Definition
Loopback ID	The loopback ID associated with the rest of the information in the row.
Interface	The interface name.
IP Address	The IPv4 address of the interface.
Received Packets	The number of packets received on this interface.
Sent Packets	The number of packets transmitted from this interface.
IPv6 Address	The IPv6 address of this interface.

If you specify a loopback ID, the following information appears:

Term	Definition
Interface Link Status	Shows whether the link is up or down.
IP Address	The IPv4 address of the interface.
IPv6 is enabled (disabled)	Shows whether IPv6 is enabled on the interface.
IPv6 Prefix is	The IPv6 address of the interface.
MTU size	The maximum transmission size for packets on this interface, in bytes.

## Spanning Tree Protocol (STP) Commands

This section describes the commands you use to configure Spanning Tree Protocol (STP). STP helps prevent network loops, duplicate messages, and network instability.

### spanning-tree

This command sets the spanning-tree operational mode to enabled.

Default	enabled
Format	spanning-tree
Mode	Global Config

### no spanning-tree

This command sets the spanning-tree operational mode to disabled. While disabled, the spanning-tree configuration is retained and can be changed, but is not activated.

Format	no spanning-tree
Mode	Global Config

### spanning-tree auto-edge

This command enables auto-edge on the interface or range of interfaces. When enabled, the interface becomes an edge port if it does not see BPDUs for edge delay time.

Default	enabled
Format	spanning-tree auto-edge
Mode	Interface Config

**no spanning-tree auto-edge**

This command disables auto-edge on the interface or range of interfaces.

Format	<code>no spanning-tree auto-edge</code>
Mode	Interface Config

**spanning-tree bpdudfilter**

Use this command to enable BPDU Filter on an interface or range of interfaces.

Default	disabled
Format	<code>spanning-tree bpdudfilter</code>
Mode	Interface Config

**no spanning-tree bpdudfilter**

Use this command to disable BPDU Filter on the interface or range of interfaces.

Default	disabled
Format	<code>no spanning-tree bpdudfilter</code>
Mode	Interface Config

**spanning-tree bpdudfilter default**

Use this command to enable BPDU Filter on all the edge port interfaces.

Default	disabled
Format	<code>spanning-tree bpdudfilter</code>
Mode	Global Config

**no spanning-tree bpdudfilter default**

Use this command to disable BPDU Filter on all the edge port interfaces.

Default	enabled
Format	<code>no spanning-tree bpdudfilter default</code>
Mode	Global Config

### spanning-tree bpduflood

Use this command to enable BPDU Flood on the interface.

Default	disabled
Format	spanning-tree bpduflood
Mode	Interface Config

### no spanning-tree bpduflood

Use this command to disable BPDU Flood on the interface.

Format	no spanning-tree bpduflood
Mode	Interface Config

### spanning-tree bpduguard

Use this command to enable BPDU Guard on the switch.

Default	disabled
Format	spanning-tree bpduguard
Mode	Global Config

### no spanning-tree bpduguard

Use this command to disable BPDU Guard on the switch.

Format	no spanning-tree bpduguard
Mode	Global Config

### spanning-tree bpdumigrationcheck

Use this command to force a transmission of rapid spanning tree (RSTP) and multiple spanning tree (MSTP) BPDUs. Use the `<slot/port>` parameter to transmit a BPDU from a specified interface, or use the `all` keyword to transmit BPDUs from all interfaces. This command forces the BPDU transmission when you execute it, so the command does not change the system configuration or have a “no” version.

Format	spanning-tree bpdumigrationcheck {<slot/port>   all}
Mode	Global Config

### spanning-tree configuration name

This command sets the Configuration Identifier Name for use in identifying the configuration that this switch is currently using. The *<name>* is a string of up to 32 characters.

Default	base MAC address in hexadecimal notation
Format	spanning-tree configuration name <i>&lt;name&gt;</i>
Mode	Global Config

### no spanning-tree configuration name

This command resets the Configuration Identifier Name to its default.

Format	no spanning-tree configuration name
Mode	Global Config

### spanning-tree configuration revision

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using. The Configuration Identifier Revision Level is a number in the range of 0–65535.

Default	0
Format	spanning-tree configuration revision <i>&lt;0-65535&gt;</i>
Mode	Global Config

### no spanning-tree configuration revision

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using to the default value.

Format	no spanning-tree configuration revision
Mode	Global Config

### spanning-tree edgeport

This command specifies that this port is an Edge Port within the Common and Internal Spanning Tree. This allows this port to transition to Forwarding State without delay.

Default	Enabled
Format	spanning-tree edgeport
Mode	Interface Config

### no spanning-tree edgeport

This command specifies that this port is not an Edge Port within the Common and Internal Spanning Tree.

Format	<code>no spanning-tree edgeport</code>
Mode	Interface Config

### spanning-tree forceversion

This command sets the Force Protocol Version parameter to a new value.

Default	802.1s
Format	<code>spanning-tree forceversion {802.1d   802.1s   802.1w}</code>
Mode	Global Config

- Use 802.1d to specify that the switch transmits ST BPDUs rather than MST BPDUs (IEEE 802.1d functionality supported).
- Use 802.1s to specify that the switch transmits MST BPDUs (IEEE 802.1s functionality supported).
- Use 802.1w to specify that the switch transmits RST BPDUs rather than MST BPDUs (IEEE 802.1w functionality supported).

### no spanning-tree forceversion

This command sets the Force Protocol Version parameter to the default value.

Format	<code>no spanning-tree forceversion</code>
Mode	Global Config

### spanning-tree forward-time

This command sets the Bridge Forward Delay parameter to a new value for the Common and Internal Spanning Tree. The forward-time value is in seconds within a range of 4–30, with the value being greater than or equal to  $(\text{Bridge Max Age} / 2) + 1$ .

Default	15
Format	<code>spanning-tree forward-time &lt;4-30&gt;</code>
Mode	Global Config

**no spanning-tree forward-time**

This command sets the Bridge Forward Delay parameter for the Common and Internal Spanning Tree to the default value.

Format	<code>no spanning-tree forward-time</code>
Mode	Global Config

**spanning-tree guard**

This command selects whether loop guard or root guard is enabled on an interface. If neither is enabled, the port operates in accordance with the multiple spanning tree protocol.

Default	none
Format	<code>spanning-tree guard {none   root   loop}</code>
Mode	Interface Config

**no spanning-tree guard**

This command disables loop guard or root guard on the interface.

Format	<code>no spanning-tree guard</code>
Mode	Interface Config

**spanning-tree tcnguard**

This command enables the propagation of received topology change notifications and topology changes to other ports.

Default	disable
Format	<code>spanning-tree tcnguard</code>
Mode	Interface Config

**no spanning-tree tcnguard**

This command disables the propagation of received topology change notifications and topology changes to other ports.

Format	<code>no spanning-tree tcnguard</code>
Mode	Interface Config



### spanning-tree max-age

This command sets the Bridge Max Age parameter to a new value for the Common and Internal Spanning Tree. The max-age value is in seconds within a range of 6–40, with the value being less than or equal to 2 x (Bridge Forward Delay - 1).

Default	20
Format	<code>spanning-tree max-age &lt;6-40&gt;</code>
Mode	Global Config

### no spanning-tree max-age

This command sets the Bridge Max Age parameter for the Common and Internal Spanning Tree to the default value.

Format	<code>no spanning-tree max-age</code>
Mode	Global Config

### spanning-tree max-hops

This command sets the MSTP Max Hops parameter to a new value for the Common and Internal Spanning Tree. The max-hops value is a range from 6 to 40.

Default	20
Format	<code>spanning-tree max-hops &lt;1-127&gt;</code>
Mode	Global Config

### no spanning-tree max-hops

This command sets the Bridge Max Hops parameter for the Common and Internal Spanning Tree to the default value.

Format	<code>no spanning-tree max-hops</code>
Mode	Global Config

### spanning-tree mst

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the Common and Internal Spanning Tree. If you specify an `<mstid>` parameter that corresponds to an existing multiple spanning tree instance, the configurations are done for that multiple spanning tree instance. If you specify 0 (defined as the default CIST ID) as the `<mstid>`, the configurations are done for the Common and Internal Spanning Tree instance.

If you specify the `cost` option, the command sets the path cost for this port within a multiple spanning tree instance or the Common and Internal Spanning Tree instance, depending on

the *<mstid>* parameter. You can set the path cost as a number in the range of 1–200000000 or **auto**. If you select **auto** the path cost value is set based on Link Speed.

If you specify the **external-cost** option, this command sets the external-path cost for MST instance 0 that is, CIST instance. You can set the external cost as a number in the range of 1–200000000 or **auto**. If you specify **auto**, the external path cost value is set based on Link Speed.

If you specify the **port-priority** option, this command sets the priority for this port within a specific multiple spanning tree instance or the Common and Internal Spanning Tree instance, depending on the *<mstid>* parameter. The port-priority value is a number in the range of 0–240 in increments of 16.

Default	<ul style="list-style-type: none"> <li>• cost—auto</li> <li>• external-cost—auto</li> <li>• port-priority—128</li> </ul>
Format	<code>spanning-tree mst &lt;mstid&gt; {{cost &lt;1-200000000&gt;   auto}   {external-cost &lt;1-200000000&gt;   auto}   port-priority &lt;0-240&gt;}</code>
Mode	Interface Config

### no spanning-tree mst

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance, or in the Common and Internal Spanning Tree to the respective default values. If you specify an *<mstid>* parameter that corresponds to an existing multiple spanning tree instance, you are configuring that multiple spanning tree instance. If you specify 0 (defined as the default CIST ID) as the *<mstid>*, you are configuring the Common and Internal Spanning Tree instance.

If you specify **cost**, this command sets the path cost for this port within a multiple spanning tree instance or the Common and Internal Spanning Tree instance, depending on the *<mstid>* parameter, to the default value, that is, a path cost value based on the Link Speed.

If you specify **external-cost**, this command sets the external path cost for this port for mst '0' instance, to the default value, that is, a path cost value based on the Link Speed.

If you specify **port-priority**, this command sets the priority for this port within a specific multiple spanning tree instance or the Common and Internal Spanning Tree instance, depending on the *<mstid>* parameter, to the default value.

Format	<code>no spanning-tree mst &lt;mstid&gt; [cost   external-cost   port-priority]</code>
Mode	Interface Config

### spanning-tree mst instance

This command adds a multiple spanning tree instance to the switch. The parameter *<mstid>* is a number within a range of 1–4094, that corresponds to the new instance ID to be added. The maximum number of multiple instances supported by the switch is 4.

Default	none
Format	spanning-tree mst instance <i>&lt;mstid&gt;</i>
Mode	Global Config

### no spanning-tree mst instance

This command removes a multiple spanning tree instance from the switch and reallocates all VLANs allocated to the deleted instance to the Common and Internal Spanning Tree. The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance to be removed.

Format	no spanning-tree mst instance <i>&lt;mstid&gt;</i>
Mode	Global Config

### spanning-tree mst priority

This command sets the bridge priority for a specific multiple spanning tree instance. The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance. The priority value is a number within a range of 0–61440 in increments of 4096.

If you specify 0 (defined as the default CIST ID) as the *<mstid>*, this command sets the Bridge Priority parameter to a new value for the Common and Internal Spanning Tree. The bridge priority value is a number within a range of 0–61440. The twelve least significant bits are masked according to the 802.1s specification. This causes the priority to be rounded down to the next lower valid priority.

Default	32768
Format	spanning-tree mst priority <i>&lt;mstid&gt;</i> <i>&lt;0-61440&gt;</i>
Mode	Global Config

### no spanning-tree mst priority

This command sets the bridge priority for a specific multiple spanning tree instance to the default value. The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance.

If 0 (defined as the default CIST ID) is passed as the *<mstid>*, this command sets the Bridge Priority parameter for the Common and Internal Spanning Tree to the default value.

Format	<code>no spanning-tree mst priority &lt;mstid&gt;</code>
Mode	Global Config

### spanning-tree mst vlan

This command adds an association between a multiple spanning tree instance and one or more VLANs so that the VLAN(s) are no longer associated with the Common and Internal Spanning Tree. The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance. The vlan range can be specified as a list or as a range of values. To specify a list of VLANs, enter a list of VLAN IDs, each separated by a comma with no spaces in between. To specify a range of VLANs, separate the beginning and ending VLAN ID with a dash ("-").

Format	<code>spanning-tree mst vlan &lt;mstid&gt; &lt;vlanid&gt;</code>
Mode	Global Config

### no spanning-tree mst vlan

This command removes an association between a multiple spanning tree instance and one or more VLANs so that the VLAN(s) are again associated with the Common and Internal Spanning Tree.

Format	<code>no spanning-tree mst vlan &lt;mstid&gt; &lt;vlanid&gt;</code>
Mode	Global Config

### spanning-tree port mode

This command sets the Administrative Switch Port State for this port to enabled.

Default	enabled
Format	<code>spanning-tree port mode</code>
Mode	Interface Config

### no spanning-tree port mode

This command sets the Administrative Switch Port State for this port to disabled.

Format	<code>no spanning-tree port mode</code>
Mode	Interface Config

### spanning-tree port mode all

This command sets the Administrative Switch Port State for all ports to enabled.

Default	enabled
Format	spanning-tree port mode all
Mode	Global Config

### no spanning-tree port mode all

This command sets the Administrative Switch Port State for all ports to disabled.

Format	no spanning-tree port mode all
Mode	Global Config

### spanning-tree edgeport all

This command specifies that every port is an Edge Port within the Common and Internal Spanning Tree. This allows all ports to transition to Forwarding State without delay.

Format	spanning-tree edgeport all
Mode	Global Config

### no spanning-tree edgeport all

This command disables Edge Port mode for all ports within the Common and Internal Spanning Tree.

Format	no spanning-tree edgeport all
Mode	Global Config

### spanning-tree bpduforwarding

Normally a switch will not forward Spanning Tree Protocol (STP) BPDU packets if STP is disabled. However, if in some network setup, the user wishes to forward BPDU packets received from other network devices, this command can be used to enable the forwarding.

Default	disabled
Format	spanning-tree bpduforwarding
Mode	Global Config

**no spanning-tree bpduforwarding**

This command will cause the STP BPDU packets received from the network to be dropped if STP is disabled.

Format	no spanning-tree bpduforwarding
Mode	Global Config

**show spanning-tree**

This command displays spanning tree settings for the Common and Internal Spanning Tree. The following details are displayed.

Format	show spanning-tree
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Bridge Priority	Specifies the bridge priority for the Common and Internal Spanning Tree (CST). The value lies between 0 and 61440. It is displayed in multiples of 4096.
Bridge Identifier	The bridge identifier for the CST. It is made up using the bridge priority and the base MAC address of the bridge.
Time Since Topology Change	Time in seconds.
Topology Change Count	Number of times changed.
Topology Change	Boolean value of the Topology Change parameter for the switch indicating if a topology change is in progress on any port assigned to the Common and Internal Spanning Tree.
Designated Root	The bridge identifier of the root bridge. It is made up from the bridge priority and the base MAC address of the bridge.
Root Path Cost	Value of the Root Path Cost parameter for the Common and Internal Spanning Tree.
Root Port Identifier	Identifier of the port to access the Designated Root for the CST
Root Port Max Age	Derived value.
Root Port Bridge Forward Delay	Derived value.
Hello Time	Configured value of the parameter for the CST.

Term	Definition
Bridge Hold Time	Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs).
Bridge Max Hops	Bridge max-hops count for the device.
CST Regional Root	Bridge Identifier of the CST Regional Root. It is made up using the bridge priority and the base MAC address of the bridge.
Regional Root Path Cost	Path Cost to the CST Regional Root.
Associated FIDs	List of forwarding database identifiers currently associated with this instance.
Associated VLANs	List of VLAN IDs currently associated with this instance.

### show spanning-tree brief

This command displays spanning tree settings for the bridge. The following information appears.

Format	<code>show spanning-tree brief</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Bridge Priority	Configured value.
Bridge Identifier	The bridge identifier for the selected MST instance. It is made up using the bridge priority and the base MAC address of the bridge.
Bridge Max Age	Configured value.
Bridge Max Hops	Bridge max-hops count for the device.
Bridge Hello Time	Configured value.
Bridge Forward Delay	Configured value.
Bridge Hold Time	Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs).

## show spanning-tree interface

This command displays the settings and parameters for a specific switch port within the Common and Internal Spanning Tree. The *<slot/port>* is the desired switch port. The following details are displayed on execution of the command.

Format	<code>show spanning-tree interface &lt;slot/port&gt;</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Hello Time	Admin hello time for this port.
Port Mode	Enabled or disabled.
BPDU Guard Effect	Enabled or disabled.
Root Guard	Enabled or disabled.
Loop Guard	Enabled or disabled.
TCN Guard	Enable or disable the propagation of received topology change notifications and topology changes to other ports.
BPDU Filter Mode	Enabled or disabled.
BPDU Flood Mode	Enabled or disabled.
Auto Edge	To enable or disable the feature that causes a port that has not seen a BPDU for 'edge delay' time, to become an edge port and transition to forwarding faster.
Port Up Time Since Counters Last Cleared	Time since port was reset, displayed in days, hours, minutes, and seconds.
STP BPDUs Transmitted	Spanning Tree Protocol Bridge Protocol Data Units sent.
STP BPDUs Received	Spanning Tree Protocol Bridge Protocol Data Units received.
RSTP BPDUs Transmitted	Rapid Spanning Tree Protocol Bridge Protocol Data Units sent.
RSTP BPDUs Received	Rapid Spanning Tree Protocol Bridge Protocol Data Units received.
MSTP BPDUs Transmitted	Multiple Spanning Tree Protocol Bridge Protocol Data Units sent.
MSTP BPDUs Received	Multiple Spanning Tree Protocol Bridge Protocol Data Units received.



## show spanning-tree mst port detailed

This command displays the detailed settings and parameters for a specific switch port within a particular multiple spanning tree instance. The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance. The *<slot/port>* is the desired switch port.

Format	show spanning-tree mst port detailed <i>&lt;mstid&gt;</i> <i>&lt;slot/port&gt;</i>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
MST Instance ID	The ID of the existing MST instance.
Port Identifier	The port identifier for the specified port within the selected MST instance. It is made up from the port priority and the interface number of the port.
Port Priority	The priority for a particular port within the selected MST instance. The port priority is displayed in multiples of 16.
Port Forwarding State	Current spanning tree state of this port.
Port Role	Each enabled MST Bridge Port receives a Port Role for each spanning tree. The port role is one of the following values: Root Port, Designated Port, Alternate Port, Backup Port, Master Port, or Disabled Port
Auto-Calculate Port Path Cost	Indicates whether auto calculation for port path cost is enabled.
Port Path Cost	Configured value of the Internal Port Path Cost parameter.
Designated Root	The Identifier of the designated root for this port.
Root Path Cost	The path cost to get to the root bridge for this instance. The root path cost is zero if the bridge is the root bridge for that instance.
Designated Bridge	Bridge Identifier of the bridge with the Designated Port.
Designated Port Identifier	Port on the Designated Bridge that offers the lowest cost to the LAN.
Loop Inconsistent State	The current loop inconsistent state of this port in this MST instance. When in loop inconsistent state, the port has failed to receive BPDUs while configured with loop guard enabled. Loop inconsistent state maintains the port in a "blocking" state until a subsequent BPDU is received.

Term	Definition
Transitions Into Loop Inconsistent State	The number of times this interface has transitioned into loop inconsistent state.
Transitions Out of Loop Inconsistent State	The number of times this interface has transitioned out of loop inconsistent state.

If you specify 0 (defined as the default CIST ID) as the *<mstid>*, this command displays the settings and parameters for a specific switch port within the Common and Internal Spanning Tree. The *<slot/port>* is the desired switch port. In this case, the following are displayed.

Term	Definition
Port Identifier	The port identifier for this port within the CST.
Port Priority	The priority of the port within the CST.
Port Forwarding State	The forwarding state of the port within the CST.
Port Role	The role of the specified interface within the CST.
Auto-Calculate Port Path Cost	Indicates whether auto calculation for port path cost is enabled or not (disabled).
Port Path Cost	The configured path cost for the specified interface.
Auto-Calculate External Port Path Cost	Indicates whether auto calculation for external port path cost is enabled.
External Port Path Cost	The cost to get to the root bridge of the CIST across the boundary of the region. This means that if the port is a boundary port for an MSTP region, the external path cost is used.
Designated Root	Identifier of the designated root for this port within the CST.
Root Path Cost	The root path cost to the LAN by the port.
Designated Bridge	The bridge containing the designated port.
Designated Port Identifier	Port on the Designated Bridge that offers the lowest cost to the LAN.
Topology Change Acknowledgement	Value of flag in next Configuration Bridge Protocol Data Unit (BPDU) transmission indicating if a topology change is in progress for this port.
Hello Time	The hello time in use for this port.
Edge Port	The configured value indicating if this port is an edge port.

Term	Definition
Edge Port Status	The derived value of the edge port status. True if operating as an edge port; false otherwise.
Point To Point MAC Status	Derived value indicating if this port is part of a point to point link.
CST Regional Root	The regional root identifier in use for this port.
CST Internal Root Path Cost	The internal root path cost to the LAN by the designated external port.
Loop Inconsistent State	The current loop inconsistent state of this port in this MST instance. When in loop inconsistent state, the port has failed to receive BPDUs while configured with loop guard enabled. Loop inconsistent state maintains the port in a "blocking" state until a subsequent BPDU is received.
Transitions Into Loop Inconsistent State	The number of times this interface has transitioned into loop inconsistent state.
Transitions Out of Loop Inconsistent State	The number of times this interface has transitioned out of loop inconsistent state.

### show spanning-tree mst port summary

This command displays the settings of one or all ports within the specified multiple spanning tree instance. The parameter `<mstid>` indicates a particular MST instance. The parameter `{<slot/port> | all}` indicates the desired switch port or all ports.

If you specify 0 (defined as the default CIST ID) as the `<mstid>`, the status summary displays for one or all ports within the Common and Internal Spanning Tree.

Format	<code>show spanning-tree mst port summary &lt;mstid&gt; {&lt;slot/port&gt;   all}</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
MST Instance ID	The MST instance associated with this port.
Interface	Valid slot and port number separated by forward slashes.
STP Mode	Indicates whether spanning tree is enabled or disabled on the port.
Type	Currently not used.
STP State	The forwarding state of the port in the specified spanning tree instance.

Term	Definition
Port Role	The role of the specified port within the spanning tree.
Desc	Indicates whether the port is in loop inconsistent state or not. This field is blank if the loop guard feature is not available.

### show spanning-tree mst port summary active

This command displays settings for the ports within the specified multiple spanning tree instance that are active links.

Format	<code>show spanning-tree mst port summary &lt;mstid&gt; active</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
mstid	The ID of the existing MST instance.
Interface	slot/port
STP Mode	Indicates whether spanning tree is enabled or disabled on the port.
Type	Currently not used.
STP State	The forwarding state of the port in the specified spanning tree instance.
Port Role	The role of the specified port within the spanning tree.
Desc	Indicates whether the port is in loop inconsistent state or not. This field is blank if the loop guard feature is not available.

### show spanning-tree mst summary

This command displays summary information about all multiple spanning tree instances in the switch. On execution, the following details are displayed.

Format	<code>show spanning-tree mst summary</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
MST Instance ID List	List of multiple spanning trees IDs currently configured.
For each MSTID: <ul style="list-style-type: none"> <li>• Associated FIDs</li> <li>• Associated VLANs</li> </ul>	<ul style="list-style-type: none"> <li>• List of forwarding database identifiers associated with this instance.</li> <li>• List of VLAN IDs associated with this instance.</li> </ul>

### show spanning-tree summary

This command displays spanning tree settings and parameters for the switch. The following details are displayed on execution of the command.

Format	<code>show spanning-tree summary</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Spanning Tree Adminmode	Enabled or disabled.
Spanning Tree Version	Version of 802.1 currently supported (IEEE 802.1s, IEEE 802.1w, or IEEE 802.1d) based upon the Force Protocol Version parameter.
BPDU Guard Mode	Enabled or disabled.
BPDU Filter Mode	Enabled or disabled.
Configuration Name	Identifier used to identify the configuration currently being used.
Configuration Revision Level	Identifier used to identify the configuration currently being used.
Configuration Digest Key	A generated Key used in the exchange of the BPDUs.
Configuration Format Selector	Specifies the version of the configuration format being used in the exchange of BPDUs. The default value is zero.
MST Instances	List of all multiple spanning tree instances configured on the switch.

## show spanning-tree vlan

This command displays the association between a VLAN and a multiple spanning tree instance. The `<vlanid>` corresponds to an existing VLAN ID.

Format	<code>show spanning-tree vlan &lt;vlanid&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
VLAN Identifier	The VLANs associated with the selected MST instance.
Associated Instance	Identifier for the associated multiple spanning tree instance or “CST” if associated with the Common and Internal Spanning Tree.

## VLAN Commands

This section describes the commands you use to configure VLAN settings.

### vlan database

This command gives you access to the VLAN Config mode, which allows you to configure VLAN characteristics.

Format	<code>vlan database</code>
Mode	Privileged EXEC

### network mgmt\_vlan

This command configures the Management VLAN ID.

Default	1
Format	<code>network mgmt_vlan &lt;1-4093&gt;</code>
Mode	Privileged EXEC

### no network mgmt\_vlan

This command sets the Management VLAN ID to the default.

Format	<code>no network mgmt_vlan</code>
Mode	Privileged EXEC

## vlan

This command creates a new VLAN and assigns it an ID. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). The vlan-list contains VlanId's in range <1-4093>. Separate non-consecutive IDs with ',' and no spaces and no zeros in between the range; Use '-' for range.

Format	<code>vlan &lt;vlan-list&gt;</code>
Mode	VLAN Config

## no vlan

This command deletes an existing VLAN. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). The vlan-list contains VlanId's in range <1-4093>. Separate non-consecutive IDs with ',' and no spaces and no zeros in between the range; Use '-' for range.

Format	<code>no vlan &lt;vlan-list&gt;</code>
Mode	VLAN Config

## vlan acceptframe

This command sets the frame acceptance mode per interface. For VLAN Only mode, untagged frames or priority frames received on this interface are discarded. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

Default	all
Format	<code>vlan acceptframe {untaggedonly   vlanonly   all}</code>
Mode	Interface Config

## no vlan acceptframe

This command resets the frame acceptance mode for the interface to the default value.

Format	<code>no vlan acceptframe</code>
Mode	Interface Config

### vlan ingressfilter

This command enables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Default	disabled
Format	vlan ingressfilter
Mode	Interface Config

### no vlan ingressfilter

This command disables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Format	no vlan ingressfilter
Mode	Interface Config

### vlan makestatic

This command changes a dynamically created VLAN (one that is created by GVRP registration) to a static VLAN (one that is permanently configured and defined). The ID is a valid VLAN identification number. VLAN range is 2-4093.

Format	vlan makestatic <2-4093>
Mode	VLAN Config

### vlan name

This command changes the name of a VLAN. The name is an alphanumeric string of up to 32 characters, and the ID is a valid VLAN identification number. ID range is 1-4093.

Default	<ul style="list-style-type: none"> <li>VLAN ID 1 - default</li> <li>other VLANS - blank string</li> </ul>
Format	vlan name <1-4093> <name>
Mode	VLAN Config

### no vlan name

This command sets the name of a VLAN to a blank string.

Format	no vlan name <1-4093>
Mode	VLAN Config



## vlan participation

This command configures the degree of participation for a specific interface in a VLAN. The ID is a valid VLAN identification number, and the interface is a valid interface number.

Format	<code>vlan participation {exclude   include   auto} &lt;1-4093&gt;</code>
Mode	Interface Config

Participation options are:

Participation Options	Definition
include	The interface is always a member of this VLAN. This is equivalent to registration fixed.
exclude	The interface is never a member of this VLAN. This is equivalent to registration forbidden.
auto	The interface is dynamically registered in this VLAN by GVRP. The interface will not participate in this VLAN unless a join request is received on this interface. This is equivalent to registration normal.

## vlan participation all

This command configures the degree of participation for all interfaces in a VLAN. The ID is a valid VLAN identification number.

Format	<code>vlan participation all {exclude   include   auto} &lt;1-4093&gt;</code>
Mode	Global Config

You can use the following participation options:

Participation Options	Definition
include	The interface is always a member of this VLAN. This is equivalent to registration fixed.
exclude	The interface is never a member of this VLAN. This is equivalent to registration forbidden.
auto	The interface is dynamically registered in this VLAN by GVRP. The interface will not participate in this VLAN unless a join request is received on this interface. This is equivalent to registration normal.

## vlan port acceptframe all

This command sets the frame acceptance mode for all interfaces.

Default	all
Format	vlan port acceptframe all {vlanonly   all}
Mode	Global Config

The modes defined as follows:

Mode	Definition
VLAN Only mode	Untagged frames or priority frames received on this interface are discarded.
Admit All mode	Untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port.

With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

## no vlan port acceptframe all

This command sets the frame acceptance mode for all interfaces to Admit All. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

Format	no vlan port acceptframe all
Mode	Global Config

## vlan port ingressfilter all

This command enables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Default	disabled
Format	vlan port ingressfilter all
Mode	Global Config

**no vlan port ingressfilter all**

This command disables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Format	<code>no vlan port ingressfilter all</code>
Mode	Global Config

**vlan port pvid all**

This command changes the VLAN ID for all interface.

Default	1
Format	<code>vlan port pvid all &lt;1-4093&gt;</code>
Mode	Global Config

**no vlan port pvid all**

This command sets the VLAN ID for all interfaces to 1.

Format	<code>no vlan port pvid all</code>
Mode	Global Config

**vlan port tagging all**

This command configures the tagging behavior for all interfaces in a VLAN to enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Format	<code>vlan port tagging all &lt;1-4093&gt;</code>
Mode	Global Config

**no vlan port tagging all**

This command configures the tagging behavior for all interfaces in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Format	<code>no vlan port tagging all</code>
Mode	Global Config

## vlan protocol group

This command adds protocol-based VLAN groups to the system. When it is created, the protocol group will be assigned a unique number (1-128) that will be used to identify the group in subsequent commands.

Format	vlan protocol group <1-128>
Mode	Global Config

## no vlan protocol group

This command removes a protocol group.

Format	no vlan protocol group <1-128>
Mode	Global Config

## vlan protocol group name

This command assigns a name to a protocol-based VLAN group. The *groupname* variable can be a character string of 0–16 characters.

Format	vlan protocol group name <1-128> <groupname>
Mode	Global Config

## no vlan protocol group name

This command removes the name from a protocol-based VLAN group.

Format	no vlan protocol group name <1-128>
Mode	Global Config

## vlan protocol group add protocol

This command adds the protocol to the protocol-based VLAN identified by *groupid*. A group may have more than one protocol associated with it. Each interface and protocol combination can only be associated with one group. If adding a protocol to a group causes any conflicts with interfaces currently associated with the group, this command fails and the protocol is not added to the group. The possible values for *protocol-list* includes the keywords **ip**, **arp**, and **ipx** and hexadecimal or decimal values ranging from 0x0600 (1536) to 0xFFFF (65535). The protocol list can accept up to 16 protocols separated by a comma.

Default	none
Format	vlan protocol group add protocol <groupid> <ethertype> {<protocol-list>   arp   ip   ipx}
Mode	Global Config

### no vlan protocol group add protocol

This command removes the *<protocol>* from this protocol-based VLAN group that is identified by this *<groupid>*. The possible values for protocol are **ip**, **arp**, and **ipx**.

Format	no vlan protocol group add protocol <i>&lt;groupid&gt;</i> <i>&lt;ethertype&gt;</i> { <i>&lt;protocol-list&gt;</i>   arp   ip   ipx}
Mode	Global Config

### protocol group

This command attaches a *<vlanid>* to the protocol-based VLAN identified by *<groupid>*. A group may only be associated with one VLAN at a time, however the VLAN association can be changed.

Default	none
Format	protocol group <i>&lt;groupid&gt;</i> <i>&lt;vlanid&gt;</i>
Mode	VLAN Config

### no protocol group

This command removes the *<vlanid>* from this protocol-based VLAN group that is identified by this *<groupid>*.

Format	no protocol group <i>&lt;groupid&gt;</i> <i>&lt;vlanid&gt;</i>
Mode	VLAN Config

### protocol vlan group

This command adds the physical interface to the protocol-based VLAN identified by *<groupid>*. You can associate multiple interfaces with a group, but you can only associate each interface and protocol combination with one group. If adding an interface to a group causes any conflicts with protocols currently associated with the group, this command fails and the interface(s) are not added to the group.

Default	none
Format	protocol vlan group <i>&lt;groupid&gt;</i>
Mode	Interface Config

**no protocol vlan group**

This command removes the interface from this protocol-based VLAN group that is identified by this *<groupid>*.

Format	no protocol vlan group <i>&lt;groupid&gt;</i>
Mode	Interface Config

**protocol vlan group all**

This command adds all physical interfaces to the protocol-based VLAN identified by *<groupid>*. You can associate multiple interfaces with a group, but you can only associate each interface and protocol combination with one group. If adding an interface to a group causes any conflicts with protocols currently associated with the group, this command will fail and the interface(s) will not be added to the group.

Default	none
Format	protocol vlan group all <i>&lt;groupid&gt;</i>
Mode	Global Config

**no protocol vlan group all**

This command removes all interfaces from this protocol-based VLAN group that is identified by this *<groupid>*.

Format	no protocol vlan group all <i>&lt;groupid&gt;</i>
Mode	Global Config

**vlan pvid**

This command changes the VLAN ID per interface.

Default	1
Format	vlan pvid <i>&lt;1-4093&gt;</i>
Mode	Interface Config

**no vlan pvid**

This command sets the VLAN ID per interface to 1.

Format	no vlan pvid
Mode	Interface Config

## vlan tagging

This command configures the tagging behavior for a specific interface in a VLAN to enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The vlan-list contains VlanId's in range <1-4093>. Separate non-consecutive IDs with ',' and no spaces and no zeros in between the range; Use '-' for range.

Format	vlan tagging <vlan-list>
Mode	Interface Config

## no vlan tagging

This command configures the tagging behavior for a specific interface in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The vlan-list contains VlanId's in range <1-4093>. Separate non-consecutive IDs with ',' and no spaces and no zeros in between the range; Use '-' for range.

Format	no vlan tagging <vlan-list>
Mode	Interface Config

## vlan association subnet

This command associates a VLAN to a specific IP-subnet.

Format	vlan association subnet <ipaddr> <netmask> <1-4093>
Mode	VLAN Config

## no vlan association subnet

This command removes association of a specific IP-subnet to a VLAN.

Format	no vlan association subnet <ipaddr> <netmask>
Mode	VLAN Config

## vlan association mac

This command associates a MAC address to a VLAN.

Format	vlan association mac <macaddr> <1-4093>
Mode	VLAN database

**no vlan association mac**

This command removes the association of a MAC address to a VLAN.

Format	<code>no vlan association mac &lt;macaddr&gt;</code>
Mode	VLAN database

**remote-span**

This command identifies the VLAN as the RSPAN VLAN.

Format	<code>remote span</code>
Mode	VLAN configuration

**show vlan**

This command displays a list of all configured VLANs or detailed information for a specific VLAN.

Format	<code>show vlan [&lt;vlanid&gt;]</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
VLAN ID	A VLAN Identifier (VID) is associated with each VLAN. The range of the VLAN ID is 1–4093.
VLAN Name	A string associated with this VLAN as a convenience. It can be up to 32 alphanumeric characters long, including blanks. The default is blank. VLAN ID 1 always has a name of "Default." This field is optional.
VLAN Type	Type of VLAN, which can be Default (VLAN ID = 1) or static (one that is configured and permanently defined), or Dynamic (one that is created by GVRP registration).



If you enter the optional `<vlanid>` parameter, the command output also displays detailed information, including interface information, for a specific VLAN. The ID is a valid VLAN identification number.

Term	Definition
Interface	Valid slot and port number separated by forward slashes. It is possible to set the parameters for all ports by using the selectors on the top line.
Current	The degree of participation of this port in this VLAN. The permissible values are: <ul style="list-style-type: none"> <li>• <b>Include</b> - This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard.</li> <li>• <b>Exclude</b> - This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q standard.</li> <li>• <b>Autodetect</b> - To allow the port to be dynamically registered in this VLAN via GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.</li> </ul>
Configured	The configured degree of participation of this port in this VLAN. The permissible values are: <ul style="list-style-type: none"> <li>• <b>Include</b> - This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard.</li> <li>• <b>Exclude</b> - This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q standard.</li> <li>• <b>Autodetect</b> - To allow the port to be dynamically registered in this VLAN via GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.</li> </ul>
Tagging	The tagging behavior for this port in this VLAN. <ul style="list-style-type: none"> <li>• <b>Tagged</b> - Transmit traffic for this VLAN as tagged frames.</li> <li>• <b>Untagged</b> - Transmit traffic for this VLAN as untagged frames.</li> </ul>

## show vlan brief

This command displays a list of all configured VLANs.

Format	<code>show vlan brief</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

## show vlan port

This command displays VLAN port information.

Format	<code>show vlan port {&lt;slot/port&gt;   all}</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Interface	Valid slot and port number separated by forward slashes. It is possible to set the parameters for all ports by using the selectors on the top line.
Port VLAN ID	The VLAN ID that this port will assign to untagged frames or priority tagged frames received on this port. The value must be for an existing VLAN. The factory default is 1.
Acceptable Frame Types	The types of frames that may be received on this port. The options are 'VLAN only' and 'Admit All'. When set to 'VLAN only', untagged frames or priority tagged frames received on this port are discarded. When set to 'Admit All', untagged frames or priority tagged frames received on this port are accepted and assigned the value of the Port VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance to the 802.1Q VLAN specification.
Ingress Filtering	May be enabled or disabled. When enabled, the frame is discarded if this port is not a member of the VLAN with which this frame is associated. In a tagged frame, the VLAN is identified by the VLAN ID in the tag. In an untagged frame, the VLAN is the Port VLAN ID specified for the port that received this frame. When disabled, all frames are forwarded in accordance with the 802.1Q VLAN bridge specification. The factory default is disabled.
GVRP	May be enabled or disabled.
Default Priority	The 802.1p priority assigned to tagged packets arriving on the port.

### show vlan association subnet

This command displays the VLAN associated with a specific configured IP-Address and net mask. If no IP address and net mask are specified, the VLAN associations of all the configured IP-subnets are displayed.

Format	<code>show vlan association subnet [&lt;ipaddr&gt; &lt;netmask&gt;]</code>
Mode	Privileged EXEC

Term	Definition
IP Subnet	The IP address assigned to each interface.
IP Mask	The subnet mask.
VLAN ID	A VLAN Identifier (VID) is associated with each VLAN.

### show vlan association mac

This command displays the VLAN associated with a specific configured MAC address. If no MAC address is specified, the VLAN associations of all the configured MAC addresses are displayed.

Format	<code>show vlan association mac [&lt;macaddr&gt;]</code>
Mode	Privileged EXEC

Term	Definition
MAC Address	A MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes.
VLAN ID	A VLAN Identifier (VID) is associated with each VLAN.

## Switch Port Commands

This section describes the commands used for switch port mode.

### switchport mode

Use this command to configure the mode of a switch port as access, trunk, or general:

- Trunk mode.** In trunk mode, the port becomes a member of all VLANs on the switch unless specified in the allowed list in the `switchport trunk allowed vlan` command. The PVID of the port is set to the native VLAN as specified in the `switchport trunk native vlan` command. This means that trunk ports accept both tagged and untagged packets. Untagged packets are processed on the native VLAN and tagged packets are processed on the VLAN for which the ID is contained in the packet. MAC learning is performed on both tagged and untagged packets. Tagged packets that are received with a VLAN ID of which the port is not a member are discarded and MAC learning is not performed.

The trunk ports always transmit packets untagged on a native VLAN.

- Access mode.** In access mode, the port becomes a member of only one VLAN. The port sends and receives untagged traffic. The port can also receive tagged traffic. Ingress filtering is enabled on the port. This means that when the VLAN ID of a received packet is not identical to the access VLAN ID, the packet is discarded.
- General mode.** In general mode, you can perform custom configuration of the VLAN membership, PVID, tagging, ingress filtering, and so on. The general mode is legacy behavior of the switch port configuration and you use legacy CLI commands to configure the port in general mode.

Default	General mode
Format	<code>switchport mode {access   trunk   general}</code>
Mode	Interface Config

### no switchport mode

This command resets the switch port mode to its default value.

Format	no switchport mode
Mode	Interface Config

### switchport trunk allowed vlan

Use this command to configure the list of allowed VLANs that can receive and send traffic on this interface in tagged format when in trunking mode. The default is **all**.

You can modify the VLAN list by using the **add** and **remove** options and replace the VLAN list with another list by using the **all** or **except** options. If you use the **all** option, all VLANs are added to the list of allowed VLANs. The **except** option provides an exclusion list.

Default	all
Format	switchport trunk allowed vlan {<vlan-list>   all   {add <vlan-list>}   {remove <vlan-list>}   {except <vlan-list>}}
Mode	Interface Config

Parameter	Description
all	Specifies all VLANs from 1 to 4093. This keyword is not allowed for commands that do not permit all VLANs in the list to be set at the same time.
add	Adds the defined list of VLANs to those currently set instead of replacing the list.
remove	Removes the defined list of VLANs from those currently set instead of replacing the list. Valid IDs are from 1 to 4093. Extended-range VLAN IDs of the form XY or X,Y,Z are valid in this command
except	Lists the VLANs that must be calculated by inverting the defined list of VLANs. (VLANs are added except the ones specified.)
<vlan-list>	Either a single VLAN number from 1 to 4093 or a continuous range of VLANs described by two VLAN numbers, the lesser one first, separated by a hyphen.

### no switchport trunk allowed vlan

This command resets the list of allowed VLANs on the trunk port to its default value.

Format	no switchport trunk allowed vlan
Mode	Interface Config

### switchport trunk native vlan

Use this command to configure the trunk port native VLAN (PVID) parameter of the switch port. Any ingress untagged packets on the port are tagged with the value of the native VLAN.

The native VLAN must be in the allowed VLAN list for tagging of received untagged packets. Otherwise, untagged packets are discarded. Packets marked with the native VLAN are transmitted untagged from the trunk port. The default ID is 1, the default VLAN.

Default	1 (default VLAN)
Format	<code>switchport trunk native vlan &lt;vlan-id&gt;</code>
Mode	Interface Config

### no switchport trunk native vlan

Use this command to reset the trunk mode native VLAN of the switch port to its default value.

Format	<code>no switchport trunk native vlan</code>
Mode	Interface Config

### switchport access vlan

Use this command to configure the VLAN on the access port. You can assign one VLAN only to the access port. The access port is member of VLAN 1 by default. You can assign the access port to a VLAN other than VLAN 1. If you remove the access VLAN on the switch, the access port becomes a member of VLAN 1. If you configure the access port as a member of a VLAN that does not exist, an error occurs and the configuration does not change.

Default	1 (default VLAN)
Format	<code>switchport access vlan &lt;vlan-id&gt;</code>
Mode	Interface Config

### no switchport access vlan

This command resets the switch port access mode VLAN to its default value.

Format	<code>no switchport access vlan</code>
Mode	Interface Config

### show interfaces switchport

Use this command to either display the switch port status for all interfaces, for a specific interface, or for a specific mode (access, trunk, or general). If you select a mode but do not specify the interface for the mode, the selected mode is displayed for all interfaces.

Format	<code>show interfaces switchport [{&lt;slot/port&gt;}   {access   trunk   general}] [&lt;slot/port&gt;]</code>
Mode	Privileged EXEC

**Command example:**

```
(NETGEAR Switch) #show interfaces switchport 1/0
Port: 1/0
VLAN Membership Mode: General
Access Mode VLAN: 1 (default)
General Mode PVID: 1 (default)
General Mode Ingress Filtering: Disabled
General Mode Acceptable Frame Type: Admit all
General Mode Dynamically Added VLANs:
General Mode Untagged VLANs: 1
General Mode Tagged VLANs:
General Mode Forbidden VLANs:
Trunking Mode Native VLAN: 1 (default)
Trunking Mode Native VLAN tagging: Disable
Trunking Mode VLANs Enabled: All
Protected Port: False
```

**Command example:**

```
(NETGEAR Switch) #show interfaces switchport access 1/0

Intf      PVID
-----  ----
1/0       1
```

**Command example:**

```
(NETGEAR Switch) #show interfaces switchport trunk 1/6

Intf      PVID  Allowed Vlans List
-----  ----  -
1/6       1     All
```

**Command example:**

```
(NETGEAR Switch) #show interfaces switchport general 1/5

Intf      PVID  Ingress   Acceptable  Untagged  Tagged   Forbidden  Dynamic
          PVID  Filtering  Frame Type  Vlans     Vlans    Vlans      Vlans
-----  ----  -
1/5       1     Enabled   Admit All   7         10-50,55  9,100-200  88,96
```

**Command example:**

```
(NETGEAR Switch) #show interfaces switchport general
```

Intf	PVID	Ingress Filtering	Acceptable Frame Type	Untagged Vlans	Tagged Vlans	Forbidden Vlans	Dynamic Vlans
1/0/1	1	Enabled	Admit All	1,4-7	30-40,55	3,100-200	88,96
1/0/2	1	Disabled	Admit All	1	30-40,55	none	none

## Double VLAN Commands

This section describes the commands you use to configure double VLAN (DVLAN). Double VLAN tagging is a way to pass VLAN traffic from one customer domain to another through a Metro Core in a simple and cost effective manner. The additional tag on the traffic helps differentiate between customers in the MAN while preserving the VLAN identification of the individual customers when they enter their own 802.1Q domain.

### **dvlan-tunnel etherstype**

This command configures the ether-type for all interfaces. The ether-type may have the values of *802.1Q*, *vman*, or *custom*. If the ether-type has a value of *custom*, the optional value of the custom ether type must be set to a value from 0 to 65535.

Default	vman
Format	dvlan-tunnel etherstype {802.1Q   vman   custom} [<0-65535>]
Mode	Global Config

### **mode dot1q-tunnel**

This command is used to enable Double VLAN Tunneling on the specified interface.

Default	disabled
Format	mode dot1q-tunnel
Mode	Interface Config

### **no mode dot1q-tunnel**

This command is used to disable Double VLAN Tunneling on the specified interface. By default, Double VLAN Tunneling is disabled.

Format	no mode dot1q-tunnel
Mode	Interface Config

## mode dvlan-tunnel

Use this command to enable Double VLAN Tunneling on the specified interface.

---

**Note:** When you use the `mode dvlan-tunnel` command on an interface, it becomes a service provider port. Ports that do not have double VLAN tunneling enabled are customer ports.

---

Default	disabled
Format	<code>mode dvlan-tunnel</code>
Mode	Interface Config

## no mode dvlan-tunnel

This command is used to disable Double VLAN Tunneling on the specified interface. By default, Double VLAN Tunneling is disabled.

Format	<code>no mode dvlan-tunnel</code>
Mode	Interface Config

## show dot1q-tunnel

Use this command without the optional parameters to display all interfaces enabled for Double VLAN Tunneling. Use the optional parameters to display detailed information about Double VLAN Tunneling for the specified interface or all interfaces.

Format	<code>show dot1q-tunnel [interface {&lt;slot/port&gt;   all}]</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
Mode	The administrative mode through which Double VLAN Tunneling can be enabled or disabled. The default value for this field is disabled.
EtherType	A 2-byte hex EtherType to be used as the first 16 bits of the DVLAN tunnel. There are three different EtherType tags. The first is 802.1Q, which represents the commonly used value of 0x8100. The second is vMAN, which represents the commonly used value of 0x88A8. If EtherType is not one of these two values, it is a custom tunnel value, representing any value in the range of 0–65535.



## show dvlan-tunnel

Use this command without the optional parameters to display all interfaces enabled for Double VLAN Tunneling. Use the optional parameters to display detailed information about Double VLAN Tunneling for the specified interface or all interfaces.

Format	<code>show dvlan-tunnel [interface {&lt;slot/port&gt;   all}]</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
Mode	The administrative mode through which Double VLAN Tunneling can be enabled or disabled. The default value for this field is disabled.
EtherType	A 2-byte hex EtherType to be used as the first 16 bits of the DVLAN tunnel. There are three different EtherType tags. The first is 802.1Q, which represents the commonly used value of 0x8100. The second is vMAN, which represents the commonly used value of 0x88A8. If EtherType is not one of these two values, it is a custom tunnel value, representing any value in the range of 0–65535.

## Voice VLAN Commands

This section describes the commands you use for Voice VLAN. Voice VLAN enables switch ports to carry voice traffic with defined priority to enable separation of voice and data traffic coming onto the port. The benefits of using Voice VLAN is to ensure that the sound quality of an IP phone could be safeguarded from deteriorating when the data traffic on the port is high.

Also the inherent isolation provided by VLANs ensures that inter-VLAN traffic is under management control and that network- attached clients cannot initiate a direct attack on voice components. QoS-based on IEEE 802.1P Class of Service (CoS) uses classification and scheduling to sent network traffic from the switch in a predictable manner. The system uses the source MAC of the traffic traveling through the port to identify the IP phone data flow.

### voice vlan (Global Config)

Use this command to enable the Voice VLAN capability on the switch.

Default	disabled
Format	<code>voice vlan</code>
Mode	Global Config

**no voice vlan (Global Config)**

Use this command to disable the Voice VLAN capability on the switch.

Format	no voice vlan
Mode	Global Config

**voice vlan (Interface Config)**

Use this command to enable the Voice VLAN capability on the interface.

Default	disabled
Format	voice vlan {<id>   dot1p <priority>   none   untagged}
Mode	Interface Config

You can configure Voice VLAN in any of the following ways:

Parameter	Description
vlan-id	Configure the IP phone to forward all voice traffic through the specified VLAN. Valid VLAN IDs are from 1 to 4093 (the maximum supported by the platform).
dot1p	Configure the IP phone to use 802.1p priority tagging for voice traffic and to use the default native VLAN (VLAN 0) to carry all traffic. Valid <priority> range is 0–7.
none	Allow the IP phone to use its own configuration to send untagged voice traffic.
untagged	Configure the phone to send untagged voice traffic.

**no voice vlan (Interface Config)**

Use this command to disable the Voice VLAN capability on the interface.

Format	no voice vlan
Mode	Interface Config

**voice vlan data priority**

Use this command to either trust or untrust the data traffic arriving on the Voice VLAN port.

Default	trust
Format	voice vlan data priority {untrust   trust}
Mode	Interface Config

## show voice vlan

Format	<code>show voice vlan [interface {&lt;slot/port&gt;   all}]</code>
Mode	Privileged EXEC

When the **interface** parameter is not specified, only the global mode of the Voice VLAN is displayed.

Term	Definition
Administrative Mode	The Global Voice VLAN mode.

When the **interface** is specified:

Term	Definition
Voice VLAN Interface Mode	The admin mode of the Voice VLAN on the interface.
Voice VLAN ID	The Voice VLAN ID
Voice VLAN Priority	The do1p priority for the Voice VLAN on the port.
Voice VLAN Untagged	The tagging option for the Voice VLAN traffic.
Voice VLAN CoS Override	The Override option for the voice traffic arriving on the port.
Voice VLAN Status	The operational status of Voice VLAN on the port.

## Provisioning (IEEE 802.1p) Commands

This section describes the commands you use to configure provisioning, which allows you to prioritize ports.

### vlan port priority all

This command configures the port priority assigned for untagged packets for all ports presently plugged into the device. The range for the priority is 0-7. Any subsequent per port configuration will override this configuration setting.

Format	<code>vlan port priority all &lt;priority&gt;</code>
Mode	Global Config

## vlan priority

This command configures the default 802.1p port priority assigned for untagged packets for a specific interface. The range for the priority is 0–7.

Default	0
Format	<code>vlan priority &lt;priority&gt;</code>
Mode	Interface Config

## Protected Ports Commands

This section describes commands you use to configure and view protected ports on a switch. Protected ports do not forward traffic to each other, even if they are on the same VLAN. However, protected ports can forward traffic to all unprotected ports in their group. Unprotected ports can forward traffic to both protected and unprotected ports. Ports are unprotected by default.

If an interface is configured as a protected port, and you add that interface to a Port Channel or link aggregation group (LAG), the protected port status becomes operationally disabled on the interface, and the interface follows the configuration of the LAG port. However, the protected port configuration for the interface remains unchanged. Once the interface is no longer a member of a LAG, the current configuration for that interface automatically becomes effective.

### switchport protected (Global Config)

Use this command to create a protected port group. The `<groupid>` parameter identifies the set of protected ports. Use the **name** `<name>` pair to assign a name to the protected port group. The name can be up to 32 alphanumeric characters long, including blanks. The default is blank.

---

**Note:** Port protection occurs within a single switch. Protected port configuration does not affect traffic between ports on two different switches. No traffic forwarding is possible between two protected ports.

---

Format	<code>switchport protected &lt;groupid&gt; name &lt;name&gt;</code>
Mode	Global Config

### no switchport protected (Global Config)

Use this command to remove a protected port group. The *<groupid>* parameter identifies the set of protected ports. Use the **name** keyword to remove the name from the group.

Format	NO switchport protected <i>&lt;groupid&gt;</i> name
Mode	Global Config

### switchport protected (Interface Config)

Use this command to add an interface to a protected port group. The *<groupid>* parameter identifies the set of protected ports to which this interface is assigned. You can only configure an interface as protected in one group.

---

**Note:** Port protection occurs within a single switch. Protected port configuration does not affect traffic between ports on two different switches. No traffic forwarding is possible between two protected ports.

---

Default	unprotected
Format	switchport protected <i>&lt;groupid&gt;</i>
Mode	Interface Config

### no switchport protected (Interface Config)

Use this command to configure a port as unprotected. The *<groupid>* parameter identifies the set of protected ports to which this interface is assigned.

Format	no switchport protected <i>&lt;groupid&gt;</i>
Mode	Interface Config

### show switchport protected

This command displays the status of all the interfaces, including protected and unprotected interfaces.

Format	show switchport protected <i>&lt;groupid&gt;</i>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Group ID	The number that identifies the protected port group.
Name	An optional name of the protected port group. The name can be up to 32 alphanumeric characters long, including blanks. The default is blank.
List of Physical Ports	List of ports, which are configured as protected for the group identified with <groupid>. If no port is configured as protected for this group, this field is blank.

## show interfaces switchport (for a group ID)

This command displays the status of the interface (protected/unprotected) under the groupid.

Format	<code>show interfaces switchport &lt;slot/port&gt; &lt;groupid&gt;</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Name	A string associated with this group as a convenience. It can be up to 32 alphanumeric characters long, including blanks. The default is blank. This field is optional.
Protected port	Indicates whether the interface is protected or not. It shows TRUE or FALSE. If the group is a multiple groups then, it shows TRUE in Group <groupid>.

## Private VLAN Commands

The Private VLANs feature separates a regular VLAN domain into two or more subdomains. Each subdomain is defined (represented) by a primary VLAN and a secondary VLAN. The primary VLAN ID is the same for all subdomains that belong to a private VLAN. The secondary VLAN ID differentiates subdomains from each other and provides Layer 2 isolation between ports of the same private VLAN. The types of VLANs within a private VLAN are as follows:

- **Primary VLAN**—Forwards the traffic from the promiscuous ports to isolated ports, community ports, and other promiscuous ports in the same private VLAN. Only one primary VLAN can be configured per private VLAN. All ports within a private VLAN share primary VLAN.
- **Isolated VLAN**—A secondary VLAN that carries traffic from isolated ports to promiscuous ports. Only one isolated VLAN can be configured per private VLAN.
- **Community VLAN**—A secondary VLAN that forwards traffic between ports that belong to the same community and the promiscuous ports. There can be multiple community VLANs per private VLAN.

Three types of port designations exist within a private VLAN:

- **Promiscuous Ports**—An endpoint connected to a promiscuous port is allowed to communicate with any endpoint within the private VLAN. Multiple promiscuous ports can be defined for a single private VLAN domain.
- **Isolated Ports**—An endpoint connected to an isolated port is allowed to communicate with endpoints connected to promiscuous ports only. Endpoints connected to adjacent isolated ports cannot communicate with each other.
- **Community Ports**—An endpoint connected to a community port is allowed to communicate with the endpoints within a community and with any configured promiscuous port. The endpoints that belong to one community cannot communicate with endpoints that belong to a different community or with endpoints connected to isolated ports.

The Private VLANs can be extended across multiple switches through inter-switch/stack links that transport primary, community, and isolated VLANs between devices.

### switchport private-vlan

This command is used to define a private-VLAN association for an isolated or community port or a mapping for a promiscuous port.

Format	<code>switchport private-vlan {host-association &lt;primary-vlan-id&gt; &lt;secondary-vlan-id&gt;   mapping &lt;primary-vlan-id&gt; {add   remove} &lt;secondary-vlan-list&gt;}</code>
Mode	Interface Config

Parameter	Definition
host-association	Defines VLAN association for community or host ports.
<primary-vlan-id>	Primary VLAN ID of a private VLAN.
secondary-vlan-id	Secondary (isolated or community) VLAN ID of a private VLAN.
mapping	Defines the private VLAN mapping for promiscuous ports.
add	Associates the secondary VLAN with the primary one.
remove	Deletes the secondary VLANs from the primary VLAN association.
<secondary-vlan-list>	A list of secondary VLANs to be mapped to a primary VLAN.

### no switchport private-vlan

This command is used to remove the private-VLAN association or mapping from the port.

Format	<code>no switchport private-vlan {host-association   mapping}</code>
Mode	Interface Config

## switchport mode private-vlan

This command is used to configure a port as a promiscuous or host private VLAN port. Note that the properties of each mode can be configured even when the switch is not in that mode. However, they will only be applicable once the switch is in that particular mode.

Format	<code>switchport mode private-vlan {host   promiscuous}</code>
Mode	Interface Config
Default	General

Parameter	Definition
host	Configures an interface as a private VLAN host port. It can be either isolated or community port depending on the secondary VLAN it is associated with.
promiscuous	Configures an interface as a private VLAN promiscuous port. The promiscuous ports are members of the primary VLAN.

## no switchport mode

This command is used to remove the private-VLAN association or mapping from the port.

Format	<code>no switchport mode private-vlan</code>
Mode	Interface Config

## private-vlan

This command is used to configure the private VLANs and to configure the association between the primary private VLAN and secondary VLANs.

Format	<code>private-vlan {association [add   remove] &lt;secondary-vlan-list&gt;   community   isolated   primary}</code>
Mode	VLAN Config

Parameter	Definition
association	Associates the primary and secondary VLAN.
<secondary-vlan-list>	A list of secondary VLANs to be mapped to a primary VLAN.
community	Designates a VLAN as a community VLAN.
isolated	Designates a VLAN as the isolated VLAN.
primary	Designates a VLAN as the primary VLAN.



### no private-vlan

This command is used to restore normal VLAN configuration.

Format	<code>no private-vlan {association}</code>
Mode	VLAN Config

### vlan (Private VLAN)

Use this command to enter the private vlan configuration. The VLAN range is 1-4094.

Format	<code>vlan &lt;vlan-list&gt;</code>
Mode	Global Config

### show vlan private-vlan

This command displays information about the configured private VLANs including primary and secondary VLAN IDs, type (community, isolated, or primary) and the ports that belong to a private VLAN.

Format	<code>show vlan private-vlan [type]</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Private -vlan	Displays information about the configured private VLANs
type	Displays only private VLAN ID and its type.
Primary	Displays primary VLAN ID
Secondary	Displays secondary VLAN ID
Type	Displays secondary VLAN type
Ports	Displays ports which are associated with a private VLAN

### show interface ethernet switchport

This command displays the private VLAN mapping information for the switch interfaces.

Format	<code>show interface ethernet &lt;slot/port&gt; switchport</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Private-vlan host-association	Displays VLAN association for the private-VLAN host ports.
Private-vlan mapping	Displays VLAN mapping for the private-VLAN promiscuous ports

## GARP Commands

This section describes the commands you use to configure Generic Attribute Registration Protocol (GARP) and view GARP status. The commands in this section affect both GARP VLAN Registration Protocol (GVRP) and Garp Multicast Registration Protocol (GMRP). GARP is a protocol that allows client stations to register with the switch for membership in VLANS (by using GVMP) or multicast groups (by using GVMP).

### set garp timer join

This command sets the GVRP join time for one port (Interface Config mode) or all (Global Config mode) and per GARP. Join time is the interval between the transmission of GARP Protocol Data Units (PDUs) registering (or re-registering) membership for a VLAN or multicast group. This command has an effect only when GVRP is enabled. The time is from 10 to 100 (centiseconds). The value 20 centiseconds is 0.2 seconds.

Default	20
Format	<code>set garp timer join &lt;10-100&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

### no set garp timer join

This command sets the GVRP join time (for one or all ports and per GARP) to the default and only has an effect when GVRP is enabled.

Format	<code>no set garp timer join</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

### set garp timer leave

This command sets the GVRP leave time for one port (Interface Config mode) or all ports (Global Config mode) and only has an effect when GVRP is enabled. Leave time is the time to wait after receiving a unregister request for a VLAN or a multicast group before deleting the VLAN entry. This can be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. The leave time is 20–600 (centiseconds). The value 60 centiseconds is 0.6 seconds.

Default	60
Format	set garp timer leave <20-600>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

### no set garp timer leave

This command sets the GVRP leave time on all ports or a single port to the default and only has an effect when GVRP is enabled.

Format	no set garp timer leave
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

### set garp timer leaveall

This command sets how frequently Leave All PDUs are generated. A Leave All PDU indicates that all registrations will be unregistered. Participants would need to rejoin in order to maintain registration. The value applies per port and per GARP participation. The time may range from 200 to 6000 (centiseconds). The value 1000 centiseconds is 10 seconds. You can use this command on all ports (Global Config mode) or a single port (Interface Config mode), and it only has an effect only when GVRP is enabled.

Default	1000
Format	set garp timer leaveall <200-6000>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

### no set garp timer leaveall

This command sets how frequently Leave All PDUs are generated the default and only has an effect when GVRP is enabled.

Format	no set garp timer leaveall
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

## show garp

This command displays GARP information.

Format	<code>show garp</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
GMRP Admin Mode	The administrative mode of GARP Multicast Registration Protocol (GMRP) for the system.
GVRP Admin Mode	The administrative mode of GARP VLAN Registration Protocol (GVRP) for the system.

## GVRP Commands

This section describes the commands you use to configure and view GARP VLAN Registration Protocol (GVRP) information. GVRP-enabled switches exchange VLAN configuration information, which allows GVRP to provide dynamic VLAN creation on trunk ports and automatic VLAN pruning.

---

**Note:** If GVRP is disabled, the system does not forward GVRP messages.

---

### set gvrp adminmode

This command enables GVRP on the system.

Default	disabled
Format	<code>set gvrp adminmode</code>
Mode	Privileged EXEC

### no set gvrp adminmode

This command disables GVRP.

Format	<code>no set gvrp adminmode</code>
Mode	Privileged EXEC

## set gvrp interfacemode

This command enables GVRP on a single port (Interface Config mode) or all ports (Global Config mode).

Default	disabled
Format	<code>set gvrp interfacemode</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

## no set gvrp interfacemode

This command disables GVRP on a single port (Interface Config mode) or all ports (Global Config mode). If GVRP is disabled, Join Time, Leave Time, and Leave All Time have no effect.

Format	<code>no set gvrp interfacemode</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

## show gvrp configuration

This command displays Generic Attributes Registration Protocol (GARP) information for one or all interfaces.

Format	<code>show gvrp configuration {&lt;slot/port&gt;   all}</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
Join Timer	The interval between the transmission of GARP PDUs registering (or re-registering) membership for an attribute. Current attributes are a VLAN or multicast group. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 10–100 centiseconds (0.1 to 1.0 seconds). The factory default is 20 centiseconds (0.2 seconds). The finest granularity of specification is one centisecond (0.01 seconds).
Leave Timer	The period of time to wait after receiving an unregister request for an attribute before deleting the attribute. Current attributes are a VLAN or multicast group. This may be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 20–600 centiseconds (0.2 to 6.0 seconds). The factory default is 60 centiseconds (0.6 seconds).

Term	Definition
LeaveAll Timer	This Leave All Time controls how frequently LeaveAll PDUs are generated. A LeaveAll PDU indicates that all registrations will shortly be deregistered. Participants will need to rejoin in order to maintain registration. There is an instance of this timer on a per-Port, per-GARP participant basis. The Leave All Period Timer is set to a random value in the range of LeaveAllTime to 1.5*LeaveAllTime. Permissible values are 200–6000 centiseconds (2–60 seconds). The factory default is 1000 centiseconds (10 seconds).
Port GVMRP Mode	The GVRP administrative mode for the port, which is enabled or disabled (default). If this parameter is disabled, Join Time, Leave Time, and Leave All Time have no effect.

## GMRP Commands

This section describes the commands you use to configure and view GARP Multicast Registration Protocol (GMRP) information. Like IGMP snooping, GMRP helps control the flooding of multicast packets. GMRP-enabled switches dynamically register and deregister group membership information with the MAC networking devices attached to the same segment. GMRP also allows group membership information to propagate across all networking devices in the bridged LAN that support Extended Filtering Services.

---

**Note:** If GMRP is disabled, the system does not forward GMRP messages.

---

### set gmrp adminmode

This command enables GARP Multicast Registration Protocol (GMRP) on the system.

Default	disabled
Format	set gmrp adminmode
Mode	Privileged EXEC

### no set gmrp adminmode

This command disables GARP Multicast Registration Protocol (GMRP) on the system.

Format	no set gmrp adminmode
Mode	Privileged EXEC

### set gmrp interfacemode

This command enables GARP Multicast Registration Protocol on a single interface (Interface Config mode) or all interfaces (Global Config mode). If an interface which has GARP enabled is enabled for routing or is enlisted as a member of a port-channel (LAG), GARP functionality is disabled on that interface. GARP functionality is subsequently re-enabled if routing is

disabled and port-channel (LAG) membership is removed from an interface that has GARP enabled.

Default	disabled
Format	<code>set gmrp interfacemode</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

### no set gmrp interfacemode

This command disables GARP Multicast Registration Protocol on a single interface or all interfaces. If an interface which has GARP enabled is enabled for routing or is enlisted as a member of a port-channel (LAG), GARP functionality is disabled. GARP functionality is subsequently re-enabled if routing is disabled and port-channel (LAG) membership is removed from an interface that has GARP enabled.

Format	<code>no set gmrp interfacemode</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

### show gmrp configuration

This command displays Generic Attributes Registration Protocol (GARP) information for one or all interfaces.

Format	<code>show gmrp configuration {&lt;slot/port&gt;   all}</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Interface	The slot/port of the interface that this row in the table describes.
Join Timer	The interval between the transmission of GARP PDUs registering (or re-registering) membership for an attribute. Current attributes are a VLAN or multicast group. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 10–100 centiseconds (0.1 to 1.0 seconds). The factory default is 20 centiseconds (0.2 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).
Leave Timer	The period of time to wait after receiving an unregister request for an attribute before deleting the attribute. Current attributes are a VLAN or multicast group. This may be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 20–600 centiseconds (0.2 to 6.0 seconds). The factory default is 60 centiseconds (0.6 seconds).

Term	Definition
LeaveAll Timer	This Leave All Time controls how frequently LeaveAll PDUs are generated. A LeaveAll PDU indicates that all registrations will shortly be deregistered. Participants will need to rejoin in order to maintain registration. There is an instance of this timer on a per-Port, per-GARP participant basis. The Leave All Period Timer is set to a random value in the range of LeaveAllTime to 1.5*LeaveAllTime. Permissible values are 200–6000 centiseconds (2–60 seconds). The factory default is 1000 centiseconds (10 seconds).
Port GMRP Mode	The GMRP administrative mode for the port. It may be enabled or disabled. If this parameter is disabled, Join Time, Leave Time, and Leave All Time have no effect.

### show mac-address-table gmrp

This command displays the GMRP entries in the Multicast Forwarding Database (MFDB) table.

Format	show mac-address-table gmrp
Mode	Privileged EXEC

Term	Definition
Mac Address	A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address is displayed as 8 bytes.
Type	The type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.
Description	The text description of this multicast table entry.
Interfaces	The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

## Port-Based Network Access Control Commands

This section describes the commands you use to configure port-based network access control (802.1x). Port-based network access control allows you to permit access to network services only to and devices that are authorized and authenticated.

### clear dot1x statistics

This command resets the 802.1x statistics for the specified port or for all ports.

Format	clear dot1x statistics {<slot/port>   all}
Mode	Privileged EXEC



**clear radius statistics**

This command is used to clear all RADIUS statistics.

Format	<code>clear radius statistics</code>
Mode	Privileged EXEC

**dot1x eapolflood**

Use this command to enable EAPOL flood support on the switch.

Default	Disabled
Format	<code>dot1x eapolflood</code>
Mode	Global Config

**no dot1x eapolflood**

This command disables EAPOL flooding on the switch.

Format	<code>no dot1x eapolflood</code>
Mode	Global Config

**dot1x guest-vlan**

This command configures VLAN as guest vlan on a per port basis. The command specifies an active VLAN as an IEEE 802.1x guest VLAN. The range is 1 to the maximum VLAN ID supported by the platform.

Default	disabled
Format	<code>dot1x guest-vlan &lt;vlan-id&gt;</code>
Mode	Interface Config

**no dot1x guest-vlan**

This command disables Guest VLAN on the interface.

Default	disabled
Format	<code>no dot1x guest-vlan</code>
Mode	Interface Config

### dot1x initialize

This command begins the initialization sequence on the specified port. This command is only valid if the control mode for the specified port is “auto” or “mac-based”. If the control mode is not “auto” or “mac-based,” an error is returned.

Format	dot1x initialize <slot/port>
Mode	Privileged EXEC

### dot1x mac-auth-bypass

This command enables MAC-Based Authentication Bypass (MAB) for 802.1x-unaware clients. MAB provides 802.1x-unaware clients controlled access to the network using the devices’ MAC address as an identifier. This requires that the known and allowable MAC address and corresponding access rights be pre-populated in the authentication server. MAB works only when the port control mode of the port is MAC-based.

Format	dot1x mac-auth-bypass
Mode	Interface Config

### no dot1x mac-auth-bypass

This command disables MAB for 802.1x-unaware clients.

Format	no dot1x mac-auth-bypass
Mode	Interface Config

### dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant. The <count> value must be in the range 1 - 10.

Default	2
Format	dot1x max-req <count>
Mode	Interface Config

### no dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant.

Format	no dot1x max-req
Mode	Interface Config

### dot1x max-users

Use this command to set the maximum number of clients supported on the port when MAC-based dot1x authentication is enabled on the port. The maximum users supported per port is dependent on the product. The *<count>* value is in the range 1 - 48.

Default	48
Format	dot1x max-users <i>&lt;count&gt;</i>
Mode	Interface Config

### no dot1x max-users

This command resets the maximum number of clients allowed per port to its default value.

Format	no dot1x max-req
Mode	Interface Config

### dot1x port-control

This command sets the authentication mode to use on the specified port. Select **force-unauthorized** to specify that the authenticator PAE unconditionally sets the controlled port to unauthorized. Select **force-authorized** to specify that the authenticator PAE unconditionally sets the controlled port to authorized. Select **auto** to specify that the authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator, and the authentication server. If the **mac-based** option is specified, MAC-based dot1x authentication is enabled on the port.

Default	auto
Format	dot1x port-control {force-unauthorized   force-authorized   auto   mac-based}
Mode	Interface Config

### no dot1x port-control

This command sets the 802.1x port control mode on the specified port to the default value.

Format	no dot1x port-control
Mode	Interface Config

### dot1x port-control all

This command sets the authentication mode to use on all ports. Select **force-unauthorized** to specify that the authenticator PAE unconditionally sets the controlled port to unauthorized. Select **force-authorized** to specify that the authenticator PAE unconditionally sets the controlled port to authorized. Select **auto** to specify that the

authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator, and the authentication server. If the **mac-based** option is specified, MAC-based dot1x authentication is enabled on the port.

Default	auto
Format	dot1x port-control all {force-unauthorized   force-authorized   auto   mac-based}
Mode	Global Config

### no dot1x port-control all

This command sets the authentication mode on all ports to the default value.

Format	no dot1x port-control all
Mode	Global Config

### dot1x re-authenticate

This command begins the re-authentication sequence on the specified port. This command is only valid if the control mode for the specified port is “auto” or “mac-based”. If the control mode is not “auto” or “mac-based”, an error will be returned.

Format	dot1x re-authenticate <slot/port>
Mode	Privileged EXEC

### dot1x re-authentication

This command enables re-authentication of the supplicant for the specified port.

Default	disabled
Format	dot1x re-authentication
Mode	Interface Config

### no dot1x re-authentication

This command disables re-authentication of the supplicant for the specified port.

Format	no dot1x re-authentication
Mode	Interface Config

## dot1x system-auth-control

Use this command to enable the dot1x authentication support on the switch. While disabled, the dot1x configuration is retained and can be changed, but is not activated.

Default	disabled
Format	dot1x system-auth-control
Mode	Global Config

## no dot1x system-auth-control

This command is used to disable the dot1x authentication support on the switch.

Format	no dot1x system-auth-control
Mode	Global Config

## dot1x timeout

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port. Depending on the token used and the value (in seconds) passed, various time-out configurable parameters are set.

Default	<ul style="list-style-type: none"> <li>• guest-vlan-period: 90 seconds</li> <li>• reauth-period: 3600 seconds</li> <li>• quiet-period: 60 seconds</li> <li>• tx-period: 30 seconds</li> <li>• supp-timeout: 30 seconds</li> <li>• server-timeout: 30 seconds</li> </ul>
Format	dot1x timeout {{guest-vlan-period <seconds>}   {reauth-period <seconds>}   {quiet-period <seconds>}   {tx-period <seconds>}   {supp-timeout <seconds>}   {server-timeout <seconds>}}
Mode	Interface Config

The following table describes the tokens that are supported.

Tokens	Definition
guest-vlan-period	The time, in seconds, for which the authenticator waits to see if any EAPOL packets are received on a port before authorizing the port and placing the port in the guest vlan (if configured). The guest vlan timer is only relevant when guest vlan has been configured on that specific port.
reauth-period	The value, in seconds, of the timer used by the authenticator state machine on this port to determine when re-authentication of the supplicant takes place. The reauth-period must be a value in the range 1 - 65535.

Tokens	Definition
quiet-period	The value, in seconds, of the timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The quiet-period must be a value in the range 0 - 65535.
tx-period	The value, in seconds, of the timer used by the authenticator state machine on this port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The quiet-period must be a value in the range 1 - 65535.
supp-timeout	The value, in seconds, of the timer used by the authenticator state machine on this port to timeout the supplicant. The supp-timeout must be a value in the range 1 - 65535.
server-timeout	The value, in seconds, of the timer used by the authenticator state machine on this port to timeout the authentication server. The supp-timeout must be a value in the range 1 - 65535.

### no dot1x timeout

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port to the default values. Depending on the token used, the corresponding default values are set.

Format	<code>no dot1x timeout {guest-vlan-period   reauth-period   quiet-period   tx-period   supp-timeout   server-timeout}</code>
Mode	Interface Config

### dot1x unauthenticated-vlan

Use this command to configure the unauthenticated VLAN associated with that port. The unauthenticated VLAN ID can be a valid VLAN ID from 0-Maximum supported VLAN ID. The unauthenticated VLAN must be statically configured in the VLAN database to be operational. By default, the unauthenticated VLAN is 0, that is, invalid and not operational.

Default	0
Format	<code>dot1x unauthenticated-vlan &lt;vlan id&gt;</code>
Mode	Interface Config

### no dot1x unauthenticated-vlan

This command resets the unauthenticated-vlan associated with the port to its default value.

Format	<code>no dot1x unauthenticated-vlan</code>
Mode	Interface Config

### dot1x user

This command adds the specified user to the list of users with access to the specified port or all ports. The `<user>` parameter must be a configured user.

Format	<code>dot1x user &lt;user&gt; {&lt;slot/port&gt;   all}</code>
Mode	Global Config

### no dot1x user

This command removes the user from the list of users with access to the specified port or all ports.

Format	<code>no dot1x user &lt;user&gt; {&lt;slot/port&gt;   all}</code>
Mode	Global Config

### clear dot1x authentication-history

This command clears the authentication history table captured during successful and unsuccessful authentication on all interface or the specified interface.

Format	<code>clear dot1x authentication-history [slot/port]</code>
Mode	Global Config

### dot1x dynamic-vlan enable

Use this command to enable the switch to create VLANs dynamically when a RADIUS assigned VLAN does not exist in the switch.

Format	<code>dot1x dynamic-vlan enable</code>
Mode	Global Config
Default	Disabled

### no dot1x dynamic-vlan enable

Use this command to disable the switch from creating VLANs dynamically when a RADIUS assigned VLAN does not exist in the switch.

Format	<code>no dot1x dynamic-vlan enable</code>
Mode	Global Config

### dot1x system-auth-control monitor

Use this command to enable the 802.1X monitor mode on the switch. The purpose of Monitor mode is to help troubleshoot port-based authentication configuration issues without disrupting network access for hosts connected to the switch. In Monitor mode, a host is granted network access to an 802.1X-enabled port even if it fails the authentication process. The results of the process are logged for diagnostic purposes.

Format	<code>dot1x system-auth-control monitor</code>
Mode	Global Config
Default	Disabled

### no dot1x system-auth-control monitor

Use this command to disable the 802.1X monitor on the switch.

Format	<code>no dot1x system-auth-control monitor</code>
Mode	Global Config

### show dot1x authentication-history

This command displays 802.1X authentication events and information during successful and unsuccessful Dot1x authentication process for all interfaces or the specified interface. Use the optional keywords to display only failure authentication events in summary or in detail.

Format	<code>show dot1x authentication-history {slot/port   all} [failedauth-only] [detail]</code>
Mode	Privileged EXEC

Term	Definition
Time Stamp	The exact time at which the event occurs.
Interface	Physical Port on which the event occurs.
Mac-Address	The supplicant/client MAC address.
VLAN assigned	The VLAN assigned to the client/port on authentication.
VLAN assigned Reason	The type of VLAN ID assigned, which can be Guest VLAN, Unauth, Default, RADIUS Assigned, or Monitor Mode VLAN ID.
Auth Status	The authentication status.
Reason	The actual reason behind the successful or failed authentication.



## show authentication methods

This command displays information about the authentication methods.

Format	show authentication methods
Mode	Privileged EXEC

### Command example:

```
Login Authentication Method Lists
```

```
-----
```

```
Console_Default: None
```

```
Network_Default:Local
```

```
Enable Authentication Lists
```

```
-----
```

```
Console_Default: Enable None
```

```
Network_Default:Enable
```

```
Line Login Method List Enable Method Lists
```

```
-----
```

```
Console Console_Default Console_Default
```

```
Telnet Network_Default Network_Default
```

```
SSH Network_Default Network_Default
```

```
http : Local
```

```
https : Local
```

```
dot1x :
```

## show dot1x

This command is used to show a summary of the global dot1x configuration, summary information of the dot1x configuration for a specified port or all ports, the detailed dot1x configuration for a specified port and the dot1x statistics for a specified port - depending on the tokens used.

Format	show dot1x [{summary {<slot/port>   all}   detail <slot/port>   statistics <slot/port>}]
Mode	Privileged EXEC

If you do not use the optional <slot/port> parameters, the command displays the global dot1x mode, the VLAN Assignment mode, and the Dynamic VLAN Creation mode.

Term	Definition
Administrative Mode	Indicates whether authentication control on the switch is enabled or disabled.
VLAN Assignment Mode	Indicates whether assignment of an authorized port to a RADIUS assigned VLAN is allowed (enabled) or not (disabled).

Term	Definition
Dynamic VLAN Creation Mode	Indicates whether the switch can dynamically create a RADIUS-assigned VLAN if it does not currently exist on the switch.
Monitor Mode	Indicates whether the Dot1x Monitor mode on the switch is enabled or disabled.

If you use the optional parameter **summary** {<slot/port> | **all**}, the dot1x configuration for the specified port or all ports are displayed.

Term	Definition
Interface	The interface whose configuration is displayed.
Control Mode	The configured control mode for this port. Possible values are force-unauthorized   force-authorized   auto   mac-based   authorized   unauthorized.
Operating Control Mode	The control mode under which this port is operating. Possible values are authorized   unauthorized.
Reauthentication Enabled	Indicates whether re-authentication is enabled on this port.
Port Status	Indicates whether the port is authorized or unauthorized. Possible values are authorized   unauthorized.

If you use the optional parameter **detail** <slot/port>, the detailed dot1x configuration for the specified port is displayed.

Term	Definition
Port	The interface whose configuration is displayed.
Protocol Version	The protocol version associated with this port. The only possible value is 1, corresponding to the first version of the dot1x specification.
PAE Capabilities	The port access entity (PAE) functionality of this port. Possible values are Authenticator or Supplicant.
Control Mode	The configured control mode for this port. Possible values are force-unauthorized   force-authorized   auto   mac-based.
Authenticator PAE State	Current state of the authenticator PAE state machine. Possible values are Initialize, Disconnected, Connecting, Authenticating, Authenticated, Aborting, Held, ForceAuthorized, and ForceUnauthorized. When MAC-based authentication is enabled on the port, this parameter is deprecated.
Backend Authentication State	Current state of the backend authentication state machine. Possible values are Request, Response, Success, Fail, Timeout, Idle, and Initialize. When MAC-based authentication is enabled on the port, this parameter is deprecated.
Quiet Period	The timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The value is expressed in seconds and will be in the range 0 and 65535.

## M4100 Series ProSAFE Managed Switches

Term	Definition
Transmit Period	The timer used by the authenticator state machine on the specified port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The value is expressed in seconds and will be in the range of 1 and 65535.
Guest-VLAN ID	The guest VLAN identifier configured on the interface.
Guest VLAN Period	The time in seconds for which the authenticator waits before authorizing and placing the port in the Guest VLAN, if no EAPOL packets are detected on that port.
Supplicant Timeout	The timer used by the authenticator state machine on this port to timeout the supplicant. The value is expressed in seconds and will be in the range of 1 and 65535.
Server Timeout	The timer used by the authenticator on this port to timeout the authentication server. The value is expressed in seconds and will be in the range of 1 and 65535.
Maximum Requests	The maximum number of times the authenticator state machine on this port will retransmit an EAPOL EAP Request/Identity before timing out the supplicant. The value will be in the range of 1 and 10.
VLAN Id	The VLAN assigned to the port by the radius server. This is only valid when the port control mode is not Mac-based.
VLAN Assigned Reason	The reason the VLAN identified in the VLAN Id field has been assigned to the port. Possible values are RADIUS, Unauthenticated VLAN, Guest VLAN, default, and Not Assigned. When the VLAN Assigned Reason is 'Not Assigned', it means that the port has not been assigned to any VLAN by dot1x. This only valid when the port control mode is not MAC-based.
Reauthentication Period	The timer used by the authenticator state machine on this port to determine when reauthentication of the supplicant takes place. The value is expressed in seconds and will be in the range of 1 and 65535.
Reauthentication Enabled	Indicates if reauthentication is enabled on this port. Possible values are "True" or "False".
Key Transmission Enabled	Indicates if the key is transmitted to the supplicant for the specified port. Possible values are True or False.
Control Direction	The control direction for the specified port or ports. Possible values are both or in.
Maximum Users	The maximum number of clients that can get authenticated on the port in the MAC-based dot1x authentication mode. This value is used only when the port control mode is not MAC-based.
Unauthenticated VLAN ID	Indicates the unauthenticated VLAN configured for this port. This value is valid for the port only when the port control mode is not MAC-based.
Session Timeout	Indicates the time for which the session is valid. The time period in seconds is returned by the RADIUS server on authentication of the port. This value is valid for the port only when the port control mode is not MAC-based.
Session Termination Action	This value indicates the action to be taken once the session timeout expires. Possible values are Default, Radius-Request. If the value is Default, the session is terminated the port goes into unauthorized state. If the value is Radius-Request, a reauthentication of the client authenticated on the port is performed. This value is valid for the port only when the port control mode is not MAC-based.

The **show dot1x detail** *<slot/port>* command displays the following MAC-based dot1x fields if the port-control mode for that specific port is MAC-based. For each client authenticated on the port, the **show dot1x detail** *<slot/port>* command displays the following MAC-based dot1x parameters if the port-control mode for that specific port is MAC-based.

Term	Definition
Supplicant MAC-Address	The MAC-address of the supplicant.
Authenticator PAE State	Current state of the authenticator PAE state machine. Possible values are Initialize, Disconnected, Connecting, Authenticating, Authenticated, Aborting, Held, ForceAuthorized, and ForceUnauthorized.
Backend Authentication State	Current state of the backend authentication state machine. Possible values are Request, Response, Success, Fail, Timeout, Idle, and Initialize.
VLAN-Assigned	The VLAN assigned to the client by the radius server.
Logical Port	The logical port number associated with the client.

If you use the optional parameter **statistics** *<slot/port>*, the following dot1x statistics for the specified port appear.

Term	Definition
Port	The interface whose statistics are displayed.
EAPOL Frames Received	The number of valid EAPOL frames of any type that have been received by this authenticator.
EAPOL Frames Transmitted	The number of EAPOL frames of any type that have been transmitted by this authenticator.
EAPOL Start Frames Received	The number of EAPOL start frames that have been received by this authenticator.
EAPOL Logoff Frames Received	The number of EAPOL logoff frames that have been received by this authenticator.
Last EAPOL Frame Version	The protocol version number carried in the most recently received EAPOL frame.
Last EAPOL Frame Source	The source MAC address carried in the most recently received EAPOL frame.
EAP Response/Id Frames Received	The number of EAP response/identity frames that have been received by this authenticator.

Term	Definition
EAP Response Frames Received	The number of valid EAP response frames (other than resp/id frames) that have been received by this authenticator.
EAP Request/Id Frames Transmitted	The number of EAP request/identity frames that have been transmitted by this authenticator.
EAP Request Frames Transmitted	The number of EAP request frames (other than request/identity frames) that have been transmitted by this authenticator.
Invalid EAPOL Frames Received	The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.
EAP Length Error Frames Received	The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.

### show dot1x clients

This command displays 802.1x client information. This command also displays information about the number of clients that are authenticated using Monitor mode and using 802.1x.

Format	<code>show dot1x clients {&lt;slot/port&gt;   all}</code>
Mode	Privileged EXEC

Term	Definition
Clients Authenticated using Monitor Mode	Indicates the number of the Dot1x clients authenticated using Monitor mode.
Clients Authenticated using Dot1x	Indicates the number of Dot1x clients authenticated using 802.1x authentication process.
Logical Interface	The logical port number associated with a client.
Interface	The physical port to which the supplicant is associated.
User Name	The user name used by the client to authenticate to the server.
Supplicant MAC Address	The supplicant device MAC address.
Session Time	The time since the supplicant is logged on.
Filter ID	Identifies the Filter ID returned by the RADIUS server when the client was authenticated. This is a configured DiffServ policy name on the switch.
VLAN ID	The VLAN assigned to the port.

Term	Definition
VLAN Assigned	The reason the VLAN identified in the VLAN ID field has been assigned to the port. Possible values are RADIUS, Unauthenticated VLAN, or Default. When the VLAN Assigned reason is Default, it means that the VLAN was assigned to the port because the PVID of the port was that VLAN ID.
Session Timeout	This value indicates the time for which the session is valid. The time period in seconds is returned by the RADIUS server on authentication of the port. This value is valid for the port only when the port-control mode is not MAC-based.
Session Termination Action	This value indicates the action to be taken once the session timeout expires. Possible values are Default and Radius-Request. If the value is Default, the session is terminated and client details are cleared. If the value is Radius-Request, a reauthentication of the client is performed.

### show dot1x users

This command displays 802.1x port security user information for locally configured users.

Format	<code>show dot1x users &lt;slot/port&gt;</code>
Mode	Privileged EXEC

Term	Definition
Users	Users configured locally to have access to the specified port.

## 802.1X Supplicant Commands

802.1X (“dot1x”) supplicant functionality is on point-to-point ports. The administrator can configure the user name and password used in authentication and capabilities of the supplicant port.

### dot1x pae

Use this command to set the port’s dot1x role. The port can serve as either a supplicant or an authenticator.

Format	<code>dot1x pae {supplicant   authenticator}</code>
Mode	Interface Config

### dot1x supplicant port-control

Use this command to set the ports authorization state (Authorized or Unauthorized) either manually or by setting the port to auto-authorize upon startup. By default all the ports are authenticators. If the port’s attribute must be moved from authenticator to supplicant or supplicant to authenticator, use this command.

Format	<code>dot1x supplicant port-control {auto   force-authorized   force_unauthorized}</code>
Mode	Interface Config

Parameter	Description
auto	The port is in the Unauthorized state until it presents its user name and password credentials to an authenticator. If the authenticator authorizes the port, then it is placed in the Authorized state.
force-authorized	Sets the authorization state of the port to Authorized, bypassing the authentication process.
force- unauthorized	Sets the authorization state of the port to Unauthorized, bypassing the authentication process.

### no dot1x supplicant port-control

Use this command to set the port-control mode to the default, auto.

Default	Auto
Format	<code>no dot1x supplicant port-control</code>
Mode	Interface Config

### dot1x supplicant max-start

Use this command to configure the number of attempts that the supplicant makes to find the authenticator before the supplicant assumes that there is no authenticator.

Default	3
Format	<code>dot1x supplicant max-start &lt;1-10&gt;</code>
Mode	Interface Config

### no dot1x supplicant max-start

Use this command to set the max-start value to the default.

Format	<code>no dot1x supplicant max-start</code>
Mode	Interface Config

### dot1x supplicant timeout start-period

Use this command to configure the start period timer interval in seconds to wait for the EAP identity request from the authenticator.

Default	30 seconds
Format	dot1x supplicant timeout start-period <1-65535>
Mode	Interface Config

### no dot1x supplicant timeout start-period

Use this command to set the start-period value to the default.

Format	no dot1x supplicant timeout start-period
Mode	Interface Config

### dot1x supplicant timeout held-period

Use this command to configure the held period timer interval in seconds to wait for the next authentication on previous authentication fail.

Default	30 seconds
Format	dot1x supplicant timeout held-period <1-65535>
Mode	Interface Config

### no dot1x supplicant timeout held-period

Use this command to set the held-period value to the default value.

Format	no dot1x supplicant timeout held-period
Mode	Interface Config

### dot1x supplicant timeout auth-period

Use this command to configure the authentication period timer interval in seconds to wait for the next EAP request challenge from the authenticator.

Default	30 seconds
Format	dot1x supplicant timeout auth-period <1-65535>
Mode	Interface Config



### no dot1x supplicant timeout auth-period

Use this command to set the auth-period value to the default value.

Format	no dot1x supplicant timeout auth-period
Mode	Interface Config

### dot1x supplicant user

Use this command to map the user to the port.

Format	dot1x supplicant user
Mode	Interface Config

## Storm-Control Commands

This section describes commands you use to configure storm control and view storm control configuration information. A traffic storm is a condition that occurs when incoming packets flood the LAN, which creates performance degradation in the network. The storm control feature protects against this condition.

The switch provides broadcast, multicast, and unicast storm recovery for individual interfaces. Unicast storm control protects against traffic whose MAC addresses are not known by the system. For broadcast, multicast, and unicast storm control, if the rate of traffic ingressing on an interface increases beyond the configured threshold for that type, the traffic is dropped.

To configure storm control, you can enable the feature for all interfaces or for individual interfaces, and you can set the threshold (storm-control level), beyond which the broadcast, multicast, or unicast traffic is dropped. The storm control feature allows you to limit the rate of specific types of packets through the switch on a per-port, per-type, basis.

Configuring a storm-control level also enables that form of storm control. Disabling a storm-control level (using the **no** version of the command) sets the storm control level back to the default value and disables that form of storm control. Using the **no** version of the **storm-control** command (without stating a level) disables that form of storm control but maintains the configured level (to be active the next time that form of storm control is enabled.)

---

**Note:** The actual rate of ingress traffic required to activate storm control is based on the size of incoming packets and the hard-coded average packet size of 512 bytes—used to calculate a packet-per-second (pps) rate—as the forwarding-plane requires pps versus an absolute rate kbps. For example, if the configured limit is 10 percent, this is converted to ~25000 pps, and this pps limit is set in forwarding plane (hardware). You get the approximate desired output when 512 bytes packets are used.

---

### storm-control broadcast (Interface Config)

Use this command to enable broadcast storm recovery mode for a specific interface. If the mode is enabled, broadcast storm recovery is active and, if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic is dropped. Therefore, the rate of broadcast traffic will be limited to the configured threshold.

Default	enabled
Format	storm-control broadcast
Mode	Interface Config

### no storm-control broadcast

Use this command to disable broadcast storm recovery mode for a specific interface.

Format	no storm-control broadcast
Mode	Interface Config

### storm-control broadcast level (Interface Config)

Use this command to configure the broadcast storm recovery threshold for an interface as a percentage of link speed and enable broadcast storm recovery. If the mode is enabled, broadcast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic is dropped. Therefore, the rate of broadcast traffic is limited to the configured threshold.

If the **shutdown** option is selected, and the broadcast traffic increases beyond the threshold, the interface shuts down instead of dropping packets. To recover the port, issue the **no shutdown** command under the port manually.

Default	5
Format	storm-control broadcast level <0-100> {action [ratelimit   shutdown]}
Mode	Interface Config

### no storm-control broadcast level

This command sets the broadcast storm recovery threshold to the default value for an interface and disables broadcast storm recovery.

Format	no storm-control broadcast level
Mode	Interface Config

### storm-control broadcast rate (Interface Config)

Use this command to configure the broadcast storm recovery threshold for an interface in packets per second. If the mode is enabled, broadcast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic is dropped. Therefore, the rate of broadcast traffic is limited to the configured threshold.

Default	0
Format	storm-control broadcast rate <0-14880000>
Mode	Interface Config

### no storm-control broadcast rate

This command sets the broadcast storm recovery threshold to the default value for an interface and disables broadcast storm recovery.

Format	no storm-control broadcast rate
Mode	Interface Config

### storm-control broadcast (Global Config)

This command enables broadcast storm recovery mode for all interfaces. If the mode is enabled, broadcast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of broadcast traffic will be limited to the configured threshold.

Default	disabled
Format	storm-control broadcast
Mode	Global Config

### no storm-control broadcast

This command disables broadcast storm recovery mode for all interfaces.

Format	no storm-control broadcast
Mode	Global Config

### storm-control broadcast level (Global Config)

This command configures the broadcast storm recovery threshold for all interfaces as a percentage of link speed and enables broadcast storm recovery. If the mode is enabled, broadcast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore,

the rate of broadcast traffic will be limited to the configured threshold. This command also enables broadcast storm recovery mode for all interfaces.

If the 'shutdown' option is selected, and the broadcast traffic increases beyond the threshold, the interface shuts down instead of dropping packets. To recover the port, issue 'no shutdown' under the port manually.

Default	5
Format	<code>storm-control broadcast level &lt;0-100&gt;</code>
Mode	Global Config

### no storm-control broadcast level

This command sets the broadcast storm recovery threshold to the default value for all interfaces and disables broadcast storm recovery.

Format	<code>no storm-control broadcast level</code>
Mode	Global Config

### storm-control broadcast rate (Global Config)

Use this command to configure the broadcast storm recovery threshold for all interfaces in packets per second. If the mode is enabled, broadcast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic is dropped. Therefore, the rate of broadcast traffic is limited to the configured threshold.

Default	0
Format	<code>storm-control broadcast rate &lt;0-14880000&gt;</code>
Mode	Global Config

### no storm-control broadcast rate

This command sets the broadcast storm recovery threshold to the default value for all interfaces and disables broadcast storm recovery.

Format	<code>no storm-control broadcast rate</code>
Mode	Global Config

### storm-control multicast (Interface Config)

This command enables multicast storm recovery mode for an interface. If the mode is enabled, multicast storm recovery is active, and if the rate of L2 multicast traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of multicast traffic will be limited to the configured threshold.

Default	disabled
Format	storm-control multicast
Mode	Interface Config

### no storm-control multicast

This command disables multicast storm recovery mode for an interface.

Format	no storm-control multicast
Mode	Interface Config

### storm-control multicast level (Interface Config)

This command configures the multicast storm recovery threshold for an interface as a percentage of link speed and enables multicast storm recovery mode. If the mode is enabled, multicast storm recovery is active, and if the rate of L2 multicast traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of multicast traffic will be limited to the configured threshold.

Default	5
Format	storm-control multicast level <0-100>
Mode	Interface Config

### no storm-control multicast level

This command sets the multicast storm recovery threshold to the default value for an interface and disables multicast storm recovery.

Format	no storm-control multicast level <0-100>
Mode	Interface Config

### storm-control multicast rate (Interface Config)

Use this command to configure the multicast storm recovery threshold for an interface in packets per second. If the mode is enabled, multicast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic is dropped. Therefore, the rate of multicast traffic is limited to the configured threshold.

Default	0
Format	storm-control multicast rate <0-14880000>
Mode	Interface Config

### no storm-control multicast rate

This command sets the multicast storm recovery threshold to the default value for an interface and disables multicast storm recovery.

Format	no storm-control multicast rate
Mode	Interface Config

### storm-control multicast (Global Config)

This command enables multicast storm recovery mode for all interfaces. If the mode is enabled, multicast storm recovery is active, and if the rate of L2 multicast traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of multicast traffic will be limited to the configured threshold.

Default	disabled
Format	storm-control multicast
Mode	Global Config

### no storm-control multicast

This command disables multicast storm recovery mode for all interfaces.

Format	no storm-control multicast
Mode	Global Config

### storm-control multicast level (Global Config)

This command configures the multicast storm recovery threshold for all interfaces as a percentage of link speed and enables multicast storm recovery mode. If the mode is enabled, multicast storm recovery is active, and if the rate of L2 multicast traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of multicast traffic will be limited to the configured threshold.

Default	5
Format	storm-control multicast level <0-100>
Mode	Global Config

**no storm-control multicast level**

This command sets the multicast storm recovery threshold to the default value for all interfaces and disables multicast storm recovery.

Format	<code>no storm-control multicast level</code>
Mode	Global Config

**storm-control multicast rate (Global Config)**

Use this command to configure the multicast storm recovery threshold for all interfaces in packets per second. If the mode is enabled, multicast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic is dropped. Therefore, the rate of multicast traffic is limited to the configured threshold.

Default	0
Format	<code>storm-control multicast rate &lt;0-14880000&gt;</code>
Mode	Global Config

**no storm-control broadcast rate**

This command sets the broadcast storm recovery threshold to the default value for all interfaces and disables broadcast storm recovery.

Format	<code>no storm-control broadcast rate</code>
Mode	Global Config

**storm-control unicast (Interface Config)**

This command enables unicast storm recovery mode for an interface. If the mode is enabled, unicast storm recovery is active, and if the rate of unknown L2 unicast (destination lookup failure) traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of unknown unicast traffic will be limited to the configured threshold.

Default	disabled
Format	<code>storm-control unicast</code>
Mode	Interface Config

**no storm-control unicast**

This command disables unicast storm recovery mode for an interface.

Format	<code>no storm-control unicast</code>
Mode	Interface Config

**storm-control unicast level (Interface Config)**

This command configures the unicast storm recovery threshold for an interface as a percentage of link speed, and enables unicast storm recovery. If the mode is enabled, unicast storm recovery is active, and if the rate of unknown L2 unicast (destination lookup failure) traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of unknown unicast traffic will be limited to the configured threshold. This command also enables unicast storm recovery mode for an interface.

Default	5
Format	<code>storm-control unicast level &lt;0-100&gt;</code>
Mode	Interface Config

**no storm-control unicast level**

This command sets the unicast storm recovery threshold to the default value for an interface and disables unicast storm recovery.

Format	<code>no storm-control unicast level</code>
Mode	Interface Config

**storm-control unicast rate (Interface Config)**

Use this command to configure the unicast storm recovery threshold for an interface in packets per second. If the mode is enabled, unicast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic is dropped. Therefore, the rate of unicast traffic is limited to the configured threshold.

Default	0
Format	<code>storm-control unicast rate &lt;0-14880000&gt;</code>
Mode	Interface Config



**no storm-control unicast rate**

This command sets the unicast storm recovery threshold to the default value for an interface and disables unicast storm recovery.

Format	<code>no storm-control unicast rate</code>
Mode	Interface Config

**storm-control unicast (Global Config)**

This command enables unicast storm recovery mode for all interfaces. If the mode is enabled, unicast storm recovery is active, and if the rate of unknown L2 unicast (destination lookup failure) traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of unknown unicast traffic will be limited to the configured threshold.

Default	disabled
Format	<code>storm-control unicast</code>
Mode	Global Config

**no storm-control unicast**

This command disables unicast storm recovery mode for all interfaces.

Format	<code>no storm-control unicast</code>
Mode	Global Config

**storm-control unicast level (Global Config)**

This command configures the unicast storm recovery threshold for all interfaces as a percentage of link speed, and enables unicast storm recovery. If the mode is enabled, unicast storm recovery is active, and if the rate of unknown L2 unicast (destination lookup failure) traffic ingressing on an interface increases beyond the configured threshold, the traffic will be dropped. Therefore, the rate of unknown unicast traffic will be limited to the configured threshold.

Default	5
Format	<code>storm-control unicast level &lt;0-100&gt;</code>
Mode	Global Config

### no storm-control unicast level

This command sets the unicast storm recovery threshold to the default value and disables unicast storm recovery for all interfaces.

Format	<code>no storm-control unicast level</code>
Mode	Global Config

### storm-control unicast rate (Global Config)

Use this command to configure the unicast storm recovery threshold for all interfaces in packets per second. If the mode is enabled, unicast storm recovery is active, and if the rate of L2 broadcast traffic ingressing on an interface increases beyond the configured threshold, the traffic is dropped. Therefore, the rate of unicast traffic is limited to the configured threshold.

Default	0
Format	<code>storm-control unicast rate &lt;0-14880000&gt;</code>
Mode	Global Config

### no storm-control unicast rate

This command sets the multicast storm recovery threshold to the default value for an interface and disables multicast storm recovery.

Format	<code>no storm-control unicast rate</code>
Mode	Global Config

### show storm-control

This command displays switch configuration information. If you do not use any of the optional parameters, this command displays global storm control configuration parameters:

- **Broadcast Storm Control Mode.** Might be enabled or disabled. The factory default is disabled.
- **Broadcast Storm Control Level.** The factory default is 5 percent.
- **Multicast Storm Control Mode.** Might be enabled or disabled. The factory default is disabled.
- **Multicast Storm Control Level.** The factory default is 5 percent.
- **Unicast Storm Control Mode.** Might be enabled or disabled. The factory default is disabled.
- **Unicast Storm Control Level.** The factory default is 5 percent.

Use the `a11` keyword to display the per-port configuration parameters for all interfaces, or specify the `slot/port` to display information about a specific interface.

Format	<code>show storm-control [all   &lt;slot/port&gt;]</code>
Mode	Privileged EXEC

Term	Definition
Bcast Mode	Shows whether the broadcast storm control mode is enabled or disabled. The factory default is disabled.
Bcast Level	The broadcast storm control level.
Mcast Mode	Shows whether the multicast storm control mode is enabled or disabled.
Mcast Level	The multicast storm control level.
Ucast Mode	Shows whether the Unknown Unicast or DLF (Destination Lookup Failure) storm control mode is enabled or disabled.
Ucast Level	The Unknown Unicast or DLF (Destination Lookup Failure) storm control level.

## Flow Control Commands

In 802.3x flow control, the MAC control PAUSE operation is specified in IEEE 802.3 Annex 31 B. It allows traffic from one device to be throttled for a specified period of time and is defined for devices that are directly connected. A device that needs to inhibit transmission of data frames from another device on the LAN transmits a PAUSE frame as defined in the IEEE specification.

This feature allows the user to configure the switch to use symmetric, asymmetric, or no flow control. Asymmetric flow control allows the switch to respond to received PAUSE frames, but the port cannot generate PAUSE frames. Symmetric flow control allows the switch to both respond to and generate MAC control PAUSE frames.

### flowcontrol

Use this command to enable or disable the symmetric or asymmetric flow control on the switch. Use the `no` form of command to disable the symmetric or asymmetric flow control. Asymmetric here means that Tx Pause can never be enabled. Only Rx Pause can be enabled.

Default	Disabled
Format	<code>flowcontrol {symmetric   asymmetric}</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

**no flowcontrol**

Format	no flowcontrol
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

**show flowcontrol**

Use this command to display the IEEE 802.3 Annex 31B flow control settings and status for a specific interface or all interfaces. It also displays 802.3 Tx and Rx pause counts. Priority Flow Control frames counts are not displayed. If the port is enabled for priority flow control, operational flow control status is displayed as “Inactive”. Operational flow control status for stacking ports is always displayed as “N/A”.

Format	show flowcontrol [slot/port]
Mode	Privileged Exec

**Command example:**

```
(NETGEAR Switch)#show flowcontrol
```

```
Admin Flow Control: Symmetric
```

```

Port      Flow Control   RxPause   TxPause
-----  -
0/1      Active         310       611
0/2      Inactive       0         0

```

**Command example:**

```
(NETGEAR Switch)#show flowcontrol interface 0/1
```

```
Admin Flow Control: Symmetric
```

```

Port      Flow Control   RxPause   TxPause
-----  -
0/1      Active         310       611

```

## Port-Channel/LAG (802.3ad) Commands

This section describes the commands you use to configure port-channels, which are also known as link aggregation groups (LAGs). Link aggregation allows you to combine multiple full-duplex Ethernet links into a single logical link. Network devices treat the aggregation as if it were a single link, which increases fault tolerance and provides load sharing. The LAG feature initially load shares traffic based upon the source and destination MAC address. Assign the port-channel (LAG) VLAN membership after you create a port-channel. If you do not assign VLAN membership, the port-channel might become a member of the management VLAN which can result in learning and switching issues.

A port-channel (LAG) interface can be either static or dynamic, but not both. All members of a port channel must participate in the same protocols.) A static port-channel interface does not require a partner system to be able to aggregate its member ports.

---

**Note:** If you configure the maximum number of dynamic port-channels (LAGs) that your platform supports, additional port-channels that you configure are automatically static.

---

### addport

This command adds one port to the port-channel (LAG). The interface is a logical slot/port number or a group ID of a configured port-channel.

---

**Note:** Before adding a port to a port-channel, set the physical mode of the port. For more information, see *speed* on page 22.

---

Format	<code>addport {&lt;logical slot/port&gt;   lag &lt;lag-group-id&gt;}</code>
Mode	Interface Config

### deleteport (Interface Config)

This command deletes the port from the port-channel (LAG). The interface is a logical slot/port number or a group ID of a configured port-channel.

Format	<code>deleteport {&lt;logical slot/port&gt;   lag &lt;lag-group-id&gt;}</code>
Mode	Interface Config

## deleteport (Global Config)

This command deletes all configured ports from the port-channel (LAG). The interface is a logical slot/port number of a configured port-channel. To clear the port channels, see [clear port-channel](#) on page 368.

Format	<code>deleteport &lt;logical slot/port&gt;</code>
Mode	Global Config

## lacp admin key

Use this command to configure the administrative value of the key for the port-channel. The value range of `<key>` is 0–65535.

Default	0x8000
Format	<code>lacp admin key &lt;key&gt;</code>
Mode	Interface Config

---

**Note:** This command is only applicable to port-channel interfaces.

---

## no lacp admin key

Use this command to configure the default administrative value of the key for the port-channel.

Format	<code>no lacp admin key</code>
Mode	Interface Config

## lacp collector max-delay

Use this command to configure the port-channel collector max delay. The valid range of `<delay>` is 0-65535.

Default	0x8000
Format	<code>lacp collector max-delay &lt;delay&gt;</code>
Mode	Interface Config

---

**Note:** This command is only applicable to port-channel interfaces.

---

**no lacp collector max delay**

Use this command to configure the default port-channel collector max delay.

Format	<code>no lacp collector max-delay</code>
Mode	Interface Config

**lacp actor admin key**

Use this command to configure the administrative value of the LACP actor admin key. The valid range for *<key>* is 0-65535.

Default	Internal Interface Number of this Physical Port
Format	<code>lacp actor admin key &lt;key&gt;</code>
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

**no lacp actor admin key**

Use this command to configure the default administrative value of the key.

Format	<code>no lacp actor admin key</code>
Mode	Interface Config

**lacp actor admin state individual**

Use this command to set LACP actor admin state to individual.

Format	<code>lacp actor admin state individual</code>
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

**no lacp actor admin state individual**

Use this command to set the LACP actor admin state to aggregation.

Format	<code>no lacp actor admin state individual</code>
Mode	Interface Config

### lacp actor admin state longtimeout

Use this command to set LACP actor admin state to longtimeout.

Format	lacp actor admin state longtimeout
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp actor admin state longtimeout

Use this command to set the LACP actor admin state to short timeout.

Format	no lacp actor admin state longtimeout
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### lacp actor admin state passive

Use this command to set the LACP actor admin state to passive.

Format	lacp actor admin state passive
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp actor admin state passive

Use this command to set the LACP actor admin state to active.

Format	no lacp actor admin state passive
Mode	Interface Config



### lacp actor port priority

Use this command to configure the priority value assigned to the Aggregation Port. The valid range for *<priority>* is 0–255.

Default	0x80
Format	lacp actor port priority <i>&lt;priority&gt;</i>
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp actor port priority

Use this command to configure the default priority value assigned to the Aggregation Port.

Format	no lacp actor port priority
Mode	Interface Config

### lacp actor system priority

Use this command to configure the priority value associated with the LACP Actor's SystemID. The range for *<priority>* is 0–65535.

Default	32768
Format	lacp actor system priority <i>&lt;priority&gt;</i>
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp actor system priority

Use this command to configure the priority value associated with the Actor's SystemID.

Format	no lacp actor system priority
Mode	Interface Config

### lacp partner admin key

Use this command to configure the administrative value of the key for the protocol partner. The valid range for <key> is 0–65535.

Default	0x0
Format	lacp partner admin key <key>
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp partner admin key

Use this command to set the administrative value of the key for the protocol partner to the default.

Format	no lacp partner admin key
Mode	Interface Config

### lacp partner admin state individual

Use this command to set LACP partner admin state to individual.

Format	lacp partner admin state individual
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp partner admin state individual

Use this command to set the LACP partner admin state to aggregation.

Format	no lacp partner admin state individual
Mode	Interface Config

### lacp partner admin state longtimeout

Use this command to set LACP partner admin state to longtimeout.

Format	lacp partner admin state longtimeout
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp partner admin state longtimeout

Use this command to set the LACP partner admin state to short timeout.

Format	no lacp partner admin state longtimeout
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### lacp partner admin state passive

Use this command to set the LACP partner admin state to passive.

Format	lacp partner admin state passive
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp partner admin state passive

Use this command to set the LACP partner admin state to active.

Format	no lacp partner admin state passive
Mode	Interface Config

### lacp partner port id

Use this command to configure the LACP partner port id. The valid range for *<port-id>* is 0–65535.

Default	0x80
Format	lacp partner portid <i>&lt;port-id&gt;</i>
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp partner port id

Use this command to set the LACP partner port id to the default.

Format	no lacp partner portid
Mode	Interface Config

### lacp partner port priority

Use this command to configure the LACP partner port priority. The valid range for *<priority>* is 0–255.

Default	0x0
Format	lacp partner port priority <i>&lt;priority&gt;</i>
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp partner port priority

Use this command to configure the default LACP partner port priority.

Format	no lacp partner port priority
Mode	Interface Config

### lacp partner system id

Use this command to configure the 6-octet MAC Address value representing the administrative value of the Aggregation Port's protocol Partner's System ID. The valid range of *<system-id>* is 00:00:00:00:00:00 - FF:FF:FF:FF:FF:FF.

Default	00:00:00:00:00:00
Format	lacp partner system id <i>&lt;system-id&gt;</i>
Mode	Interface Config

---

**Note:** This command is only applicable to physical interfaces.

---

### no lacp partner system id

Use this command to configure the default value representing the administrative value of the Aggregation Port's protocol Partner's System ID.

Format	no lacp partner system id
Mode	Interface Config

### lacp partner system priority

Use this command to configure the administrative value of the priority associated with the Partner's System ID. The valid range for *<priority>* is 0–65535.

Default	0x0
Format	lacp partner system priority <i>&lt;priority&gt;</i>
Mode	Interface Config

---

**Note:** This command is applicable only to physical interfaces.

---

### no lacp partner system priority

Use this command to configure the default administrative value of priority associated with the Partner's System ID.

Format	no lacp partner system priority
Mode	Interface Config

### port-channel local-preference

This command enables the local-preference mode on a port-channel (LAG) interface or range of interfaces. By default, the local-preference mode for a port-channel is disabled. This command can be used only on port-channel interfaces.

Default	disabled
Format	port-channel local-preference
Mode	Interface Config

### no port-channel local-preference

This command disables the local-preference mode on a port-channel.

Format	no port-channel local-preference
Mode	Interface Config

### port-channel static

This command enables the static mode on a port-channel (LAG) interface. By default the static mode for a new port-channel is disabled, which means the port-channel is dynamic. However if the maximum number of allowable dynamic port-channels are already present in the system, the static mode for a new port-channel enabled, which means the port-channel is static. You can only use this command on port-channel interfaces.

Default	disabled
Format	port-channel static
Mode	Interface Config

### no port-channel static

This command sets the static mode on a particular port-channel (LAG) interface to the default value. This command will be executed only for interfaces of type port-channel (LAG).

Format	no port-channel static
Mode	Interface Config

### port lacpmode

This command enables Link Aggregation Control Protocol (LACP) on a port.

Default	enabled
Format	port lacpmode
Mode	Interface Config

**no port lacpmode**

This command disables Link Aggregation Control Protocol (LACP) on a port.

Format	no port lacpmode
Mode	Interface Config

**port lacpmode enable all**

This command enables Link Aggregation Control Protocol (LACP) on all ports.

Format	port lacpmode enable all
Mode	Global Config

**no port lacpmode enable all**

This command disables Link Aggregation Control Protocol (LACP) on all ports.

Format	no port lacpmode enable all
Mode	Global Config

**port lacptimeout (Interface Config)**

This command sets the timeout on a physical interface of a particular device type (**actor** or **partner**) to either **long** or **short** time-out.

Default	long
Format	port lacptimeout {actor   partner} {long   short}
Mode	Interface Config

**no port lacptimeout**

This command sets the timeout back to its default value on a physical interface of a particular device type (**actor** or **partner**).

Format	no port lacptimeout {actor   partner}
Mode	Interface Config

## port lacptimeout (Global Config)

This command sets the timeout for all interfaces of a particular device type (**actor** or **partner**) to either **long** or **short** time-out.

Default	long
Format	port lacptimeout {actor   partner} {long   short}
Mode	Global Config

## no port lacptimeout

This command sets the timeout for all physical interfaces of a particular device type (**actor** or **partner**) back to their default values.

Format	no port lacptimeout {actor   partner}
Mode	Global Config

## port-channel adminmode

This command enables a port-channel (LAG). This command sets every configured port-channel with the same administrative mode setting.

Format	port-channel adminmode all
Mode	Global Config

## no port-channel adminmode

This command disables a port-channel (LAG). This command clears every configured port-channel with the same administrative mode setting.

Format	no port-channel adminmode [all]
Mode	Global Config

## port-channel linktrap

This command enables link trap notifications for the port-channel (LAG). The interface is a logical slot/port for a configured port-channel. This command enables link trap notifications for the port-channel (LAG).

The interface is a logical *<slot/port>* for a configured port-channel. The option **all** enables link trap notifications for all the configured port-channels. Instead of *<slot/port>*, you can use **lag** *<lag-group-id>* as an alternate way to specify the LAG interface, in which *<lag-group-id>* is the LAG port number.



Default	enabled
Format	port-channel linktrap {<slot/port>   lag <lag-group-id>   all}
Mode	Global Config

### no port-channel linktrap

This command disables link trap notifications for the port-channel (LAG). The interface is a logical slot and port for a configured port-channel. The option **a11** disables link trap notifications for all the configured port-channels.

Format	no port-channel linktrap {<slot/port>   lag <lag-group-id>   all}
Mode	Global Config

### port-channel load-balance

This command selects the load-balancing option used on a port-channel (LAG). Traffic is balanced on a port-channel (LAG) by selecting one of the links in the channel over which to transmit specific packets. The link is selected by creating a binary pattern from selected fields in a packet, and associating that pattern with a particular link.

Load-balancing is not supported on every device. The range of options for load-balancing can vary per device. The switch also supports enhanced hashing mode, which has the following advantages:

- MODULO-N (where N is the number of active link members in a LAG) operation based on the number of ports in the LAG.
- Packet attributes selection based on the packet type: For L2 packets, source and destination MAC address are used for hash computation. For L3 packets, source IP, destination IP address, TCP/UDP ports are used.
- Non-Unicast traffic and unicast traffic is hashed using a common hash algorithm
- Excellent load balancing performance.

The interface is a logical <slot/port> for a configured port-channel. The option **a11** enables the configuration for all the configured port-channels. Instead of <slot/port>, you can use **lag** <lag-group-id> as an alternate way to specify the LAG interface, in which <lag-group-id> is the LAG port number.

Default	3
Format	port-channel load-balance {1   2   3   4   5   6   7} {<slot/port>   lag <lag-group-id>   all}
Mode	Interface Config Global Config

Parameter	Definition
1	Source MAC, VLAN, EtherType, and incoming port associated with the packet
2	Destination MAC, VLAN, EtherType, and incoming port associated with the packet
3	Source/Destination MAC, VLAN, EtherType, and incoming port associated with the packet
4	Source IP and Source TCP/UDP fields of the packet
5	Destination IP and Destination TCP/UDP Port fields of the packet
6	Source/Destination IP and source/destination TCP/UDP Port fields of the packet
7	Enhanced Hashing Mode

### no port-channel load-balance

This command reverts to the default load balancing configuration.

Format	no port-channel load-balance {<slot/port>   lag <lag-group-id>   all}
Mode	Interface Config Global Config

### port-channel name

This command defines a name for the port-channel (LAG). Use <name> to specify an alphanumeric string up to 15 characters.

The interface is a logical <slot/port> for a configured port-channel. Instead of <slot/port>, you can use **lag** <lag-group-id> as an alternate way to specify the LAG interface, in which <lag-group-id> is the LAG port number.

Format	port-channel name {<slot/port>   lag <lag-group-id>   <name>}
Mode	Global Config

### port-channel system priority

Use this command to configure port-channel system priority. The valid range of <priority> is 0-65535.

Default	0x8000
Format	port-channel system priority <priority>
Mode	Global Config

### no port-channel system priority

Use this command to configure the default port-channel system priority value.

Format	no port-channel system priority
Mode	Global Config

### show lacp actor

Use this command to display LACP actor attributes.

The interface is a logical `<slot/port>` for a configured port-channel. The option **all** displays the configuration for all the configured port-channels. Instead of `<slot/port>`, you can use **lag** `<lag-group-id>` as an alternate way to specify the LAG interface, in which `<lag-group-id>` is the LAG port number.

Format	show lacp actor {<slot/port>   lag <lag-group-id>   all}
Mode	Global Config

The following output parameters are displayed.

Term	Description
System Priority	The system priority assigned to the Aggregation Port.
Admin Key	The administrative value of the Key.
Port Priority	The priority value assigned to the Aggregation Port.
Admin State	The administrative values of the actor state as transmitted by the Actor in LACPDUs.

### show lacp partner

Use this command to display LACP partner attributes.

The interface is a logical `<slot/port>` for a configured port-channel. The option **all** displays the configuration for all the configured port-channels. Instead of `<slot/port>`, you can use **lag** `<lag-group-id>` as an alternate way to specify the LAG interface, in which `<lag-group-id>` is the LAG port number.

Format	show lacp partner {<slot/port>   lag <lag-group-id>   all}
Mode	Privileged EXEC

The following output parameters are displayed.

Term	Description
System Priority	The administrative value of priority associated with the Partner's System ID.
System ID	The value representing the administrative value of the Aggregation Port's protocol Partner's System ID.
Admin Key	The administrative value of the Key for the protocol Partner.
Port Priority	The administrative value of the port priority for the protocol Partner.
Port-ID	The administrative value of the port number for the protocol Partner.
Admin State	The administrative values of the actor state for the protocol Partner.

### show port-channel brief

This command displays the static capability of all port-channel (LAG) interfaces on the device as well as a summary of individual port-channel interfaces.

Format	<code>show port-channel brief</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

For each port-channel the following information is displayed:

Term	Definition
Logical Interface	The slot/port of the logical interface.
Port-channel Name	The name of port-channel (LAG) interface.
Link-State	Shows whether the link is up or down.
Trap Flag	Shows whether trap flags are enabled or disabled.
Type	Shows whether the port-channel is statically or dynamically maintained.
Mbr Ports	The members of this port-channel.
Active Ports	The ports that are actively participating in the port-channel.

### show port-channel

This command displays an overview of all port-channels (LAGs) on the switch.

Format	<code>show port-channel</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Logical Interface	Valid slot and port number separated by forward slashes.
Port-Channel Name	The name of this port-channel (LAG). You may enter any string of up to 15 alphanumeric characters.
Link State	Indicates whether the Link is up or down.
Admin Mode	May be enabled or disabled. The factory default is enabled.
Type	The status designating whether a particular port-channel (LAG) is statically or dynamically maintained. <ul style="list-style-type: none"> <li>• <b>Static</b> - The port-channel is statically maintained.</li> <li>• <b>Dynamic</b> - The port-channel is dynamically maintained.</li> </ul>
Mbr Ports	A listing of the ports that are members of this port-channel (LAG), in slot/port notation. There can be a maximum of eight ports assigned to a port-channel (LAG).
Device Timeout	For each port, lists the timeout ( <i>long</i> or <i>short</i> ) for Device Type ( <i>actor</i> or <i>partner</i> ).
Port Speed	Speed of the port-channel port.
Ports Active	This field lists the ports that are actively participating in the port-channel (LAG).
Load Balance Option	The load balance option associated with this LAG. See <a href="#">port-channel load-balance</a> on page 121.
Local Preference Mode	Indicates whether the local preference mode is enabled or disabled.

### show port-channel system priority

Use this command to display the port-channel system priority.

Format	<code>show port-channel system priority</code>
Mode	Privileged EXEC

## Port Mirroring Commands

Port mirroring, which is also known as port monitoring, selects network traffic that you can analyze with a network analyzer, such as a SwitchProbe device or other Remote Monitoring (RMON) probe.

### monitor session

This command configures a probe port and a monitored port for monitor session (port monitoring). Use the **source interface** *<slot/port>* parameter to specify the interface to monitor. Use **rx** to monitor only ingress packets or use **tx** to monitor only egress packets. If you do not specify an **rx** or **tx** option, the destination port monitors both ingress and egress packets.

A VLAN can be configured as the source to a session (all member ports of that VLAN are monitored). Remote port mirroring is configured by adding the RSPAN VLAN ID. At the source switch, the destination is configured as the RSPAN VLAN and at the destination switch, the source is configured as the RSPAN VLAN.

---

**Note:** The source and destination cannot be configured as remote on the same device.

---

The reflector-port is configured at the source switch. The reflector-port forwards the mirrored traffic towards the destination switch.

---

**Note:** This port must be configured with RSPAN VLAN membership.

---

IP/MAC ACL can be attached to a session by giving the access list number/name.

Use the **destination interface** *<slot/port>* to specify the interface to receive the monitored traffic.

Use the **mode** parameter to enable the administrative mode of the session. If enabled, the probe port monitors all the traffic received and transmitted on the physical monitored port.

Use the filter parameter to filter a specified access group either by IP address or MAC address.

Format	<code>monitor session &lt;session-id&gt; {source {interface &lt;slot/port&gt; / cpu / vlan &lt;vlan-id&gt;   remote vlan &lt;vlan-id&gt;} [{rx   tx}]   destination {interface &lt;slot/port&gt;   remote vlan &lt;vlan-id&gt;} reflector-port &lt;slot/port&gt;}   mode}</code>
Mode	Global Config

**Command example:**

To configure the RSPAN VLAN source:

```
monitor session <session-id> source {interface <slot/port> | vlan <vlan-id> / remote vlan <vlan-id>} [rx | tx]
```

**Command example:**

To the configure RSPAN VLAN destination:

```
monitor session <session-id> destination {interface <slot/port> | remote vlan <vlan-id>} reflector-port <slot/port>}
```

### no monitor session

Use this command without optional parameters to remove the monitor session (port monitoring) designation from the source probe port, the destination monitored port and all VLANs. Once the port is removed from the VLAN, you must manually add the port to any desired VLANs. Use the **source interface** *<slot/port>* parameter or **destination interface** to remove the specified interface from the port monitoring session. Use the **mode** parameter to disable the administrative mode of the session.

---

**Note:** Because the current version of NETGEAR Managed Switch SMB software only supports one session, if you do not supply optional parameters, the behavior of this command is similar to the behavior of the **no monitor** command.

---

Format	no monitor session <i>&lt;session-id&gt;</i> [{source interface <i>&lt;slot/port&gt;</i>   destination interface   mode}]
Mode	Global Config

### no monitor

This command removes all the source ports and a destination port for the and restores the default value for mirroring session mode for all the configured sessions.

---

**Note:** This is a stand-alone **no** command. This command does not have a normal form.

---

Default	enabled
Format	no monitor
Mode	Global Config

### show monitor session

This command displays the Port monitoring information for a particular mirroring session.

---

**Note:** The *<session-id>* parameter is an integer value used to identify the session. In the current version of the software, the *<session-id>* parameter is always 1.

---

Format	<code>show monitor session &lt;session-id&gt;</code>
Mode	Privileged EXEC

Term	Definition
Session ID	An integer value used to identify the session. Its value can be anything between 1 and the maximum number of mirroring sessions allowed on the platform.
Monitor Session Mode	Indicates whether the Port Mirroring feature is enabled or disabled for the session identified with <session-id>. The possible values are Enabled and Disabled.
Probe Port	Probe port (destination port) for the session identified with <session-id>. If probe port is not set then this field is blank.
Source Port	The port, which is configured as mirrored port (source port) for the session identified with <session-id>. If no source port is configured for the session then this field is blank.
Type	Direction in which source port configured for port mirroring. Types are tx for transmitted packets and rx for receiving packets.
Src VLAN	All member ports of this VLAN are mirrored. If the source VLAN is not configured, this field is blank.
Ref. Port	This port carries all the mirrored traffic at the source switch.
Src Remote VLAN	The source VLAN is configured at the destination switch. If the remote VLAN is not configured, this field is blank.
Dst Remote VLAN	The destination VLAN is configured at the source switch. If the remote VLAN is not configured, this field is blank.
IP ACL	The IP access-list id or name attached to the port mirroring session.
MAC ACL	The MAC access-list name attached to the port mirroring session.

## show vlan remote-span

This command displays the configured RSPAN VLAN.

Format	<code>show vlan remote-span</code>
Mode	Privileged Exec Mode

### Command example:

```
(NETGEAR Switch)# show vlan remote-span
```

```
Remote SPAN VLAN
```

```
-----  
100
```



## Static MAC Filtering Commands

The commands in this section describe how to configure static MAC filtering. Static MAC filtering allows you to configure destination ports for a static multicast MAC filter irrespective of the platform.

### macfilter

This command adds a static MAC filter entry for the MAC address *<macaddr>* on the VLAN *<vlanid>*. A packet with a specific destination MAC address in a specific VLAN is admitted only if the ingress port is defined in the set of source ports, otherwise the packet is dropped. On the egress side, a packet that was admitted is sent through all ports that are defined in the set of destination ports.

The value of the *<macaddr>* parameter is a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The following MAC addresses are restricted: 00:00:00:00:00:00, 01:80:C2:00:00:00 to 01:80:C2:00:00:0F, 01:80:C2:00:00:20 to 01:80:C2:00:00:21, and FF:FF:FF:FF:FF:FF. The *<vlanid>* parameter must identify a valid VLAN.

The number of static mac filters supported on the system is different for MAC filters where source ports are configured and MAC filters where destination ports are configured.

- For unicast MAC address filters and multicast MAC address filters with source port lists, the maximum number of static MAC filters supported is 20.
- For multicast MAC address filters with destination ports configured, the maximum number of static filters supported is 256.

For example, for current platforms you can configure the following combinations:

- Unicast MAC and source port (max = 20)
- Multicast MAC and source port (max=20)
- Multicast MAC and destination port (only) (max=256)
- Multicast MAC and source ports and destination ports (max=20)

Format	<code>macfilter &lt;macaddr&gt; &lt;vlanid&gt;</code>
Mode	Global Config

### no macfilter

This command removes all filtering restrictions and the static MAC filter entry for the MAC address *<macaddr>* on the VLAN *<vlanid>*. The *<macaddr>* parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The *<vlanid>* parameter must identify a valid VLAN.

Format	<code>no macfilter &lt;macaddr&gt; &lt;vlanid&gt;</code>
Mode	Global Config

### macfilter adddest

Use this command to add the interface to the destination filter set for the MAC filter with the *<macaddr>* and VLAN of *<vlanid>*. The *<macaddr>* parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The *<vlanid>* parameter must identify a valid VLAN.

---

**Note:** Configuring a destination port list is only valid for multicast MAC addresses.

---

Format	macfilter adddest <i>&lt;macaddr&gt;</i> <i>&lt;vlanid&gt;</i>
Mode	Interface Config

### no macfilter adddest

This command removes a port from the destination filter set for the MAC filter with the *<macaddr>* and VLAN of *<vlanid>*. The *<macaddr>* parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The *<vlanid>* parameter must identify a valid VLAN.

Format	no macfilter adddest <i>&lt;macaddr&gt;</i> <i>&lt;vlanid&gt;</i>
Mode	Interface Config

### macfilter adddest all

This command adds all interfaces to the destination filter set for the MAC filter with the *<macaddr>* and VLAN of *<vlanid>*. The *<macaddr>* parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The *<vlanid>* parameter must identify a valid VLAN.

---

**Note:** Configuring a destination port list is only valid for multicast MAC addresses.

---

Format	macfilter adddest all <i>&lt;macaddr&gt;</i> <i>&lt;vlanid&gt;</i>
Mode	Global Config

### no macfilter adddest all

This command removes all ports from the destination filter set for the MAC filter with the *<macaddr>* and VLAN of *<vlanid>*. The *<macaddr>* parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The *<vlanid>* parameter must identify a valid VLAN.

Format	no macfilter adddest all <macaddr> <vlanid>
Mode	Global Config

### macfilter addsrc

This command adds the interface to the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The <vlanid> parameter must identify a valid VLAN.

Format	macfilter addsrc <macaddr> <vlanid>
Mode	Interface Config

### no macfilter addsrc

This command removes a port from the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The <vlanid> parameter must identify a valid VLAN.

Format	no macfilter addsrc <macaddr> <vlanid>
Mode	Interface Config

### macfilter addsrc all

This command adds all interfaces to the source filter set for the MAC filter with the MAC address of <macaddr> and <vlanid>. You must specify the <macaddr> parameter as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The <vlanid> parameter must identify a valid VLAN.

Format	macfilter addsrc all <macaddr> <vlanid>
Mode	Global Config

### no macfilter addsrc all

This command removes all interfaces to the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlanid>. You must specify the <macaddr> parameter as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	no macfilter addsrc all <macaddr> <vlanid>
Mode	Global Config

## show mac-address-table static

This command displays the static MAC filtering information for all static MAC filters. If you select **all**, all the static MAC filters in the system are displayed. If you supply a value for `<macaddr>`, you must also enter a value for `<vlanid>`, and the system displays static MAC filter information only for that MAC address and VLAN.

Format	<code>show mac-address-table static {&lt;macaddr&gt; &lt;vlanid&gt;   all}</code>
Mode	Privileged EXEC

Term	Definition
MAC Address	The MAC Address of the static MAC filter entry.
VLAN ID	The VLAN ID of the static MAC filter entry.
Source Port(s)	The source port filter set's slot and port(s).

---

**Note:** Only multicast address filters will have destination port lists.

---

## show mac-address-table staticfiltering

This command displays the static filtering entries in the Multicast Forwarding Database (MFDB) table.

Format	<code>show mac-address-table staticfiltering</code>
Mode	Privileged EXEC

Term	Definition
Mac Address	A unicast MAC address for which the switch has forwarding and or filtering information. As the data is gleaned from the MFDB, the address will be a multicast address. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes.
Type	The type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.
Description	The text description of this multicast table entry.
Interfaces	The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

## DHCP L2 Relay Agent Commands

You can enable the switch to operate as a DHCP Layer 2 relay agent to relay DHCP requests from clients to a Layer 3 relay agent or server. The Circuit ID and Remote ID can be added to DHCP requests relayed from clients to a DHCP server. This information is included in DHCP Option 82, as specified in sections 3.1 and 3.2 of RFC3046.

### dhcp l2relay

Use this command to enable the DHCP Layer 2 Relay agent for an interface, a range of interfaces, or all interfaces. The subsequent commands mentioned in this section can be used only when the DHCP L2 relay is enabled.

Format	<code>dhcp l2relay</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no dhcp l2relay

Use this command to disable the DHCP Layer 2 relay agent for an interface or range of interfaces.

Format	<code>no dhcp l2relay</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### dhcp l2relay circuit-id vlan

Use this parameter to set the DHCP Option-82 Circuit ID for a VLAN. When enabled, the interface number is added as the Circuit ID in DHCP option 82. Vlan-list range is 1–4093. Separate non-consecutive IDs with a comma (,), and do not insert spaces or zeros in between the range. Use a dash (–) for the range.

Format	<code>dhcp l2relay circuit-id vlan &lt;vlan-list&gt;</code>
Mode	Global Config

### no dhcp l2relay circuit-id vlan

Use this parameter to clear the DHCP Option-82 Circuit ID for a VLAN.

Format	<code>no dhcp l2relay circuit-id vlan &lt;vlan-list&gt;</code>
Mode	Global Config

### dhcp l2relay remote-id vlan

Use this parameter to set the DHCP Option-82 Remote ID for a VLAN and subscribed service (based on subscription-name). The vlan-list range is 1–4093. Separate non-consecutive IDs with a comma (,), and do not insert spaces or zeros between the range. Use a dash (–) for the range.

Format	dhcp l2relay remote-id <remote-id-string> vlan <vlan-list>
Mode	Global Config

### no dhcp l2relay remote-id vlan

Use this parameter to clear the DHCP Option-82 Remote ID for a VLAN and subscribed service (based on subscription-name).

Format	no dhcp l2relay remote-id vlan <vlan-list>
Mode	Global Config

### dhcp l2relay vlan

Use this command to enable the DHCP L2 Relay agent for a set of VLANs. All DHCP packets which arrive on interfaces in the configured VLAN are subject to L2 Relay processing. vlan-list range is 1–4093. Separate non-consecutive IDs with a comma (,), and do not insert spaces or zeros between the range. Use a dash (–) for the range.

Default	disabled
Format	dhcp l2relay vlan <vlan-list>
Mode	Global Config

### no dhcp l2relay vlan

Use this command to disable the DHCP L2 Relay agent for a set of VLANs.

Format	no dhcp l2relay vlan <vlan-list>
Mode	Global Config

### dhcp l2relay trust

Use this command to configure an interface or range of interfaces as trusted for Option-82 reception.

Default	untrusted
Format	dhcp l2relay trust
Mode	Interface Config

### no dhcp l2relay trust

Use this command to configure an interface to the default untrusted for Option-82 reception.

Format	no dhcp l2relay trust
Mode	Interface Config

### show dhcp l2relay all

Use this command to display the summary of DHCP L2 Relay configuration.

Format	show dhcp l2relay all
Mode	Privileged EXEC

#### Command example:

```
(NETGEAR Switch) #show dhcp l2relay all
DHCP L2 Relay is Enabled.
Interface          L2RelayMode      TrustMode
-----
0/2                Enabled          untrusted
0/4                Disabled         trusted
VLAN Id           L2 Relay         CircuitId         RemoteId
-----
3                 Disabled         Enabled          --NULL--
5                 Enabled          Enabled          --NULL--
6                 Enabled          Enabled          netgear
7                 Enabled          Disabled         --NULL--
8                 Enabled          Disabled         --NULL--
9                 Enabled          Disabled         --NULL--
10                Enabled          Disabled         --NULL--
```

### show dhcp l2relay interface

Use this command to display DHCP L2 relay configuration specific to interfaces.

Format	show dhcp l2relay interface {all   <slot/port>}
Mode	Privileged EXEC

#### Command example:

```
(NETGEAR Switch) #show dhcp l2relay interface all
DHCP L2 Relay is Enabled.
Interface          L2RelayMode      TrustMode
-----
0/2                Enabled          untrusted
0/4                Disabled         trusted
```

## show dhcp l2relay stats interface

Use this command to display statistics specific to DHCP L2 Relay configured interface.

Format	show dhcp l2relay stats interface {all   <slot/port>}
Mode	Privileged EXEC

### Command example:

```
(NETGEAR Switch) #show dhcp l2relay stats interface all
```

DHCP L2 Relay is Enabled.

Interface	UntrustedServer MsgsWithOpt82	UntrustedClient MsgsWithOpt82	TrustedServer MsgsWithoutOpt82	TrustedClient MsgsWithoutOpt82
0/1	0	0	0	0
0/2	0	0	3	7
0/3	0	0	0	0
0/4	0	12	0	0
0/5	0	0	0	0
0/6	3	0	0	0
0/7	0	0	0	0
0/8	0	0	0	0
0/9	0	0	0	0

## show dhcp l2relay agent-option vlan

Use this command to display the DHCP L2 Relay Option-82 configuration specific to VLAN.

Format	show dhcp l2relay agent-option vlan <vlan-range>
Mode	Privileged EXEC

### Command example:

```
(NETGEAR Switch) #show dhcp l2relay agent-option vlan 5-10
```

DHCP L2 Relay is Enabled.

VLAN Id	L2 Relay	CircuitId	RemoteId
5	Enabled	Enabled	--NULL--
6	Enabled	Enabled	netgear
7	Enabled	Disabled	--NULL--
8	Enabled	Disabled	--NULL--
9	Enabled	Disabled	--NULL--
10	Enabled	Disabled	--NULL--



## DHCP Client Commands

DHCP Client can include vendor and configuration information in DHCP client requests relayed to a DHCP server. This information is included in DHCP Option 60, Vendor Class Identifier. The information is a string of 128 octets.

### dhcp client vendor-id-option

Use this command to enable the inclusion of DHCP Option-60, Vendor Class Identifier included in the requests transmitted to the DHCP server by the DHCP client operating in the switch.

Format	<code>dhcp client vendor-id-option</code>
Mode	Global Config

### no dhcp client vendor-id-option

Use this command to disable the inclusion of DHCP Option-60, Vendor Class Identifier included in the requests transmitted to the DHCP server by the DHCP client operating in the switch.

Format	<code>no dhcp client vendor-id-option</code>
Mode	Global Config

### dhcp client vendor-id-option-string

Use this command to set the DHCP Vendor Option-60 string to be included in requests transmitted to the DHCP server by the DHCP client operating in the switch.

Format	<code>dhcp client vendor-id-option-string &lt;string&gt;</code>
Mode	Global Config

### no dhcp client vendor-id-option-string

Use this command to clear the DHCP Vendor Option-60 string.

Format	<code>no dhcp client vendor-id-option-string</code>
Mode	Global Config

## show dhcp client vendor-id-option

Use this command to display the configured administration mode of the vendor-id-option and the vendor-id string to be included in Option-43 in DHCP requests.

Format	show dhcp client vendor-id-option
Mode	Privileged EXEC

### Command example:

```
(NETGEAR Switch) #show dhcp client vendor-id-option
DHCP Client Vendor Identifier Option ..... Enabled
DHCP Client Vendor Identifier Option string .... Client
```

## DHCP Snooping Configuration Commands

This section describes commands you use to configure DHCP Snooping.

### ip dhcp snooping

Use this command to enable DHCP Snooping globally.

Default	disabled
Format	ip dhcp snooping
Mode	Global Config

### no ip dhcp snooping

Use this command to disable DHCP Snooping globally.

Format	no ip dhcp snooping
Mode	Global Config

### ip dhcp snooping vlan

Use this command to enable DHCP Snooping on a list of comma-separated VLAN ranges.

Default	disabled
Format	ip dhcp snooping vlan <vlan-list>
Mode	Global Config

**no ip dhcp snooping vlan**

Use this command to disable DHCP Snooping on VLANs.

Format	<code>no ip dhcp snooping vlan &lt;vlan-list&gt;</code>
Mode	Global Config

**ip dhcp snooping verify mac-address**

Use this command to enable verification of the source MAC address with the client hardware address in the received DHCP message.

Default	enabled
Format	<code>ip dhcp snooping verify mac-address</code>
Mode	Global Config

**no ip dhcp snooping verify mac-address**

Use this command to disable verification of the source MAC address with the client hardware address.

Format	<code>no ip dhcp snooping verify mac-address</code>
Mode	Global Config

**ip dhcp snooping database**

Use this command to configure the persistent location of the DHCP Snooping database. This can be local or a remote file on a specified computer.

Default	local
Format	<code>ip dhcp snooping database {local   &lt;tftp://hostIP&gt; / &lt;filename&gt;}</code>
Mode	Global Config

**ip dhcp snooping database write-delay**

Use this command to configure the interval in seconds at which the DHCP Snooping database will be persisted. The interval value ranges from 15 to 86,400 seconds.

Default	300 seconds
Format	<code>ip dhcp snooping database write-delay &lt;seconds&gt;</code>
Mode	Global Config

**no ip dhcp snooping database write-delay**

Use this command to set the write delay value to the default value.

Format	no ip dhcp snooping database write-delay
Mode	Global Config

**ip dhcp snooping binding**

Use this command to configure static DHCP Snooping binding.

Format	ip dhcp snooping binding <mac-address> vlan <vlan id> <ip address> interface <slot/port>
Mode	Global Config

**no ip dhcp snooping binding <mac-address>**

Use this command to remove the DHCP static entry from the DHCP Snooping database.

Format	no ip dhcp snooping binding <mac-address>
Mode	Global Config

**ip verify binding**

Use this command to configure static IP source guard (IPSG) entries.

Format	ip verify binding <mac-address> vlan <vlan id> <ip address> interface <slot/port>
Mode	Global Config

**no ip verify binding**

Use this command to remove the IPSG static entry from the IPSG database.

Format	no ip verify binding <mac-address> vlan <vlan id> <ip address> interface <slot/port>
Mode	Global Config

### ip dhcp snooping limit

Use this command to control the rate at which the DHCP Snooping messages come. The default rate is 15 pps with a range from 0 to 30 pps. The default burst level is 1 second with a range of 1–15 seconds.

Default	15 pps for rate limiting and 1 sec for burst interval
Format	<code>ip dhcp snooping limit {rate &lt;pps&gt; [burst interval &lt;seconds&gt;]}</code>
Mode	Interface Config

### no ip dhcp snooping limit

Use this command to set the rate at which the DHCP Snooping messages come, and the burst level, to the defaults.

Format	<code>no ip dhcp snooping limit</code>
Mode	Interface Config

### ip dhcp snooping log-invalid

Use this command to control the logging DHCP messages filtration by the DHCP Snooping application.

Default	disabled
Format	<code>ip dhcp snooping log-invalid</code>
Mode	Interface Config

### no ip dhcp snooping log-invalid

Use this command to disable the logging DHCP messages filtration by the DHCP Snooping application.

Format	<code>no ip dhcp snooping log-invalid</code>
Mode	Interface Config

### ip dhcp snooping trust

Use this command to configure the port as trusted.

Default	disabled
Format	<code>ip dhcp snooping trust</code>
Mode	Interface Config

### no ip dhcp snooping trust

Use this command to configure the port as untrusted.

Format	<code>no ip dhcp snooping trust</code>
Mode	Interface Config

### ip verify source

Use this command to configure the IPSG source ID attribute to filter the data traffic in the hardware. Source ID is the combination of IP address and MAC address. Normal command allows data traffic filtration based on the IP address. With the `port-security` option, the data traffic will be filtered based on the IP and MAC addresses.

Default	The source ID is the IP address
Format	<code>ip verify source [port-security]</code>
Mode	Interface Config

### no ip verify source

Use this command to disable the IPSG configuration in the hardware. You cannot disable port-security alone if it is configured.

Format	<code>no ip verify source</code>
Mode	Interface Config

### show ip dhcp snooping

Use this command to display the DHCP Snooping global configurations and per port configurations.

Format	<code>show ip dhcp snooping</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Interface	The interface for which data is displayed.
Trusted	If it is enabled, DHCP snooping considers the port as trusted. The factory default is disabled.
Log Invalid Pkts	If it is enabled, DHCP snooping application logs invalid packets on the specified interface.

**Command example:**

```
(NETGEAR Switch) #show ip dhcp snooping
```

```
DHCP snooping is Disabled
DHCP snooping source MAC verification is enabled
DHCP snooping is enabled on the following VLANs:
11 - 30, 40
```

Interface	Trusted	Log Invalid Pkts
0/1	Yes	No
0/2	No	Yes
0/3	No	Yes
0/4	No	No
0/6	No	No

**show ip dhcp snooping binding**

Use this command to display the DHCP Snooping binding entries. To restrict the output, use the following options:

- **Dynamic:** Restrict the output based on DHCP snooping.
- **Interface:** Restrict the output based on a specific interface.
- **Static:** Restrict the output based on static entries.
- **VLAN:** Restrict the output based on VLAN.

Format	show ip dhcp snooping binding [static   dynamic] [interface <slot/port>] [<vlan id>]
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
MAC Address	Displays the MAC address for the binding that was added. The MAC address is the key to the binding database.
IP Address	Displays the valid IP address for the binding rule.
VLAN	The VLAN for the binding rule.
Interface	The interface to add a binding into the DHCP snooping interface.
Type	Binding type; statically configured from the CLI or dynamically learned.
Lease (sec)	The remaining lease time for the entry.

**Command example:**

```
(NETGEAR Switch) #show ip dhcp snooping binding
```

```
Total number of bindings: 2
```

MAC Address	IP Address	VLAN	Interface	Type	Lease (Secs)
00:02:B3:06:60:80	210.1.1.3	10	0/1		86400
00:0F:FE:00:13:04	210.1.1.4	10	0/1		86400

**show ip dhcp snooping database**

Use this command to display the DHCP Snooping configuration related to the database persistency.

Format	show ip dhcp snooping database
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Agent URL	Bindings database agent URL.
Write Delay	The maximum write time to write the database into local or remote.

**Command example:**

```
(NETGEAR Switch) #show ip dhcp snooping database
```

```
agent url: /10.131.13.79:/sail.txt
```

```
write-delay: 5000
```

**show ip dhcp snooping interfaces**

Use this command to show the DHCP Snooping status of the interfaces.

Format	show ip dhcp snooping interfaces
Mode	Privileged EXEC



## show ip dhcp snooping statistics

Use this command to list statistics for DHCP Snooping security violations on untrusted ports.

Format	show ip dhcp snooping statistics
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Interface	The IP address of the interface in slot/port format.
MAC Verify Failures	Represents the number of DHCP messages that were filtered on an untrusted interface because of source MAC address and client HW address mismatch.
Client Ifc Mismatch	Represents the number of DHCP release and Deny messages received on the different ports than learned previously.
DHCP Server Msgs Rec'd	Represents the number of DHCP server messages received on Untrusted ports.

### Command example:

```
(NETGEAR Switch) #show ip dhcp snooping statistics
```

Interface	MAC Verify Failures	Client Ifc Mismatch	DHCP Server Msgs Rec'd
0/2	0	0	0
0/3	0	0	0
0/4	0	0	0
0/5	0	0	0
0/6	0	0	0
0/7	0	0	0
0/8	0	0	0
0/9	0	0	0
0/10	0	0	0
0/11	0	0	0
0/12	0	0	0
0/13	0	0	0
0/14	0	0	0
0/15	0	0	0
0/16	0	0	0
0/17	0	0	0
0/18	0	0	0
0/19	0	0	0
0/20	0	0	0

## clear ip dhcp snooping binding

Use this command to clear all DHCP Snooping bindings on all interfaces or on a specific interface.

Format	<code>clear ip dhcp snooping binding [interface &lt;slot/port&gt;]</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

## clear ip dhcp snooping statistics

Use this command to clear all DHCP Snooping statistics.

Format	<code>clear ip dhcp snooping statistics</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

## show ip verify source

Use this command to display the IPSG configurations on all ports.

Format	<code>show ip verify source</code>
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Interface	Interface address in slot/port format.
Filter Type	Is one of two values: <ul style="list-style-type: none"> <li>ip-mac: User has configured MAC address filtering on this interface.</li> <li>ip: Only IP address filtering on this interface.</li> </ul>
IP Address	IP address of the interface
MAC Address	If MAC address filtering is not configured on the interface, the MAC Address field is empty. If port security is disabled on the interface, then the MAC Address field displays "permit-all."
VLAN	The VLAN for the binding rule.

### Command example:

```
(NETGEAR Switch) #show ip verify source
```

Interface	Filter Type	IP Address	MAC Address	Vlan
0/1	ip-mac	210.1.1.3	00:02:B3:06:60:80	10
0/1	ip-mac	210.1.1.4	00:0F:FE:00:13:04	10

## show ip source binding

This command displays the IPSG bindings.

Format	show ip source binding [static   dynamic] [interface <slot/port>] [<vlan id>]
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
MAC Address	The MAC address for the entry that is added.
IP Address	The IP address of the entry that is added.
Type	Entry type; statically configured from CLI or dynamically learned from DHCP Snooping.
VLAN	VLAN for the entry.
Interface	IP address of the interface in slot/port format.

### Command example:

```
(NETGEAR Switch) #show ip source binding
```

MAC Address	IP Address	Type	Vlan	Interface
00:00:00:00:00:08	1.2.3.4	dhcp-snooping	2	0/1
00:00:00:00:00:09	1.2.3.4	dhcp-snooping	3	0/1
00:00:00:00:00:0A	1.2.3.4	dhcp-snooping	4	0/1

## Dynamic ARP Inspection Commands

Dynamic ARP Inspection (DAI) is a security feature that rejects invalid and malicious ARP packets. DAI prevents a class of man-in-the-middle attacks, where an unfriendly station intercepts traffic for other stations by poisoning the ARP caches of its unsuspecting neighbors. The miscreant sends ARP requests or responses mapping another station's IP address to its own MAC address.

DAI relies on DHCP snooping. DHCP snooping listens to DHCP message exchanges and builds a binding database of valid (MAC address, IP address, VLAN, and interface) tuples.

When DAI is enabled, the switch drops ARP packets whose sender MAC address and sender IP address do not match an entry in the DHCP snooping bindings database. You can optionally configure additional ARP packet validation.

### ip arp inspection vlan

Use this command to enable Dynamic ARP Inspection on a list of comma-separated VLAN ranges.

Default	disabled
Format	<code>ip arp inspection vlan &lt;vlan-list&gt;</code>
Mode	Global Config

### no ip arp inspection vlan

Use this command to disable Dynamic ARP Inspection on a list of comma-separated VLAN ranges.

Format	<code>no ip arp inspection vlan &lt;vlan-list&gt;</code>
Mode	Global Config

### ip arp inspection validate

Use this command to enable additional validation checks like source-mac validation, destination-mac validation, and ip address validation on the received ARP packets. Each command overrides the configuration of the previous command. For example, if a command enables src-mac and dst-mac validations, and a second command enables IP validation only, the src-mac and dst-mac validations are disabled as a result of the second command.

Default	disabled
Format	<code>ip arp inspection validate {[src-mac] [dst-mac] [ip]}</code>
Mode	Global Config

### no ip arp inspection validate

Use this command to disable the additional validation checks on the received ARP packets.

Format	<code>no ip arp inspection validate {[src-mac] [dst-mac] [ip]}</code>
Mode	Global Config

### ip arp inspection vlan logging

Use this command to enable logging of invalid ARP packets on a list of comma-separated VLAN ranges.

Default	enabled
Format	<code>ip arp inspection vlan &lt;vlan-list&gt; logging</code>
Mode	Global Config

### no ip arp inspection vlan logging

Use this command to disable logging of invalid ARP packets on a list of comma-separated VLAN ranges.

Format	<code>no ip arp inspection vlan &lt;vlan-list&gt; logging</code>
Mode	Global Config

### ip arp inspection trust

Use this command to configure an interface as trusted for Dynamic ARP Inspection.

Default	enabled
Format	<code>ip arp inspection trust</code>
Mode	Interface Config

### no ip arp inspection trust

Use this command to configure an interface as untrusted for Dynamic ARP Inspection.

Format	<code>no ip arp inspection trust</code>
Mode	Interface Config

### ip arp inspection limit

Use this command to configure the rate limit and burst interval values for an interface. Configuring none for the limit means that the interface is not rate limited for Dynamic ARP Inspections.

---

**Note:** The user interface will accept a rate limit for a trusted interface, but the limit will not be enforced unless the interface is configured to be untrusted.

---

Default	15 pps for rate and 1 second for burst-interval
Format	<code>ip arp inspection limit {rate &lt;pps&gt; [burst interval &lt;seconds&gt;]   none}</code>
Mode	Interface Config

### no ip arp inspection limit

Use this command to set the rate limit and burst interval values for an interface to the default values of 15 pps and 1 second, respectively.

Format	<code>no ip arp inspection limit</code>
Mode	Interface Config

### ip arp inspection filter

Use this command to configure the ARP ACL used to filter invalid ARP packets on a list of comma-separated VLAN ranges. If you enter the `static` keyword, packets that do not match a permit statement are dropped without consulting the DHCP snooping bindings.

Default	No ARP ACL is configured on a VLAN
Format	<code>ip arp inspection filter &lt;acl-name&gt; vlan &lt;vlan-list&gt; [static]</code>
Mode	Global Config

### no ip arp inspection filter

Use this command to unconfigure the ARP ACL used to filter invalid ARP packets on a list of comma-separated VLAN ranges.

Format	<code>no ip arp inspection filter &lt;acl-name&gt; vlan &lt;vlan-list&gt; [static]</code>
Mode	Global Config

### arp access-list

Use this command to create an ARP ACL.

Format	<code>arp access-list &lt;acl-name&gt;</code>
Mode	Global Config

### no arp access-list

Use this command to delete a configured ARP ACL.

Format	<code>no arp access-list &lt;acl-name&gt;</code>
Mode	Global Config

### permit ip host mac host

Use this command to configure a rule for a valid IP address and MAC address combination used in ARP packet validation.

Format	<code>permit ip host &lt;sender-ip&gt; mac host &lt;sender-mac&gt;</code>
Mode	ARP Access-list Config

### no permit ip host mac host

Use this command to delete a rule for a valid IP and MAC combination.

Format	<code>no permit ip host &lt;sender-ip&gt; mac host &lt;sender-mac&gt;</code>
Mode	ARP Access-list Config

### show ip arp inspection

Use this command to display the Dynamic ARP Inspection global configuration and configuration on all the VLANs. With the `<vlan-list>` argument (that is, comma-separated VLAN ranges), the command displays the global configuration and configuration on all the VLANs in the VLAN list. The global configuration includes the source mac validation, destination mac validation, and invalid IP validation information.

Format	<code>show ip arp inspection [vlan &lt;vlan-list&gt;]</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Source MAC Validation	Displays whether Source MAC Validation of ARP frame is enabled or disabled.
Destination MAC Validation	Displays whether Destination MAC Validation is enabled or disabled.
IP Address Validation	Displays whether IP Address Validation is enabled or disabled.
VLAN	The VLAN ID for each displayed row.
Configuration	Displays whether DAI is enabled or disabled on the VLAN.
Log Invalid	Displays whether logging of invalid ARP packets is enabled on the VLAN.
ACL Name	The ARP ACL Name, if configured on the VLAN.
Static Flag	If the ARP ACL is configured static on the VLAN.

**Command example:**

```
(NETGEAR Switch) #show ip arp inspection vlan 10-12
```

```
Source Mac Validation      : Disabled
Destination Mac Validation : Disabled
IP Address Validation      : Disabled
```

Vlan	Configuration	Log Invalid	ACL Name	Static flag
10	Enabled	Enabled	H2	Enabled
11	Disabled	Enabled		
12	Enabled	Disabled		

**show ip arp inspection statistics**

Use this command to display the statistics of the ARP packets processed by Dynamic ARP Inspection. Give the vlan-list argument and the command displays the statistics on all DAI-enabled VLANs in that list. Give the single vlan argument and the command displays the statistics on that VLAN. If no argument is included, the command lists a summary of the forwarded and dropped ARP packets.

Format	show ip arp inspection statistics [vlan <vlan-list>]
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
VLAN	The VLAN ID for each displayed row.
Forwarded	The total number of valid ARP packets forwarded in this VLAN.
Dropped	The total number of not valid ARP packets dropped in this VLAN.
DHCP Drops	The number of packets dropped due to DHCP snooping binding database match failure.
ACL Drops	The number of packets dropped due to ARP ACL rule match failure.
DHCP Permits	The number of packets permitted due to DHCP snooping binding database match.
ACL Permits	The number of packets permitted due to ARP ACL rule match.
Bad Src MAC	The number of packets dropped due to Source MAC validation failure.
Bad Dest MAC	The number of packets dropped due to Destination MAC validation failure.
Invalid IP	The number of packets dropped due to invalid IP checks.



**Command example:**

The following example shows CLI output for the `show ip arp inspection statistics` command, which lists the summary of forwarded and dropped ARP packets on all DAI-enabled VLANs.

```
VLAN  Forwarded  Dropped
-----
  10         90       14
  20         10        3
```

**Command example:**

```
(NETGEAR Switch) #show ip arp inspection statistics vlan <vlan-list>
```

```
VLAN  DHCP      ACL      DHCP      ACL      Bad Src  Bad Dest  Invalid
      Drops   Drops   Permits   Permits   MAC      MAC       IP
-----
  10   11       1       65       25       1       1       0
  20   1       0       8        2       0       1       1
```

**clear ip arp inspection statistics**

Use this command to reset the statistics for Dynamic ARP Inspection on all VLANs.

Default	none
Format	clear ip arp inspection statistics
Mode	Privileged EXEC

**show ip arp inspection interfaces**

Use this command to display the Dynamic ARP Inspection configuration on all the DAI-enabled interfaces. An interface is said to be enabled for DAI if at least one VLAN, that the interface is a member of, is enabled for DAI. If you enter the `<slot/port>` interface argument, the command displays the values for that interface whether the interface is enabled for DAI or not.

Format	show ip arp inspection interfaces [ <code>&lt;slot/port&gt;</code> ]
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Interface	The interface ID for each displayed row.
Trust State	Whether the interface is trusted or untrusted for DAI.

Term	Definition
Rate Limit	The configured rate limit value in packets per second.
Burst Interval	The configured burst interval value in seconds.

**Command example:**

```
(NETGEAR Switch) #show ip arp inspection interfaces
```

```

Interface          Trust State   Rate Limit   Burst Interval
                   (pps)        (seconds)
-----
0/1                 Untrusted    15           1
0/2                 Untrusted    10           10

```

**show arp access-list**

Use this command to display the configured ARP ACLs with the rules. Giving an ARP ACL name as the argument will display only the rules in that ARP ACL.

Format	<code>show arp access-list [&lt;acl-name&gt;]</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

**Command example:**

```
(NETGEAR Switch) #show arp access-list
```

```

ARP access list H2
  permit ip host 1.1.1.1 mac host 00:01:02:03:04:05
  permit ip host 1.1.1.2 mac host 00:03:04:05:06:07
ARP access list H3
ARP access list H4
  permit ip host 2.1.1.2 mac host 00:03:04:05:06:08

```

## IGMP Snooping Configuration Commands

This section describes the commands you use to configure IGMP snooping. The software supports IGMP Versions 1, 2, and 3. The IGMP snooping feature can help conserve bandwidth because it allows the switch to forward IP multicast traffic only to connected hosts that request multicast traffic. IGMPv3 adds source filtering capabilities to IGMP versions 1 and 2.

## set igmp

This command enables IGMP Snooping on the system (Global Config Mode) or an interface (Interface Config Mode). This command also enables IGMP snooping on a particular VLAN (VLAN Config Mode) and can enable IGMP snooping on all interfaces participating in a VLAN.

If an interface has IGMP Snooping enabled and you enable this interface for routing or enlist it as a member of a port-channel (LAG), IGMP Snooping functionality is disabled on that interface. IGMP Snooping functionality is re-enabled if you disable routing or remove port-channel (LAG) membership from an interface that has IGMP Snooping enabled.

The IGMP application supports the following activities:

- Validation of the IP header checksum (as well as the IGMP header checksum) and discarding of the frame upon checksum error.
- Maintenance of the forwarding table entries based on the MAC address versus the IP address.
- Flooding of unregistered multicast data packets to all ports in the VLAN.

Default	disabled
Format	set igmp
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

Format	set igmp <vlanid>
Mode	VLAN Config

## no set igmp

This command disables IGMP Snooping on the system, an interface, or a VLAN.

Format	no set igmp
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

Format	no set igmp <vlanid>
Mode	VLAN Config

## set igmp interfacemode

This command enables IGMP Snooping on all interfaces. If an interface has IGMP Snooping enabled and you enable this interface for routing or enlist it as a member of a port-channel (LAG), IGMP Snooping functionality is disabled on that interface. IGMP Snooping functionality is re-enabled if you disable routing or remove port-channel (LAG) membership from an interface that has IGMP Snooping enabled.

Default	disabled
Format	set igmp interfacemode
Mode	Global Config

### no set igmp interfacemode

This command disables IGMP Snooping on all interfaces.

Format	no set igmp interfacemode
Mode	Global Config

### set igmp fast-leave

This command enables or disables IGMP Snooping fast-leave admin mode on a selected interface or VLAN. Enabling fast-leave allows the switch to immediately remove the layer 2 LAN interface from its forwarding table entry upon receiving an IGMP leave message for that multicast group without first sending out MAC-based general queries to the interface.

You should enable fast-leave admin mode only on VLANs where only one host is connected to each layer 2 LAN port. This prevents the inadvertent dropping of the other hosts that were connected to the same layer 2 LAN port but were still interested in receiving multicast traffic directed to that group. Also, fast-leave processing is supported only with IGMP version 2 hosts.

Default	disabled
Format	set igmp fast-leave
Mode	Interface Config

Format	set igmp fast-leave <vlan id>
Mode	VLAN Config

### no set igmp fast-leave

This command disables IGMP Snooping fast-leave admin mode on a selected interface.

Format	no set igmp fast-leave
Mode	Interface Config

Format	no set igmp fast-leave <vlan id>
Mode	VLAN Config

## set igmp groupmembership-interval

This command sets the IGMP Group Membership Interval time on a VLAN, one interface, or all interfaces. The Group Membership Interval time is the amount of time in seconds that a switch waits for a report from a particular group on a particular interface before deleting the interface from the entry. This value must be greater than the IGMPv3 Maximum Response time value. The range is 2–3600 seconds.

Default	260 seconds
Format	<code>set igmp groupmembership-interval &lt;2-3600&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

Format	<code>set igmp groupmembership-interval &lt;vlan id&gt; &lt;2-3600&gt;</code>
Mode	VLAN Config

## no set igmp groupmembership-interval

This command sets the IGMPv3 Group Membership Interval time to the default value.

Format	<code>no set igmp groupmembership-interval</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> </ul>

Format	<code>no set igmp groupmembership-interval &lt;vlan id&gt;</code>
Mode	VLAN Config

## set igmp maxresponse

This command sets the IGMP Maximum Response time for the system, or on a particular interface or VLAN. The Maximum Response time is the amount of time in seconds that a switch will wait after sending a query on an interface because it did not receive a report for a particular group in that interface. This value must be less than the IGMP Query Interval time value. The range is 1–25 seconds.

Default	10 seconds
Format	<code>set igmp maxresponse &lt;1-25&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

Format	<code>set igmp maxresponse &lt;vlan id&gt; &lt;1-25&gt;</code>
Mode	VLAN Config

**no set igmp maxresponse**

This command sets the max response time (on the interface or VLAN) to the default value.

Format	<code>no set igmp maxresponse</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

Format	<code>no set igmp maxresponse &lt;vlan id&gt;</code>
Mode	VLAN Config

**set igmp mcrtrexpiretime**

This command sets the Multicast Router Present Expiration time. The time is set for the system, on a particular interface or VLAN. This is the amount of time in seconds that a switch waits for a query to be received on an interface before the interface is removed from the list of interfaces with multicast routers attached. The range is 0–3600 seconds. A value of 0 indicates an infinite time-out, that is, no expiration.

Default	0
Format	<code>set igmp mcrtrexpiretime &lt;0-3600&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

Format	<code>set igmp mcrtrexpiretime &lt;vlan id&gt; &lt;0-3600&gt;</code>
Mode	VLAN Config

**no set igmp mcrtrexpiretime**

This command sets the Multicast Router Present Expiration time to 0. The time is set for the system, on a particular interface or a VLAN.

Format	<code>no set igmp mcrtrexpiretime</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

Format	<code>no set igmp mcrtrexpiretime &lt;vlan id&gt;</code>
Mode	VLAN Config

### set igmp mrouter

This command configures the VLAN ID (<vlan id>) for which the multicast router mode enabled.

Format	<code>set igmp mrouter &lt;vlan id&gt;</code>
Mode	Interface Config

### no set igmp mrouter

This command disables multicast router mode for a particular VLAN ID (<vlan id>).

Format	<code>no set igmp mrouter &lt;vlan id&gt;</code>
Mode	Interface Config

### set igmp mrouter interface

This command configures the interface as a multicast router interface. When configured as a multicast router interface, the interface is treated as a multicast router interface in all VLANs.

Default	disabled
Format	<code>set igmp mrouter interface</code>
Mode	Interface Config

### no set igmp mrouter interface

This command disables the status of the interface as a statically configured multicast router interface.

Format	<code>no set igmp mrouter interface</code>
Mode	Interface Config

### set igmp report-suppression

Use this command to suppress the IGMP reports on a VLAN. In order to optimize the number of reports traversing the network with no added benefits, a Report Suppression mechanism is implemented. When more than one client responds to an MGMT query for the same Multicast Group address within the max-response-time, only the first response is forwarded to the query and others are suppressed at the switch.

Default	Disabled
Format	<code>set igmp report-suppression &lt;1-4093&gt;</code>
Mode	VLAN Config

**no set igmp report-suppression**

Use this command to restore the system default.

Format	no set igmp report-suppression
Mode	VLAN Config

**set igmp header-validation**

If IGMP IP header validation is enabled, then 3 fields TTL (Time To Live), ToS (Type of Service), and Router Alert options are checked. The fields checked depend on the IGMP version. The TTL field is validated in all the versions (IGMPv1, IGMPv2 and IGMPv3). The Router Alert field is validated in IGMPv2 and IGMPv3. The ToS field is validated only in IGMP version3.

Default	Enabled
Format	set igmp header-validation
Mode	Global Config

**no set igmp header-validation**

This command disabled the IGMP IP header validation.

Format	no set igmp header-validation
Mode	Global Config

**mac address-table multicast forbidden-unregistered vlan**

Use this command to forbid forwarding unregistered multicast addresses (in other words, unknown multicast traffic) on a VLAN.

Default	Disabled
Format	mac address-table multicast forbidden-unregistered vlan <1-4093>
Mode	Global Config

**no mac address-table multicast forbidden-unregistered vlan**

Use this command to restore the default.

Format	mac address-table multicast forbidden-unregistered vlan
Mode	Global Config



### mac address-table multicast forward-unregistered vlan

Use this command to enable forwarding unregistered multicast address (in other words, unknown multicast traffic) on a VLAN.

Format	mac address-table multicast forward-unregistered vlan <1-4093>
Mode	Global Config

### mac address-table multicast forward-all vlan

Use this command to enable forwarding of all multicast packets on a VLAN.

Format	mac address-table multicast forward-all vlan <1-4093>
Mode	Global Config

### no mac address-table multicast forward-all vlan

Use this command to restore the system default.

Format	no mac address-table multicast forward-all vlan
Mode	Global Config

### show igmpsnooping

This command displays IGMP Snooping information. Configured information is displayed whether or not IGMP Snooping is enabled.

Format	show igmpsnooping [<slot/port>   <vlan id>]
Mode	Privileged EXEC

If you do not use the optional <slot/port> or <vlan id> argument, the command displays the information that is described in the following table.

Term	Definition
Admin Mode	Indicates whether or not IGMP Snooping is active on the switch.
Multicast Control Frame Count	The number of multicast control frames that are processed by the CPU.
Interface Enabled for IGMP Snooping	The list of interfaces on which IGMP Snooping is enabled.
VLANS Enabled for IGMP Snooping	The list of VLANS on which IGMP Snooping is enabled.

If you specify the `<slot/port>` values, the command displays the information that is described in the following table.

Term	Definition
IGMP Snooping Admin Mode	Indicates whether IGMP Snooping is active on the interface.
Fast Leave Mode	Indicates whether IGMP Snooping Fast-leave is active on the interface.
Group Membership Interval	The amount of time in seconds that a switch will wait for a report from a particular group on a particular interface before deleting the interface from the entry. This value may be configured.
Maximum Response Time	The amount of time the switch waits after it sends a query on an interface because it did not receive a report for a particular group on that interface. This value may be configured.
Multicast Router Expiry Time	The amount of time to wait before removing an interface from the list of interfaces with multicast routers attached. The interface is removed if a query is not received. This value may be configured.

If you specify the `<vlan id>` value, the command displays the information that is described in the following table.

Term	Definition
VLAN ID	The VLAN ID.
IGMP Snooping Admin Mode	Indicates whether IGMP Snooping is active on the VLAN.
Fast Leave Mode	Indicates whether IGMP Snooping Fast-leave is active on the VLAN.
Group Membership Interval	The amount of time in seconds that a switch will wait for a report from a particular group on a particular interface, which is participating in the VLAN, before deleting the interface from the entry. This value may be configured.
Maximum Response Time	The amount of time the switch waits after it sends a query on an interface, participating in the VLAN, because it did not receive a report for a particular group on that interface. This value may be configured.
Multicast Router Expiry Time	The amount of time to wait before removing an interface that is participating in the VLAN from the list of interfaces with multicast routers attached. The interface is removed if a query is not received. This value may be configured.

### show igmpsnooping mrouter interface

This command displays information about statically configured ports.

Format	<code>show igmpsnooping mrouter interface &lt;slot/port&gt;</code>
Mode	Privileged EXEC

Term	Definition
Interface	The port on which multicast router information is being displayed.
Multicast Router Attached	Indicates whether multicast router is statically enabled on the interface.
VLAN ID	The list of VLANs of which the interface is a member.

### show igmpsnooping mrouter vlan

This command displays information about statically configured ports.

Format	show igmpsnooping mrouter vlan <slot/port>
Mode	Privileged EXEC

Term	Definition
Interface	The port on which multicast router information is being displayed.
VLAN ID	The list of VLANs of which the interface is a member.

### show mac-address-table igmpsnooping

This command displays the IGMP Snooping entries in the MFDB table.

Format	show mac-address-table igmpsnooping
Mode	Privileged EXEC

### show mac address-table multicast filtering

Use this command to display the multicast filtering details for a VLAN.

Format	show mac address-table multicast filtering <vlan-id>
Mode	Privileged EXEC

Field	Description
<vlan id>	A valid VLAN ID
mode	The filtering mode

#### Command example:

```
(NETGEAR Switch) #show mac address-table multicast filtering 1
VLAN-ID..... 1
Mode..... Forward-Forbidden-Unregistered
```

## IGMP Snooping Querier Commands

IGMP Snooping requires that one central switch or router periodically query all end-devices on the network to announce their multicast memberships. This central device is the “IGMP Querier”. The IGMP query responses, known as IGMP reports, keep the switch updated with the current multicast group membership on a port-by-port basis. If the switch does not receive updated membership information in a timely fashion, it will stop forwarding multicast to the port where the end device is located.

This section describes commands used to configure and display information about IGMP Snooping Queriers on the network and, separately, on VLANs.

### set igmp querier

Use this command to enable IGMP Snooping Querier on the system, using Global Config mode, or on a VLAN. Using this command, you can specify the IP Address that the Snooping Querier switch should use as the source address while generating periodic queries.

If a VLAN has IGMP Snooping Querier enabled and IGMP Snooping is operationally disabled on it, IGMP Snooping Querier functionality is disabled on that VLAN. IGMP Snooping functionality is re-enabled if IGMP Snooping is operational on the VLAN.

---

**Note:** The Querier IP Address assigned for a VLAN takes preference over global configuration.

---

The IGMP Snooping Querier application supports sending periodic general queries on the VLAN to solicit membership reports.

Default	disabled
Format	<code>set igmp querier [&lt;vlan-id&gt;] [address &lt;ipv4-address&gt;]</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• VLAN Mode</li> </ul>

### no set igmp querier

Use this command to disable IGMP Snooping Querier on the system. Use the optional **address** parameter to reset the querier address to 0.0.0.0.

Format	<code>no set igmp querier [&lt;vlan-id&gt;] [address]</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• VLAN Mode</li> </ul>

### set igmp querier query-interval

Use this command to set the IGMP Querier Query Interval time. It is the amount of time in seconds that the switch waits before sending another general query.

Default	disabled
Format	set igmp querier query-interval <1-18000>
Mode	Global Config

### no set igmp querier query-interval

Use this command to set the IGMP Querier Query Interval time to its default value.

Format	no set igmp querier query-interval
Mode	Global Config

### set igmp querier timer expiry

Use this command to set the IGMP Querier timer expiration period. It is the time period that the switch remains in Non-Querier mode once it has discovered that there is a Multicast Querier in the network.

Default	60 seconds
Format	set igmp querier timer expiry <60-300>
Mode	Global Config

### no set igmp querier timer expiry

Use this command to set the IGMP Querier timer expiration period to its default value.

Format	no set igmp querier timer expiry
Mode	Global Config

### set igmp querier version

Use this command to set the IGMP version of the query that the snooping switch is going to send periodically.

Default	1
Format	set igmp querier version <1-2>
Mode	Global Config

**no set igmp querier version**

Use this command to set the IGMP Querier version to its default value.

Format	<code>no set igmp querier version</code>
Mode	Global Config

**set igmp querier election participate**

Use this command to enable the Snooping Querier to participate in the Querier Election process when it discovers the presence of another Querier in the VLAN. When this mode is enabled, if the Snooping Querier finds that the other Querier's source address is better (less) than the Snooping Querier's address, it stops sending periodic queries. If the Snooping Querier wins the election, then it will continue sending periodic queries.

Default	disabled
Format	<code>set igmp querier election participate</code>
Mode	VLAN Config

**no set igmp querier election participate**

Use this command to set the Snooping Querier not to participate in querier election but go into non-querier mode as soon as it discovers the presence of another querier in the same VLAN.

Format	<code>no set igmp querier election participate</code>
Mode	VLAN Config

**show igmpsnooping querier**

Use this command to display IGMP Snooping Querier information. Configured information is displayed whether or not IGMP Snooping Querier is enabled.

Format	<code>show igmpsnooping querier [detail   vlan &lt;vlan-id&gt;]</code>
Mode	Privileged EXEC

If you do not use the optional `<vlan-id>` argument, the command displays the information that is shown in the following table.

Term	Description
Admin Mode	Indicates whether or not IGMP Snooping Querier is active on the switch.
Admin Version	The version of IGMP that will be used while sending out the queries.

Term	Description
Querier Address	The IP Address which will be used in the IPv4 header while sending out IGMP queries. It can be configured using the appropriate command.
Query Interval	The amount of time in seconds that a Snooping Querier waits before sending out the periodic general query.
Querier Timeout	The amount of time to wait in the Non-Querier operational state before moving to a Querier state.

If you specify a value for the `<vlan-id>` argument, the command displays the information that is shown in the following table.

Term	Description
VLAN Admin Mode	Indicates whether iGMP Snooping Querier is active on the VLAN.
VLAN Operational State	Indicates whether IGMP Snooping Querier is in "Querier" or "Non-Querier" state. When the switch is in Querier state, it will send out periodic general queries. When in Non-Querier state, it will wait for moving to Querier state and does not send out any queries.
VLAN Operational Max Response Time	Indicates the time to wait before removing a Leave from a host upon receiving a Leave request. This value is calculated dynamically from the Queries received from the network. If the Snooping Switch is in Querier state, then it is equal to the configured value.
Querier Election Participation	Indicates whether the IGMP Snooping Querier participates in querier election if it discovers the presence of a querier in the VLAN.
Querier VLAN Address	The IP address will be used in the IPv4 header while sending out IGMP queries on this VLAN. It can be configured using the appropriate command.
Operational Version	The version of IPv4 will be used while sending out IGMP queries on this VLAN.
Last Querier Address	Indicates the IP address of the most recent Querier from which a Query was received.
Last Querier Version	Indicates the IGMP version of the most recent Querier from which a Query was received on this VLAN.

If you use the optional `detail` argument, the command shows the global information and the information for all querier-enabled VLANs.

## MLD Snooping Commands

This section describes commands used for MLD Snooping. In IPv4, Layer 2 switches can use IGMP Snooping to limit the flooding of multicast traffic by dynamically configuring Layer 2 interfaces so that multicast traffic is forwarded only to those interfaces associated with IP multicast addresses. In IPv6, MLD Snooping performs a similar function. With MLD Snooping, IPv6 multicast data is selectively forwarded to a list of ports that want to receive the data, instead of being flooded to all ports in a VLAN. This list is constructed by snooping IPv6 multicast control packets.

### set mld

Use this command to enable MLD Snooping on the system (Global Config Mode) or an interface (Interface Config Mode). This command also enables MLD Snooping on a particular VLAN and enables MLD Snooping on all interfaces participating in a VLAN.

If an interface has MLD Snooping enabled and you enable this interface for routing or enlist it as a member of a port-channel (LAG), MLD Snooping functionality is disabled on that interface. MLD Snooping functionality is re-enabled if you disable routing or remove port channel (LAG) membership from an interface that has MLD Snooping enabled.

MLD Snooping supports the following activities:

- Validation of address version, payload length consistencies and discarding of the frame upon error.
- Maintenance of the forwarding table entries based on the MAC address versus the IPv6 address.
- Flooding of unregistered multicast data packets to all ports in the VLAN.

Default	disabled
Format	<code>set mld &lt;vlan-id&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> <li>• VLAN Mode</li> </ul>

### no set mld

Use this command to disable MLD Snooping on the system.

Format	<code>no set mld &lt;vlan-id&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> <li>• VLAN Mode</li> </ul>



### set mld interfacemode

Use this command to enable MLD Snooping on all interfaces. If an interface has MLD Snooping enabled and you enable this interface for routing or enlist it as a member of a port-channel (LAG), MLD Snooping functionality is disabled on that interface. MLD Snooping functionality is re-enabled if you disable routing or remove port-channel (LAG) membership from an interface that has MLD Snooping enabled.

Default	disabled
Format	<code>set mld interfacemode</code>
Mode	Global Config

### no set mld interfacemode

Use this command to disable MLD Snooping on all interfaces.

Format	<code>no set mld interfacemode</code>
Mode	Global Config

### set mld fast-leave

Use this command to enable MLD Snooping fast-leave admin mode on a selected interface or VLAN. Enabling fast-leave allows the switch to immediately remove the Layer 2 LAN interface from its forwarding table entry upon receiving and MLD done message for that multicast group without first sending out MAC-based general queries to the interface.

---

**Note:** You should enable fast-leave admin mode only on VLANs where only one host is connected to each Layer 2 LAN port. This prevents the inadvertent dropping of the other hosts that were connected to the same layer 2 LAN port but were still interested in receiving multicast traffic directed to that group.

---



---

**Note:** Fast-leave processing is supported only with MLD version 1 hosts.

---

Default	disabled
Format	<code>set mld fast-leave &lt;vlan-id&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• VLAN Mode</li> </ul>

**no set mld fast-leave**

Use this command to disable MLD Snooping fast-leave admin mode on a selected interface.

Format	<code>no set mld fast-leave &lt;vlan-id&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• VLAN Mode</li> </ul>

**set mld groupmembership-interval**

Use this command to set the MLD Group Membership Interval time on a VLAN, one interface or all interfaces. The Group Membership Interval time is the amount of time in seconds that a switch waits for a report from a particular group on a particular interface before deleting the interface from the entry. This value must be greater than the MLDv2 Maximum Response time value. The range is 2 to 3600 seconds.

Default	260 seconds
Format	<code>set mld groupmembership-interval &lt;vlan-id&gt; &lt;2-3600&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> <li>• VLAN Mode</li> </ul>

**no set groupmembership-interval**

Use this command to set the MLDv2 Group Membership Interval time to the default value.

Format	<code>no set mld groupmembership-interval</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Global Config</li> <li>• VLAN Mode</li> </ul>

**set mld maxresponse**

Use this command to set the MLD Maximum Response time for the system, on a particular interface or VLAN. The Maximum Response time is the amount of time in seconds that a switch will wait after sending a query on an interface because it did not receive a report for a particular group in that interface. This value must be less than the MLD Query Interval time value. The range is 1–65 seconds.

Default	10 seconds
Format	<code>set mld maxresponse &lt;1-65&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> <li>• VLAN Mode</li> </ul>

**no set mld maxresponse**

Use this command to set the max response time (on the interface or VLAN) to the default value.

Format	<code>no set mld maxresponse</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> <li>• VLAN Mode</li> </ul>

**set mld mcrtexpiretime**

Use this command to set the Multicast Router Present Expiration time. The time is set for the system, on a particular interface or VLAN. This is the amount of time in seconds that a switch waits for a query to be received on an interface before the interface is removed from the list of interfaces with multicast routers attached. The range is 0–3600 seconds. A value of 0 indicates an infinite timeout, that is, no expiration.

Default	0
Format	<code>set mld mcrtexpiretime &lt;vlan-id&gt; &lt;0-3600&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

**no set mld mcrtexpiretime**

Use this command to set the Multicast Router Present Expiration time to 0. The time is set for the system, on a particular interface or a VLAN.

Format	<code>no set mld mcrtexpiretime &lt;vlan-id&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

**set mld mrouter**

Use this command to configure the VLAN ID for the VLAN that has the multicast router attached mode enabled.

Format	<code>set mld mrouter &lt;vlan-id&gt;</code>
Mode	Interface Config

### no set mld mrouter

Use this command to disable multicast router attached mode for a VLAN with a particular VLAN ID.

Format	<code>no set mld mrouter &lt;vlan-id&gt;</code>
Mode	Interface Config

### set mld mrouter interface

Use this command to configure the interface as a multicast router-attached interface. When configured as a multicast router interface, the interface is treated as a multicast router-attached interface in all VLANs.

Default	disabled
Format	<code>set mld mrouter interface</code>
Mode	Interface Config

### no set mld mrouter interface

Use this command to disable the status of the interface as a statically configured multicast router-attached interface.

Format	<code>no set mld mrouter interface</code>
Mode	Interface Config

### show mldsnoping

Use this command to display MLD Snooping information. Configured information is displayed whether or not MLD Snooping is enabled.

Format	<code>show mldsnoping [&lt;slot/port&gt;   &lt;vlan-id&gt;]</code>
Mode	Privileged EXEC

When the optional arguments `<slot/port>` or `<vlan-id>` are not used, the command output displays the information that is shown in the following table.

Term	Definition
Admin Mode	Indicates whether or not MLD Snooping is active on the switch.
Interfaces Enabled for MLD Snooping	Interfaces on which MLD Snooping is enabled.

Term	Definition
MLD Control Frame Count	Displays the number of MLD Control frames that are processed by the CPU.
VLANs Enabled for MLD Snooping	VLANs on which MLD Snooping is enabled.

When you specify the `<slot/port>` values, the command output displays the information that is shown in the following table.

Term	Definition
MLD Snooping Admin Mode	Indicates whether MLD Snooping is active on the interface.
Fast Leave Mode	Indicates whether MLD Snooping Fast Leave is active on the VLAN.
Group Membership Interval	Shows the amount of time in seconds that a switch will wait for a report from a particular group on a particular interface, which is participating in the VLAN, before deleting the interface from the entry. This value may be configured.
Max Response Time	Displays the amount of time the switch waits after it sends a query on an interface, participating in the VLAN, because it did not receive a report for a particular group on that interface. This value may be configured.
Multicast Router Present Expiration Time	Displays the amount of time to wait before removing an interface that is participating in the VLAN from the list of interfaces with multicast routers attached. The interface is removed if a query is not received. This value may be configured.

When you specify a value for `<vlan-id>`, the command output displays the information that is shown in the following table.

Term	Definition
VLAN Admin Mode	Indicates whether MLD Snooping is active on the VLAN.

### show mldsnoping mrouter interface

Use this command to display information about statically configured multicast router attached interfaces.

Format	<code>show mldsnoping mrouter interface &lt;slot/port&gt;</code>
Mode	Privileged EXEC

Term	Definition
Interface	Shows the interface on which multicast router information is being displayed.
Multicast Router Attached	Indicates whether multicast router is statically enabled on the interface.
VLAN ID	Displays the list of VLANs of which the interface is a member.

### show mldsnoping mrouter vlan

Use this command to display information about statically configured multicast router-attached interfaces.

Format	<code>show mldsnoping mrouter vlan &lt;slot/port&gt;</code>
Mode	Privileged EXEC

Term	Definition
Interface	Shows the interface on which multicast router information is being displayed.
VLAN ID	Displays the list of VLANs of which the interface is a member.

### show mac-address-table mldsnoping

Use this command to display the MLD Snooping entries in the Multicast Forwarding Database (MFDB) table.

Format	<code>show mac-address-table mldsnoping</code>
Mode	Privileged EXEC

Term	Definition
VLAN ID	The VLAN in which the MAC address is learned.
MAC Address	A multicast MAC address for which the switch has forwarding or filtering information. The format is 6 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.
Type	The type of entry, which is either static (added by the user) or dynamic (added to the table as a result of a learning process or protocol.)
Description	The text description of this multicast table entry.
Interfaces	The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

## MLD Snooping Querier Commands

In an IPv6 environment, MLD Snooping requires that one central switch or router periodically query all end-devices on the network to announce their multicast memberships. This central device is the MLD Querier. The MLD query responses, known as MLD reports, keep the switch updated with the current multicast group membership on a port-by-port basis. If the switch does not receive updated membership information in a timely fashion, it will stop forwarding multicast frames to the port where the end device is located.

This section describes the commands you use to configure and display information on MLD Snooping queries on the network and, separately, on VLANs.

### set mld querier

Use this command to enable MLD Snooping Querier on the system (Global Config Mode) or on a VLAN. Using this command, you can specify the IP address that the snooping querier switch should use as a source address while generating periodic queries.

If a VLAN has MLD Snooping Querier enabled and MLD Snooping is operationally disabled on it, MLD Snooping Querier functionality is disabled on that VLAN. MLD Snooping functionality is re-enabled if MLD Snooping is operational on the VLAN.

The MLD Snooping Querier sends periodic general queries on the VLAN to solicit membership reports.

Default	disabled
Format	<code>set mld querier [vlan-id] [address ipv6_address]</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• VLAN Mode</li> </ul>

### no set mld querier

Use this command to disable MLD Snooping Querier on the system. Use the optional parameter `address` to reset the querier address.

Format	<code>no set mld querier [vlan-id] [address]</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• VLAN Mode</li> </ul>

### set mld querier query\_interval

Use this command to set the MLD Querier Query Interval time. This is the amount of time in seconds that the switch waits before sending another general query.

Default	disabled
Format	set mld querier query_interval <1-18000>
Mode	Global Config

### no set mld querier query\_interval

Use this command to set the MLD Querier Query Interval time to its default value.

Format	no set mld querier query_interval
Mode	Global Config

### set mld querier timer expiry

Use this command to set the MLD Querier timer expiration period. This is the time period that the switch remains in Non-Querier mode once it discovers that there is a Multicast Querier in the network.

Default	60 seconds
Format	set mld querier timer expiry <60-300>
Mode	Global Config

### no set mld querier timer expiry

Use this command to set the MLD Querier timer expiration period to its default value.

Format	no set mld querier timer expiry
Mode	Global Config

### set mld querier election participate

Use this command to enable the Snooping Querier to participate in the Querier Election process when it discovers the presence of another Querier in the VLAN. When this mode is enabled, if the Snooping Querier finds that the other Querier's source address is better (less) than the Snooping Querier's address, it stops sending periodic queries. If the Snooping Querier wins the election, then it will continue sending periodic queries.

Default	disabled
Format	set mld querier election participate
Mode	VLAN Config



**no set mld querier election participate**

Use this command to set the snooping querier not to participate in querier election, but go into a non-querier mode as soon as it discovers the presence of another querier in the same VLAN.

Format	<code>no set mld querier election participate</code>
Mode	VLAN Config

**show mldsnopping querier**

Use this command to display MLD Snooping Querier information. Configured information is displayed whether or not MLD Snooping Querier is enabled.

Format	<code>show mldsnopping querier [{detail   vlan &lt;vlanid&gt;}]</code>
Mode	Privileged EXEC

When the optional arguments *vlanid* are not used, the command displays the following information.

Term	Description
Admin Mode	Indicates whether or not MLD Snooping Querier is active on the switch.
Admin Version	Indicates the version of MLD that will be used while sending out the queries. This is defaulted to MLD v1 and it cannot be changed.
Querier Address	Shows the IP address which will be used in the IPv6 header while sending out MLD queries. It can be configured using the appropriate command.
Query Interval	Shows the amount of time in seconds that a Snooping Querier waits before sending out the periodic general query.
Querier Timeout	Displays the amount of time to wait in the Non-Querier operational state before moving to a Querier state.

When you specify a value for *vlanid*, the following information appears.

Term	Description
VLAN Admin Mode	Indicates whether MLD Snooping Querier is active on the VLAN.
VLAN Operational State	Indicates whether MLD Snooping Querier is in “Querier” or “Non-Querier” state. When the switch is in Querier state, it will send out periodic general queries. When in Non-Querier state, it will wait for moving to Querier state and does not send out any queries.
Operational Max Response Time	Indicates the time to wait before removing a Leave from a host upon receiving a Leave request. This value is calculated dynamically from the Queries received from the network. If the Snooping Switch is in Querier state, then it is equal to the configured value.

Term	Description
Querier Election Participate	Indicates whether the MLD Snooping Querier participates in querier election if it discovers the presence of a querier in the VLAN.
Querier VLAN Address	The IP address will be used in the IPv6 header while sending out MLD queries on this VLAN. It can be configured using the appropriate command.
Operational Version	This version of IPv6 will be used while sending out MLD queriers on this VLAN.
Last Querier Address	Indicates the IP address of the most recent Querier from which a Query was received.
Last Querier Version	Indicates the MLD version of the most recent Querier from which a Query was received on this VLAN.

When the optional argument `detail` is used, the command shows the global information and the information for all Querier-enabled VLANs.

## Port Security Commands

This section describes the commands you use to configure Port Security on the switch. Port security, which is also known as port MAC locking, allows you to secure the network by locking allowable MAC addresses on a port. Packets with a matching source MAC address are forwarded normally, and all other packets are discarded.

---

**Note:** To enable the SNMP trap specific to port security, see [snmp-server enable traps violation](#) on page 494.

---

### port-security

This command enables port locking at the system level (Global Config) or port level (Interface Config).

Default	disabled
Format	<code>port-security</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

**no port-security**

This command disables port locking for one (Interface Config) or all (Global Config) ports.

Format	<code>no port-security</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

**port-security max-dynamic**

This command sets the maximum number of dynamically locked MAC addresses allowed on a specific port.

Default	600
Format	<code>port-security max-dynamic &lt;maxvalue&gt;</code>
Mode	Interface Config

**no port-security max-dynamic**

This command resets the maximum number of dynamically locked MAC addresses allowed on a specific port to its default value.

Format	<code>no port-security max-dynamic</code>
Mode	Interface Config

**port-security max-static**

This command sets the maximum number of statically locked MAC addresses allowed on a port.

Default	20
Format	<code>port-security max-static &lt;maxvalue&gt;</code>
Mode	Interface Config

**no port-security max-static**

This command sets maximum number of statically locked MAC addresses to the default value.

Format	<code>no port-security max-static</code>
Mode	Interface Config

### port-security mac-address

This command adds a MAC address to the list of statically locked MAC addresses. The *<vid>* is the VLAN ID.

Format	<code>port-security mac-address &lt;mac-address&gt; &lt;vid&gt;</code>
Mode	Interface Config

### no port-security mac-address

This command removes a MAC address from the list of statically locked MAC addresses.

Format	<code>no port-security mac-address &lt;mac-address&gt; &lt;vid&gt;</code>
Mode	Interface Config

### port-security mac-address move

This command converts dynamically locked MAC addresses to statically locked addresses.

Format	<code>port-security mac-address move</code>
Mode	Interface Config

### port-security mac-address sticky

This command enables sticky mode Port MAC Locking on a port. If accompanied by a MAC address and a VLAN id (for interface config mode only), it adds a sticky MAC address to the list of statically locked MAC addresses. These sticky addresses are converted back to dynamically locked addresses if sticky mode is disabled on the port. The *<vid>* is the VLAN ID. The Global command applies the sticky mode to all valid interfaces (physical and LAG). There is no global sticky mode as such.

Sticky addresses that are dynamically learned display in the output of the **show running config** command as `port-security mac-address sticky <mac> <vid>` entries. This distinguishes them from static entries.

Format	<code>port-security mac-address sticky [&lt;mac-address&gt; &lt;vid&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no port-security mac-address sticky

The no form removes the sticky mode. The sticky MAC address can be deleted by using the command **no port-security mac-address** *<mac-address>* *<vid>*.

Format	<code>no port-security mac-address sticky [<i>&lt;mac-address&gt;</i> <i>&lt;vid&gt;</i>]</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### show port-security

This command displays the port-security settings. If you do not use a parameter, the command displays the settings for the entire system. Use the optional parameters to display the settings on a specific interface or on all interfaces.

Format	<code>show port-security [<i>&lt;slot/port&gt;</i>   all]</code>
Mode	Privileged EXEC

Term	Definition
Admin Mode	Port Locking mode for the entire system. This field displays if you do not supply any parameters.

For each interface, or for the interface you specify, the following information appears:

Term	Definition
Admin Mode	Port Locking mode for the Interface.
Dynamic Limit	Maximum dynamically allocated MAC Addresses.
Static Limit	Maximum statically allocated MAC Addresses.
Violation Trap Mode	Whether violation traps are enabled.

### show port-security dynamic

This command displays the dynamically locked MAC addresses for the port.

Format	<code>show port-security dynamic [lag <i>&lt;lag-intf-num&gt;</i>   <i>&lt;slot/port&gt;</i>]</code>
Mode	Privileged EXEC

Term	Definition
MAC Address	MAC Address of dynamically locked MAC.

## show port-security static

This command displays the statically locked MAC addresses for port.

Format	<code>show port-security static [lag &lt;lag-intf-num&gt;   &lt;slot/port&gt;]</code>
Mode	Privileged EXEC

Term	Definition
MAC Address	MAC Address of statically locked MAC.

## show port-security violation

This command displays the source MAC address of the last packet discarded on a locked port.

Format	<code>show port-security violation [lag &lt;lag-intf-num&gt;   &lt;slot/port&gt;]</code>
Mode	Privileged EXEC

Term	Definition
MAC Address	MAC Address of discarded packet on locked port.

## LLDP (802.1AB) Commands

This section describes the command you use to configure Link Layer Discovery Protocol (LLDP), which is defined in the IEEE 802.1AB specification. LLDP allows stations on an 802 LAN to advertise major capabilities and physical descriptions. The advertisements allow a network management system (NMS) to access and display this information.

### lldp transmit

Use this command to enable the LLDP advertise capability.

Default	enabled
Format	<code>lldp transmit</code>
Mode	Interface Config

### no lldp transmit

Use this command to return the local data transmission capability to the default.

Format	<code>no lldp transmit</code>
Mode	Interface Config

## lldp receive

Use this command to enable the LLDP receive capability.

Default	enabled
Format	lldp receive
Mode	Interface Config

## no lldp receive

Use this command to return the reception of LLDPDUs to the default value.

Format	no lldp receive
Mode	Interface Config

## lldp timers

Use this command to set the timing parameters for local data transmission on ports enabled for LLDP. The *<interval-seconds>* determines the number of seconds to wait between transmitting local data LLDPDUs. The range is 1-32768 seconds. The *<hold-value>* is the multiplier on the transmit interval that sets the TTL in local data LLDPDUs. The multiplier range is 2-10. The *<reinit-seconds>* is the delay before re-initialization, and the range is 1-0 seconds.

Default	<ul style="list-style-type: none"> <li>• interval—30 seconds</li> <li>• hold—4</li> <li>• reinit—2 seconds</li> </ul>
Format	lldp timers [interval <i>&lt;interval-seconds&gt;</i> ] [hold <i>&lt;hold-value&gt;</i> ] [reinit <i>&lt;reinit-seconds&gt;</i> ]
Mode	Global Config

## no lldp timers

Use this command to return any or all timing parameters for local data transmission on ports enabled for LLDP to the default values.

Format	no lldp timers [interval] [hold] [reinit]
Mode	Global Config

## lldp transmit-tlv

Use this command to specify which optional type length values (TLVs) in the 802.1AB basic management set are transmitted in the LLDPDUs. Use **sys-name** to transmit the system name TLV. To configure the system name, see *snmp-server* on page 491. Use **sys-desc** to transmit the system description TLV. Use **sys-cap** to transmit the system capabilities TLV.

Use **port-desc** to transmit the port description TLV. To configure the port description, see [description](#) on page 20

Default	all optional TLVs are included
Format	<code>lldp transmit-tlv [sys-desc] [sys-name] [sys-cap] [port-desc]</code>
Mode	Interface Config

### no lldp transmit-tlv

Use this command to remove an optional TLV from the LLDPDUs. Use the command without parameters to remove all optional TLVs from the LLDPDU.

Format	<code>no lldp transmit-tlv [sys-desc] [sys-name] [sys-cap] [port-desc]</code>
Mode	Interface Config

### lldp transmit-mgmt

Use this command to include transmission of the local system management address information in the LLDPDUs.

Default	enabled
Format	<code>lldp transmit-mgmt</code>
Mode	Interface Config

### no lldp transmit-mgmt

Use this command to include transmission of the local system management address information in the LLDPDUs. Use this command to cancel inclusion of the management information in LLDPDUs.

Format	<code>no lldp transmit-mgmt</code>
Mode	Interface Config

### lldp notification

Use this command to enable remote data change notifications.

Default	disabled
Format	<code>lldp notification</code>
Mode	Interface Config



**no lldp notification**

Use this command to disable notifications.

Default	disabled
Format	no lldp notification
Mode	Interface Config

**lldp notification-interval**

Use this command to configure how frequently the system sends remote data change notifications. The *<interval>* parameter is the number of seconds to wait between sending notifications. The valid interval range is 5-3600 seconds.

Default	5
Format	lldp notification-interval <i>&lt;interval&gt;</i>
Mode	Global Config

**no lldp notification-interval**

Use this command to return the notification interval to the default value.

Format	no lldp notification-interval
Mode	Global Config

**clear lldp statistics**

Use this command to reset all LLDP statistics, including MED-related information.

Format	clear lldp statistics
Mode	Privileged Exec

**clear lldp remote-data**

Use this command to delete all information from the LLDP remote data table, including MED-related information.

Format	clear lldp remote-data
Mode	Global Config

## show lldp

Use this command to display a summary of the current LLDP configuration.

Format	show lldp
Mode	Privileged Exec

Term	Definition
Transmit Interval	How frequently the system transmits local data LLDPDUs, in seconds.
Transmit Hold Multiplier	The multiplier on the transmit interval that sets the TTL in local data LLDPDUs.
Re-initialization Delay	The delay before re-initialization, in seconds.
Notification Interval	How frequently the system sends remote data change notifications, in seconds.

## show lldp interface

Use this command to display a summary of the current LLDP configuration for a specific interface or for all interfaces.

Format	show lldp interface {<slot/port>   all}
Mode	Privileged Exec

Term	Definition
Interface	The interface in a slot/port format.
Link	Shows whether the link is up or down.
Transmit	Shows whether the interface transmits LLDPDUs.
Receive	Shows whether the interface receives LLDPDUs.
Notify	Shows whether the interface sends remote data change notifications.
TLVs	Shows whether the interface sends optional TLVs in the LLDPDUs. The TLV codes can be 0 (Port Description), 1 (System Name), 2 (System Description), or 3 (System Capability).
Mgmt	Shows whether the interface transmits system management address information in the LLDPDUs.

## show lldp statistics

Use this command to display the current LLDP traffic and remote table statistics for a specific interface or for all interfaces.

Format	show lldp statistics {<slot/port>   all}
Mode	Privileged Exec

Term	Definition
Last Update	The amount of time since the last update to the remote table in days, hours, minutes, and seconds.
Total Inserts	Total number of inserts to the remote data table.
Total Deletes	Total number of deletes from the remote data table.
Total Drops	Total number of times the complete remote data received was not inserted due to insufficient resources.
Total Ageouts	Total number of times a complete remote data entry was deleted because the Time to Live interval expired.

The table contains the following column headings:

Term	Definition
Interface	The interface in slot/port format.
Transmit Total	Total number of LLDP packets transmitted on the port.
Receive Total	Total number of LLDP packets received on the port.
Discards	Total number of LLDP frames discarded on the port for any reason.
Errors	The number of invalid LLDP frames received on the port.
Ageouts	Total number of times a complete remote data entry was deleted for the port because the Time to Live interval expired.
TLV Discards	The number of TLVs discarded.
TLV Unknowns	Total number of LLDP TLVs received on the port where the type value is in the reserved range, and not recognized.
TLV MED	Total number of LLDP MED TLVs received on the local ports.
TVL802.1	Total number of 802.1 LLDP TLVs received on the local ports.
TVL802.3	Total number of 802.3 LLDP TLVs received on the local ports.

## show lldp remote-device

Use this command to display summary information about remote devices that transmit current LLDP data to the system. You can show information about LLDP remote data received on all ports or on a specific port.

Format	show lldp remote-device {<slot/port>   all}
Mode	Privileged EXEC

Term	Definition
Local Interface	The interface that received the LLDPDU from the remote device.
RemID	An internal identifier to the switch to mark each remote device to the system.
Chassis ID	The ID that is sent by a remote device as part of the LLDP message, it is usually a MAC address of the device.
Port ID	The port number that transmitted the LLDPDU.
System Name	The system name of the remote device.

### Command example:

```
(NETGEAR Switch) #show lldp remote-device all
```

```
LLDP Remote Device Summary
```

```
Local
Interface RemID    Chassis ID          Port ID              System Name
-----
0/1
0/2
0/3
0/4
0/5
0/6
0/7      2      00:FC:E3:90:01:0F    00:FC:E3:90:01:11
0/7      3      00:FC:E3:90:01:0F    00:FC:E3:90:01:12
0/7      4      00:FC:E3:90:01:0F    00:FC:E3:90:01:13
0/7      5      00:FC:E3:90:01:0F    00:FC:E3:90:01:14
0/7      1      00:FC:E3:90:01:0F    00:FC:E3:90:03:11
0/7      6      00:FC:E3:90:01:0F    00:FC:E3:90:04:11
0/8
0/9
0/10
0/11
0/12
```

## show lldp remote-device detail

Use this command to display detailed information about remote devices that transmit current LLDP data to an interface on the system.

Format	show lldp remote-device detail <slot/port>
Mode	Privileged EXEC

Term	Definition
Local Interface	The interface that received the LLDPDU from the remote device.
Remote Identifier	An internal identifier to the switch to mark each remote device to the system.
Chassis ID Subtype	The type of identification used in the Chassis ID field.
Chassis ID	The chassis of the remote device.
Port ID Subtype	The type of port on the remote device.
Port ID	The port number that transmitted the LLDPDU.
System Name	The system name of the remote device.
System Description	Describes the remote system by identifying the system name and versions of hardware, operating system, and networking software supported in the device.
Port Description	Describes the port in an alpha-numeric format. The port description is configurable.
System Capabilities Supported	Indicates the primary function(s) of the device.
System Capabilities Enabled	Shows which of the supported system capabilities are enabled.
Management Address	For each interface on the remote device with an LLDP agent, lists the type of address the remote LLDP agent uses and specifies the address used to obtain information related to the device.
Time To Live	The amount of time (in seconds) the remote device's information received in the LLDPDU should be treated as valid information.

### Command example:

```
(NETGEAR Switch) #show lldp remote-device detail 0/7
```

```
LLDP Remote Device Detail
```

```
Local Interface: 0/7
```

```
Remote Identifier: 2
```

```
Chassis ID Subtype: MAC Address
```

Chassis ID: 00:FC:E3:90:01:0F

Port ID Subtype: MAC Address

Port ID: 00:FC:E3:90:01:11

System Name:

System Description:

Port Description:

System Capabilities Supported:

System Capabilities Enabled:

Time to Live: 24 seconds

## show lldp local-device

Use this command to display summary information about the advertised LLDP local data. This command can display summary information or detail for each interface.

Format	<code>show lldp local-device {&lt;slot/port&gt;   all}</code>
Mode	Privileged EXEC

Term	Definition
Interface	The interface in a slot/port format.
Port ID	The port ID associated with this interface.
Port Description	The port description associated with the interface.

## show lldp local-device detail

Use this command to display detailed information about the LLDP data a specific interface transmits.

Format	<code>show lldp local-device detail &lt;slot/port&gt;</code>
Mode	Privileged EXEC

Term	Definition
Interface	The interface that sends the LLDPDU.
Chassis ID Subtype	The type of identification used in the Chassis ID field.
Chassis ID	The chassis of the local device.
Port ID Subtype	The type of port on the local device.
Port ID	The port number that transmitted the LLDPDU.
System Name	The system name of the local device.

Term	Definition
System Description	Describes the local system by identifying the system name and versions of hardware, operating system, and networking software supported in the device.
Port Description	Describes the port in an alpha-numeric format.
System Capabilities Supported	Indicates the primary function(s) of the device.
System Capabilities Enabled	Shows which of the supported system capabilities are enabled.
Management Address	The type of address and the specific address the local LLDP agent uses to send and receive information.

## LLDP-MED Commands

Link Layer Discovery Protocol - Media Endpoint Discovery (LLDP-MED) (ANSI-TIA-1057) provides an extension to the LLDP standard. Specifically, LLDP-MED provides extensions for network configuration and policy, device location, Power over Ethernet (PoE) management and inventory management.

### lldp med

Use this command to enable MED. By enabling MED, you will be effectively enabling the transmit and receive function of LLDP.

Default	enabled
Format	lldp med
Mode	Interface Config

### no lldp med

Use this command to disable MED.

Format	no lldp med
Mode	Interface Config

## lldp med confignotification

Use this command to configure all the ports to send the topology change notification.

Default	enabled
Format	lldp med confignotification
Mode	Interface Config

## no lldp med confignotification

Use this command to disable notifications.

Format	no lldp med confignotification
Mode	Interface Config

## lldp med transmit-tlv

Use this command to specify which optional Type Length Values (TLVs) in the LLDP MED set will be transmitted in the Link Layer Discovery Protocol Data Units (LLDPDUs).

Default	By default, the capabilities and network policy TLVs are included.
Format	lldp med transmit-tlv [capabilities] [ex-pd] [ex-pse] [inventory] [location] [network-policy]
Mode	Interface Config

Parameter	Definition
capabilities	Transmit the LLDP capabilities TLV.
ex-pd	Transmit the LLDP extended PD TLV.
ex-pse	Transmit the LLDP extended PSE TLV.
inventory	Transmit the LLDP inventory TLV.
location	Transmit the LLDP location TLV.
network-policy	Transmit the LLDP network policy TLV.

---

**Note:** The current implementation supports one network policy: the voice VLAN as defined by the `voice vlan` commands.

---



**no lldp med transmit-tlv**

Use this command to remove a TLV.

Format	no lldp med transmit-tlv [capabilities] [network-policy] [ex-pse] [ex-pd] [location] [inventory]
Mode	Interface Config

**lldp med all**

Use this command to configure LLDP-MED on all the ports.

Format	lldp med all
Mode	Global Config

**no lldp med all**

Use this command to remove LLDP-MD on all ports.

Format	no lldp med all
Mode	Global Config

**lldp med confignotification all**

Use this command to configure all the ports to send the topology change notification.

Format	lldp med confignotification all
Mode	Global Config

**no lldp med confignotification all**

Use this command to disable all the ports to send the topology change notification.

Format	no lldp med confignotification all
Mode	Global Config

**lldp med faststartrepeatcount**

Use this command to set the value of the fast start repeat count. *<count>* is the number of LLDP PDUs that will be transmitted when the product is enabled. The range is 1 to 10.

Default	3
Format	lldp med faststartrepeatcount [ <i>&lt;count&gt;</i> ]
Mode	Global Config

**no lldp med faststartrepeatcount**

Use this command to return to the factory default value.

Format	no lldp med faststartrepeatcount
Mode	Global Config

**lldp med transmit-tlv all**

Use this command to specify which optional Type Length Values (TLVs) in the LLDP MED set will be transmitted in the Link Layer Discovery Protocol Data Units (LLDPDUs).

Default	By default, the capabilities and network policy TLVs are included.
Format	lldp med transmit-tlv all [capabilities] [ex-pd] [ex-pse] [inventory] [location] [network-policy]
Mode	Global Config

Parameter	Definition
capabilities	Transmit the LLDP capabilities TLV.
ex-pd	Transmit the LLDP extended PD TLV.
ex-pse	Transmit the LLDP extended PSE TLV.
inventory	Transmit the LLDP inventory TLV.
location	Transmit the LLDP location TLV.
network-policy	Transmit the LLDP network policy TLV.

**no lldp med transmit-tlv**

Use this command to remove a TLV.

Format	no lldp med transmit-tlv all [capabilities] [network-policy] [ex-pse] [ex-pd] [location] [inventory]
Mode	Global Config

**show lldp med**

Use this command to display a summary of the current LLDP MED configuration.

Format	show lldp med
Mode	Privileged Exec

Term	Definition
Fast Start Repeat Count	The number of LLDP PDUs that will be transmitted when the protocol is enabled.
Device Class	The local device's MED Classification. There are four different kinds of devices, three of them represent the actual end points (classified as Class I Generic [IP Communication Controller etc.], Class II Media Conference Bridge etc.], Class III Communication [IP Telephone etc.]. Class IV Network Connectivity Device, which is typically a LAN Switch, Router, IEEE 802.11 Wireless Access Point, etc.

**Command example:**

```
(NETGEAR Switch) #show lldp med
LLDP MED Global Configuration
```

```
Fast Start Repeat Count: 3
Device Class: Network Connectivity
```

**show lldp med interface**

Use this command to display a summary of the current LLDP MED configuration for a specific interface. *<slot/port>* indicates a specific physical interface. *all* indicates all valid LLDP interfaces.

Format	show lldp med interface {<slot/port>   all}
Mode	Privileged Exec

Term	Definition
Interface	The interface in a slot/port format.
Link	Shows whether the link is up or down.
ConfigMED	Shows if the LLDP-MED mode is enabled or disabled on this interface
OperMED	Shows if the LLDP-MED TLVs are transmitted or not on this interface.
ConfigNotify	Shows if the LLDP-MED topology notification mode of this interface.
TLVsTx	Shows whether the interface sends optional TLVs in the LLDPDUs. The TLV codes can be 0 (Capabilities), 1 (Network Policy), 2 (Location), 3 (Extended PSE), 4 (Extended Pd), or 5 (Inventory).

**Command example:**

```
(NETGEAR Switch) #show lldp med interface all
```

```
Interface  Link    configMED operMED   ConfigNotify TLVsTx
-----  -
0/1       Down   Disabled  Disabled  Disabled     0,1
0/2       Up     Disabled  Disabled  Disabled     0,1
```

```

0/3      Down    Disabled Disabled Disabled 0,1
0/4      Down    Disabled Disabled Disabled 0,1
0/5      Down    Disabled Disabled Disabled 0,1
0/6      Down    Disabled Disabled Disabled 0,1
0/7      Down    Disabled Disabled Disabled 0,1
0/8      Down    Disabled Disabled Disabled 0,1
0/9      Down    Disabled Disabled Disabled 0,1
0/10     Down    Disabled Disabled Disabled 0,1
0/11     Down    Disabled Disabled Disabled 0,1
0/12     Down    Disabled Disabled Disabled 0,1
0/13     Down    Disabled Disabled Disabled 0,1
0/14     Down    Disabled Disabled Disabled 0,1
    
```

TLV Codes: 0- Capabilities,           1- Network Policy  
           2- Location,               3- Extended PSE  
           4- Extended Pd,           5- Inventory

**Command example:**

```
(NETGEAR Switch) #show lldp med interface 0/2
```

```

Interface  Link    configMED operMED    ConfigNotify TLVsTx
-----
0/2        Up      Disabled Disabled Disabled    0,1
    
```

TLV Codes: 0- Capabilities,           1- Network Policy  
           2- Location,               3- Extended PSE  
           4- Extended Pd,           5- Inventory

**show lldp med local-device detail**

This command displays detailed information about the LLDP data a specific interface transmits.

Format	show lldp med local-device detail <slot/port>
Mode	Privileged EXEC

Term	Definition
Media Application Type	Shows the application type. Types are unknown, voice, voicesignaling, guestvoice, guestvoicesignaling, sftophonevoice, videoconferencing, streamingvideo, videosignaling.
Vlan ID	Shows the VLAN id associated with a particular policy type
Priority	Shows the priority associated with a particular policy type.
DSCP	Shows the DSCP associated with a particular policy type.

Term	Definition
Unknown	Indicates if the policy type is unknown. In this case, the VLAN ID, Priority and DSCP are ignored.
Tagged	Indicates if the policy type is using tagged or untagged VLAN.
Hardware Rev	Shows the local hardware version.
Firmware Rev	Shows the local firmware version.
Software Rev	Shows the local software version.
Serial Num	Shows the local serial number.
Mfg Name	Shows the manufacture name.
Model Name	Shows the model name.

### Command example:

```
(NETGEAR Switch) #show lldp med local-device detail 0/8
```

```
LLDP MED Local Device Detail
```

```
Interface: 0/8
```

```
Network Policies
```

```
Media Policy Application Type : voice
```

```
Vlan ID: 10
```

```
Priority: 5
```

```
DSCP: 1
```

```
Unknown: False
```

```
Tagged: True
```

```
Media Policy Application Type : streamingvideo
```

```
Vlan ID: 20
```

```
Priority: 1
```

```
DSCP: 2
```

```
Unknown: False
```

```
Tagged: True
```

```
Inventory
```

```
Hardware Rev: xxx xxx xxx
```

```
Firmware Rev: xxx xxx xxx
```

```
Software Rev: xxx xxx xxx
```

```
Serial Num: xxx xxx xxx
```

```
Mfg Name: xxx xxx xxx
```

```
Model Name: xxx xxx xxx
```

```
Asset ID: xxx xxx xxx
```

```
Location
Subtype: elin
Info: xxx xxx xxx
```

```
Extended POE
Device Type: pseDevice
```

```
Extended POE PSE
Available: 0.3 Watts
Source: primary
Priority: critical
```

```
Extended POE PD
```

```
Required: 0.2 Watts
Source: local
Priority: low
```

## show lldp med remote-device

This command displays summary information about remote devices that transmit current LLDP MED data to the system. You can show information about LLDP remote data received on all ports or on a specific port.

Format	show lldp med remote-device {<slot/port>   all}
Mode	Privileged EXEC

Term	Definition
Interface	The interface in a slot/port format.
Device Class	The Remote device's MED Classification. There are four different kinds of devices, three of them represent the actual end points (classified as Class I Generic [IP Communication Controller etc.], Class II Media [Conference Bridge etc.], Class III Communication [IP Telephone etc]). The fourth device is Network Connectivity Device, which is typically a LAN Switch/Router, IEEE 802.1 Bridge, IEEE 802.11 Wireless Access Point etc.

### Command example:

```
(NETGEAR Switch) #show lldp med remote-device all
```

```
LLDP MED Remote Device Summary
```

```
Local
Interface Remote ID Device Class
-----
0/8          1          Class I
```

0/9	2	Not Defined
0/10	3	Class II
0/11	4	Class III
0/12	5	Network Con

## show lldp med remote-device detail

Use this command to display detailed information about remote devices that transmit current LLDP MED data to an interface on the system.

Format	<code>show lldp med remote-device detail &lt;slot/port&gt;</code>
Mode	Privileged EXEC

Term	Definition
Supported Capabilities	Shows the supported capabilities that were received in MED TLV on this port.
Enabled capabilities	Shows the enabled capabilities that were enabled in MED TLV on this port.
Device Class	Shows the device class as advertized by the device remotely connected to the port.
Network Policy Information	Shows if network policy TLV is received in the LLDP frames on this port.
Media Application Type	Shows the application type. Types of applications are unknown, voice, voicesignaling, guestvoice, guestvoicesignaling, sftophonevoice, videoconferencing, streamingvideo, videesignaling.
VLAN Id	Shows the VLAN id associated with a particular policy type.
Priority	Shows the priority associated with a particular policy type.
DSCP	Shows the DSCP associated with a particular policy type.
Unknown	Indicates if the policy type is unknown. In this case, the VLAN id, Priority and DSCP are ignored.
Tagged	Indicates if the policy type is using tagged or untagged VLAN.
Hardware Revision	Shows the hardware version of the remote device.
Firmware Revision	Shows the firmware version of the remote device.
Software Revision	Shows the software version of the remote device.
Serial Number	Shows the serial number of the remote device.
Manufacturer Name	Shows the manufacture name of the remote device.

Term	Definition
Model Name	Shows the model name of the remote device.
Asset ID	Shows the asset id of the remote device.
Sub Type	Shows the type of location information.
Location Information	Shows the location information as a string for a type of location ID.
Device Type	Shows the remote device's PoE device type connected to this port.
Available	Shows the remote port's PSE power value in tenths of a watt.
Source	Shows the remote port's PSE power source.
Priority	Shows the remote port's PSE priority.
Required	Shows the remote port's PD power requirement.
Source	Shows the remote port's PD power source.
Priority	Shows the remote port's PD power priority.

### Command example:

```
(NETGEAR Switch) #show lldp med remote-device detail 0/8
```

```
LLDP MED Remote Device Detail
```

```
Local Interface: 0/8
```

```
Remote Identifier: 18
```

```
Capabilities
```

```
MED Capabilities Supported: capabilities, networkpolicy, location, extendedpse
```

```
MED Capabilities Enabled: capabilities, networkpolicy
```

```
Device Class: Endpoint Class I
```

```
Network Policies
```

```
Media Policy Application Type : voice
```

```
Vlan ID: 10
```

```
Priority: 5
```

```
DSCP: 1
```

```
Unknown: False
```

```
Tagged: True
```

```
Media Policy Application Type : streamingvideo
```

```
Vlan ID: 20
```

```
Priority: 1
```

```
DSCP: 2
```

```
Unknown: False
```

```
Tagged: True
```



### Inventory

Hardware Rev: xxx xxx xxx  
Firmware Rev: xxx xxx xxx  
Software Rev: xxx xxx xxx  
Serial Num: xxx xxx xxx  
Mfg Name: xxx xxx xxx  
Model Name: xxx xxx xxx  
Asset ID: xxx xxx xxx

### Location

Subtype: elin  
Info: xxx xxx xxx

### Extended POE

Device Type: pseDevice

### Extended POE PSE

Available: 0.3 Watts  
Source: primary  
Priority: critical

### Extended POE PD

Required: 0.2 Watts  
Source: local  
Priority: low

## Denial of Service Commands

This section describes the commands you use to configure Denial of Service (DoS) Control. The software provides support for classifying and blocking specific types of Denial of Service attacks. You can configure your system to monitor and block these types of attacks:

- **SIP=DIP:** Source IP address = Destination IP address.
- **First Fragment:** TCP Header size smaller than configured value.
- **TCP Fragment:** IP Fragment Offset = 1.
- **TCP Flag:** TCP Flag SYN set and Source Port < 1024 or TCP Control Flags = 0 and TCP Sequence Number = 0 or TCP Flags FIN, URG, and PSH set and TCP Sequence Number = 0 or TCP Flags SYN and FIN set.
- **L4 Port:** Source TCP/UDP Port = Destination TCP/UDP Port.
- **ICMP:** Limiting the size of ICMP Ping packets.
- **SMAC = DMAC:** Source MAC address = Destination MAC address.
- **TCP Port:** Source TCP Port = Destination TCP Port.

- **UDP Port:** Source UDP Port = Destination UDP Port.
- **TCP Flag & Sequence:** TCP Flag SYN set and Source Port < 1024 or TCP Control Flags = 0 and TCP Sequence Number = 0 or TCP Flags FIN, URG, and PSH set and TCP Sequence Number = 0 or TCP Flags SYN and FIN set.
- **TCP Offset:** TCP Header Offset = 1.
- **TCP SYN:** TCP Flag SYN set.
- **TCP SYN & FIN:** TCP Flags SYN and FIN set.
- **TCP FIN & URG & PSH:** TCP Flags FIN and URG and PSH set and TCP Sequence Number = 0.
- **ICMP V6:** Limiting the size of ICMPv6 Ping packets.
- **ICMP Fragment:** Checks for fragmented ICMP packets.

### dos-control all

This command enables Denial of Service protection checks globally.

Default	disabled
Format	dos-control all
Mode	Global Config

### no dos-control all

This command disables Denial of Service prevention checks globally.

Format	no dos-control all
Mode	Global Config

### dos-control sipdip

This command enables Source IP address = Destination IP address (SIP=DIP) Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress with SIP=DIP, the packets will be dropped if the mode is enabled.

Default	disabled
Format	dos-control sipdip
Mode	Global Config

**no dos-control sipdip**

This command disables Source IP address = Destination IP address (SIP=DIP) Denial of Service prevention.

Format	no dos-control sipdip
Mode	Global Config

**dos-control firstfrag**

This command enables Minimum TCP Header Size Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having a TCP Header Size smaller than the configured value, the packets will be dropped if the mode is enabled. The default is disabled. If you enable dos-control firstfrag, but do not provide a Minimum TCP Header Size, the system sets that value to 20.

Default	disabled <20>
Format	dos-control firstfrag [<0-255>]
Mode	Global Config

**no dos-control firstfrag**

This command sets Minimum TCP Header Size Denial of Service protection to the default value of disabled.

Format	no dos-control firstfrag
Mode	Global Config

**dos-control tcpfrag**

This command enables TCP Fragment Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having IP Fragment Offset equal to one (1), the packets will be dropped if the mode is enabled.

Default	disabled
Format	dos-control tcpfrag
Mode	Global Config

**no dos-control tcpfrag**

This command disabled TCP Fragment Denial of Service protection.

Format	no dos-control tcpfrag
Mode	Global Config

### dos-control tcpflag

This command enables TCP Flag Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attacks. If packets ingress having TCP Flag SYN set and a source port less than 1024 or having TCP Control Flags set to 0 and TCP Sequence Number set to 0 or having TCP Flags FIN, URG, and PSH set and TCP Sequence Number set to 0 or having TCP Flags SYN and FIN both set, the packets will be dropped if the mode is enabled.

Default	disabled
Format	dos-control tcpflag
Mode	Global Config

### no dos-control tcpflag

This command sets disables TCP Flag Denial of Service protections.

Format	no dos-control tcpflag
Mode	Global Config

### dos-control l4port

This command enables L4 Port Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having Source TCP/UDP Port Number equal to Destination TCP/UDP Port Number, the packets will be dropped if the mode is enabled.

---

**Note:** Some applications mirror source and destination L4 ports - RIP for example uses 520 for both. If you enable dos-control l4port, applications such as RIP may experience packet loss which would render the application inoperable.

---

Default	disabled
Format	dos-control l4port
Mode	Global Config

**no dos-control l4port**

This command disables L4 Port Denial of Service protections.

Format	no dos-control l4port
Mode	Global Config

**dos-control icmp**

This command enables Maximum ICMP Packet Size Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If ICMP Echo Request (PING) packets ingress having a size greater than the configured value, the packets will be dropped if the mode is enabled.

Default	disabled <512>
Format	dos-control icmp [<0-1023>]
Mode	Global Config

**no dos-control icmp**

This command disables Maximum ICMP Packet Size Denial of Service protections.

Format	no dos-control icmp
Mode	Global Config

**dos-control smacdmac**

This command enables Source MAC address = Destination MAC address (SMAC=DMAC) Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress with SMAC=DMAC, the packets will be dropped if the mode is enabled.

Default	disabled
Format	dos-control smacdmac
Mode	Global Config

**no dos-control smacdmac**

This command disables Source MAC address = Destination MAC address (SMAC=DMAC) Denial of Service protection.

Format	no dos-control smacdmac
Mode	Global Config

### dos-control tcpport

This command enables TCP L4 source = destination port number (Source TCP Port = Destination TCP Port) Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress with Source TCP Port = Destination TCP Port, the packets will be dropped if the mode is enabled.

Default	disabled
Format	<code>dos-control tcpport</code>
Mode	Global Config

### no dos-control tcpport

This command disables TCP L4 source = destination port number (Source TCP Port = Destination TCP Port) Denial of Service protection.

Format	<code>no dos-control smacdmac</code>
Mode	Global Config

### dos-control udpport

This command enables UDP L4 source = destination port number (Source UDP Port = Destination UDP Port) Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress with Source UDP Port = Destination UDP Port, the packets will be dropped if the mode is enabled.

Default	disabled
Format	<code>dos-control udppport</code>
Mode	Global Config

### no dos-control udpport

This command disables UDP L4 source = destination port number (Source UDP Port = Destination UDP Port) Denial of Service protection.

Format	<code>no dos-control udppport</code>
Mode	Global Config

### dos-control tcpflagseq

This command enables TCP Flag and Sequence Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP Flag SYN set and a source port less than 1024 or having TCP Control Flags set to 0 and TCP Sequence Number set to 0 or having TCP Flags FIN, URG, and PSH set and

TCP Sequence Number set to 0 or having TCP Flags SYN and FIN both set, the packets will be dropped if the mode is enabled.

Default	disabled
Format	<code>dos-control tcpflagseq</code>
Mode	Global Config

### no dos-control tcpflagseq

This command sets disables TCP Flag and Sequence Denial of Service protection.

Format	<code>no dos-control tcpflagseq</code>
Mode	Global Config

### dos-control tcpoffset

This command enables TCP Offset Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP Header Offset equal to one (1), the packets will be dropped if the mode is enabled.

Default	disabled
Format	<code>dos-control tcpoffset</code>
Mode	Global Config

### no dos-control tcpoffset

This command disabled TCP Offset Denial of Service protection.

Format	<code>no dos-control tcpoffset</code>
Mode	Global Config

### dos-control tcpsyn

This command enables TCP SYN and L4 source = 0-1023 Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP flag SYN set and an L4 source port from 0 to 1023, the packets will be dropped if the mode is enabled.

Default	disabled
Format	<code>dos-control tcpsyn</code>
Mode	Global Config

**no dos-control tcpsyn**

This command sets disables TCP SYN and L4 source = 0-1023 Denial of Service protection.

Format	<code>no dos-control tcpsyn</code>
Mode	Global Config

**dos-control tcpsynfin**

This command enables TCP SYN and FIN Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP flags SYN and FIN set, the packets will be dropped if the mode is enabled.

Default	disabled
Format	<code>dos-control tcpsynfin</code>
Mode	Global Config

**no dos-control tcpsynfin**

This command sets disables TCP SYN & FIN Denial of Service protection.

Format	<code>no dos-control tcpsynfin</code>
Mode	Global Config

**dos-control tcpfinurgpsh**

This command enables TCP FIN and URG and PSH and SEQ=0 checking Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP FIN, URG, and PSH all set and TCP Sequence Number set to 0, the packets will be dropped if the mode is enabled.

Default	disabled
Format	<code>dos-control tcpfinurgpsh</code>
Mode	Global Config

**no dos-control tcpfinurgpsh**

This command sets disables TCP FIN and URG and PSH and SEQ=0 checking Denial of Service protections.

Format	<code>no dos-control tcpfinurgpsh</code>
Mode	Global Config



### dos-control icmpv4

This command enables Maximum ICMPv4 Packet Size Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If ICMPv4 Echo Request (PING) packets ingress having a size greater than the configured value, the packets will be dropped if the mode is enabled.

Default	disabled <512>
Format	dos-control icmpv4 <0-16384>
Mode	Global Config

### no dos-control icmpv4

This command disables Maximum ICMP Packet Size Denial of Service protections.

Format	no dos-control icmpv4
Mode	Global Config

### dos-control icmpv6

This command enables Maximum ICMPv6 Packet Size Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If ICMPv6 Echo Request (PING) packets ingress having a size greater than the configured value, the packets will be dropped if the mode is enabled.

Default	disabled <512>
Format	dos-control icmpv6 <0-16384>
Mode	Global Config

### no dos-control icmpv6

This command disables Maximum ICMP Packet Size Denial of Service protections.

Format	no dos-control icmpv6
Mode	Global Config

### dos-control icmpfrag

This command enables ICMP Fragment Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having fragmented ICMP packets, the packets will be dropped if the mode is enabled.

Default	disabled
Format	<code>dos-control icmpfrag</code>
Mode	Global Config

### no dos-control icmpfrag

This command disabled ICMP Fragment Denial of Service protection.

Format	<code>no dos-control icmpfrag</code>
Mode	Global Config

### show dos-control

This command displays Denial of Service configuration information.

Format	<code>show dos-control</code>
Mode	Privileged EXEC

---

**Note:** Not all messages below might be displayed for the M4100 series switches.

---

Term	Definition
First Fragment Mode	May be enabled or disabled. The factory default is disabled.
Min TCP Hdr Size <0-255>	The factory default is 20.
ICMP Mode	May be enabled or disabled. The factory default is disabled.
Max ICMPv4 Pkt Size	The range is 0-1023. The factory default is 512.
Max ICMPv6 Pkt Size	The range is 0-16384. The factory default is 512.
ICMP Fragment Mode	May be enabled or disabled. The factory default is disabled.
L4 Port Mode	May be enabled or disabled. The factory default is disabled.
TCP Port Mode	May be enabled or disabled. The factory default is disabled.
UDP Port Mode	May be enabled or disabled. The factory default is disabled.
SIPDIP Mode	May be enabled or disabled. The factory default is disabled.

Term	Definition
SMACDMAC Mode	May be enabled or disabled. The factory default is disabled.
TCP Flag Mode	May be enabled or disabled. The factory default is disabled.
TCP FIN&URG&PSH Mode	May be enabled or disabled. The factory default is disabled.
TCP Flag & Sequence Mode	May be enabled or disabled. The factory default is disabled.
TCP SYN Mode	May be enabled or disabled. The factory default is disabled.
TCP SYN & FIN Mode	May be enabled or disabled. The factory default is disabled.
TCP Fragment Mode	May be enabled or disabled. The factory default is disabled.
TCP Offset Mode	May be enabled or disabled. The factory default is disabled.

## MAC Database Commands

This section describes the commands you use to configure and view information about the MAC databases.

### bridge aging-time

This command configures the forwarding database address aging timeout in seconds. The *<seconds>* parameter must be within the range of 10 to 1,000,000 seconds.

Default	300
Format	bridge aging-time <i>&lt;seconds&gt;</i>
Mode	Global Config

### no bridge aging-time

This command sets the forwarding database address aging timeout to the default value.

Format	no bridge aging-time
Mode	Global Config

## show forwardingdb agetime

This command displays the timeout for address aging.

Default	300s
Format	show forwardingdb agetime
Mode	Privileged EXEC

Term	Definition
Address Aging Timeout	This parameter displays the address aging timeout for the associated forwarding database.

## show mac-address-table multicast

This command displays the Multicast Forwarding Database (MFDB) information. If you enter the command with no parameter, the entire table is displayed. You can display the table entry for one MAC Address by specifying the MAC address as an optional parameter.

Format	show mac-address-table multicast <macaddr>
Mode	Privileged EXEC

Term	Definition
MAC Address	A multicast MAC address for which the switch has forwarding and or filtering information. The format is two-digit hexadecimal numbers separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as a MAC address and VLAN ID combination of 8 bytes.
Type	The type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.
Component	The component that is responsible for this entry in the Multicast Forwarding Database. Possible values are IGMP Snooping, GMRP, and Static Filtering.
Description	The text description of this multicast table entry.
Interfaces	The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).
Forwarding Interfaces	The resultant forwarding list is derived from combining all the component's forwarding interfaces and removing the interfaces that are listed as the static filtering interfaces.

## show mac-address-table stats

This command displays the Multicast Forwarding Database (MFDB) statistics.

Format	show mac-address-table stats
Mode	Privileged EXEC

Term	Definition
Max MFDB Table Entries	The total number of entries that can possibly be in the Multicast Forwarding Database table.
Most MFDB Entries Since Last Reset	The largest number of entries that have been present in the Multicast Forwarding Database table. This value is also known as the MFDB high-water mark.
Current Entries	The current number of entries in the MFDB.

## ISDP Commands

This section describes the commands you use to configure the industry standard Discovery Protocol (ISDP).

### isdp run

This command enables ISDP on the switch.

Default	Enabled
Format	<code>isdp run</code>
Mode	Global Config

### no isdp run

This command disables ISDP on the switch.

Format	<code>no isdp run</code>
Mode	Global Config

### isdp holdtime

This command configures the hold time for ISDP packets that the switch transmits. The hold time specifies how long a receiving device should store information sent in the ISDP packet before discarding it. You must enter the range in seconds.

Default	180 seconds
Format	<code>isdp holdtime &lt;10-255&gt;</code>
Mode	Global Config

### isdp timer

This command sets the period of time between sending new ISDP packets. You must enter the range in seconds.

Default	30 seconds
Format	<code>isdp timer &lt;5-254&gt;</code>
Mode	Global Config

### isdp advertise-v2

This command enables the sending of ISDP version 2 packets from the device.

Default	Enabled
Format	<code>isdp advertise-v2</code>
Mode	Global Config

### no isdp advertise-v2

This command disables the sending of ISDP version 2 packets from the device.

Format	<code>no isdp advertise-v2</code>
Mode	Global Config

### isdp enable

This command enables ISDP on the interface.

Default	Enabled
Format	<code>isdp enable</code>
Mode	Interface Config

### no isdp enable

This command disables ISDP on the interface.

Format	<code>no isdp enable</code>
Mode	Interface Config

## clear isdp counters

This command clears ISDP counters.

Format	clear isdp counters
Mode	Privileged EXEC

## clear isdp table

This command clears entries in the ISDP table.

Format	clear isdp table
Mode	Privileged EXEC

## show isdp

This command displays global ISDP settings.

Format	show isdp
Mode	Privileged EXEC

Term	Definition
Timer	The frequency with which this device sends ISDP packets. This value is shown in seconds.
Hold Time	The length of time the receiving device should save information sent by this device. This value is shown in seconds.
Version 2 Advertisements	The setting for sending ISDPv2 packets. If disabled, version 1 packets are transmitted.
Device ID	The Device ID advertised by this device. The format of this Device ID is characterized by the value of the Device ID Format object.
Device ID Format Capability	Indicates the Device ID format capability of the device. <ul style="list-style-type: none"> <li>serialNumber indicates that the device uses a serial number as the format for its Device ID.</li> <li>macAddress indicates that the device uses a Layer 2 MAC address as the format for its Device ID.</li> <li>other indicates that the device uses its platform-specific format as the format for its Device ID.</li> </ul>
Device ID Format	Indicates the Device ID format of the device. <ul style="list-style-type: none"> <li>serialNumber indicates that the value is in the form of an ASCII string containing the device serial number.</li> <li>macAddress indicates that the value is in the form of a Layer 2 MAC address.</li> <li>other indicates that the value is in the form of a platform specific ASCII string containing info that identifies the device. For example, ASCII string contains serialNumber appended/prepended with system name.</li> </ul>

## show isdp interface

This command displays ISDP settings for the specified interface.

Format	<code>show isdp interface {all   &lt;slot/port&gt;}</code>
Mode	Privileged EXEC

Term	Definition
Mode	ISDP mode enabled/disabled status for the interface(s).

## show isdp entry

This command displays ISDP entries. If the device id is specified, then only entries for that device are shown.

Format	<code>show isdp entry {all   deviceid}</code>
Mode	Privileged EXEC

Term	Definition
Device ID	The device ID associated with the neighbor which advertised the information.
IP Addresses	The IP address(es) associated with the neighbor.
Platform	The hardware platform advertised by the neighbor.
Interface	The interface (slot/port) on which the neighbor's advertisement was received.
Port ID	The port ID of the interface from which the neighbor sent the advertisement.
Hold Time	The hold time advertised by the neighbor.
Version	The software version that the neighbor is running.
Advertisement Version	The version of the advertisement packet received from the neighbor.
Capability	ISDP Functional Capabilities advertised by the neighbor.

## show isdp neighbors

This command displays the list of neighboring devices.

Format	<code>show isdp neighbors [&lt;slot/port&gt;   detail]</code>
Mode	Privileged EXEC



Term	Definition
Device ID	The device ID associated with the neighbor which advertised the information.
IP Addresses	The IP addresses associated with the neighbor.
Capability	ISDP functional capabilities advertised by the neighbor.
Platform	The hardware platform advertised by the neighbor.
Interface	The interface (slot/port) on which the neighbor's advertisement was received.
Port ID	The port ID of the interface from which the neighbor sent the advertisement.
Hold Time	The hold time advertised by the neighbor.
Advertisement Version	The version of the advertisement packet received from the neighbor.
Entry Last Changed Time	Displays when the entry was last modified.
Version	The software version that the neighbor is running.

**Command example:**

```
(NETGEAR Switch) #show isdp neighbors detail

Device ID           0001f45f1bc0
Address(es):
IP Address:         10.27.7.57
Capability           Router Trans Bridge Switch IGMP
Platform            SecureStack C2
Interface           0/48
Port ID             ge.3.14
Holdtime            131
Advertisement Version 2
Entry last changed time 0 days 00:01:59
Version:            05.00.56
```

**show isdp traffic**

This command displays ISDP statistics.

Format	show isdp traffic
Mode	Privileged EXEC

Term	Definition
ISDP Packets Received	Total number of ISDP packets received
ISDP Packets Transmitted	Total number of ISDP packets transmitted

Term	Definition
ISDPv1 Packets Received	Total number of ISDPv1 packets received
ISDPv1 Packets Transmitted	Total number of ISDPv1 packets transmitted
ISDPv2 Packets Received	Total number of ISDPv2 packets received
ISDPv2 Packets Transmitted	Total number of ISDPv2 packets transmitted
ISDP Bad Header	Number of packets received with a bad header
ISDP Checksum Error	Number of packets received with a checksum error
ISDP Transmission Failure	Number of packets which failed to transmit
ISDP Invalid Format	Number of invalid packets received
ISDP Table Full	Number of times a neighbor entry was not added to the table due to a full database
ISDP IP Address Table Full	Displays the number of times a neighbor entry was added to the table without an IP address.

### debug isdp packet

This command enables tracing of ISDP packets processed by the switch. ISDP must be enabled on both the device and the interface in order to monitor packets for a particular interface.

Format	<code>debug isdp packet [receive   transmit]</code>
Mode	Privileged EXEC

### no debug isdp packet

This command disables tracing of ISDP packets on the receive or the transmit sides or on both sides.

Format	<code>no debug isdp packet [receive   transmit]</code>
Mode	Privileged EXEC

# 3

## 3. Multicast VLAN Registration Commands

---

This chapter contains the following sections:

- *About MVR*
- *MVR Commands*

## About MVR

Internet Group Management Protocol (IGMP) Layer 3 is widely used for IPv4 network multicasting. In Layer 2 networks, IGMP uses resources inefficiently. For example, a Layer 2 switch sends multicast frames to all ports, even if there are receivers connected to only a few ports.

To address this problem, the IGMP Snooping protocol was developed. The problem still appears, though, when receivers are in different VLANs.

Multicast VLAN registration (MVR) is intended to solve the problem of receivers in different VLANs. It uses a dedicated manually configured VLAN, called the multicast VLAN, to forward multicast traffic over a Layer 2 network with IGMP snooping.

## MVR Commands

### mvr

This command enables MVR.

Default	Disabled
Format	mvr
Mode	Global Config Interface Config

### no mvr

This command disables MVR.

Format	no mvr
Mode	Global Config Interface Config

### mvr group

This command adds an MVR membership group. <A.B.C.D> is the IP multicast group being added.

The count is the number of incremental multicast groups being added (the first multicast group is A.B.C.D). If a count is not specified, only one multicast group is added.

Format	mvr group <A.B.C.D> [count]
Mode	Global Config

### no mvr group

This command removes the MVR membership group.

Format	no mvr group <A.B.C.D> [count]
Mode	Global Config

### mvr mode

This command changes the MVR mode type. If the mode is set to compatible, the switch does not learn multicast groups; they need to be configured by the operator as the protocol does not forward joins from the hosts to the router. To operate in this mode, the IGMP router needs to be statically configured to transmit all required multicast streams to the MVR switch. If the mode is set to dynamic, the switch learns existing multicast groups by snooping the IGMP queries from router on source ports and forwarding the IGMP joins from the hosts to the IGMP router on the multicast VLAN (with appropriate translation of the VLAN ID).

Default	compatible
Format	mvr mode {compatible   dynamic}
Mode	Global Config

### no mvr mode

This command sets the mode type to the default value.

Format	no mvr mode
Mode	Global Config

### mvr querytime

This command sets the MVR query response time.

Default	5
Format	mvr querytime <1-100>
Mode	Global Config

### no mvr querytime

This command sets the MVR query response time to the default value.

Format	no mvr querytime
Mode	Global Config

**mvr vlan**

This command sets the MVR multicast VLAN.

Default	1
Format	mvr vlan <1-4094>
Mode	Global Config

**no mvr vlan**

This command sets the MVR multicast VLAN to the default value.

Format	no mvr vlan
Mode	Global Config

**mvr immediate**

This command enables MVR immediate leave mode. MVR has two modes of operating with the IGMP Leave messages: normal leave and immediate leave:

- In normal leave mode, when a leave is received, the general IGMP query is sent from a Layer 2 switch to the receiver port, where the leave was received. Then reports are received from other interested hosts that are also connected to that port, for example, using hub.
- In immediate leave mode, when a leave is received, the switch is immediately reconfigured not to forward a specific multicast stream to the port where a message is received. This mode is used only for ports where only one client might be connected.

Default	Disabled
Format	mvr immediate
Mode	Interface Config

**no mvr immediate**

This command sets the MVR multicast VLAN to the default value.

Format	no mvr immediate
Mode	Interface Config

### mvr type

This command sets the MVR port type. When a port is set as source, it is the port to which the multicast traffic flows using the multicast VLAN. When a port is set to receiver, it is the port where a listening host is connected to the switch.

Default	none
Format	mvr type {receiver   source}
Mode	Interface Config

### no mvr type

Use this command to set the MVR port type to none.

Format	no mvr type
Mode	Interface Config

### mvr vlan group

Use this command to include the port in the specific MVR group. *<mVLAN>* is the multicast VLAN, and *<A.B.C.D>* is the IP multicast group

Format	mvr vlan <i>&lt;mVLAN&gt;</i> group <i>&lt;A.B.C.D&gt;</i>
Mode	Interface Config

### no mvr vlan

Use this command to exclude the port from the specific MVR group.

Format	no mvr vlan <i>&lt;mVLAN&gt;</i> group <i>&lt;A.B.C.D&gt;</i>
Mode	Interface Config

### show mvr

This command displays global MVR settings.

Format	show mvr
Mode	Privileged EXEC

The following table explains the output parameters.

Term	Definition
MVR Running	MVR running state. It can be enabled or disabled.
MVR multicast VLAN	Current MVR multicast VLAN. It can be in the range from 1 to 4094.
MVR Max Multicast Groups	The maximum number of multicast groups supported by MVR.
MVR Current multicast groups	The current number of MVR groups allocated.
MVR Query response time	The current MVR query response time.
MVR Mode	The current MVR mode. It can be compatible or dynamic.

#### Command example:

```
(NETGEAR Switch)#show mvr
MVR Running..... TRUE
MVR multicast VLAN..... 1200
MVR Max Multicast Groups..... 256
MVR Current multicast groups..... 1
MVR Global query response time..... 10 (tenths of sec)
MVR Mode..... compatible
```

### show mvr members

This command displays the MVR membership groups allocated. <A.B.C.D> is a valid multicast address in IPv4 dotted notation.

Format	show mvr members [<A.B.C.D>]
Mode	Privileged EXEC

The following table describes the output parameters.

Term	Definition
MVR Group IP	MVR group multicast IP address.
Status	The status of the specific MVR group. It can be active or inactive.
Members	The list of ports that participates in the specified MVR group.

#### Command example:

```
(NETGEAR Switch)#show mvr members
MVR Group IP      Status           Members
-----
224.1.1.1        INACTIVE        0/1, 0/2, 0/3
```



**Command example:**

```
(NETGEAR Switch)#show mvr members 224.1.1.1
MVR Group IP          Status                Members
-----
224.1.1.1            INACTIVE              0/1, 0/2, 0/3
```

**show mvr interface**

This command displays the MVR-enabled interfaces configuration.

Format	show mvr interface [<interface-id> [members [vlan <vid>]]]
Mode	Privileged EXEC

The following table explains the output fields.

Field	Description
Port	Interface number
Type	The MVR port type. It can be none, receiver, or source type.
Status	The interface status. It consists of two characteristics: <ul style="list-style-type: none"> <li>active or inactive indicates whether the port is forwarding.</li> <li>inVLAN or notInVLAN indicates whether the port is part of any VLAN.</li> </ul>
Immediate Leave	The state of immediate mode. It can be enabled or disabled.

**Command example:**

```
(NETGEAR Switch)#show mvr interface
Port      Type          Status          Immediate Leave
-----
0/9      RECEIVER     ACTIVE/inVLAN   DISABLED
```

**Command example:**

```
(NETGEAR Switch)#show mvr interface 0/9
Type: RECEIVER Status: ACTIVE Immediate Leave: DISABLED
```

**Command example:**

```
(NETGEAR Switch)#show mvr interface 0/23 members
235.0.0.1 STATIC ACTIVE
```

**Command example:**

```
(NETGEAR Switch)#show mvr interface 0/23 members vlan 12
235.0.0.1 STATIC ACTIVE
235.1.1.1 STATIC ACTIVE
```

**show mvr traffic**

This command displays global MVR statistics.

Format	show mvr traffic
Mode	Privileged EXEC

The following table explains the output parameters.

Term	Definition
IGMP Query Received	Number of received IGMP queries
IGMP Report V1 Received	Number of received IGMP reports V1
IGMP Report V2 Received	Number of received IGMP reports V2
IGMP Leave Received	Number of received IGMP leaves
IGMP Query Transmitted	Number of transmitted IGMP queries
IGMP Report V1 Transmitted	Number of transmitted IGMP reports V1
IGMP Report V2 Transmitted	Number of transmitted IGMP reports V2
IGMP Leave Transmitted	Number of transmitted IGMP leaves
IGMP Packet Receive Failures	Number of failures on receiving the IGMP packets
IGMP Packet Transmit Failures	Number of failures on transmitting the IGMP packets

**Command example:**

```
(NETGEAR Switch)#show mvr traffic
```

```
IGMP Query Received..... 2
IGMP Report V1 Received..... 0
IGMP Report V2 Received..... 3
IGMP Leave Received..... 0
IGMP Query Transmitted..... 2
IGMP Report V1 Transmitted..... 0
IGMP Report V2 Transmitted..... 3
IGMP Leave Transmitted..... 1
IGMP Packet Receive Failures..... 0
IGMP Packet Transmit Failures..... 0
```

## 4 Routing Commands

---

This chapter describes the routing commands.

The chapter contains the following sections:

- *Address Resolution Protocol (ARP) Commands*
- *IP Routing Commands*
- *Virtual LAN Routing Commands*
- *DHCP and BOOTP Relay Commands*
- *IP Helper Commands*
- *ICMP Throttling Commands*

The commands in this chapter are in three functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. Every switch command has a show command that displays the configuration setting.
- Clear commands clear some or all of the settings to factory defaults.

## Address Resolution Protocol (ARP) Commands

This section describes the commands you use to configure ARP and to view ARP information about the switch. ARP associates IP addresses with MAC addresses and stores the information as ARP entries in the ARP cache.

### arp

This command creates an ARP entry. The value for *<ipaddress>* is the IP address of a device on a subnet attached to an existing routing interface. *<macaddr>* is a unicast MAC address for that device.

The format of the MAC address is 6 two-digit hexadecimal numbers that are separated by colons, for example 00:06:29:32:81:40.

Format	<code>arp &lt;ipaddress&gt; &lt;macaddr&gt;</code>
Mode	Global Config

### no arp

This command deletes an ARP entry. The value for *<arpentry>* is the IP address of the interface. The value for *<ipaddress>* is the IP address of a device on a subnet attached to an existing routing interface. *<macaddr>* is a unicast MAC address for that device.

Format	<code>no arp &lt;ipaddress&gt; &lt;macaddr&gt;</code>
Mode	Global Config

### ip local-proxy-arp

This command enables local-proxy-arp on interface or range of interfaces. The switch only responds if all next hops in its route to the destination are through interfaces other than the interface that received the ARP request. Enabling local proxy ARP removes this restriction.

Default	disabled
Format	<code>ip local-proxy-arp</code>
Mode	Interface Config

### no ip local-proxy-arp

This command disables local-proxy-arp on the interface or a range of interfaces.

Format	<code>no ip local-proxy-arp</code>
Mode	Interface Config

### ip proxy-arp

This command enables proxy ARP on a router interface. Without proxy ARP, a device only responds to an ARP request if the target IP address is an address configured on the interface where the ARP request arrived. With proxy ARP, the device might also respond if the target IP address is reachable. The device responds only if all next hops in its route to the destination are through interfaces other than the interface that received the ARP request.

Default	enabled
Format	ip proxy-arp
Mode	Interface Config

### no ip proxy-arp

This command disables proxy ARP on a router interface.

Format	no ip proxy-arp
Mode	Interface Config

### arp cachesize

This command configures the ARP cache size. The ARP cache size value is a platform-specific integer value. The default size also varies depending on the platform.

Format	arp cachesize <i>&lt;platform specific integer value&gt;</i>
Mode	Global Config

### no arp cachesize

This command configures the default ARP cache size.

Format	no arp cachesize
Mode	Global Config

### arp dynamicrenew

This command enables the ARP component to automatically renew dynamic ARP entries when they age out.

Default	enabled
Format	arp dynamicrenew
Mode	Privileged EXEC

### no arp dynamicrenew

This command prevents dynamic ARP entries from renewing when they age out.

Format	no arp dynamicrenew
Mode	Privileged EXEC

### arp purge

This command causes the specified IP address to be removed from the ARP cache. Only entries of type dynamic or gateway are affected by this command.

Format	arp purge <ipaddr>
Mode	Privileged EXEC

### arp resptime

This command configures the ARP request response time-out.

The value for <seconds> is a valid positive integer, which represents the IP ARP entry response time-out time in seconds. The range for <seconds> is between 1-10 seconds.

Default	1
Format	arp resptime <seconds>
Mode	Global Config

### no arp resptime

This command configures the default ARP request response time-out.

Format	no arp resptime
Mode	Global Config

### arp retries

This command configures the ARP count of maximum request for retries.

The value for <retries> is an integer, which represents the maximum number of requests for retries. The range for <retries> is an integer between 0-10 retries.

Default	4
Format	arp retries <retries>
Mode	Global Config

### no arp retries

This command configures the default ARP count of maximum request for retries.

Format	no arp retries
Mode	Global Config

### arp timeout

This command configures the ARP entry ageout time.

The value for *<seconds>* is a valid positive integer, which represents the IP ARP entry ageout time in seconds. The range for *<seconds>* is between 15-21600 seconds.

Default	1200
Format	arp timeout <i>&lt;seconds&gt;</i>
Mode	Global Config

### no arp timeout

This command configures the default ARP entry ageout time.

Format	no arp timeout
Mode	Global Config

### clear arp-cache

This command causes all ARP entries of type dynamic to be removed from the ARP cache. If the *gateway* keyword is specified, the dynamic entries of type gateway are purged as well.

Format	clear arp-cache [gateway]
Mode	Privileged EXEC

### clear arp-switch

Use this command to clear the contents of the switch's Address Resolution Protocol (ARP) table that contains entries learned through the Management port. To observe whether this command is successful, **ping** from the remote system to the DUT. Issue the **show arp switch** command to see the ARP entries. Then issue the **clear arp-switch** command and check the **show arp switch** entries. There will be no more arp entries.

Format	clear arp-switch
Mode	Privileged EXEC

## show arp

This command displays the Address Resolution Protocol (ARP) cache. The displayed results are not the total ARP entries. To view the total ARP entries, the operator should view the **show arp** results with the **show arp switch** results.

Format	show arp
Mode	Privileged EXEC

Term	Definition
Age Time (seconds)	The time it takes for an ARP entry to age out. This is configurable. Age time is measured in seconds.
Response Time (seconds)	The time it takes for an ARP request timeout. This value is configurable. Response time is measured in seconds.
Retries	The maximum number of times an ARP request is retried. This value is configurable.
Cache Size	The maximum number of entries in the ARP table. This value is configurable.
Dynamic Renew Mode	Displays whether the ARP component automatically attempts to renew dynamic ARP entries when they age out.
Total Entry Count Current / Peak	The total entries in the ARP table and the peak entry count in the ARP table.
Static Entry Count Configured/Active / Max	The static entry count in the ARP table, the active entry count in the ARP table, the active entry count in the ARP table, and maximum static entry count in the ARP table.

The following are displayed for each ARP entry:

Term	Definition
IP Address	The IP address of a device on a subnet attached to an existing routing interface.
MAC Address	The hardware MAC address of that device.
Interface	The routing slot/port associated with the device ARP entry.
Type	The type that is configurable. The possible values are Local, Gateway, Dynamic and Static.
Age	The current age of the ARP entry since last refresh (in hh:mm:ss format)

## show arp brief

This command displays the brief Address Resolution Protocol (ARP) table information.

Format	show arp brief
Mode	Privileged EXEC



Term	Definition
Age Time (seconds)	The time it takes for an ARP entry to age out. This value is configurable. Age time is measured in seconds.
Response Time (seconds)	The time it takes for an ARP request timeout. This value is configurable. Response time is measured in seconds.
Retries	The maximum number of times an ARP request is retried. This value is configurable.
Cache Size	The maximum number of entries in the ARP table. This value is configurable.
Dynamic Renew Mode	Displays whether the ARP component automatically attempts to renew dynamic ARP entries when they age out.
Total Entry Count Current / Peak	The total entries in the ARP table and the peak entry count in the ARP table.
Static Entry Count Current / Max	The static entry count in the ARP table and maximum static entry count in the ARP table.

### show arp switch (Address Resolution Protocol commands)

This command displays the contents of the switch's Address Resolution Protocol (ARP) table.

Format	show arp switch
Mode	Privileged EXEC

Term	Definition
IP Address	The IP address of a device on a subnet attached to the switch.
MAC Address	The hardware MAC address of that device.
Interface	The routing slot/port associated with the device's ARP entry.

## IP Routing Commands

This section describes the commands you use to enable and configure IP routing on the switch.

### routing

This command enables IPv4 and IPv6 routing for an interface. You can view the current value for this function with the `show ip brief` command. The value is labeled as “Routing Mode.”

Default	disabled
Format	routing
Mode	Interface Config

### no routing

This command disables routing for an interface.

You can view the current value for this function with the `show ip brief` command. The value is labeled as “Routing Mode.”

Format	no routing
Mode	Interface Config

### ip routing

This command enables the IP Router Admin Mode for the master switch.

Format	ip routing
Mode	Global Config

### no ip routing

This command disables the IP Router Admin Mode for the master switch.

Format	no ip routing
Mode	Global Config

### ip address

This command configures an IP address on an interface. You can also use this command to configure one or more secondary IP addresses on the interface. The command supports RFC 3021 and accepts using 31-bit prefixes on IPv4 point-to-point links. This command adds the label IP address in `show ip interface`.

---

**Note:** The 31-bit subnet mask is only supported on routing interface. This feature is not supported on a network port because it acts as a host, not a router, on the management interface.

---

Format	<code>ip address &lt;ipaddr&gt; {&lt;subnetmask&gt;   /&lt;prefix-length&gt;} [secondary]</code>
Mode	Interface Config

Parameter	Description
<ipaddr>	The IP address of the interface.
<subnetmask>	A four-digit dotted-decimal number that represents the subnet mask of the interface
<prefix-length>	Implements RFC 3021. Using the / notation of the subnet mask, this is an integer that indicates the length of the subnet mask. Range is 5–32 bits.

### no ip address

This command deletes an IP address from an interface. The value for <ipaddr> is the IP address of the interface in a.b.c.d format where the range for a, b, c, and d is 1-255. The value for <subnetmask> is a 4-digit dotted-decimal number which represents the subnet mask of the interface. To remove all of the IP addresses (primary and secondary) configured on the interface, enter the command **no ip address**.

Format	<code>no ip address [&lt;ipaddr&gt; {&lt;subnetmask&gt;   /&lt;prefix-length&gt;} [secondary]]</code>
Mode	Interface Config

### ip address dhcp

Use this command to enable the DHCPv4 client on an in-band interface so that it can acquire network information, such as the IP address, subnet mask, and default gateway from a network DHCP server. When DHCP is enabled on the interface, the system automatically deletes all manually configured IPv4 addresses on the interface.

Default	disabled
Format	<code>ip address dhcp</code>
Mode	Interface Config

### no ip address dhcp

Use this command to release a leased address and disable DHCPv4 on an interface.

Format	<code>no ip address dhcp</code>
Mode	Interface Config

### ip default-gateway

Use this command to manually configure a default gateway for the switch. Only one default gateway can be configured. If you use this command multiple times, each command replaces the previous value.

Format	<code>ip default-gateway &lt;ipaddr&gt;</code>
Mode	Global Config

### no ip default-gateway

Use this command to remove the default gateway address from the configuration.

Format	<code>no ip default-gateway &lt;ipaddr&gt;</code>
Mode	Interface Config

### release dhcp

Use this command to force the DHCPv4 client to release the leased address from the specified interface.

Format	<code>release dhcp &lt;slot/port&gt;</code>
Mode	Privileged EXEC

### renew dhcp

Use this command to force the DHCPv4 client to immediately renew an IPv4 address lease on the specified interface.

Format	<code>renew dhcp {&lt;slot/port&gt;   network-port}</code>
Mode	Privileged EXEC

---

**Note:** This command can be used on in-band ports as well as network (out-of-band) port.

---

## show dhcp lease

Use this command to display a list of IPv4 addresses currently leased from a DHCP server on a specific in-band interface or all in-band interfaces. This command does not apply to service or network ports.

Format	show dhcp lease [interface <slot/port>]
Mode	Privileged EXEC

Term	Definition
IP address, Subnet mask	The IP address and network mask leased from the DHCP server.
DHCP Lease server	The IPv4 address of the DHCP server that leased the address.
State	State of the DHCPv4 Client on this interface.
DHCP transaction ID	The transaction ID of the DHCPv4 Client.
Lease	The time (in seconds) that the IP address was leased by the server.
Renewal	The time (in seconds) when the next DHCP renew Request is sent by DHCPv4 Client to renew the leased IP address.
Rebind	The time (in seconds) when the DHCP Rebind process starts.
Retry count	Number of times the DHCPv4 client sends a DHCP REQUEST message before the server responds.

## ip route

This command configures a static route. The *<ipaddr>* parameter is a valid IP address, and *<subnetmask>* is a valid subnet mask. The *<nexthopip>* parameter is a valid IP address of the next hop router. Specifying `Null0` as nexthop parameter adds a static reject route. The optional *<preference>* parameter is an integer (value from 1 to 255) that allows you to specify the preference value (sometimes called “administrative distance”) of an individual static route. Among routes to the same destination, the route with the lowest preference value is the route entered into the forwarding database. By specifying the preference of a static route, you control whether a static route is more or less preferred than routes from dynamic routing protocols. The preference also controls whether a static route is more or less preferred than other static routes to the same destination. A route with a preference of 255 cannot be used to forward traffic.

For the static routes to be visible, you must perform the following steps:

- Enable IP routing globally.
- Enable IP routing for the interface.
- Confirm that the associated link is also up

Default	preference—1
Format	<code>ip route &lt;ipaddr&gt; &lt;subnetmask&gt; [&lt;nexthopip&gt;   Null0] [&lt;preference&gt;]</code>
Mode	Global Config

### no ip route

This command deletes a single next hop to a destination static route. If you use the `<nexthopip>` parameter, the next hop is deleted. If you use the `<preference>` value, the preference value of the static route is reset to its default.

Format	<code>no ip route &lt;ipaddr&gt; &lt;subnetmask&gt; [&lt;nexthopip&gt;   Null0] [&lt;preference&gt;]</code>
Mode	Global Config

### ip route default

This command configures the default route. The value for `<nexthopip>` is a valid IP address of the next hop router. The `<preference>` is an integer value from 1 to 255. A route with a preference of 255 cannot be used to forward traffic.

Default	preference—1
Format	<code>ip route default &lt;nexthopip&gt; [&lt;preference&gt;]</code>
Mode	Global Config

### no ip route default

This command deletes all configured default routes. If the optional `<nexthopip>` parameter is designated, the specific next hop is deleted from the configured default route and if the optional preference value is designated, the preference of the configured default route is reset to its default.

Format	<code>no ip route default [&lt;nexthopip&gt;   &lt;preference&gt;]</code>
Mode	Global Config

### ip route distance

This command sets the default distance (preference) for static routes. Lower route distance values are preferred when determining the best route. The `ip route` and `ip route default` commands allow you to optionally set the distance (preference) of an individual static route. The default distance is used when no distance is specified in these commands. Changing the default distance does not update the distance of existing static routes, even if they were assigned the original default distance. The new default distance will only be applied to static routes created after invoking the `ip route distance` command.

Default	1
Format	<code>ip route distance &lt;1-255&gt;</code>
Mode	Global Config

### no ip route distance

This command sets the default static route preference value in the router. Lower route preference values are preferred when determining the best route.

Format	<code>no ip route distance</code>
Mode	Global Config

### ip netdirbcast

This command enables the forwarding of network-directed broadcasts. When enabled, network directed broadcasts are forwarded. When disabled they are dropped.

Default	disabled
Format	<code>ip netdirbcast</code>
Mode	Interface Config

### no ip netdirbcast

This command disables the forwarding of network-directed broadcasts. When disabled, network directed broadcasts are dropped.

Format	<code>no ip netdirbcast</code>
Mode	Interface Config

### ip mtu

This command sets the IP maximum transmission unit (MTU) on a routing interface. The IP MTU is the size of the largest IP packet that can be transmitted on the interface without fragmentation. The software currently does not fragment IP packets.

- Packets forwarded in hardware ignore the IP MTU.
- Packets forwarded in software are dropped if they exceed the IP MTU of the outgoing interface.

Packets originated on the router, such as OSPF packets, might be fragmented by the IP stack. The IP stack uses its default IP MTU and ignores the value set using the `ip mtu` command.

OSPF advertises the IP MTU in the Database Description packets it sends to its neighbors during database exchange. If two OSPF neighbors advertise different IP MTUs, they will not form an adjacency. (unless OSPF has been instructed to ignore differences in IP MTU with the `ip ospf mtu-ignore` command.)

---

**Note:** The IP MTU size refers to the maximum size of the IP packet (IP Header + IP payload). It does not include any extra bytes that might be required for Layer-2 headers. To receive and process packets, the Ethernet MTU must take into account the size of the Ethernet header.

---

Default	1500 bytes
Format	<code>ip mtu &lt;68-9198&gt;</code>
Mode	Interface Config

### no ip mtu

This command resets the IP MTU to the default value.

Format	<code>no ip mtu</code>
Mode	Interface Config

### encapsulation

This command configures the link layer encapsulation type for the packet. The encapsulation type can be `ethernet` or `snap`.

Default	ethernet
Format	<code>encapsulation {ethernet   snap}</code>
Mode	Interface Config

---

**Note:** Routed frames are always Ethernet encapsulated when a frame is routed to a VLAN.

---

### clear ip route all

This command removes all the route entries learned over the network.

Format	<code>clear ip route all</code>
Mode	Privileged EXEC



Protocol	Tells which protocol added the specified route. The possibilities are: local, static, OSPF, or RIP.
Total Number of Routes	The total number of routes.

### clear ip route counters

This command resets to zero the IPv4 routing table counters reported in the output of the **show ip route summary** command. The command resets only the event counters. Counters that report the current state of the routing table, such as the number of routes of each type, are not reset.

Format	<code>clear ip route counters</code>
Mode	Privileged EXEC

### show ip brief

This command displays all the summary information of the IP, including the ICMP rate limit configuration and the global ICMP Redirect configuration.

Format	<code>show ip brief</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Default Time to Live	The computed TTL (Time to Live) of forwarding a packet from the local router to the final destination.
Routing Mode	Shows whether the routing mode is enabled or disabled.
Maximum Next Hops	The maximum number of next hops the packet can travel.
Maximum Routes	The maximum number of routes the packet can travel.
ICMP Rate Limit Interval	Shows how often the token bucket is initialized with burst-size tokens. Burst-interval is from 0 to 2,147,483,647 milliseconds. The default burst-interval is 1000 msec.
ICMP Rate Limit Burst Size	Shows the number of ICMPv4 error messages that can be sent during one burst-interval. The range is from 1 to 200 messages. The default value is 100 messages.
ICMP Echo Replies	Shows whether ICMP Echo Replies are enabled or disabled.
ICMP Redirects	Shows whether ICMP Redirects are enabled or disabled.

**Command example:**

```
(NETGEAR Switch) #show ip brief
```

```
Default Time to Live..... 64
Routing Mode..... Disabled
Maximum Next Hops..... 4
Maximum Routes..... 6000
ICMP Rate Limit Interval..... 1000 msec
ICMP Rate Limit Burst Size..... 100 messages
ICMP Echo Replies..... Enabled
ICMP Redirects..... Enabled
```

**show ip interface**

This command displays all pertinent information about the IP interface.

Format	show ip interface {<slot/port>   vlan <1-4093>   loopback <0-7>}
Modes	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Routing Interface Status	Determine the operational status of IPv4 routing Interface. The possible values are Up or Down.
Primary IP Address	The primary IP address and subnet masks for the interface. This value appears only if you configure it.
Secondary IP Address	One or more secondary IP addresses and subnet masks for the interface. This value appears only if you configure it.
Method	Shows whether the IP address was configured manually or acquired from a DHCP server.
Routing Mode	The administrative mode of router interface participation. The possible values are enable or disable. This value is configurable.
Administrative Mode	The administrative mode of the specified interface. The possible values of this field are enable or disable. This value is configurable.
Forward Net Directed Broadcasts	Displays whether forwarding of network-directed broadcasts is enabled or disabled. This value is configurable.
Proxy ARP	Displays whether Proxy ARP is enabled or disabled on the system.
Local Proxy ARP	Displays whether Local Proxy ARP is enabled or disabled on the interface.
Active State	Displays whether the interface is active or inactive. An interface is considered active if its link is up and it is in forwarding state.

Term	Definition
Link Speed Data Rate	An integer representing the physical link data rate of the specified interface. This is measured in Megabits per second (Mbps).
MAC Address	The burned in physical address of the specified interface. The format is 6 two-digit hexadecimal numbers that are separated by colons.
Encapsulation Type	The encapsulation type for the specified interface. The types are: Ethernet or SNAP.
IP MTU	The maximum transmission unit (MTU) size of a frame, in bytes.
Bandwidth	Shows the bandwidth of the interface.
Destination Unreachables	Displays whether ICMP Destination Unreachables might be sent (enabled or disabled).
ICMP Redirects	Displays whether ICMP Redirects might be sent (enabled or disabled).

**Command example:**

```
(NETGEAR Switch) >show ip interface 0/2
Routing Interface Status..... Down
Method..... None
Routing Mode..... Disable
Administrative Mode..... Enable
Forward Net Directed Broadcasts..... Disable
Proxy ARP..... Enable
Local Proxy ARP..... Disable
Active State..... Inactive
Link Speed Data Rate..... Inactive
MAC address..... 02:14:6C:FF:00:DE
Encapsulation Type..... Ethernet
IP MTU..... 1500
Bandwidth..... 100000 kbps
Destination Unreachables..... Enabled
ICMP Redirects..... Disabled
```

**show ip interface brief**

This command displays summary information about IP configuration settings for all ports in the router.

Format	show ip interface brief
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
State	Routing operational state of the interface.
IP Address	The IP address of the routing interface in 32-bit dotted decimal format.
IP Mask	The IP mask of the routing interface in 32-bit dotted decimal format.
Netdir Bcast	Indicates if IP forwards net-directed broadcasts on this interface. Possible values are Enable or Disable.
MultiCast Fwd	The multicast forwarding administrative mode on the interface. Possible values are Enable or Disable.
Method	Shows whether the IP address was configured manually or acquired from a DHCP server.

## show ip protocols

This command lists a summary of the configuration and status for each unicast routing protocol. The command lists routing protocols that are configured and enabled. If a protocol is selected on the command line, the display is limited to that protocol.

Format	<code>show ip protocols [ospf   rip]</code>
Mode	Privileged EXEC

Parameter	Description
OSPFv2	
Router ID	The router ID configured for OSPFv2
OSPF Admin Mode	Whether OSPF is enabled or disabled globally
Maximum Paths	The maximum number of next hops in an OSPF route
Routing for Networks	The address ranges configured with an OSPF network command
Distance	The administrative distance (or route preference) for intra-area, inter-area, and external routes
Default Route Advertise	Whether OSPF is configured to originate a default route
Always	Whether default advertisement depends on having a default route in the common routing table
Metric	The metric configured to be advertised with the default route
Metric Type	The metric type for the default route
Redist Source	A type of routes that OSPF is redistributing
Metric	The metric to advertise for redistributed routes of this type

Parameter	Description
Metric Type	The metric type to advertise for redistributed routes of this type
Subnets	Whether OSPF redistributes subnets of classful addresses, or only classful prefixes
Dist List	A distribute list used to filter routes of this type. Only routes that pass the distribute list are redistributed
Number of Active Areas	The number of OSPF areas with at least one interface running on this router. Also broken down by area type
ABR Status	Whether the router is an area border router. A router is an area border router if it has interfaces that are up in more than one area
ASBR Status	Whether the router is an autonomous system boundary router. The router is an ASBR if it is redistributing any routes or originating a default route
RIP	
Split Horizon Mode	Whether RIP advertises routes on the interface where they were received
Default Metric	The metric assigned to redistributed routes
Default Route Advertise	Whether this router is originating a default route
Distance	The administrative distance for RIP routes
Redistribution	A table showing information for each source protocol (connected, static, BGP, and OSPF). For each of these sources the distribution list and metric are shown. Fields which are not configured are left blank. For ospf, configured ospf match parameters are also shown
Interface	The interfaces where RIP is enabled and the version sent and accepted on each interface

## show ip route

This command displays the routing table. The *<ip-address>* specifies the network for which the route is to be displayed and displays the best matching best-route for the address. The *<mask>* specifies the subnet mask for the *<ip-address>*. When you use the **longer-prefixes** keyword, the *<ip-address>* and *<mask>* pair becomes the prefix, and the command displays the routes to the addresses that match that prefix. Use the *<protocol>* parameter to specify the protocol that installed the routes. The value for *<protocol>* can be **connected**, **ospf**, **rip**, or **static**. Use the **all** parameter to display all routes including best and non-best routes. If you do not use the **all** parameter, the command only displays the best route.

A “T” flag appended to a route indicates that it is an ECMP route, but only one of its next hops has been installed in the forwarding table. The forwarding table might limit the number of ECMP routes or the number of ECMP groups. When an ECMP route cannot be installed because such a limit is reached, the route is installed with a single next hop. Such truncated routes can be identified by a “T” after the interface name.

---

**Note:** If you use the **connected** keyword for *<protocol>*, the **all** option is not available because there are no best or non-best connected routes.

---

Format	show ip route [{<ip-address> [<protocol>]   {<ip-address> <mask> [longer-prefixes] [<protocol>]   <protocol>} [all]   all}]
Modes	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Route Codes	The key for the routing protocol codes that might appear in the routing table output.

The **show ip route** command displays the routing tables in the following format:

Code IP-Address/Mask [Preference/Metric] via Next-Hop, Route-Timestamp, Interface

The columns for the routing table display the following information:

Term	Definition
Code	The codes for the routing protocols that created the routes.
IP-Address/Mask	The IP-Address and mask of the destination network corresponding to this route.
Preference	The administrative distance associated with this route. Routes with low values are preferred over routes with higher values.
Metric	The cost associated with this route.
via Next-Hop	The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.
Route-Timestamp	The last updated time for dynamic routes. The format of Route-Timestamp will be <ul style="list-style-type: none"> <li>Days:Hours:Minutes if days &gt; = 1</li> <li>Hours:Minutes:Seconds if days &lt; 1</li> </ul>
Interface	The outgoing router interface to use when forwarding traffic to the next destination. For reject routes, the next hop interface would be Null0 interface.

To administratively control the traffic destined to a particular network and prevent it from being forwarded through the router, you can configure a static reject route on the router. Such traffic would be discarded and the ICMP destination unreachable message is sent back to the source. This is typically used for preventing routing loops. The reject route added in the RTO is of the type OSPF Inter-Area. Reject routes (routes of REJECT type installed by any protocol) are not redistributed by OSPF/RIP. Reject routes are supported in both OSPFv2 and OSPFv3.

**Command example:**

```
(NETGEAR Switch) #show ip route
```

```
Route Codes: R - RIP Derived, O - OSPF Derived, C - Connected, S - Static
```

```
  B - BGP Derived, IA - OSPF Inter Area
```

```
  E1 - OSPF External Type 1, E2 - OSPF External Type 2
```

```
  N1 - OSPF NSSA External Type 1, N2 - OSPF NSSA External Type 2
```

```
C 1.1.1.0/24 [0/1] directly connected, 0/11
C 2.2.2.0/24 [0/1] directly connected, 0/1
C 5.5.5.0/24 [0/1] directly connected, 0/5
S 7.0.0.0/8 [1/0] directly connected, Null0
OIA 10.10.10.0/24 [110/6] via 5.5.5.2, 00h:00m:01s, 0/5
C 11.11.11.0/24 [0/1] directly connected, 0/11
S 12.0.0.0/8 [5/0] directly connected, Null0
S 23.0.0.0/8 [3/0] directly connected, Null0
```

**show ip route ecmp-groups**

This command reports all current ECMP groups in the IPv4 routing table. An ECMP group is a set of two or more next hops used in one or more routes. The groups are numbered arbitrarily from 1 to  $n$ . The output indicates the number of next hops in the group and the number of routes that use the set of next hops. The output lists the IPv4 address and outgoing interface of each next hop in each group.

Format	show ip route ecmp-groups
Mode	Privileged EXEC

**Command example:**

```
(NETGEAR Switch) #show ip route ecmp-groups
```

```
ECMP Group 1 with 2 next hops (used by 1 route)
```

```
  172.20.33.100 on interface 2/33
```

```
  172.20.34.100 on interface 2/34
```

```
ECMP Group 2 with 3 next hops (used by 1 route)
```

```
  172.20.32.100 on interface 2/32
```

```
  172.20.33.100 on interface 2/33
```

```
  172.20.34.100 on interface 2/34
```

```
ECMP Group 3 with 4 next hops (used by 1 route)
```

```
  172.20.31.100 on interface 2/31
```

```
  172.20.32.100 on interface 2/32
```

```
  172.20.33.100 on interface 2/33
```

```
  172.20.34.100 on interface 2/34
```

## show ip route summary

Use this command to display the routing table summary. Use the optional *all* parameter to show the number of all routes, including best and non-best routes. To include only the number of best routes, do not use the optional parameter.

If you enter the optional **a11** keyword, some statistics, such as the number of routes from each source, include counts for alternate routes. An alternate route is a route that is not the most preferred route to its destination and therefore is not installed in the forwarding table. If you do not enter the optional **a11** keyword, the output reports only the best routes.

Format	<code>show ip route summary [all]</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Connected Routes	The total number of connected routes in the routing table.
Static Routes	Total number of static routes in the routing table.
RIP Routes	Total number of routes installed by RIP protocol.
OSPF Routes	Total number of routes installed by OSPF protocol.
Reject Routes	Total number of reject routes installed by all protocols.
Total Routes	Total number of routes in the routing table.
Best Routes	The number of best routes currently in the routing table. This number counts only the best route to each destination.
Alternate Routes	The number of alternate routes currently in the routing table. An alternate route is one that was not selected as the best route to its destination.
Route Adds	The number of routes added to the routing table.
Route Modifies	The number of routes that changed after they were initially added to the routing table.
Route Deletes	The number of routes that deleted from the routing table.
Unresolved Route Adds	The number of route adds that failed because none of the route's next hops were on a local subnet. Note that static routes can fail to be added to the routing table at startup because the routing interfaces are not up yet. This counter gets incremented in this case. The static routes are added to the routing table when the routing interfaces come up.
Invalid Route Adds	The number of routes that failed to be added to the routing table because the route was invalid. A log message is written for each of these failures.
Failed Route Adds	The number of routes that failed to be added to the routing table because of a resource limitation in the routing table.
Reserved Locals	The number of routing table entries reserved for a local subnet on a routing interface that is down. Space for local routes is always reserved so that local routes can be installed when a routing interface bounces.



Term	Definition
Unique Next Hops	The number of distinct next hops used among all routes currently in the routing table. These include local interfaces for local routes and neighbors for indirect routes.
Unique Next Hops High Water	The highest count of unique next hops since the counters were last cleared.
Next Hop Groups	The current number of next hop groups in use by one or more routes. Each next hop group includes one or more next hops.
Next Hop Groups High Water	The highest count of next hop groups since the counters were last cleared.
ECMP Groups	The number of next hop groups with multiple next hops.
ECMP Routes	The number of routes with multiple next hops currently in the routing table.
Truncated ECMP Routes	The number of ECMP routes that are currently installed in the forwarding table with just one next hop. The forwarding table might limit the number of ECMP routes or the number of ECMP groups. When an ECMP route cannot be installed because the limit is reached, the route is installed with a single next hop.
ECMP Retries	The number of ECMP routes that have been installed in the forwarding table after initially being installed with a single next hop.
Routes with n Next Hops	The current number of routes with each number of next hops.

**Command example:**

```
(NETGEAR Switch) #show ip route summary
Connected Routes..... 7
Static Routes..... 1
RIP Routes..... 20
OSPF Routes..... 1004
  Intra Area Routes..... 4
  Inter Area Routes..... 1000
  External Type-1 Routes..... 0
  External Type-2 Routes..... 0
Reject Routes..... 0
Total routes..... 1032
Best Routes (High)..... 1032 (1032)
Alternate Routes..... 0
Route Adds..... 1010
Route Modifies..... 1
Route Deletes..... 10
Unresolved Route Adds..... 0
Invalid Route Adds..... 0
Failed Route Adds..... 0
Reserved Locals..... 0
Unique Next Hops (High)..... 13 (13)
Next Hop Groups (High)..... 13 (14)
```

```

ECMP Groups (High)..... 2 (3)
ECMP Routes..... 1001
Truncated ECMP Routes..... 0
ECMP Retries..... 0
Routes with 1 Next Hop..... 31
Routes with 2 Next Hops..... 1
Routes with 4 Next Hops..... 1000

```

## show ip route preferences

This command displays detailed information about the route preferences. Route preferences are used in determining the best route. Lower router preference values are preferred over higher router preference values. A route with a preference of 255 cannot be used to forward traffic.

Format	<code>show ip route preferences</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Local	The local route preference value.
Static	The static route preference value.
OSPF Intra	The OSPF Intra route preference value.
OSPF Inter	The OSPF Inter route preference value.
OSPF External	The OSPF External route preference value.
RIP	The RIP route preference value.

## show ip stats

This command displays IP statistical information. Refer to RFC 1213 for more information about the fields that are displayed.

Format	<code>show ip stats</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

## show routing heap summary

This command displays a summary of the memory allocation from the routing heap. The routing heap is a chunk of memory set aside when the system boots for use by the routing applications.

Format	show routing heap summary
Mode	Privileged EXEC

Term	Description
Heap Size	The amount of memory, in bytes, allocated at startup for the routing heap.
Memory In Use	The number of bytes currently allocated.
Memory on Free List	The number of bytes currently on the free list. When a chunk of memory from the routing heap is freed, it is placed on a free list for future reuse.
Memory Available in Heap	The number of bytes in the original heap that have never been allocated.
In Use High Water Mark	The maximum memory in use since the system last rebooted.

### Command example:

```
(NETGEAR Switch) #show routing heap summary
Heap Size..... 92594000 bytes
Memory In Use..... 149598 bytes (0%)
Memory on Free List..... 78721 bytes (0%)
Memory Available in Heap..... 92365249 bytes (99%)
In Use High Water Mark..... 210788 bytes (0%)
```

## Virtual LAN Routing Commands

This section describes the commands you use to view and configure VLAN routing and to view VLAN routing status information.

### vlan routing

This command enables routing on a VLAN. The `vlanid` value has a range from 1 to 4093. The `[interface ID]` value has a range from 1 to 128. Typically, you will not supply the interface ID argument, and the system automatically selects the interface ID. However, if you specify an interface ID that is already in use, the CLI displays an error message and does not create the VLAN interface.

Format	vlan routing <vlan-id> [interface id]
Mode	VLAN Config

### no vlan routing

This command deletes routing on a VLAN. The `<vlanid>` value has a range from 1 to 4093.

Format	<code>no vlan routing &lt;vlan-id&gt;</code>
Mode	VLAN Config

### show ip vlan

This command displays the VLAN routing information for all VLANs with routing enabled.

Format	<code>show ip vlan</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
MAC Address used by Routing VLANs	The MAC Address associated with the internal bridge-router interface (IBRI). The same MAC Address is used by all VLAN routing interfaces. It will be displayed above the per-VLAN information.
VLAN ID	The identifier of the VLAN.
Logical Interface	The logical slot/port associated with the VLAN routing interface.
IP Address	The IP address associated with this VLAN.
Subnet Mask	The subnet mask that is associated with this VLAN.

## DHCP and BOOTP Relay Commands

This section describes the commands you use to configure BootP/DHCP Relay on the switch. A DHCP relay agent operates at Layer 3 and forwards DHCP requests and replies between clients and servers when they are not on the same physical subnet.

### bootpdhcprelay cidoptmode

This command enables the circuit ID option mode for BootP/DHCP Relay on the system.

Default	disabled
Format	<code>bootpdhcprelay cidoptmode</code>
Mode	Global Config

**no bootpdhcprelay cidoptmode**

This command disables the circuit ID option mode for BootP/DHCP Relay on the system.

Format	<code>no bootpdhcprelay cidoptmode</code>
Mode	Global Config

**bootpdhcprelay maxhopcount**

This command configures the maximum allowable relay agent hops for BootP/DHCP Relay on the system. The *<hops>* parameter has a range of 1–16.

Default	4
Format	<code>bootpdhcprelay maxhopcount &lt;hops&gt;</code>
Mode	Global Config

**no bootpdhcprelay maxhopcount**

This command configures the default maximum allowable relay agent hops for BootP/DHCP Relay on the system.

Format	<code>no bootpdhcprelay maxhopcount</code>
Mode	Global Config

**bootpdhcprelay minwaittime**

This command configures the minimum wait time in seconds for BootP/DHCP Relay on the system. When the BOOTP relay agent receives a BOOTREQUEST message, it MAY use the seconds-since-client-began-booting field of the request as a factor in deciding whether to relay the request or not. The parameter has a range of 0–100 seconds.

Default	0
Format	<code>bootpdhcprelay minwaittime &lt;0-100&gt;</code>
Mode	Global Config

**no bootpdhcprelay minwaittime**

This command configures the default minimum wait time in seconds for BootP/DHCP Relay on the system.

Format	<code>no bootpdhcprelay minwaittime</code>
Mode	Global Config

## show bootpdhcprelay

This command displays the BootP/DHCP Relay information.

Format	<code>show bootpdhcprelay</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Maximum Hop Count	The maximum allowable relay agent hops.
Minimum Wait Time (Seconds)	The minimum wait time.
Admin Mode	Indicates whether relaying of requests is enabled or disabled.
Server IP Address	The IP address for the BootP/DHCP Relay server.
Circuit Id Option Mode	The DHCP circuit Id option which might be enabled or disabled.
Requests Received	The number of requests received.
Requests Relayed	The number of requests relayed.
Packets Discarded	The number of packets discarded.

## IP Helper Commands

This section describes the commands to configure a DHCP relay agent with multiple DHCP server addresses per routing interface, and to use different server addresses for client packets arriving on different interfaces on the relay agent.

### clear ip helper statistics

Use this command to reset the statistics displayed in the `show ip helper statistics` command to zero.

Format	<code>clear ip helper statistics</code>
Mode	Privileged EXEC

## ip helper-address (Global Config)

Use the Global Configuration `ip helper-address` command to have the switch forward User Datagram Protocol (UDP) broadcasts received on an interface. To disable the forwarding of broadcast packets to specific addresses, use the no form of this command.

The `ip helper-address` command forwards specific UDP broadcast from one interface to another. You can define many helper addresses but the total number of address-port pairs is limited to 128 for the whole device. The setting of a helper address for a specific interface has precedence over a setting of a helper address for all interfaces.

- `<ip-address>` is the destination broadcast or host address to be used when forwarding UDP broadcasts. You can specify `0.0.0.0` to indicate not to forward the UDP packet to any host and enter `255.255.255.255` to broadcast the UDP packets to all hosts on the target subnet.
- `<dest-udp-port>` is the broadcast packet destination UDP port number to forward. If not specified, packets for the default services are forwarded to the helper address. The valid range is 0-65535.

Default	No helper addresses are configured.
Format	<code>ip helper-address &lt;ip-address&gt; [&lt;dest-udp-port&gt;   dhcp   domain   isakmp   mobile-ip   nameserver   netbios-dgm   netbios-ns   ntp   pim-auto-rip   rip   tacacs   tftp   time]</code>
Mode	Global Config

Parameter	Description
<code>&lt;ip-address&gt;</code>	The IPv4 unicast or directed broadcast address to which relayed UDP broadcast packets are sent. The IP address cannot be an IP address configured on any interface of the local router.
<code>&lt;dest-udp-port&gt;</code>	A destination UDP port number from 0 to 65535.
port name options	The destination UDP port may be optionally specified by its name. Whether a port is specified by its number or its name has no effect on behavior. The names recognized are as follows: <ul style="list-style-type: none"> <li>• dhcp (port 67)</li> <li>• domain (port 53)</li> <li>• isakmp (port 500)</li> <li>• mobile-ip (port 434)</li> <li>• nameserver (port 42)</li> <li>• netbios-dgm (port 138)</li> <li>• netbios-ns (port 137)</li> <li>• ntp (port 123)</li> <li>• pim-auto-rp (port 496)</li> <li>• rip (port 520)</li> <li>• tacacs (port 49)</li> <li>• tftp (port 69)</li> <li>• time (port 37)</li> </ul> Other ports must be specified by number.

### no ip helper-address (Global Config)

Use this command to remove the IP address from the previously configured list. The no command without an *<ip-address>* argument removes the entire list of helper addresses on that interface.

Format	no ip helper-address <i>&lt;ip-address&gt;</i> [ <i>&lt;dest-udp-port&gt;</i>   dhcp   domain   isakmp   mobile-ip   nameserver   netbios-dgm   netbios-ns   ntp   pim-auto-rip   rip   tacacs   tftp   time]
Mode	GlobalConfig

### ip helper enable

Use this command to enable relay of UDP packets. This command can be used to temporarily disable IP helper without deleting all IP helper addresses. This command replaces the **bootpdhcrelay enable** command, but affects not only relay of DHCP packets, but also relay of any other protocols for which an IP helper address has been configured.

Default	disabled
Format	ip helper enable
Mode	Global Config

### no ip helper enable

Use this command to disable relay of all UDP packets.

Format	no ip helper enable
Mode	Global Config

### ip helper-address (Interface Config)

Use this command to add a unicast helper address to the list of helper addresses on an interface. This is the address of a DHCP server. This command can be applied multiple times on the routing interface to form the helper addresses list until the list reaches the maximum supported helper addresses.

Default	No helper addresses are configured.
Format	ip helper-address <i>&lt;ip-address&gt;</i> [ <i>&lt;dest-udp-port&gt;</i>   dhcp   domain   isakmp   mobile-ip   nameserver   netbios-dgm   netbios-ns   ntp   pim-auto-rip   rip   tacacs   tftp   time]
Mode	Interface Config



Parameter	Description
<code>&lt;ip-address&gt;</code>	The IPv4 unicast or directed broadcast address to which relayed UDP broadcast packets are sent. The IP address cannot be in a subnet on the interface where the relay entry is configured, and cannot be an IP address configured on any interface of the local router.
<code>&lt;dest-udp-port&gt;</code>	A destination UDP port number from 0 to 65535.
port name options	<p>The destination UDP port may be optionally specified by its name. Whether a port is specified by its number or its name has no effect on behavior. The names recognized are as follows:</p> <ul style="list-style-type: none"> <li>• dhcp (port 67)</li> <li>• domain (port 53)</li> <li>• isakmp (port 500)</li> <li>• mobile-ip (port 434)</li> <li>• nameserver (port 42)</li> <li>• netbios-dgm (port 138)</li> <li>• netbios-ns (port 137)</li> <li>• ntp (port 123)</li> <li>• pim-auto-rp (port 496)</li> <li>• rip (port 520)</li> <li>• tacacs (port 49)</li> <li>• tftp (port 69)</li> <li>• time (port 37)</li> </ul> <p>Other ports must be specified by number.</p>

### no ip helper-address

Use this command to remove the IP address from the previously configured list. The `no` command without an `<ip-address>` argument removes the entire list of helper addresses on that interface.

Format	<code>no ip helper-address &lt;ip-address&gt; [&lt;dest-udp-port&gt;   dhcp   domain   isakmp   mobile-ip   nameserver   netbios-dgm   netbios-ns   ntp   pim-auto-rip   rip   tacacs   tftp   time]</code>
Mode	Interface Config

### ip helper-address discard

Use this command to drop matching packets. Matching packets are discarded rather than relayed, even if a global ip helper-address configuration matches the packet.

Format	<code>ip helper-address discard [&lt;dest-udp-port&gt;   dhcp   domain   isakmp   mobile-ip   nameserver   netbios-dgm   netbios-ns   ntp   pim-auto-rip   rip   tacacs   tftp   time]</code>
Mode	Interface Config

Parameter	Description
<code>&lt;dest-udp-port&gt;</code>	A destination UDP port number from 0 to 65535.
port name options	<p>The destination UDP port may be optionally specified by its name. Whether a port is specified by its number or its name has no effect on behavior. The names recognized are as follows:</p> <ul style="list-style-type: none"> <li>• dhcp (port 67)</li> <li>• domain (port 53)</li> <li>• isakmp (port 500)</li> <li>• mobile-ip (port 434)</li> <li>• nameserver (port 42)</li> <li>• netbios-dgm (port 138)</li> <li>• netbios-ns (port 137)</li> <li>• ntp (port 123)</li> <li>• pim-auto-rp (port 496)</li> <li>• rip (port 520)</li> <li>• tacacs (port 49)</li> <li>• tftp (port 69)</li> <li>• time (port 37)</li> </ul> <p>Other ports must be specified by number.</p>

### no ip helper-address discard

Use this command to permit the matching packets.

Format	<code>no ip helper-address discard [&lt;dest-udp-port&gt;   dhcp   domain   isakmp   mobile-ip   nameserver   netbios-dgm   netbios-ns   ntp   pim-auto-rip   rip   tacacs   tftp   time]</code>
Mode	Interface Config

### show ip helper-address

Use this command to display the configured helper addresses on the interface.

Format	<code>show ip helper-address &lt;interface&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

#### Command example:

```
(NETGEAR Switch) #show ip helper-address 0/1
```

```
Helper IP Address..... 1.2.3.4
..... 1.2.3.5
```

## show ip helper statistics

Use this command to display the number of DHCP and other UDP packets processed and relayed by the UDP relay agent.

Format	show ip helper statistics
Mode	Privileged EXEC

Term	Definition
DHCP client messages received	The number of valid messages received from a DHCP client. The count is incremented only if IP helper is enabled globally, the ingress routing interface is up, and the packet passes a number of validity checks, such as having a TTL>1 and having valid source and destination IP addresses.
DHCP client messages relayed	The number of DHCP client messages relayed to a server. If a message is relayed to multiple servers, the count is incremented once for each server.
DHCP server messages received	The number of DHCP responses received from the DHCP server. This count includes only messages that the DHCP server unicasts to the relay agent for relay to the client.
DHCP server messages relayed	The number of DHCP server messages relayed to a client.
UDP clients messages received	The number of valid UDP packets received. This count includes DHCP messages and all other protocols relayed. Conditions are similar to those for the first statistic in this table.
UDP clients messages relayed	The number of UDP packets relayed. This count includes DHCP messages relayed as well as all other protocols. The count is incremented for each server to which a packet is sent.
DHCP message hop count exceeded max	The number of DHCP client messages received whose hop count is larger than the maximum allowed. The maximum hop count is a configurable value listed in show bootpdhcrelay. A log message is written for each such failure. The DHCP relay agent does not relay these packets.
DHCP message with secs field below min	The number of DHCP client messages received whose secs field is less than the minimum value. The minimum secs value is a configurable value and is displayed in show bootpdhcrelay. A log message is written for each such failure. The DHCP relay agent does not relay these packets.
DHCP message with giaddr set to local address	The number of DHCP client messages received whose gateway address, giaddr, is already set to an IP address configured on one of the relay agent's own IP addresses. In this case, another device is attempting to spoof the relay agent's address. The relay agent does not relay such packets. A log message gives details for each occurrence.
Packets with expired TTL	The number of packets received with TTL of 0 or 1 that might otherwise have been relayed.
Packets that matched a discard entry	The number of packets ignored by the relay agent because they match a discard relay entry.

## ICMP Throttling Commands

This section describes the commands you use to configure options for the transmission of various types of ICMP messages.

### ip unreachable

Use this command to enable the generation of ICMP Destination Unreachable messages. By default, the generation of ICMP Destination Unreachable messages is enabled.

Default	enable
Format	ip unreachable
Mode	Interface Config

### no ip unreachable

Use this command to prevent the generation of ICMP Destination Unreachable messages.

Format	no ip unreachable
Mode	Interface Config

### ip redirects

Use this command to enable the generation of ICMP Redirect messages by the router. By default, the generation of ICMP Redirect messages is disabled.

Default	disabled
Format	ip redirects
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no ip redirects

Use this command to prevent the generation of ICMP Redirect messages by the router.

Format	no ip redirects
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### ip icmp echo-reply

Use this command to enable the generation of ICMP Echo Reply messages by the router. By default, the generation of ICMP Echo Reply messages is enabled.

Default	enabled
Format	ip icmp echo-reply
Mode	Global Config

### no ip icmp echo-reply

Use this command to prevent the generation of ICMP Echo Reply messages by the router.

Format	no ip icmp echo-reply
Mode	Global Config

### ip icmp error-interval

Use this command to limit the rate at which IPv4 ICMP error messages are sent. The rate limit is configured as a token bucket, with two configurable parameters, *burst-size* and *burst-interval*.

- *<burst-interval>* specifies how often the token bucket is initialized with burst-size tokens. burst-interval is from 0 to 2147483647 milliseconds (msec).
- *<burst-size>* is the number of ICMP error messages that can be sent during one burst-interval. The range is from 1 to 200 messages.

To disable ICMP rate limiting, set the burst interval to zero (0).

Default	<ul style="list-style-type: none"> <li>• burst-interval of 1000 msec.</li> <li>• burst-size of 100 messages</li> </ul>
Format	ip icmp error-interval <i>&lt;burst-interval&gt;</i> [ <i>&lt;burst-size&gt;</i> ]
Mode	Global Config

### no ip icmp error-interval

Use this command to return the burst interval and burst size to their default values.

Format	no ip icmp error-interval
Mode	Global Config

# Quality of Service Commands

---

# 5

This chapter describes the Quality of Service (QoS) commands available in the managed switch CLI.

The chapter contains the following sections:

- *Class of Service (CoS) Commands*
- *Differentiated Services (DiffServ) Commands*
- *DiffServ Class Commands*
- *DiffServ Policy Commands*
- *DiffServ Service Commands*
- *DiffServ Show Commands*
- *MAC Access Control List (ACL) Commands*
- *IP Access Control List (ACL) Commands*
- *IPv6 Access Control List (ACL) Commands*
- *Time Range Commands for Time-Based ACLs*
- *AutoVoIP Commands*

The commands in this chapter are in two functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. Every switch command has a show command that displays the configuration setting.

## Class of Service (CoS) Commands

This section describes the commands you use to configure and view Class of Service (CoS) settings for the switch. The commands in this section allow you to control the priority and transmission rate of traffic.

---

**Note:** Commands you issue in the Interface Config mode only affect a single interface. Commands you issue in the Global Config mode affect all interfaces.

---

### classofservice dot1p-mapping

This command maps an 802.1p priority to an internal traffic class. The *<userpriority>* values can range from 0-7. The *<trafficclass>* values range from 0-6, although the actual number of available traffic classes depends on the platform. For more information about 802.1p priority, see [Voice VLAN Commands](#) on page 65.

Format	<code>classofservice dot1p-mapping &lt;userpriority&gt; &lt;trafficclass&gt;</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no classofservice dot1p-mapping

This command maps each 802.1p priority to its default internal traffic class value.

Format	<code>no classofservice dot1p-mapping</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### classofservice ip-dscp-mapping

This command maps an IP DSCP value to an internal traffic class. The *<ipdscp>* value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

The *<trafficclass>* values can range from 0-6, although the actual number of available traffic classes depends on the platform.

Format	<code>classofservice ip-dscp-mapping &lt;ipdscp&gt; &lt;trafficclass&gt;</code>
Modes	Global Config

### no classofservice ip-dscp-mapping

This command maps each IP DSCP value to its default internal traffic class value.

Format	<code>no classofservice ip-dscp-mapping</code>
Modes	Global Config

### classofservice trust

This command sets the Class of Service trust mode of an interface. You can set the mode to trust one of the Dot1p (802.1p), IP DSCP, or IP Precedence packet markings. You can also set the interface mode to untrusted. If you configure an interface to use Dot1p, the mode does not appear in the output of the `show running config` command because Dot1p is the default.

Default	dot1p
Format	<code>classofservice trust {dot1p   ip-dscp   ip-precedence   untrusted}</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no classofservice trust

This command sets the interface mode to the default value.

Format	<code>no classofservice trust</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### cos-queue min-bandwidth

This command specifies the minimum transmission bandwidth guarantee for each interface queue. The total number of queues supported per interface is platform-specific. A value from 0–100 (percentage of link rate) must be specified for each supported queue, with 0 indicating no guaranteed minimum bandwidth. The sum of all values entered must not exceed 100.

Format	<code>cos-queue min-bandwidth &lt;bw-0&gt; &lt;bw-1&gt; ... &lt;bw-n&gt;</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>



### no cos-queue min-bandwidth

This command restores the default for each queue's minimum bandwidth value.

Format	<code>no cos-queue min-bandwidth</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### cos-queue strict

This command activates the strict priority scheduler mode for each specified queue.

Format	<code>cos-queue strict &lt;queue-id-1&gt; [&lt;queue-id-2&gt; ... &lt;queue-id-n&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no cos-queue strict

This command restores the default weighted scheduler mode for each specified queue.

Format	<code>no cos-queue strict &lt;queue-id-1&gt; [&lt;queue-id-2&gt; ... &lt;queue-id-n&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### cos-queue random-detect

This command activates weighted random early discard (WRED) for each specified queue on the interface. Specific WRED parameters are configured using the random-detect queue-parms and the random-detect exponential-weighting-constant commands. When specified in Interface Config mode, this command affects a single interface only, whereas in Global Config mode, it applies to all interfaces. At least one, but no more than  $n$ , queue-id values are specified with this command.

Duplicate queue-id values are ignored. Each queue-id value ranges from 0 to  $(n-1)$ , where  $n$  is the total number of queues supported per interface. The number  $n$  is platform dependant and corresponds to the number of supported queues (traffic classes).

Format	<code>cos-queue random-detect &lt;queue-id-1&gt; [&lt;queue-id-2&gt; ... &lt;queue-id-n&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no cos-queue random-detect

Use this command to disable WRED and restore the default tail drop operation for the specified queues on all interfaces or one interface.

Format	<code>no cos-queue random-detect &lt;queue-id-1&gt; [&lt;queue-id-2&gt; ... &lt;queue-id-n&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### random-detect exponential-weighting-constant

Use this command to configure the WRED decay exponent for a CoS queue interface.

Format	<code>random-detect exponential-weighting-constant &lt;0-15&gt;</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>
Default	9

### no random-detect exponential-weighting-constant

Use this command to reset the WRED decay exponent to the default value on all interfaces or one interface.

Format	<code>no random-detect exponential-weighting-constant</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### random-detect queue-parms

Use this command to configure WRED parameters for each drop precedence level supported by a queue. Use it only when per-COS queue configuration is enabled (using the `cos-queue random-detect` command).

- `<min-thresh>` is the minimum threshold the queue depth (as a percentage) where WRED starts marking and dropping traffic.
- `<max-thresh>` is the maximum threshold is the queue depth (as a percentage) above which WRED marks or drops all traffic.
- `<drop-probability>` is the percentage probability that WRED marks or drops a packet, when the queue depth is at the maximum threshold. (The drop probability increases linearly from 0 just before the minimum threshold, to this value at the maximum threshold, then goes to 100 percent for larger queue depths). Each parameter is specified for each possible drop precedence (color of TCP traffic).

The last precedence applies to all non-TCP traffic. For example, in a 3-color system, four of each parameter specified: green TCP, yellow TCP, red TCP, and non-TCP, respectively.

Format	random-detect queue-parms <queue-id-1> [<queue-id-2> ... <queue-id-n>] minthresh <thresh-prec-1> ... <thresh-prec-n> max-thresh <thresh-prec-1> ... <threshprec-n> drop-probability <prob-prec-1> ... <prob-prec-n>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no random-detect queue-parms

Use this command to set the WRED configuration back to the default.

Format	no random-detect queue-parms <queue-id-1> [<queue-id-2> ... <queue-id-n>]
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### traffic-shape

This command specifies the maximum transmission bandwidth limit for the interface as a whole. Also known as rate shaping, traffic shaping has the effect of smoothing temporary traffic bursts over time so that the transmitted traffic rate is bounded.

Format	traffic-shape <bw>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no traffic-shape

This command restores the interface shaping rate to the default value.

Format	no traffic-shape
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### show classofservice dot1p-mapping

This command displays the current Dot1p (802.1p) priority mapping to internal traffic classes for a specific interface. The <slot/port> parameter is optional and is only valid on platforms that support independent per-port Class of Service mappings. If specified, the 802.1p mapping table of the interface is displayed. If omitted, the most recent global configuration settings are displayed. For more information, see [Voice VLAN Commands](#) on page 65.

Format	<code>show classofservice dot1p-mapping [&lt;slot/port&gt;]</code>
Mode	Privileged EXEC

The following information is repeated for each user priority.

Term	Definition
User Priority	The 802.1p user priority value.
Traffic Class	The traffic class internal queue identifier to which the user priority value is mapped.

### show classofservice ip-precedence-mapping

This command displays the current IP Precedence mapping to internal traffic classes for a specific interface. The `<slot/port>` parameter is optional and is only valid on platforms that support independent per-port Class of Service mappings. If specified, the IP Precedence mapping table of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

Format	<code>show classofservice ip-precedence-mapping [&lt;slot/port&gt;]</code>
Mode	Privileged EXEC

The following information is repeated for each user priority.

Term	Definition
IP Precedence	The IP Precedence value.
Traffic Class	The traffic class internal queue identifier to which the IP Precedence value is mapped.

### show classofservice ip-dscp-mapping

This command displays the current IP DSCP mapping to internal traffic classes for the global configuration settings.

Format	<code>show classofservice ip-dscp-mapping</code>
Mode	Privileged EXEC

The following information is repeated for each user priority.

Term	Definition
IP DSCP	The IP DSCP value.
Traffic Class	The traffic class internal queue identifier to which the IP DSCP value is mapped.

## show classofservice trust

This command displays the current trust mode setting for a specific interface. The `<slot/port>` parameter is optional and is only valid on platforms that support independent per-port Class of Service mappings. If you specify an interface, the command displays the port trust mode of the interface. If you do not specify an interface, the command displays the most recent global configuration settings.

Format	<code>show classofservice trust [&lt;slot/port&gt;]</code>
Mode	Privileged EXEC

Term	Definition
Non-IP Traffic Class	The traffic class used for non-IP traffic. This is only displayed when the COS trust mode is set to trust IP Precedence or IP DSCP (on platforms that support IP DSCP).
Untrusted Traffic Class	The traffic class used for all untrusted traffic. This is only displayed when the COS trust mode is set to 'untrusted'.

## show interfaces cos-queue

This command displays the class-of-service queue configuration for the specified interface. The slot/port parameter is optional and is only valid on platforms that support independent per-port Class of Service mappings. If specified, the class-of-service queue configuration of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

Format	<code>show interfaces cos-queue [&lt;slot/port&gt;]</code>
Mode	Privileged EXEC

Term	Definition
Queue Id	An interface supports n queues numbered 0 to (n-1). The specific n value is platform-dependent.
Minimum Bandwidth	The minimum transmission bandwidth guarantee for the queue, expressed as a percentage. A value of 0 means bandwidth is not guaranteed and the queue operates using best-effort. This is a configured value.
Scheduler Type	Indicates whether this queue is scheduled for transmission using a strict priority or a weighted scheme. This is a configured value.
Queue Management Type	The queue depth management technique used for this queue (tail drop).

If you specify the interface, the command also displays the following information.

Term	Definition
Interface	The slot/port of the interface. If displaying the global configuration, this output line is replaced with a Global Config indication.
Interface Shaping Rate	The maximum transmission bandwidth limit for the interface as a whole. It is independent of any per-queue maximum bandwidth value(s) in effect for the interface. This is a configured value.

### show interfaces random-detect

This command displays the global WRED settings for each CoS queue. If you specify the slot/port, the command displays the WRED settings for each CoS queue on the specified interface.

Format	<code>show interfaces random-detect [&lt;slot/port&gt;]</code>
Mode	Privileged EXEC

Term	Definition
Queue ID	An interface supports n queues numbered 0 to (n-1). The specific n value is platform-dependent.
WRED Minimum Threshold	The configured minimum threshold the queue depth (as a percentage) where WRED starts marking and dropping traffic.
WRED Maximum Threshold	The configured maximum threshold is the queue depth (as a percentage) above which WRED marks / drops all traffic.
WRED Drop Probability	The configured percentage probability that WRED will mark/drop a packet, when the queue depth is at the maximum threshold. (The drop probability increases linearly from 0 just before the minimum threshold, to this value at the maximum threshold, then goes to 100% for larger queue depths).

## Differentiated Services (DiffServ) Commands

This section describes the commands you use to configure QOS Differentiated Services (DiffServ).

You configure DiffServ in several stages by specifying three DiffServ components:

1. Class
  - a. Creating and deleting classes.
  - b. Defining match criteria for a class.

2. Policy
  - a. Creating and deleting policies
  - b. Associating classes with a policy
  - c. Defining policy statements for a policy/class combination
3. Service
  - a. Adding and removing a policy to/from an inbound or outbound interface

The DiffServ class defines the packet filtering criteria. The attributes of a DiffServ policy define the way the switch processes packets. You can define policy attributes on a per-class instance basis. The switch applies these attributes when a match occurs.

Packet processing begins when the switch tests the match criteria for a packet. The switch applies a policy to a packet when it finds a class match within that policy.

The following rules apply when you create a DiffServ class:

- Each class can contain a maximum of one referenced (nested) class
- Class definitions do not support hierarchical service policies

A class definition can contain a maximum of one reference to another class. You can combine the reference with other match criteria. The referenced class is truly a reference and not a copy, because additions to a referenced class affect all classes that reference it. Changes to any class definition currently referenced by any other class must result in valid class definitions for all derived classes, otherwise the switch rejects the change. You can remove a class reference from a class definition.

The only way to remove an individual match criterion from an existing class definition is to delete the class and re-create it.

---

**Note:** The mark possibilities for policing include CoS, IP DSCP, and IP Precedence. While the latter two are only meaningful for IP packet types, CoS marking is allowed for both IP and non-IP packets, since it updates the 802.1p user priority field contained in the VLAN tag of the layer 2 packet header.

---

## diffserv

This command sets the DiffServ operational mode to active. While disabled, the DiffServ configuration is retained and can be changed, but it is not activated. When enabled, DiffServ services are activated.

Format	diffserv
Mode	Global Config

### no diffserv

This command sets the DiffServ operational mode to inactive. While disabled, the DiffServ configuration is retained and can be changed, but it is not activated. When enabled, DiffServ services are activated.

Format	no diffserv
Mode	Global Config

## DiffServ Class Commands

Use the DiffServ class commands to define traffic classification. To classify traffic, you specify Behavior Aggregate (BA), based on DSCP and Multi-Field (MF) classes of traffic (name, match criteria)

This set of commands consists of class creation/deletion and matching, with the class match commands specifying Layer 3, Layer 2, and general match criteria. The class match criteria are also known as class rules, with a class definition consisting of one or more rules to identify the traffic that belongs to the class.

---

**Note:** Once you create a class match criterion for a class, you cannot change or delete the criterion. To change or delete a class match criterion, you must delete and re-create the entire class.

---

The CLI command root is `class-map`.

### class-map

This command defines a DiffServ class of type match-all. When used without any match condition, this command enters the class-map mode. The `<class-map-name>` is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying an existing DiffServ class.

---

**Note:** The class-map-name “default” is reserved and you must not use it.

---

The class type of `match-all` indicates all of the individual match conditions must be true for a packet to be considered a member of the class. This command might be used without specifying a class type to enter the Class-Map Config mode for an existing DiffServ class.



---

**Note:** The optional keywords [ `ipv4` | `ipv6` ] specify the Layer 3 protocol for this class. If not specified, this parameter defaults to `ipv4`. This maintains backward compatibility for configurations defined on systems before IPv6 match items were supported.

---



---

**Note:** The CLI mode is changed to Class-Map Config or Ipv6-Class-Map Config when this command is successfully executed depending on the [ `ipv4` | `ipv6` ] keyword specified.

---

Format	<code>class-map match-all &lt;class-map-name&gt; [ipv4   ipv6]</code>
Mode	Global Config

### no class-map

This command eliminates an existing DiffServ class. The `<class-map-name>` is the name of an existing DiffServ class. (The class name “default” is reserved and is not allowed here.) This command might be issued at any time; if the class is currently referenced by one or more policies or by any other class, the delete action fails.

Format	<code>no class-map &lt;class-map-name&gt;</code>
Mode	Global Config

### class-map rename

This command changes the name of a DiffServ class. The `<class-map-name>` is the name of an existing DiffServ class. The `<new-class-map-name>` parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the class.

Default	none
Format	<code>class-map rename &lt;class-map-name&gt; &lt;new-class-map-name&gt;</code>
Mode	Global Config

### match ethertype

This command adds to the specified class definition a match condition based on the value of the ethertype. The `ethertype` value is specified as a `<keyword>` argument that can be one of the following types: `appletalk`, `arp`, `ibmsna`, `ipv4`, `ipv6`, `ipx`, `mplsmcast`, `mplsucast`, `netbios`, `novell`, `pppoe`, or `rarp` or as a `<range>` argument that represents an EtherType value in the range of 0x0600-0xFFFF.

Format	match ethertype {<keyword>   custom <range>}
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match any

This command adds to the specified class definition a match condition whereby all packets are considered to belong to the class.

Default	none
Format	match any
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match class-map

This command adds to the specified class definition the set of match conditions defined for another class. The *<refclassname>* is the name of an existing DiffServ class whose match conditions are being referenced by the specified class definition.

Default	none
Format	match class-map <refclassname>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

Note the following:

- The parameters *<refclassname>* and *<class-map-name>* cannot be the same.
- Only one other class might be referenced by a class.
- Any attempts to delete the *<refclassname>* class while the class is still referenced by any *<class-map-name>* fails.
- The combined match criteria of *<class-map-name>* and *<refclassname>* must be an allowed combination based on the class type.
- Any subsequent changes to the *<refclassname>* class match criteria must maintain this validity, or the change attempt fails.
- The total number of class rules formed by the complete reference class chain (including both predecessor and successor classes) must not exceed a platform-specific maximum. In some cases, each removal of a refclass rule reduces the maximum number of available rules in the class definition by one.

### no match class-map

This command removes from the specified class definition the set of match conditions defined for another class. The *<refclassname>* is the name of an existing DiffServ class whose match conditions are being referenced by the specified class definition.

Format	<code>no match class-map &lt;refclassname&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match cos

This command adds to the specified class definition a match condition for the Class of Service value (the only tag in a single tagged packet or the first or outer 802.1Q tag of a double VLAN tagged packet). The value might be from 0 to 7.

Default	none
Format	<code>match cos &lt;0-7&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match secondary cos

This command adds to the specified class definition a match condition for the secondary Class of Service value (the only tag in a single tagged packet or the first or outer 802.1Q tag of a double VLAN tagged packet). The value might be from 0 to 7.

Default	none
Format	<code>match secondary-cos &lt;0-7&gt;</code>
Mode	Class-Map Config

### match ip6flowlbl

This command adds to the specified class definition a match condition based on the IP6flowlbl of a packet. The *<label>* is the value to match in the Flow Label field of the IPv6 header (range 0-1048575).

Format	<code>match ip6flowlbl &lt;label&gt;</code>
Mode	Ipv6-Class-Map Configuration mode

### match destination-address mac

This command adds to the specified class definition a match condition based on the destination MAC address of a packet. The *<macaddr>* parameter is any layer 2 MAC address formatted as six, two-digit hexadecimal numbers separated by colons (for example,

00:11:22:dd:ee:ff). The *<macmask>* parameter is a layer 2 MAC address bit mask, which need not to be contiguous, and is formatted as six, two-digit hexadecimal numbers separated by colons (for example, ff:07:23:ff:fe:dc).

Default	none
Format	match destination-address mac <i>&lt;macaddr&gt;</i> <i>&lt;macmask&gt;</i>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match dstip

This command adds to the specified class definition a match condition based on the destination IP address of a packet. The *<ipaddr>* parameter specifies an IP address. The *<ipmask>* parameter specifies an IP address bit mask and must consist of a contiguous set of leading 1 bits.

Default	none
Format	match dstip <i>&lt;ipaddr&gt;</i> <i>&lt;ipmask&gt;</i>
Mode	Class-Map Config

### match dstip6

This command adds to the specified class definition a match condition based on the destination IPv6 address of a packet.

Default	none
Format	match dstip6 <i>&lt;destination-ipv6-prefix/prefix-length&gt;</i>
Mode	Ipv6-Class-Map Config

### match dstl4port

This command adds to the specified class definition a match condition based on the destination layer 4 port of a packet using a single keyword or numeric notation. To specify the match condition as a single keyword, the value for *<portkey>* is one of the supported port name keywords. The currently supported *<portkey>* values are: **domain**, **echo**, **ftp**, **ftpdata**, **http**, **smtp**, **snmp**, **telnet**, **tftp**, or **www**. Each of these translates into its equivalent port number. To specify the match condition using a numeric notation, one layer 4-port number is required. The port number is an integer from 0 to 65535.

Default	none
Format	match dstl4port { <i>&lt;portkey&gt;</i>   <i>&lt;0-65535&gt;</i> }
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

## match ip dscp

This command adds to the specified class definition a match condition based on the value of the IP DiffServ Code Point (DSCP) field in a packet, which is defined as the high-order six bits of the Service Type octet in the IP header (the low-order two bits are not checked).

The *<dscpval>* value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

---

**Note:** The `match ip dscp`, `match ip precedence`, and `match ip tos` commands provide alternative ways to specify a match criterion for the same Service Type field in the IP header, but each command requires a slightly different user notation.

---

Default	none
Format	<code>match ip dscp &lt;dscpval&gt;</code>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

## match ip precedence

This command adds to the specified class definition a match condition based on the value of the IP Precedence field in a packet, which is defined as the high-order three bits of the Service Type octet in the IP header (the low-order five bits are not checked). The precedence value is an integer from 0 to 7.

---

**Note:** The `match ip dscp`, `match ip precedence`, and `match ip tos` commands provide alternative ways to specify a match criterion for the same Service Type field in the IP header, but each command requires a slightly different user notation.

---

Default	none
Format	<code>match ip precedence &lt;0-7&gt;</code>
Mode	Class-Map Config

## match ip tos

This command adds to the specified class definition a match condition based on the value of the IP ToS field in a packet, which is defined as all eight bits of the Service Type octet in the IP header. The value of *<tosbits>* is a two-digit hexadecimal number from 00 to ff. The value of *<tosmask>* is a two-digit hexadecimal number from 00 to ff. The *<tosmask>*

denotes the bit positions in *<tosbits>* that are used for comparison against the IP TOS field in a packet. For example, to check for an IP TOS value having bits 7 and 5 set and bit 1 clear, where bit 7 is most significant, use a *<tosbits>* value of a0 (hex) and a *<tosmask>* of a2 (hex).

---

**Note:** The `match ip dscp`, `match ip precedence`, and `match ip tos` commands provide alternative ways to specify a match criterion for the same Service Type field in the IP header, but each command requires a slightly different user notation.

---



---

**Note:** This “free form” version of the IP DSCP, IP precedence, and IP ToS match specification gives you complete control when specifying which bits of the IP Service Type field must be checked.

---

Default	none
Format	<code>match ip tos &lt;tosbits&gt; &lt;tosmask&gt;</code>
Mode	Class-Map Config

## match protocol

This command adds to the specified class definition a match condition based on the value of the IP Protocol field in a packet using a single keyword notation or a numeric value notation.

To specify the match condition using a single keyword notation, the value for *<protocol-name>* is one of the supported protocol name keywords. The currently supported values are: `icmp`, `igmp`, `ip`, `tcp`, `udp`. A value of `ip` matches all protocol number values.

To specify the match condition using a numeric value notation, the protocol number is a standard value assigned by IANA and is interpreted as an integer from 0 to 255.

---

**Note:** This command does not validate the protocol number value against the current list defined by IANA.

---

Default	none
Format	<code>match protocol {&lt;protocol-name&gt;   &lt;0-255&gt;}</code>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match source-address mac

This command adds to the specified class definition a match condition based on the source MAC address of a packet. The *<address>* parameter is any layer 2 MAC address formatted as six, two-digit hexadecimal numbers separated by colons (for example, 00:11:22:dd:ee:ff). The *<macmask>* parameter is a layer 2 MAC address bit mask, which might not be contiguous, and is formatted as six, two-digit hexadecimal numbers separated by colons (for example, ff:07:23:ff:fe:dc).

Default	none
Format	match source-address mac <i>&lt;address&gt;</i> <i>&lt;macmask&gt;</i>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match srcip

This command adds to the specified class definition a match condition based on the source IP address of a packet. The *<ipaddr>* parameter specifies an IP address. The *<ipmask>* parameter specifies an IP address bit mask and must consist of a contiguous set of leading 1 bits.

Default	none
Format	match srcip <i>&lt;ipaddr&gt;</i> <i>&lt;ipmask&gt;</i>
Mode	Class-Map Config

### match srcip6

This command adds to the specified class definition a match condition based on the source IP address of a packet.

Default	none
Format	match srcip6 <i>&lt;source-ipv6-prefix/prefix-length&gt;</i>
Mode	Ipv6-Class-Map Config

### match srcl4port

This command adds to the specified class definition a match condition based on the source layer 4 port of a packet using a single keyword or numeric notation. To specify the match condition as a single keyword notation, the value for *<portkey>* is one of the supported port name keywords (listed below). The currently supported *<portkey>* values are: **domain**, **echo**, **ftp**, **ftpdata**, **http**, **smtp**, **snmp**, **telnet**, **tftp**, **www**. Each of these translates into its equivalent port number, which is used as both the start and end of a port range.

To specify the match condition as a numeric value, one layer 4-port number is required. The port number is an integer from 0 to 65535.

Default	none
Format	match srcl4port {<portkey>   <0-65535>}
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match vlan

This command adds to the specified class definition a match condition based on the value of the layer 2 VLAN Identifier field (the 802.1Q tag of a VLAN tagged packet). The VLAN is an integer from 0 to 4095.

Default	none
Format	match vlan <0-4095>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

### match secondary-vlan

This command adds to the specified class definition a match condition based on the value of the layer 2 secondary VLAN Identifier field (the 802.1Q tag of a double VLAN tagged packet). The VLAN is an integer from 0 to 4095.

Default	none
Format	match secondary-vlan <0-4095>
Mode	<ul style="list-style-type: none"> <li>• Class-Map Config</li> <li>• Ipv6-Class-Map Config</li> </ul>

## DiffServ Policy Commands

Use the DiffServ policy commands to specify traffic conditioning actions, such as policing and marking, to apply to traffic classes

Use the policy commands to associate a traffic class that you define by using the class command set with one or more QoS policy attributes. Assign the class/policy association to an interface to form a service. Specify the policy name when you create the policy.

Each traffic class defines a particular treatment for packets that match the class definition. You can associate multiple traffic classes with a single policy. When a packet satisfies the conditions of more than one class, preference is based on the order in which you add the classes to the policy. The first class you add has the highest precedence.

This set of commands consists of policy creation/deletion, class addition/removal, and individual policy attributes.



---

**Note:** The only way to remove an individual policy attribute from a class instance within a policy is to remove the class instance and re-add it to the policy. The values associated with an existing policy attribute can be changed without removing the class instance.

---

The CLI command root is `policy-map`.

### assign-queue

This command modifies the queue id to which the associated traffic stream is assigned. The `<queueid>` is an integer from 0 to  $n-1$ , where  $n$  is the number of egress queues supported by the device.

Format	<code>assign-queue &lt;queueid&gt;</code>
Mode	Policy-Class-Map Config
Incompatibilities	Drop

### drop

This command specifies that all packets for the associated traffic stream are to be dropped at ingress.

Format	<code>drop</code>
Mode	Policy-Class-Map Config
Incompatibilities	Assign Queue, Mark (all forms), Mirror, Police, Redirect

### mirror

This command specifies that all incoming packets for the associated traffic stream are copied to a specific egress interface (physical port or LAG).

Format	<code>mirror &lt;slot/port&gt;</code>
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Redirect

## redirect

This command specifies that all incoming packets for the associated traffic stream are redirected to a specific egress interface (physical port or port-channel).

Format	<code>redirect &lt;slot/port&gt;</code>
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Mirror

## conform-color

Use this command to enable color-aware traffic policing and define the conform-color class map. Used with the police command where the fields for the conform level are specified. The `<class-map-name>` parameter is the name of an existing DiffServ class map.

---

**Note:** This command might only be used after specifying a police command for the policy-class instance.

---

Format	<code>conform-color &lt;class-map-name&gt;</code>
Mode	Policy-Class-Map Config

## class

This command creates an instance of a class definition within the specified policy for defining treatment of the traffic class through subsequent policy attribute statements. The `<classname>` is the name of an existing DiffServ class.

---

**Note:** This command causes the specified policy to create a reference to the class definition.

---



---

**Note:** The CLI mode is changed to Policy-Class-Map Config when this command is successfully executed.

---

Format	<code>class &lt;classname&gt;</code>
Mode	Policy-Map Config

## no class

This command deletes the instance of a particular class and its defined treatment from the specified policy. *<classname>* is the names of an existing DiffServ class.

---

**Note:** This command removes the reference to the class definition for the specified policy.

---

Format	no class <i>&lt;classname&gt;</i>
Mode	Policy-Map Config

## mark cos

This command marks all packets for the associated traffic stream with the specified Class of Service value in the priority field of the 802.1p header (the only tag in a single tagged packet or the first or outer 802.1Q tag of a double VLAN tagged packet). If the packet does not already contain this header, one is inserted. The CoS value is an integer from 0 to 7.

Default	1
Format	mark-cos <i>&lt;0-7&gt;</i>
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Mark IP DSCP, IP Precedence, Police

## mark cos-as-sec-cos

This command marks outer VLAN tag priority bits of all packets as the inner VLAN tag priority, marking CoS as Secondary CoS. This essentially means that the inner VLAN tag CoS is copied to the outer VLAN tag CoS.

Format	mark-cos-as-sec-cos
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Mark IP DSCP, IP Precedence, Police

## mark ip-dscp

This command marks all packets for the associated traffic stream with the specified IP DSCP value.

The *<dscpval>* value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: **af11**, **af12**, **af13**, **af21**, **af22**, **af23**, **af31**, **af32**, **af33**, **af41**, **af42**, **af43**, **be**, **cs0**, **cs1**, **cs2**, **cs3**, **cs4**, **cs5**, **cs6**, **cs7**, or **ef**.

Format	mark ip-dscp <dscpval>
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Mark CoS, Mark IP Precedence, Police

## mark ip-precedence

This command marks all packets for the associated traffic stream with the specified IP Precedence value. The IP Precedence value is an integer from 0 to 7.

---

**Note:** This command might not be used on IPv6 classes. IPv6 does not have a precedence field.

---

Format	mark ip-precedence <0-7>
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Mark CoS, Mark IP Precedence, Police
Policy Type	In

## police-simple

This command is used to establish the traffic policing style for the specified class. The simple form of the police command uses a single data rate and burst size, resulting in two outcomes: conform and violate. The conforming data rate is specified in kilobits-per-second (Kbps) and is an integer from 1 to 4294967295. The conforming burst size is specified in kilobytes (KB) and is an integer from 1 to 128.

For each outcome, the only possible actions are drop, set-cos-transmit, set-dscp-transmit, set-prec-transmit, or transmit. In this simple form of the police command, the conform action defaults to transmit and the violate action defaults to drop.

For **set-cos-transmit**, an 802.1p priority value is required and is specified as an integer from 0-7.

For **set-dscp-transmit**, a <dscpval> value is required and is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: **af11**, **af12**, **af13**, **af21**, **af22**, **af23**, **af31**, **af32**, **af33**, **af41**, **af42**, **af43**, **be**, **cs0**, **cs1**, **cs2**, **cs3**, **cs4**, **cs5**, **cs6**, **cs7**, or **ef**.

For **set-prec-transmit**, an IP Precedence value is required and is specified as an integer from 0-7.

For **set-cos-transmit**, an 802.1p priority value is required and is specified as an integer from 0-7.

Format	<code>police-simple {&lt;1-4294967295&gt; &lt;1-128&gt; conform-action {drop   set-prec-transmit &lt;0-7&gt;   set-dscp-transmit &lt;0-63&gt;   set-cos-transmit &lt;0-7&gt;   transmit} [violate-action {drop   set-prec-transmit &lt;0-7&gt;   set-dscp-transmit &lt;0-63&gt;   set-cos-transmit &lt;0-7&gt;   transmit}]}</code>
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Mark (all forms)

## police-two-rate

This command is the two-rate form of the `police` command and is used to establish the traffic policing style for the specified class. For each outcome, the only possible actions are drop, set-cos-as-sec-cos, set-cos-transmit, set-sec-cos-transmit, set-dscp-transmit, set-prec-transmit, or transmit. In this two-rate form of the `police` command, the conform action defaults to send, the exceed action defaults to drop, and the violate action defaults to drop. These actions can be set with this command after the style is configured.

Format	<code>police-two-rate {&lt;1-4294967295&gt; &lt;1-128&gt; &lt;1-4294967295&gt; &lt;1-128&gt; conform-action {drop   set-cos-as-sec-cos   set-cos-transmit &lt;0-7&gt;   set-sec-cos-transmit &lt;0-7&gt;   set-prec-transmit &lt;0-7&gt;   set-dscp-transmit &lt;0-63&gt;   transmit} exceed-action {drop   set-cos-as-sec-cos   set-cos-transmit &lt;0-7&gt;   set-sec-cos-transmit &lt;0-7&gt;   set-prec-transmit &lt;0-7&gt;   set-dscp-transmit &lt;0-63&gt;   transmit} violate-action {drop   set-cos-as-sec-cos   set-cos-transmit &lt;0-7&gt;   set-sec-cos-transmit &lt;0-7&gt;   set-prec-transmit &lt;0-7&gt;   set-dscp-transmit &lt;0-63&gt;   transmit}}</code>
Mode	Policy-Class-Map Config

## policy-map

This command establishes a new DiffServ policy. The `<policyname>` parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the policy. The type of policy is specific to the inbound traffic direction as indicated by the parameter

---

**Note:** The CLI mode is changed to Policy-Map Config when this command is successfully executed.

---

Format	<code>policy-map &lt;policyname&gt; [in   out]</code>
Mode	Global Config

### no policy-map

This command eliminates an existing DiffServ policy. The *<policyname>* parameter is the name of an existing DiffServ policy. This command might be issued at any time. If the policy is referenced by one or more interface service attachments, this delete attempt fails.

Format	no policy-map <i>&lt;policyname&gt;</i>
Mode	Global Config

### policy-map rename

This command changes the name of a DiffServ policy. The *<policyname>* is the name of an existing DiffServ class. The *<newpolicyname>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the policy.

Format	policy-map rename <i>&lt;policyname&gt;</i> <i>&lt;newpolicyname&gt;</i>
Mode	Global Config

## DiffServ Service Commands

Use the DiffServ service commands to assign a DiffServ traffic conditioning policy, which you specified by using the policy commands, to an interface in the incoming direction

The service commands attach a defined policy to a directional interface. You can assign only one policy at any one time to an interface in the inbound direction. DiffServ is not used in the outbound direction.

This set of commands consists of service addition/removal.

The CLI command root is **service-policy**.

### service-policy

This command attaches a policy to an interface in the inbound direction. The *<policyname>* parameter is the name of an existing DiffServ policy. This command causes a service to create a reference to the policy.

---

**Note:** This command effectively enables DiffServ on an interface in the inbound direction. There is no separate interface administrative 'mode' command for DiffServ.

---

---

**Note:** This command fails if any attributes within the policy definition exceed the capabilities of the interface. Once a policy is successfully attached to an interface, any attempt to change the policy definition, that would result in a violation of the interface capabilities, causes the policy change attempt to fail.

---

Format	<code>service-policy {in   out} &lt;polycyname&gt;</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

---

**Note:** Each interface can have one policy attached.

---

### no service-policy

This command detaches a policy from an interface in the inbound direction. The `<polycyname>` parameter is the name of an existing DiffServ policy.

---

**Note:** This command causes a service to remove its reference to the policy. This command effectively disables DiffServ on an interface in the inbound direction. There is no separate interface administrative 'mode' command for DiffServ.

---

Format	<code>no service-policy in &lt;polycyname&gt;</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

## DiffServ Show Commands

Use the DiffServ show commands to display configuration and status information for classes, policies, and services. You can display DiffServ information in summary or detailed formats. The status information is only shown when the DiffServ administrative mode is enabled.

## show class-map

This command displays all configuration information for the specified class. The `<class-name>` is the name of an existing DiffServ class.

Format	<code>show class-map &lt;class-name&gt;</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

If the class-name is specified, the fields that are shown in the following table are displayed.

Term	Definition
Class Name	The name of this class.
Class Type	A class type of 'all' means every match criterion defined for the class is evaluated simultaneously and must all be true to indicate a class match.
Class Layer3 Protocol	The Layer 3 protocol for this class. Possible values are IPv4 and IPv6.
Match Criteria	The Match Criteria fields are only displayed if they have been configured. Not all platforms support all match criteria values. They are displayed in the order entered by the user. The fields are evaluated in accordance with the class type. The possible Match Criteria fields are: Destination IP Address, Destination Layer 4 Port, Destination MAC Address, Ethertype, Source MAC Address, VLAN, Class of Service, Every, IP DSCP, IP Precedence, IP TOS, Protocol Keyword, Reference Class, Source IP Address, and Source Layer 4 Port.
Values	The values of the Match Criteria.

If you do not specify the class name, this command displays a list of all defined DiffServ classes. The fields that are shown in the following table are displayed.

Term	Definition
Class Name	The name of this class. (Note that the order in which classes are displayed is not necessarily the same order in which they were created.)
Class Type	A class type of 'all' means every match criterion defined for the class is evaluated simultaneously and must all be true to indicate a class match.
Reference Class Name	The name of an existing DiffServ class whose match conditions are being referenced by the specified class definition.



## show diffserv

This command displays the DiffServ General Status Group information, which includes the current administrative mode setting as well as the current and maximum number of rows in each of the main DiffServ private MIB tables. This command provides no options.

Format	show diffserv
Mode	Privileged EXEC

Term	Definition
DiffServ Admin mode	The current value of the DiffServ administrative mode.
Class Table Size Current /Max	The current number of entries (rows) and the maximum allowed entries (rows) in the Class Table.
Class Rule Table Size Current /Max	The current number of entries (rows) and the maximum allowed entries (rows) in the Class Rule Table.
Policy Table Size Current /Max	The current number of entries (rows) and the maximum allowed entries (rows) in the Policy Table.
Policy Instance Table Size Current /Max	Current number of entries (rows) and the maximum allowed entries (rows) in the Policy Instance Table.
Policy Attribute Table Size Current /Max	Current number of entries (rows) and the maximum allowed entries (rows) in the Policy Attribute Table.
Service Table Size Current /Max	The current number of entries (rows) i and the maximum allowed entries (rows) in the Service Table.

## show policy-map

This command displays all configuration information for the specified policy. The *<policyname>* is the name of an existing DiffServ policy.

Format	show policy-map [ <i>&lt;policyname&gt;</i> ]
Mode	Privileged EXEC

If the policy name is specified, the fields that are shown in the following table are displayed.

Term	Definition
Policy Name	The name of this policy.
Policy Type	The policy type (Only inbound policy definitions are supported for this platform.)

The information that is shown in the following table is repeated for each class that is associated with this policy (only the policy attributes that are configured are displayed).

Term	Definition
Assign Queue	Directs traffic stream to the specified QoS queue. This allows a traffic classifier to specify which one of the supported hardware queues are used for handling packets belonging to the class.
Class Name	The name of this class.
Committed Burst Size (KB)	The committed burst size, used in simple policing.
Committed Rate (Kbps)	The committed rate, used in simple policing.
Conform Action	The current setting for the action taken on a packet considered to conform to the policing parameters. This is not displayed if policing is not in use for the class under this policy.
Conform COS	The CoS mark value if the conform action is set-cos-transmit.
Conform DSCP Value	The DSCP mark value if the conform action is set-dscp-transmit.
Conform IP Precedence Value	The IP Precedence mark value if the conform action is set-prec-transmit.
Drop	Drop a packet upon arrival. This is useful for emulating access control list operation using DiffServ, especially when DiffServ and ACL cannot co-exist on the same interface.
Mark CoS	The Class of Service value that is set in the 802.1p header of inbound packets. This is not displayed if the mark cos was not specified.
Mark IP DSCP	The mark/re-mark value used as the DSCP for traffic matching this class. This is not displayed if mark ip description is not specified.
Mark IP Precedence	The mark/re-mark value used as the IP Precedence for traffic matching this class. This is not displayed if mark ip precedence is not specified.
Mirror	Copies a classified traffic stream to a specified egress port (physical port or LAG). This can occur in addition to any marking or policing action. It might also be specified along with a QoS queue assignment.
Non-Conform Action	The current setting for the action taken on a packet considered to not conform to the policing parameters. This is not displayed if policing not in use for the class under this policy.
Non-Conform COS	The CoS mark value if the non-conform action is set-cos-transmit.
Non-Conform DSCP Value	The DSCP mark value if the non-conform action is set-dscp-transmit.
Non-Conform IP Precedence Value	The IP Precedence mark value if the non-conform action is set-prec-transmit.

Term	Definition
Policing Style	The style of policing, if any, used (simple).
Redirect	Forces a classified traffic stream to a specified egress port (physical or LAG). This can occur in addition to any marking or policing action. It might also be specified along with a QoS queue assignment.

If the policy name is not specified, this command displays a list of all defined DiffServ policies. The fields that are shown in the following table are displayed.

Term	Definition
Policy Name	The name of this policy. (The order in which the policies are displayed is not necessarily the same order in which they were created.)
Policy Type	The policy type (Only inbound is supported).
Class Members	List of all class names associated with this policy.

### show diffserv service

This command displays policy service information for the specified interface and direction. The `<slot/port>` parameter specifies a valid slot/port number for the system.

Format	<code>show diffserv service &lt;slot/port&gt; [in   out]</code>
Mode	Privileged EXEC

Term	Definition
DiffServ Admin Mode	The current setting of the DiffServ administrative mode. An attached policy is only in effect on an interface while DiffServ is in an enabled mode.
Interface	Valid slot and port number separated by forward slashes.
Direction	The traffic direction of this interface service.
Operational Status	The current operational status of this DiffServ service interface.
Policy Name	The name of the policy attached to the interface in the indicated direction.
Policy Details	Attached policy details, whose content is identical to that described for the <code>show policy-map &lt;polycymapname&gt;</code> command (content not repeated here for brevity).

### show diffserv service brief

This command displays all interfaces in the system to which a DiffServ policy has been attached. The inbound direction parameter is optional.

Format	<code>show diffserv service brief [in   out]</code>
Mode	Privileged EXEC

Term	Definition
DiffServ Admin Mode	The current setting of the DiffServ administrative mode. An attached policy is only active on an interface while DiffServ is in an enabled mode.

The information that is shown in the following table is repeated for each interface and direction (only those interfaces configured with an attached policy are shown).

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
Direction	The traffic direction of this interface service.
OperStatus	The current operational status of this DiffServ service interface.
Policy Name	The name of the policy attached to the interface in the indicated direction.

### show policy-map interface

This command displays policy-oriented statistics information for the specified interface and direction. The `<slot/port>` parameter specifies a valid interface for the system.

---

**Note:** This command is only allowed while the DiffServ administrative mode is enabled.

---

Format	<code>show policy-map interface &lt;slot/port&gt; [in   out]</code>
Mode	Privileged EXEC

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
Direction	The traffic direction of this interface service.
Operational Status	The current operational status of this DiffServ service interface.
Policy Name	The name of the policy attached to the interface in the indicated direction.

The information that is shown in the following table is repeated for each class instance within this policy.

Term	Definition
Class Name	The name of this class instance.
In Discarded Packets	A count of the packets discarded for this class instance for any reason due to DiffServ treatment of the traffic class.

## show service-policy

This command displays a summary of policy-oriented statistics information for all interfaces in the specified direction.

Format	show service-policy {in   out}
Mode	Privileged EXEC

The information that is shown in the following table is repeated for each interface and direction (only those interfaces configured with an attached policy are shown).

Term	Definition
Interface	Valid slot and port number separated by forward slashes.
Operational Status	The current operational status of this DiffServ service interface.
Policy Name	The name of the policy attached to the interface.

## MAC Access Control List (ACL) Commands

This section describes the commands you use to configure MAC ACL settings. MAC ACLs ensure that only authorized users have access to specific resources and block any unwarranted attempts to reach network resources.

The following rules apply to MAC ACLs:

- The maximum number of ACLs you can create is hardware-dependent. The limit applies to all ACLs, regardless of type.
- The system supports only Ethernet II frame types.
- The maximum number of rules per MAC ACL is hardware-dependent.

### mac access-list extended

This command creates a MAC access control list (ACL) identified by *<name>*, consisting of classification fields defined for the Layer 2 header of an Ethernet frame. The *<name>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the MAC access list.

If a MAC ACL by this name exists, this command enters Mac-Access-List config mode to allow updating the existing MAC ACL.

---

**Note:** The CLI mode changes to Mac-Access-List Config mode when you successfully execute this command.

---

Format	mac access-list extended <name>
Mode	Global Config

### no mac access-list extended

This command deletes a MAC ACL identified by <name> from the system.

Format	no mac access-list extended <name>
Mode	Global Config

### mac access-list extended rename

This command changes the name of a MAC access control list (ACL). The <name> parameter is the name of an existing MAC ACL. The <newname> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the MAC access list.

This command fails if a MAC ACL by the name <newname> exists.

Format	mac access-list extended rename <name> <newname>
Mode	Global Config

### {deny | permit} (MAC ACL)

This command creates a new rule for the current MAC access list. Each rule is appended to the list of configured rules for the list.

---

**Note:** The **no** form of this command is not supported, since the rules within a MAC ACL cannot be deleted individually. Rather, the entire MAC ACL must be deleted and respecified.

---



---

**Note:** An implicit **deny all** MAC rule always terminates the access list.

---

A rule might either deny or permit traffic according to the specified classification fields. At a minimum, the source and destination MAC value must be specified, each of which might be substituted using the keyword **any** to indicate a match on any value in that field. The remaining command parameters are all optional, but the most frequently used parameters appear in the same relative order as shown in the command format.

The Ethertype might be specified as either a keyword or a four-digit hexadecimal value from 0x0600-0xFFFF. The currently supported <ethertypekey> values are: **appletalk**, **arp**,

`ibmsna`, `ipv4`, `ipv6`, `ipx`, `mplsmcast`, `mplsucast`, `netbios`, `novell`, `pppoe`, and `rarp`. Each of these translates into its equivalent Ethertype value or values.

The time-range parameter allows imposing time limitation on the MAC ACL rule as defined by the parameter `<time-range-name>`. If a time range with the specified name does not exist and the MAC ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied immediately. If a time range with a specified name exists and the MAC ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied when the time range with a specified name becomes active. The ACL rule is removed when the time range with a specified name becomes inactive.

Ethertype Keyword	Corresponding Value
appletalk	0x809B
arp	0x0806
ibmsna	0x80D5
ipv4	0x0800
ipv6	0x86DD
ipx	0x8037
mplsmcast	0x8848
mplsucast	0x8847
netbios	0x8191
novell	0x8137, 0x8138
pppoe	0x8863, 0x8864
rarp	0x8035

The `vlan` and `cos` parameters refer to the VLAN identifier and 802.1p user priority fields, respectively, of the VLAN tag. For packets containing a double VLAN tag, this is the first (or outer) tag.

The `assign-queue` parameter allows specification of a particular hardware queue for handling traffic that matches this rule. The allowed `<queue-id>` value is  $0-(n-1)$ , where  $n$  is the number of user configurable queues available for the hardware platform. The `assign-queue` parameter is valid only for a permit rule.

---

**Note:** The special command form `{deny | permit} any any` is used to match all Ethernet layer 2 packets, and is the equivalent of the IP access list `match every` rule.

---

Format	{deny   permit} {<srcmac>   any} {<dstmac>   any} [ <i>&lt;ethertypekey&gt;</i>   <0x0600-0xFFFF>] [vlan {eq <0-4095>}] [cos <0-7>] [[log] [time-range <time-range-name>] [assign-queue <queue-id>]] [{mirror   redirect} <slot/port>]
Mode	Mac-Access-List Config

### mac access-group

This command either attaches a specific MAC access control list (ACL) identified by *<name>* to an interface, or associates it with a VLAN ID in a specific direction. The *<name>* parameter must be the name of an existing MAC ACL.

An optional sequence number might be specified to indicate the order of this mac access list relative to other mac access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified mac access list replaces the currently attached mac access list using that sequence number. If the sequence number is not specified for this command, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used.

This command specified in Interface Config mode only affects a single interface, whereas the Global Config mode setting is applied to all interfaces. The VLAN keyword is only valid in the Global Config mode. The Interface Config mode command is available only on platforms that support independent per-port Class of Service queue configuration.

Format	mac access-group <i>&lt;name&gt;</i> {in   {vlan <i>&lt;vlan-id&gt;</i> in}} [sequence <1-4294967295>]
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no mac access-group

This command removes a MAC ACL identified by *<name>* from the interface in a specific direction.

Format	no mac access-group <i>&lt;name&gt;</i> {in   {vlan <i>&lt;vlan-id&gt;</i> in}}
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>



## show mac access-lists

This command displays a MAC access list and all of the rules that are defined for the MAC ACL. Use the [ <name> ] parameter to identify a specific MAC ACL to display.

Format	show mac access-lists [<name>]
Mode	Privileged EXEC

Term	Definition
Rule Number	The ordered rule number identifier defined within the MAC ACL.
Action	The action associated with each rule. The possible values are Permit or Deny.
Source MAC Address	The source MAC address for this rule.
Destination MAC Address	The destination MAC address for this rule.
Ethertype	The Ethertype keyword or custom value for this rule.
VLAN ID	The VLAN identifier value or range for this rule.
COS	The COS (802.1p) value for this rule.
Log	Displays when you enable logging for the rule.
Assign Queue	The queue identifier to which packets matching this rule are assigned.
Mirror Interface	The slot/port to which packets matching this rule are copied.
Redirect Interface	The slot/port to which packets matching this rule are forwarded.
Time Range name	Displays the name of the time-range if the MAC ACL rule has referenced a time range.
Rule Status	Status (Active/Inactive) of the MAC ACL rule

## IP Access Control List (ACL) Commands

This section describes the commands you use to configure IP ACL settings. IP ACLs ensure that only authorized users have access to specific resources and block any unwarranted attempts to reach network resources.

The following rules apply to IP ACLs:

- Managed switch software does not support IP ACL configuration for IP packet fragments.
- The maximum number of ACLs you can create is hardware-dependent. The limit applies to all ACLs, regardless of type.
- The maximum number of rules per IP ACL is hardware-dependent.

- Wildcard masking for ACLs operates differently from a subnet mask. A wildcard mask is in essence the inverse of a subnet mask. With a subnet mask, the mask has ones (1's) in the bit positions that are used for the network address, and has zeros (0's) for the bit positions that are not used. In contrast, a wildcard mask has (0's) in a bit position that must be checked. A '1' in a bit position of the ACL mask indicates the corresponding bit can be ignored.

## access-list

This command creates an IP access control list (ACL) that is identified by the access list number, which is 1-99 for standard ACLs or 100-199 for extended ACLs.

### IP Standard ACL:

Format	<code>access-list &lt;1-99&gt; {deny   permit} {every   &lt;srcip&gt; &lt;srcmask&gt;} [[log] [rate-limit &lt;1-4294967295&gt; &lt;1-128&gt;][assign-queue &lt;queue-id&gt;] [{mirror   redirect} &lt;slot/port&gt;]</code>
Mode	Global Config

### IP Extended ACL:

Format	<code>access-list &lt;100-199&gt; {deny   permit} {every   {{icmp   igmp   ip   tcp   udp   &lt;number&gt;} {&lt;srcip&gt; &lt;srcmask&gt;} [eq {&lt;portkey&gt;   &lt;0-65535&gt;}] {&lt;dstip&gt; &lt;dstmask&gt;} [eq {&lt;portkey&gt;   &lt;0-65535&gt;}] [precedence &lt;precedence&gt;   tos &lt;tos&gt; &lt;tosmask&gt;   dscp &lt;dscp&gt;]}} [[log] [rate-limit &lt;1-4294967295&gt; &lt;1-128&gt;] [assign-queue &lt;queue-id&gt;] [{mirror   redirect} &lt;slot/port&gt;]</code>
Mode	Global Config

Parameter	Description
<1-99> or <100-199>	Range 1–99 is the access list number for an IP standard ACL. Range 100–199 is the access list number for an IP extended ACL.
{deny   permit}	Specifies whether the IP ACL rule permits or denies an action.
every	Match every packet
{icmp   igmp   ip   tcp   udp   <number>}	Specifies the protocol to filter for an extended IP ACL rule. <number> can be a value from 0-255.
<srcip> <srcmask>	Specifies a source IP address and source netmask for match condition of the IP ACL rule.

Parameter	Description
<code>eq {&lt;portkey&gt;   &lt;0-65535&gt;}</code>	<p><b>Note:</b> This option is available only if the protocol is <code>tcp</code> or <code>udp</code>.</p> <p>When <code>eq</code> is specified, an IP ACL rule matches only if the Layer 4 port number is equal to the specified port number or port key. You can enter the port number, which ranges from 0-65535, or the port key, which can be one of the following keywords:</p> <p>For <code>tcp</code> protocol: <code>bgp</code>, <code>domain</code>, <code>echo</code>, <code>ftp</code>, <code>ftp-data</code>, <code>http</code>, <code>smtp</code>, <code>telnet</code>, <code>www</code>, <code>pop2</code>, or <code>pop3</code>.</p> <p>For <code>udp</code> protocol: <code>domain</code>, <code>echo</code>, <code>ntp</code>, <code>rip</code>, <code>snmp</code>, <code>tftp</code>, <code>time</code>, or <code>who</code>.</p> <p>Each of these keywords translates into its equivalent port number.</p> <p><b>Note:</b> Port number matches-only apply to unfragmented or first fragments.</p> <p><b>Note:</b> You can specify a port key or port number for the source and a port key or port number for the destination.</p>
<code>&lt;dstip&gt; &lt;dstmask&gt;</code>	Specifies a destination IP address and netmask for match condition of the IP ACL rule.
<code>[precedence &lt;precedence&gt;   tos &lt;tos&gt; [&lt;tosmask&gt;]   dscp &lt;dscp&gt;]</code>	Specifies the ToS for an IP ACL rule depending on a match of precedence or DSCP values using the parameters <code>precedence &lt;precedence&gt;</code> , <code>tos &lt;tos&gt;</code> , or <code>dscp &lt;dscp&gt;</code> . <code>&lt;tosmask&gt;</code> is an optional parameter.
<code>[log]</code>	Specifies that this rule is to be logged.
<code>[rate-limit &lt;1-4294967295&gt; &lt;1-128&gt;]</code>	You can specify a simple rate limiter for packets matching an ACL <code>permit</code> rule. You must specify the allowed rate of traffic in kbps (from 1-429496729) and burst size in kbytes (from 1-128). The conforming traffic is allowed to transmit and nonconforming traffic is dropped. This action is ignored for any <code>deny</code> rule, because, by definition, matching packets are dropped.
<code>[assign-queue &lt;queue-id&gt;]</code>	Specifies the assign-queue, which is the queue identifier to which packets matching this rule are assigned.
<code>[{mirror   redirect} &lt;slot/port&gt;]</code>	Specifies the mirror or redirect interface, which is the <code>&lt;slot/port&gt;</code> to which packets matching this rule are copied or forwarded, respectively.

### no access-list

This command deletes an IP ACL that is identified by the parameter `<accesslistnumber>` from the system. The range for `<accesslistnumber>` 1-99 for standard access lists and 100-199 for extended access lists.

Format	<code>no access-list &lt;accesslistnumber&gt;</code>
Mode	Global Config

## ip access-list

This command creates an extended IP access control list (ACL) identified by *<name>*, consisting of classification fields defined for the IP header of an IPv4 frame. The *<name>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the IP access list.

If an IP ACL by this name exists, this command enters IPv4-Access List config mode to allow updating the existing IP ACL.

---

**Note:** The CLI mode changes to IPv4-Access-List Config mode when you successfully execute this command.

---

Format	<code>ip access-list &lt;name&gt;</code>
Mode	Global Config

## no ip access-list

This command deletes the IP ACL identified by *<name>* from the system.

Format	<code>no ip access-list &lt;name&gt;</code>
Mode	Global Config

## ip access-list rename

This command changes the name of an IP access control list (ACL). The *<name>* parameter is the names of an existing IP ACL. The *<newname>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the IP access list.

This command fails if an IP ACL by the name *<newname>* exists.

Format	<code>ip access-list rename &lt;name&gt; &lt;newname&gt;</code>
Mode	Global Config

## {deny | permit} (IP ACL)

This command creates a new rule for the current IP access list. Each rule is appended to the list of configured rules for the list.

---

**Note:** The `no` form of this command is not supported, since the rules within an IP ACL cannot be deleted individually. Rather, the entire IP ACL must be deleted and respecified.

---

---

**Note:** An implicit **deny** **all** IP rule always terminates the access list.

---



---

**Note:** The **mirror** parameter allows traffic matching this rule to be copied to the specified *<slot/port>*, while the **redirect** parameter allows traffic matching this rule to be forwarded to the specified *<slot/port>*. The **assign-queue** and **redirect** parameters are valid only for a **permit** rule.

---

A rule might either deny or permit traffic according to the specified classification fields. At a minimum, either every keyword or the protocol, source address, and destination address values must be specified. The source and destination IP address fields might be specified using the keyword **any** to indicate a match on any value in that field. The remaining command parameters are all optional, but the most frequently used parameters appear in the same relative order as shown in the command format.

The **assign-queue** parameter allows specification of a particular hardware queue for handling traffic that matches this rule. The allowed *<queue-id>* value is 0-(*n*-1), where *n* is the number of user configurable queues available for the hardware platform. The **assign-queue** parameter is valid only for a **permit** rule.

The **time-range** parameter allows imposing time limitation on the IP ACL rule as defined by the parameter *<time-range-name>*. If a time range with the specified name does not exist and the IP ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied immediately. If a time range with specified name exists and the IP ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied when the time range with specified name becomes active. The ACL rule is removed when the time range with specified name becomes inactive.

You can specify a simple rate limiter for packets matching an ACL **permit** rule. You must specify the burst size in kbytes and allowed rate of traffic in kbps. The conforming traffic is allowed to transmit, and non-conforming traffic is dropped. This action is ignored for any **deny** rule, since by definition matching packets are dropped.

Format	{deny   permit} {every   {{icmp   igmp   ip   tcp   udp   <number>} {<srcip> <srcmask>} [eq {<portkey>   <0-65535>}] {<dstip> <dstmask>} [eq {<portkey>   <0-65535>}] [precedence <precedence>   tos <tos> <tosmask>   dscp <dscp>]}} [log] [rate-limit <1-4294967295> <1-128>] [timerange <time-range-name>] [assign-queue <queue-id>] [{mirror   redirect} [lag <lag-group-id>   <slot/port>]]
Mode	Ipv4-Access-List Config

Parameter	Description
{deny   permit}	Specifies whether the IP ACL rule permits or denies the matching traffic.
every	Match every packet.
{icmp   igmp   ip   tcp   udp   <number>}	Specifies the protocol to match for the IP ACL rule. <number> can be a value from 0-255.
<srcip> <srcmask>	Specifies a source IP address and source netmask to match for the IP ACL rule.
eq {<portkey>   <0-65535>}	<p><b>Note:</b> This option is available only if the protocol is <code>tcp</code> or <code>udp</code>.</p> <p>When <code>eq</code> is specified, an IP ACL rule matches only if the Layer 4 port number is equal to the specified port number or port key. You can enter the port number, which ranges from 0-65535, or the port key, which can be one of the following keywords:</p> <p>For <code>tcp</code> protocol: <code>bgp</code>, <code>domain</code>, <code>echo</code>, <code>ftp</code>, <code>ftp-data</code>, <code>http</code>, <code>smtp</code>, <code>telnet</code>, <code>www</code>, <code>pop2</code>, or <code>pop3</code>.</p> <p>For <code>udp</code> protocol: <code>domain</code>, <code>echo</code>, <code>ntp</code>, <code>rip</code>, <code>snmp</code>, <code>tftp</code>, <code>time</code>, or <code>who</code>.</p> <p>Each of these keywords translates into its equivalent port number.</p> <p><b>Note:</b> Port number matches-only apply to unfragmented or first fragments.</p> <p><b>Note:</b> You can specify a port key or port number for the source and a port key or port number for the destination.</p>
<dstip> <dstmask>	Specifies a destination IP address and netmask for match condition of the IP ACL rule.
[precedence <precedence>   tos <tos> [<tosmask>]   dscp <dscp>]	Specifies the ToS for an IP ACL rule depending on a match of precedence or DSCP values using the parameters <b>precedence</b> <precedence>, <b>tos</b> <tos>, or <b>dscp</b> <dscp>. <tosmask> is an optional parameter.
log	Specifies that this rule is to be logged.
[rate-limit <1-4294967295> <1-128>]	Specifies the allowed rate of traffic as per the configured rate in kbps (from 1-4294967295) and burst-size in kbytes (from 1-128).
time-range <time-range-name>	Allows imposing a time limitation on the ACL rule as defined by the parameter <time-range-name.> If a time range with the specified name does not exist and the ACL containing this ACL rule is applied to an interface or bound to a VLAN, the ACL rule is applied immediately. If a time range with specified name exists and the ACL containing this ACL rule is applied to an interface or bound to a VLAN, the ACL rule is applied when the time-range with specified name becomes active. The ACL rule is removed when the time-range with specified name becomes inactive.

Parameter	Description
assign-queue <queue-id>	Specifies the assign-queue, which is the queue identifier to which packets matching this rule are assigned.
[{mirror   redirect} [lag <lag-group-id>   <slot/port>]	Specifies the mirror or redirect interface which is the <lag-group-id> or <slot/port> to which packets matching this rule are copied or forwarded, respectively.

## ip access-group

This command either attaches a specific IP ACL identified by <accesslistnumber> to an interface or associates with a VLAN ID in a specific direction. The parameter <name> is the name of the access control list.

An optional sequence number might be specified to indicate the order of this IP access list relative to other IP access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified access list replaces the currently attached IP access list using that sequence number. If the sequence number is not specified for this command, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used.

Default	none
Format	ip access-group {<accesslistnumber>   <name>} {in   {vlan <vlan-id> in}} [sequence <1-4294967295>]
Modes	<ul style="list-style-type: none"> <li>Interface Config</li> <li>Global Config</li> </ul>

## no ip access-group

This command removes a specified IP ACL from an interface.

Default	none
Format	no ip access-group {<accesslistnumber>   <name>} {in   {vlan <vlan-id> in}}
Mode	<ul style="list-style-type: none"> <li>Interface Config</li> <li>Global Config</li> </ul>

## acl-trapflags

This command enables the ACL trap mode.

Default	disabled
Format	acl-trapflags
Mode	Global Config

**no acl-trapflags**

This command disables the ACL trap mode.

Format	no acl-trapflags
Mode	Global Config

**show ip access-lists**

This command displays an IP ACL *<accesslistnumber>* is the number used to identify the IP ACL.

Format	show ip access-lists <i>&lt;accesslistnumber&gt;</i>
Mode	Privileged EXEC

---

**Note:** Only the access list fields that you configure are displayed.

---

Term	Definition
Rule Number	The number identifier for each rule that is defined for the IP ACL.
Action	The action associated with each rule. The possible values are Permit or Deny.
Match All	Indicates whether this access list applies to every packet. Possible values are True or False.
Protocol	The protocol to filter for this rule.
Source IP Address	The source IP address for this rule.
Source IP Mask	The source IP Mask for this rule.
Source L4 Port Keyword	The source port for this rule.
Destination IP Address	The destination IP address for this rule.
Destination IP Mask	The destination IP Mask for this rule.
Destination L4 Port Keyword	The destination port for this rule.
IP DSCP	The value specified for IP DSCP.
IP Precedence	The value specified IP Precedence.
IP TOS	The value specified for IP TOS.



Term	Definition
Log	Displays when you enable logging for the rule.
Assign Queue	The queue identifier to which packets matching this rule are assigned.
Mirror Interface	The slot/port to which packets matching this rule are copied.
Redirect Interface	The slot/port to which packets matching this rule are forwarded.
Time Range Name	Displays the name of the time-range if the ACL rule has referenced a time range.
Rule Status	Status (Active/Inactive) of the ACL rule.

### show access-lists

This command displays IP ACLs, IPv6 ACLs, and MAC access control lists information for a designated interface and direction.

Format	<code>show access-lists interface &lt;slot/port&gt; [in   out]</code>
Mode	Privileged EXEC

Term	Definition
ACL Type	Type of access list (IP, IPv6, or MAC).
ACL ID	Access List name for a MAC or IPv6 access list or the numeric identifier for an IP access list.
Sequence Number	An optional sequence number might be specified to indicate the order of this access list relative to other access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified access list replaces the currently attached access list using that sequence number. If the sequence number is not specified by the user, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used. Valid range is (1–4,294,967,295).

## IPv6 Access Control List (ACL) Commands

This section describes the commands you use to configure IPv6 ACL settings. IPv6 ACLs ensure that only authorized users have access to specific resources and block any unwarranted attempts to reach network resources.

The following rules apply to IPv6 ACLs:

- The maximum number of ACLs you create is 100, regardless of type.
- The system supports only Ethernet II frame types.
- The maximum number of rules per IPv6 ACL is hardware-dependent.

## ipv6 access-list

This command creates an IPv6 access control list (ACL) identified by *<name>*, consisting of classification fields defined for the IP header of an IPv6 frame. The *<name>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the IPv6 access list.

If an IPv6 ACL by this name exists, this command enters IPv6-Access-List config mode to allow updating the existing IPv6 ACL.

---

**Note:** The CLI mode changes to IPv6-Access-List Config mode when you successfully execute this command.

---

Format	<code>ipv6 access-list &lt;name&gt;</code>
Mode	Global Config

## no ipv6 access-list

This command deletes the IPv6 ACL identified by *<name>* from the system.

Format	<code>no ipv6 access-list &lt;name&gt;</code>
Mode	Global Config

## ipv6 access-list rename

This command changes the name of an IPv6 ACL. The *<name>* parameter is the name of an existing IPv6 ACL. The *<newname>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the IPv6 access list.

This command fails if an IPv6 ACL by the name *<newname>* already exists.

Format	<code>ipv6 access-list rename &lt;name&gt; &lt;newname&gt;</code>
Mode	Global Config

## {deny | permit} (IPv6)

This command creates a new rule for the current IPv6 access list. Each rule is appended to the list of configured rules for the list.

---

**Note:** The `no` form of this command is not supported because the rules within an IPv6 ACL cannot be deleted individually. Rather, the entire IPv6 ACL must be deleted and respecified.

---

---

**Note:** An implicit **deny** all IPv6 rule always terminates the access list.

---

A rule might either deny or permit traffic according to the specified classification fields. At a minimum, either the **every** keyword or the protocol, source address, and destination address values must be specified. The source and destination IPv6 address fields might be specified using the **any** keyword to indicate a match on any value in that field. The remaining command parameters are all optional, but the most frequently used parameters appear in the same relative order as shown in the command format.

The **assign-queue** parameter allows specification of a particular hardware queue for handling traffic that matches this rule. The allowed *<queue-id>* value is 0-(*n*-1), where *n* is the number of user configurable queues available for the hardware platform. The **assign-queue** parameter is valid only for a permit rule.

The **mirror** parameter allows the traffic matching this rule to be copied to the specified *<slot/port>*, while the **redirect** parameter allows the traffic matching this rule to be forwarded to the specified *<slot/port>*. The **assign-queue** and **redirect** parameters are only valid for a permit rule.

The **time-range** parameter allows imposing time limitation on the IPv6 ACL rule as defined by the parameter *<time-range-name>*. If a time range with the specified name does not exist and the IPv6 ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied immediately. If a time range with specified name exists and the IPv6 ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied when the time-range with specified name becomes active. The ACL rule is removed when the time-range with specified name becomes inactive.

Format	{deny   permit} {every   {icmp   igmp   ipv6   tcp   udp   <number>}} [log] [timerange <time-range-name>] [assign-queue <queue-id>] [ {mirror   redirect} <slot/port> ]
Mode	IPv6-Access-List Config

## ipv6 traffic-filter

This command either attaches a specific IPv6 ACL identified by *<name>* to an interface or associates with a VLAN ID in a specific direction. The *<name>* parameter must be the name of an existing IPv6 ACL.

An optional sequence number might be specified to indicate the order of this mac access list relative to other IPv6 access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified IPv6 access list replaces the currently attached IPv6 access list using that sequence number. If the sequence number is not specified for this command, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used.

This command specified in Interface Config mode only affects a single interface, whereas the Global Config mode setting is applied to all interfaces. The **vlan** keyword is valid only in the

Global Config mode. The Interface Config mode command is only available on platforms that support independent per-port Class of Service queue configuration.

Format	<code>ipv6 traffic-filter &lt;name&gt; {in   {vlan &lt;vlan-id&gt; in}} [sequence &lt;1-4294967295&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no ipv6 traffic-filter

This command removes an IPv6 ACL identified by <name> from the interface or interfaces in a specific direction.

Format	<code>no ipv6 traffic-filter &lt;name&gt; {in   {vlan &lt;vlan-id&gt; in}}</code>
Modes	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### show ipv6 access-lists

This command displays an IPv6 access list and all of the rules that are defined for the IPv6 ACL. Use the [*<name>*] parameter to identify a specific IPv6 ACL to display.

Format	<code>show ipv6 access-lists [&lt;name&gt;]</code>
Mode	Privileged EXEC

Term	Definition
Rule Number	The ordered rule number identifier defined within the IPv6 ACL.
Action	The action associated with each rule. The possible values are Permit or Deny.
Match All	Indicates whether this access list applies to every packet. Possible values are True or False.
Protocol	The protocol to filter for this rule.
Source IP Address	The source IP address for this rule.
Source L4 Port Keyword	The source port for this rule.
Destination IP Address	The destination IP address for this rule.
Destination L4 Port Keyword	The destination port for this rule.
IP DSCP	The value specified for IP DSCP.
Flow Label	The value specified for IPv6 Flow Label.

Term	Definition
Log	Displays when you enable logging for the rule.
Assign Queue	The queue identifier to which packets matching this rule are assigned.
Mirror Interface	The slot/port to which packets matching this rule are copied.
Redirect Interface	The slot/port to which packets matching this rule are forwarded.
Time Range Name	Displays the name of the time-range if the IPv6 ACL rule has referenced a time range.
Rule Status	Status (Active/Inactive) of the IPv6 ACL rule.

## Time Range Commands for Time-Based ACLs

Time-based ACLs allow one or more rules within an ACL to be based on time. Each ACL rule within an ACL, except for the implicit deny all rule, can be configured to be active and operational only during a specific time period. The time range commands allow you to define specific times of the day and week to implement time-based ACLs. The time range is identified by a name and can then be referenced by an ACL rule defined within an ACL.

### time-range

Use this command to create a time range identified by *<name>*, consisting of one absolute time entry and/or one or more periodic time entries. The *<name>* parameter is a case-sensitive, alphanumeric string from 1 to 31 characters that uniquely identifies the time range. An alpha-numeric string is defined as consisting of only alphabetic, numeric, dash, underscore, or space characters. If a time range by this name exists, this command enters Time-Range config mode to allow updating the time range entries

---

**Note:** When you successfully execute this command, the CLI mode changes to Time-Range Config mode.

---

Format	time-range <i>&lt;name&gt;</i>
Mode	Global Config

### no time-range

Use this command to delete a time-range identified by *<name>*.

Format	no time-range <i>&lt;name&gt;</i>
Mode	Global Config

## absolute

Use this command to add an absolute time entry to a time range. Only one absolute time entry is allowed per time-range. The `<time>` parameters are based on the currently configured time zone. The `[start <time> <date>]` parameters indicate the time and date at which the configuration that referenced the time range starts going into effect. The time is expressed in a 24-hour clock, in the form of hours:minutes. For example, 8:00 is 8:00 am and 20:00 is 8:00 pm. The date is expressed in the format day month year. If no start time and date are specified, the configuration statement is in effect immediately. The `[end <time> <date>]` parameters indicate the time and date at which the configuration that referenced the time range is no longer in effect. The end time and date must be after the start time and date. If no end time and date are specified, the configuration statement is in effect indefinitely.

Format	<code>absolute {[start &lt;time&gt; &lt;date&gt;] [end &lt;time&gt; &lt;date&gt;]}</code>
Mode	Time-Range Config

## no absolute

Use this command to delete the absolute time entry in the time range.

Format	<code>no absolute</code>
Mode	Time-Range Config

## periodic

Use this command to add a periodic time entry to a time range. The `<time>` parameters are based off the currently configured time zone. The first occurrence of the `<days-of-the-week>` argument is the starting day(s) from which the configuration that referenced the time range starts going into effect. The second occurrence is the ending day or days from which the configuration that referenced the time range is no longer in effect. If the end days-of-the-week are the same as the start, they can be omitted. This argument can be any single day or combinations of days: Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, Sunday. Other possible values are:

- `daily`—Monday through Sunday
- `weekdays`—Monday through Friday
- `weekend`—Saturday and Sunday

If the ending days of the week are the same as the starting days of the week, they can be omitted. The first occurrence of the `<time>` argument is the starting hours:minutes which the configuration that referenced the time range starts going into effect. The second occurrence is the ending hours:minutes at which the configuration that referenced the time range is no longer in effect. The hours:minutes are expressed in a 24-hour clock. For example, 8:00 is 8:00 am and 20:00 is 8:00 pm

The frequency is how often this periodic entry will become active. If the value is set to 0, the timer schedule will be treated as absolute.

Format	<code>periodic &lt;frequency&gt; {&lt;days-of-the-week&gt; &lt;time&gt;} to</code> <code>{[&lt;days-of-the-week&gt;] &lt;time&gt;}</code>
Mode	Time-Range Config

**no periodic**

Use this command to delete a periodic time entry from a time range.

Format	<code>no periodic &lt;frequency&gt; {&lt;days-of-the-week&gt; &lt;time&gt;} to</code> <code>{[&lt;days-of-the-week&gt;] &lt;time&gt;}</code>
Mode	Time-Range Config

**periodic time**

Use this command to configure the start or end time for the time range.

Format	<code>periodic {start   end} time</code>
Mode	Time-Range Config

**show time-range**

Use this command to display a time range and all the absolute/periodic time entries that are defined for the time range. Use the [ <name> ] parameter to identify a specific time range to display. When [ <name> ] is not specified, all the time ranges defined in the system are displayed.

Format	<code>show time-range [&lt;name&gt;]</code>
Mode	Privileged EXEC

Term	Definition
Number of Time Ranges	Number of time ranges configured in the system.
Time Range Name	Name of the time range.
Time Range Status	Status of the time range (active/inactive).
Absolute start	Start time and day for absolute time entry.
Absolute end	End time and day for absolute time entry.
Periodic Entries	Number of periodic entries in a time-range.
Periodic start	Start time and day for periodic entry.
Periodic end	End time and day for periodic entry.

## AutoVoIP Commands

AutoVoIP detects the VoIP streams and put the VoIP streams in the specific VLAN (auto-voip VLAN) and provides higher Class of Service to the VoIP streams automatically (both data and signaling). It detects the VoIP streams in two modes.

- **Protocol-based Auto VoIP.** In a VoIP system, various signaling protocols are used to establish the connection between two VoIP devices. The supported signaling protocols are SIP, H.323, and SCCP.
- **OUI-based Auto VoIP.** The OUI-based Auto VoIP feature prioritizes VoIP packets based on the OUI bytes in the source MAC address. A default list of OUIs is maintained. User is also allowed to configure OUIs that need prioritization apart from the default OUI list. Up to 128 OUIs are allowed on the device or system, including the default OUIs.

---

**Note:** If voice VLAN and Auto-VoIP are enabled at the same time, one of them is operational. If the connected phone is LLDP-MED capable, voice VLAN has precedence over the Auto VoIP and Auto VoIP is operational if the phone does not support LLDP-MED.

---

### auto-voip

This command is used to configure auto VoIP mode. The supported modes are protocol-based and OUI-based. Protocol-based auto VoIP prioritizes the voice data based on the layer 4 port used for the voice session. OUI-based auto VOIP prioritizes the phone traffic based on the known OUI of the phone.

Default	oui-based
Format	auto-voip {protocol-based   oui-based}
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no auto-voip {protocol-based | oui-based}

This command is used to set default mode.

Format	no auto-voip {protocol-based   oui-based}
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>



### auto-voip oui

This command is used to configure an OUI for Auto VoIP. The traffic from the configured OUI will get the highest priority over the other traffic.

Default	A list of known OUIs is present
Format	<code>auto-voip oui &lt;oui-prefix&gt; oui-desc &lt;string&gt;</code>
Mode	Global Config

### no auto-voip oui

This command is to delete already configured OUI.

Format	<code>no auto-voip oui &lt;oui-prefix&gt;</code>
Mode	Global Config

### auto-voip vlan

This command is used to configure the global auto VoIP VLAN ID. The VLAN behavior depends on the configured auto VoIP mode.

Default	None
Format	<code>auto-voip vlan &lt;vlan-id&gt;</code>
Mode	Global Config

### no auto-voip vlan

This command is used to remove the configured auto VoIP mode.

Format	<code>no auto-voip vlan</code>
Mode	Global Config

### auto-voip oui-based priority

This command is used to configure the global OUI based auto VoIP priority. If the phone OUI matches one of the configured OUI, the priority of traffic from the phone is changed to OUI priority configured through this command.

Default	Highest available priority
Format	<code>auto-voip oui-based priority &lt;priority-value&gt;</code>
Mode	Global Config

### no auto-voip oui-based priority

This command is used to set the priority to the default value.

Format	no auto-voip oui-based priority <priority-value>
Mode	Global Config

### auto-voip protocol-based

This command is used to configure the global protocol based auto-VoIP remarking priority/traffic-class. If the remark priority is configured, the voice data of the session is remarked with the priority configured through this command.

---

**Note:** You must enable tagging on auto-VoIP-enabled ports to remark the voice data when it is egressed.

---

Default	Traffic-class 7
Format	auto-voip protocol-based {remark <remark-priority>   traffic-class <tc>}
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no auto-voip protocol-based {remark | traffic-class}

This command is used to set the traffic-class to the default value.

Format	no auto-voip protocol-based {remark <remark-priority>   traffic-class <tc>}
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### show auto-voip

Use this command to display the auto VoIP settings on the interface or interfaces of the switch.

Format	show auto-voip {protocol-based   oui-based} interface {<slot/port>   all}
Mode	Privileged EXEC

Field	Description
VoIP	The global VoIP VLAN ID.
Prioritize Type	The type of prioritization used on voice traffic.

Field	Description
Class Value	<ul style="list-style-type: none"> <li>If the Prioritization Type is configured as traffic-class, this value is the queue value.</li> <li>If the Prioritization Type is configured as remark, this value is 802.1p priority used to remark the voice traffic.</li> </ul>
Priority	The 802.1p priority. This field is valid for OUI auto VoIP.
AutoVoIPMode	The Auto VoIP mode on the interface.

**Command example:**

```
(NETGEAR Switch)# show auto-voip protocol-based interface all
```

```
VoIP VLAN Id..... 2
Prioritization Type..... traffic-class
Class Value..... 7
```

```
Interface Auto VoIP   Operational Status
Mode
-----
0/1      Disabled      Down
0/2      Disabled      Down
0/3      Disabled      Down
0/4      Disabled      Down
```

**Command example:**

```
(Netgear Switch)# show auto-voip oui-based interface all
```

```
VoIP VLAN Id..... 2
Priority..... 7
```

```
Interface Auto VoIP   Operational Status
Mode
-----
0/1      Disabled      Down
0/2      Disabled      Down
0/3      Disabled      Down
0/4      Disabled      Down
0/5      Disabled      Down
```

## show auto-voip oui-table

This command lists all of the configured OUIs.

Format	show auto-voip oui-table
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
OUI	OUI of the source MAC address
Status	Default or Configured entry.
OUI Description	Description of the OUI

### Command example:

```
(Netgear Switch)# show auto-voip oui-table
OUI           Status      Description
-----
00:01:E3      Default     SIEMENS
00:03:6B      Default     CISCO1
00:01:01      Configured  VoIP phone
```

## 6. Power over Ethernet Commands

---

# 6

This chapter contains the following sections:

- *About PoE*
- *PoE Commands*

## About PoE

Power over Ethernet (PoE) describes a technology to pass electrical power safely along with data on existing Ethernet cabling. The PSE or power supply equipment is the device or switch that delivers electrical power, and the PD or powered device is the end device that powers up through the power delivered along the Ethernet cable.

This technology is governed by two standards:

- IEEE 802.3af-2003. This is the original standard, also known as the low-power standard, which mandates delivery of up to 15.4 watts by the PSE. Because of power dissipation, only 12.95 watts are assured to be available at the powered device (PD). The PD needs to be designed so that it can accept power over Ethernet cabling. Category 3 cables can be used to deliver power to the PD. However, with the advent of 802.11n, the newer wireless APs required more power. To account for this, a newer standard was developed in 2009, known as 802.3at.
- IEEE 802.3at-2009. This is the newer standard, also known as PoE+. This is also known as the high-power standard, which mandates delivery of up to 34.2 watts by the PSE. Because of power dissipation, PoE+ provides only a maximum of 25.5 watts at the powered device. Some PSEs can provide up to 51 watts. Before this standard became available in 2009, the industry started using different implementations to allow for more power. All these needed to be brought under the purview of the newer 802.3at standard.

## PoE Commands

### poe

Use this command to enable the Power over Ethernet (PoE) functionality on a global basis or per interface.

Default	enabled
Format	poe
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no poe

Use this command to disable the Power over Ethernet (PoE) functionality on a global basis or per interface.

Format	no poe
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

## poe detection

Use this command to configure the detection type on a global basis or per interface. It is used to configure which types of PDs will be detected and powered by the switch. There are three options:

- **ieee**. Detect resistive-type devices (IEEE standard)
- **pre-ieee**. Legacy capacitive detection only (nonstandard)
- **auto**. Perform resistive detection first (IEEE standard) and capacitive detection (pre-IEEE standard)

Default	auto
Format	poe detection {ieee   pre-ieee   auto}
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

## no poe detection

Use this command to set the detection mode to the default on a global basis or per interface.

Format	no poe detection
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

## poe high-power

Use this command to switch a port from 802.3af mode to high-power mode. This mode is used to power up devices that require more power than the current IEEE 802.3af power (more than 12.95 watts at the PD). There are three options:

- **legacy**. Use this mode if the device can power up (more than 12.95 watts) with higher current and it cannot identify itself as a Class 4 device.
- **pre-dot3at**. Use this mode if the device cannot identify itself as a Class 4 device and it does not have LLDP support.
- **dot3at**. Use this mode if the device is a Class 4 device capable of figuring out power requirements through 2-event classification or LLDP.

Default	dot3at
Format	poe high-power {legacy   pre-dot3at   dot3at}
Mode	Interface Config

### no poe high-power

Use this command to disable the high-power mode. The port will support only IEEE 902.3af devices.

This command works on a global basis or per interface.

Format	<code>no poe high-power</code>
Mode	Interface Config

### poe power limit

Use this command to configure the type of power limit for a port. If the power limit type is **user-defined**, the command also allows you to configure a maximum power limit.

There are three options:

- **class-based**. Allows the port to draw up to the maximum power based on the classification of the device connected.
- **none**. Allows the port to draw up to Class 0 maximum power if it is in low-power mode and up to Class 4 maximum power if it is in high-power mode.
- **user-defined**. Allows you to define the maximum power to the port. This can be a value from 3 through 32 watts.

Default	User-defined, with a maximum of 30 watts
Format	<code>poe power limit {class-based   none   user-defined [&lt;3000-32000&gt;]}</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no poe power limit

Use this command to set the power limit type to the default. It also sets the maximum power limit to the default if the power limit type is user-defined.

Format	<code>no poe power limit [user-defined]</code>
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### poe power management

Use this command to configure the power management mode based on each individual PoE unit or on all PoE units.

Both the power management modes mentioned here will power up a device based on first come, first served. When the available power is less than the power limit defined on a port, no more power will be delivered.



Static and dynamic modes differ in how the available power is calculated, as follows:

- **Static Power Management**

Available power = power limit of the source - total allocated power where total allocated power is calculated as the power limit configured on the port.

- **Dynamic Power Management**

Available power = power limit of the source - total allocated power, where total allocated power is calculated as the amount of power consumed by the port.

For example, assume that the power limit of the source is 300 watts. One port is powered up and is drawing 3 watts of power. The power limit defined on the port is user-defined as 15 watts. In this case, the available power for static and dynamic would be as follows:

- **Static Power Management**

Available power = 300 watts - 15 watts = 285 watts

- **Dynamic Power Management**

Available power = 300 watts - 3 watts = 297 watts

Default	dynamic
Format	<code>poe power management {&lt;unit&gt;   all} {dynamic   static}</code>
Mode	Global Config

### no poe power management

Use this command to set the power management mode to the default.

Format	<code>no poe power management {&lt;unit&gt;   all}</code>
Mode	Global Config

### poe priority

Use this command to configure the priority on a specific port. This is used for power management purposes. The switch might not be able to supply power to all connected devices, so the port priority is used to determine which ports will supply power if adequate power capacity is not available for all enabled ports. For ports that have the same priority level, the lower numbered port will have higher priority. There are three options:

- **crit.** Critical priority
- **high.** High priority
- **low.** Low priority

Default	low
Format	poe priority {crit   high   low}
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### no poe priority

Use this command to set the priority to the default.

Format	no poe priority
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### poe reset

Use this command to reset the PoE state of every port (in global mode) or a specific port (in interface mode). When the PoE port status is shown to be in an error state, this command can be used to reset the PoE port. The command can also reset the power-delivering ports. Note that this command takes effect only once after it is executed and cannot be saved across power cycles.

Format	poe reset
Mode	<ul style="list-style-type: none"> <li>• Global Config</li> <li>• Interface Config</li> </ul>

### poe timer schedule name

Use this command to allow you to attach a timer schedule to a PoE port.

You can define a time schedule using the existing time range commands. This schedule has start and stop times. When this timer schedule is applied to a PoE-enabled port, the capability of the port to deliver power is affected. At the scheduled start time, the PoE port is disabled such that it cannot deliver any power. At the scheduled stop time, the PoE port is reenabled so that it can deliver power.

---

**Note:** For information about creating a timer schedule, see *Time Range Commands for Time-Based ACLs* on page 309.

---

Format	poe timer schedule <name>
Mode	Interface Config

### no poe timer schedule name

Use this command to detach the schedule from the port.

Format	no poe timer schedule
Mode	Interface Config

### poe usagethreshold

Use this command to set a threshold (as a percentage) for the total amount of power that can be delivered by the switch. For example, if the switch can deliver up to a maximum of 300 watts, a usage threshold of 90 percent ensures that only 270 watts are used for delivering power to devices. This ensures that more power is not drawn than the switch can provide.

When the usage threshold is set, all the PDs are brought down and then brought back up. If the consumed power is less than the threshold power (in the preceding case, 270 watts), then the devices continue to power up. If the consumed power is 269 watts or less, the next device is powered up. The moment consumed power exceeds the threshold power (270 watts), no other devices can power up.

This command allows you to set the usage threshold based on each individual PoE unit or all PoE units.

Default	90
Format	poe usagethreshold {<unit>   all} <1-99>
Mode	Global Config

### no poe usagethreshold

Use this command to set the usage threshold to a default value.

Format	no poe usagethreshold {<unit>   all}
Mode	Global Config

### poe traps

Use this command to enable logging of specific PoE-related events, such as a PoE port powering a device, the threshold being exceeded, and so on.

Default	Enable
Format	poe traps
Mode	Global Config

**no poe traps**

Use this command to disable logging the PoE traps.

Format	no poe traps
Mode	Global Config

**show poe**

Use this command to get global information regarding the PoE status.

Format	show poe
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Firmware Version	The firmware version of the PoE controller on the switch.
PSE Main Operational Status	Indicates the status of the PoE controller: <ul style="list-style-type: none"> <li>• ON—Indicates that the PoE controller is actively delivering power.</li> <li>• OFF—Indicates that the PoE controller is not delivering power.</li> <li>• FAULTY—Indicates that the PoE controller is not functioning.</li> </ul>
Total Power (Main AC)	Indicates the maximum amount of power that can be delivered by this PoE unit when on system power.
Total Power (RPS)	Indicates the maximum amount of power that can be delivered by this PoE unit when on RPS.
Total Power (PD)	Indicates the maximum amount of power that can be delivered by this PoE unit when on the PD source. This field is applicable only for the GSM5212P.
Power Source	Indicates the power source being used: main AC, RPS, or PD. If PD is used as a source, "PD <portNo>" is displayed.
Threshold Power	System can power up one port, if consumed power is less than this power. That is, the consumed power can be between the total power and threshold power values. The threshold power value is effected by changing the system usage threshold.
Total Power Consumed	Indicates the total amount of power being delivered to all the devices plugged into the switch.
Usage Threshold	Indicates the usage threshold level.
Power Management Mode	Indicates the management mode used by the PoE controller.
Auto Reset Mode	Indicates whether the PoE ports will be automatically reset in case of an error on a port.
Traps	Configures the traps.

**Command example:**

```
(NETGEAR Switch) #show poe
```

```
Firmware Version..... 1.0.0.2
PSE Main Operational Status..... ON
Total Power (Main AC)..... 380
Total Power (RPS)..... 300
Total Power (PD) ..... 25
Power Source..... Main AC
Threshold Power..... 342
Total Power Consumed..... 7
Usage Threshold..... 90
Power Management Mode..... Dynamic
Configure port Auto Reset Mode..... Disable
Traps..... Enable
```

**show poe port configuration**

Use this command to see how the PoE ports are configured. You can display information based on each individual port or all the ports collectively.

Format	show poe port configuration [<port>   all]
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

**Command example:**

```
(NETGEAR Switch) #show poe port configuration all
```

```

      Admin      Power  Power Limit  High Power  Detection
Intf  Mode  Priority  Limit  Type      Mode      Type
      (W)
-----
  0/1  Enable  Low   15.400  User Defined  Disable   Auto
  0/2  Enable  Low   15.400  User Defined  Disable   Auto
```

**Command example:**

```
(NETGEAR Switch) #show poe port configuration 0/2
```

```

      Admin      Power  Power Limit  High Power  Detection
Intf  Mode  Priority  Limit  Type      Mode      Type
      (W)
-----
  0/2  Enable  Low   15.400  User Defined  Disable   Auto
```

## show poe port info

Use this command to get information about the status of the PoE ports. You can display information based on each individual port or all the ports collectively. The command displays only PSE-capable ports.

Format	show poe port info [<port>   all]
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Intf	Interface on which PoE is configured.
Class	Class of the powered device according to the IEEE802.3af and IEEE802.3at definition. <ul style="list-style-type: none"> <li>Class Usage Max Power (watts)</li> <li>0 Default 0.44-12.95</li> <li>1 Optional 0.44-3.84</li> <li>2 Optional 3.84-6.49</li> <li>3 Optional 6.49-12.95</li> <li>4 Optional 12.95-25.5</li> </ul>
Power	The power supplied to the powered device (in watts).
Output Current (mA)	The current supplied to the powered device (in mA).
Output Voltage (volts)	The voltage supplied to the powered device (in volts).
Status	<p>The Status field reports the state of power supplied to the port. The possible values are:</p> <ul style="list-style-type: none"> <li>Disabled—The PoE function is disabled on this port.</li> <li>Searching—The port is detecting the PoE device.</li> <li>Delivering Power—The port is providing power to the PoE device.</li> <li>Fault—The POE device is not IEEE compliant; no power is provided.</li> <li>Test—The port is in testing state.</li> <li>Other Fault—The port has experienced problems other than compliance issues.</li> </ul> <p>When a port begins to deliver power, there is a trap indicating so. When a port stops delivering power, there is a trap indicating so.</p>

### Command example:

```
(NETGEAR Switch) #show poe port info all
```

Intf	High Power	Max Power (W)	Class	Power (W)	Output Current (mA)	Output Voltage (volt)	Status	Fault Status
0/1	Yes	32.0	Unknown	00.000	0	00.00	Searching	No Error

**Command example:**

```
(NETGEAR Switch) #show poe port info 0/33
```

Intf	High Power	Max Power (W)	Class	Power (W)	Output Current (mA)	Output Voltage (volt)	Status	Fault Status
0/33	No	18.0	2	04.400	84	53.3	Delivering Power	No Error

**show poe pd**


---

**Note:** This command is supported on the M4100-D12G-POE+ (GSM5212P) only.

---

Use this command to get information about the PD ports. You can display information based on each individual port or all the PD ports collectively.

Format	show poe pd [<port>   all]
Mode	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
Intf	Show the PD device interface number, only 0/1 or 0/2 on the GSM5212P. In other devices, the table is empty. If <port-id> is not specified, all PD ports are displayed.
Mode	Displays the port POE role and is always PD.
Class	Displays the POE class.
Detection Mode	PD detection mode when getting power from the PSE: <ul style="list-style-type: none"> <li>1-event—PSE detects the PD in 1-event mode (802.1f)</li> <li>2-event—PSE detects the PD in 2-event mode (802.1at)</li> <li>LLDP—PSE detects the PD in LLDP mode (802.1at)</li> </ul>
Status	Shows whether the port 0/1 or 0/2 is providing power: <ul style="list-style-type: none"> <li>Powered—Receiving power from PSE</li> <li>Off—No power from the PSE (when main AC is in used)</li> </ul>

**Command example:**

```
(NETGEAR Switch) #show poe pd all
```

Intf	Mode	Class	Detection Mode	Status
0/1	PD	class 4	2-event	powered
0/2	PD	class 4	LLDP	powered

# 7 Utility Commands

---

# 7

This chapter describes the utility commands available in the CLI.

The chapter contains the following sections:

- *Auto Install Commands*
- *Dual Image Commands*
- *System Information and Statistics Commands*
- *Logging Commands*
- *Email Alerting and Mail Server Commands*
- *System Utility and Clear Commands*
- *Simple Network Time Protocol (SNTP) Commands*
- *DHCP Server Commands*
- *DNS Client Commands*
- *Packet Capture Commands*
- *Serviceability Packet Tracing Commands*
- *Cable Test Command*
- *sFlow Commands*
- *IP Address Conflict Commands*
- *RMON Stats and History Commands*
- *UniDirectional Link Detection Commands*
- *USB Commands*

The commands in this chapter are in four functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. Every switch command has a show command that displays the configuration setting.
- Copy commands transfer or save configuration and informational files to and from the switch.
- Clear commands clear some or all of the settings to factory defaults.



## Auto Install Commands

This section describes the Auto Install Commands. Auto Install is a software feature which provides for the configuration of a switch automatically when the device is initialized and no configuration file is found on the switch. The Auto Install process requires DHCP to be enabled by default in order for it to be completed. The downloaded config file is not automatically saved to the startup-config. An administrator must explicitly issue a save request in order to save the configuration. The Auto Install process depends upon the configuration of other devices in the network, including a DHCP or BOOTP server, a TFTP server and, if necessary, a DNS server.

There are three steps to Auto Install:

1. Configuration or assignment of an IP address for the device.
2. Assignment of a TFTP server.
3. Obtain a configuration file for the device from the TFTP server.

### show autoinstall

This command displays the status of the Auto Config process.

Format	show autoinstall
Mode	Privileged EXEC

Term	Definition
AutoInstall Mode	The administrator mode is enabled or disabled.
AutoSave Modet	If this option is enabled, the downloaded config file will be saved. Otherwise, you must explicitly issue a <code>copy running-config startup-config</code> command in order to save the configuration.
AutoInstall Retry Count	the number of attempts to download a configuration.
AutoInstall State	The status of the AutoInstall.

### Command example: Example

```
(NETGEAR Switch) #show autoinstall
AutoInstall Mode..... Stopped
AutoSave Mode..... Disabled
AutoInstall Persistant Mode..... Enabled
AutoInstall Retry Count..... 3
AutoInstall State..... Waiting for boot options
```

### boot host auto-save

This command is used to enable automatically saving the downloaded configuration on the switch.

Default	Disabled
Format	boot host auto-save
Mode	Privileged EXEC

### no boot host auto-save

This command is used to disable automatically saving the downloaded configuration on the switch.

Format	no boot host auto-save
Mode	Privileged EXEC

### boot autoinstall start

The command is used to start Auto Install on the switch. Auto Install tries to download a config file from a TFTP server.

Format	boot autoinstall start
Mode	Privileged EXEC

### boot autoinstall stop

The command is used to A user might terminate the Auto Install process at any time prior to the downloading of the config file. This is most optimally done when the switch is disconnected from the network, or if the requisite configuration files have not been configured on TFTP servers. Termination of the Auto Install process ends further periodic requests for a host-specific file.

Format	boot autoinstall stop
Mode	Privileged EXEC

### boot host retry-count

This command is used to set the number of attempts to download a configuration. The valid range is from 1 to 6.

Default	3
Format	boot host retry-count <count>
Mode	Privileged EXEC

### no boot host retry-count

This command is used to reset the number to the default. The default number is 3.

Format	no boot host retry-count
Mode	Privileged EXEC

### boot host dhcp

This command is used to enable AutoInstall on the switch for the next reboot cycle. The command does not change the current behavior of AutoInstall and saves the command to NVRAM.

Default	Enabled
Format	boot host dhcp
Mode	Privileged EXEC

### no boot host dhcp

This command is used to disable AutoInstall on the switch for the next reboot cycle. The command does not change the current behavior of AutoInstall and saves the command to NVRAM.

Format	no boot host dhcp
Mode	Privileged EXEC

### erase startup-config

Use this command to erase the text-based configuration file stored in non-volatile memory. If the switch boots and no startup-config file is found, the AutoInstall process automatically begins.

Format	erase startup-config
Mode	Privileged EXEC

## Dual Image Commands

The software supports a dual image feature that allows the switch to have two software images in the permanent storage. You can specify which image is the active image to be loaded in subsequent reboots. This feature allows reduced down-time when you upgrade or downgrade the software.

## delete

This command deletes the supplied image file from the permanent storage. The image to be deleted must be a backup image. If this image is the active image, or if this image is activated, an error message displays. The optional `<unit>` parameter is valid only on Stacks. Error will be returned, if this parameter is provided, on Standalone systems. In a stack, the `<unit>` parameter identifies the node on which this command must be executed. When this parameter is not supplied, the command is executed on all nodes in a Stack.

Format	<code>delete [&lt;unit&gt;] {image1   image2}</code>
Mode	Privileged EXEC

## boot system

This command activates the specified image. It will be the active-image for subsequent reboots and will be loaded by the boot loader. The current active-image is marked as the backup-image for subsequent reboots. The optional `<unit>` parameter is valid only in Stacking, where the `<unit>` parameter identifies the node on which this command must be executed. When this parameter is not supplied, the command is executed on all nodes in a Stack.

Format	<code>boot system [&lt;unit&gt;] &lt;image-file-name&gt;</code>
Mode	Privileged EXEC

## show bootvar

This command displays the version information and the activation status for the current active and backup images on the supplied unit (node) of the Stack. If you do not specify a unit number, the command displays image details for all nodes on the Stack. The command also displays any text description associated with an image. This command, when used on a Standalone system, displays the switch activation status. For a standalone system, the unit parameter is not valid.

Format	<code>show bootvar [&lt;unit&gt;]</code>
Mode	Privileged EXEC

## filedescr

This command associates a text description with an image. Any existing description will be replaced. For stacking, the `[<unit>]` parameter identifies the node on which this command must be executed. When this parameter is not supplied, the command is executed on all nodes in a Stack.

Format	<code>filedescr [&lt;unit&gt;] {image1   image2} &lt;text-description&gt;</code>
Mode	Privileged EXEC

## update bootcode

This command updates the bootcode (boot loader) on the switch. The bootcode is read from the active-image for subsequent reboots. The optional `<unit>` parameter is valid only on Stacks. Error will be returned, if this parameter is provided, on Standalone systems. For Stacking, the `<unit>` parameter identifies the node on which this command must be executed. When this parameter is not supplied, the command is executed on all nodes in a Stack.

Format	<code>update bootcode [&lt;unit&gt;]</code>
Mode	Privileged EXEC

## System Information and Statistics Commands

This section describes the commands you use to view information about system features, components, and configurations.

### show arp switch (system information and statistics commands)

This command displays the contents of the IP stack's Address Resolution Protocol (ARP) table. The IP stack only learns ARP entries associated with the management interfaces (network or service ports). ARP entries associated with routing interfaces are not listed.

Format	<code>show arp switch</code>
Mode	Privileged EXEC

Term	Definition
IP Address	IP address of the management interface or another device on the management network.
MAC Address	Hardware MAC address of that device.
Interface	For a service port the output is Management. For a network port, the output is the slot/port of the physical interface.

### show eventlog

This command displays the event log, which contains error messages from the system. The event log is not cleared on a system reset. The `<unit>` is the switch identifier.

Format	<code>show eventlog [&lt;unit&gt;]</code>
Mode	Privileged EXEC

Term	Definition
File	The file in which the event originated.
Line	The line number of the event.
Task Id	The task ID of the event.
Code	The event code.
Time	The time this event occurred.
Unit	The unit for the event.

---

**Note:** Event log information is retained across a switch reset.

---

## show hardware

This command displays inventory information for the switch.

---

**Note:** The show version command and the show hardware command display the same information. In future releases of the software, the show hardware command will not be available. For a description of the command output, see the command *show version* on page 334.

---

Format	<code>show hardware</code>
Mode	Privileged EXEC

## show version

This command displays inventory information for the switch.

---

**Note:** The show version command will replace the show hardware command in future releases of the software.

---

Format	<code>show version</code>
Mode	Privileged EXEC

Term	Definition
Switch Description	Text used to identify the product name of this switch.
Machine Type	The machine model as defined by the Vital Product Data.
Machine Model	The machine model as defined by the Vital Product Data
Serial Number	The unique box serial number for this switch.
FRU Number	The field replaceable unit number.
Manufacturer	Manufacturer descriptor field.
Burned in MAC Address	Universally assigned network address.
Software Version	The release.version.revision number of the code currently running on the switch.
Additional Packages	The additional packages incorporated into this system.

## show interface

This command displays a summary of statistics for a specific interface or a count of all CPU traffic based upon the argument.

Format	<code>show interface {&lt;slot/port&gt;   switchport   lag &lt;lag-intf-num&gt;}</code>
Mode	Privileged EXEC

If the argument is `<slot/port>` or `lag`, the display parameters are as shown in the following table.

Parameters	Definition
Packets Received Without Error	The total number of packets (including broadcast packets and multicast packets) received by the processor.
Packets Received With Error	The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
Broadcast Packets Received	The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.
Packets Transmitted Without Error	The total number of packets transmitted out of the interface.
Transmit Packets Errors	The number of outbound packets that could not be transmitted because of errors.

Parameters	Definition
Collisions Frames	The best estimate of the total number of collisions on this Ethernet segment.
Time Since Counters Last Cleared	The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

If the argument is `switchport`, the display parameters are as shown in the following table.

Term	Definition
Packets Received Without Error	The total number of packets (including broadcast packets and multicast packets) received by the processor.
Broadcast Packets Received	The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.
Packets Received With Error	The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
Packets Transmitted Without Error	The total number of packets transmitted out of the interface.
Broadcast Packets Transmitted	The total number of packets that higher-level protocols requested to be transmitted to the Broadcast address, including those that were discarded or not sent.
Transmit Packet Errors	The number of outbound packets that could not be transmitted because of errors.
Address Entries Currently In Use	The total number of Forwarding Database Address table entries now active on the switch, including learned and static entries.
VLAN Entries Currently In Use	The number of VLAN entries presently occupying the VLAN table.
Time Since Counters Last Cleared	The elapsed time, in days, hours, minutes, and seconds since the statistics for this switch were last cleared.

### show interface counters

This command reports key summary statistics for all ports (physical, CPU, and port-channel).

Format	<code>show interface counters</code>
Mode	Privileged EXEC



**Command example:**

```
(Routing) #show interface counters
Port      InOctets      InUcastPkts    InMcastPkts    InBcastPkts
-----
0/1       0              0               0               0
0/2       0              0               0               0
0/3       15098          0               31              39
0/4       0              0               0               0
0/5       0              0               0               0
0/6       0              0               0               0
0/7       0              0               0               0
0/8       0              0               0               0
0/9       0              0               0               0
0/10      0              0               0               0
0/11      0              0               0               0
```

**show interface ethernet**

This command displays detailed statistics for a specific interface or for all CPU traffic based upon the argument.

Format	show interface ethernet {<slot/port>   switchport}
Mode	Privileged EXEC

When you specify a value for <slot/port>, the command output displays the information that is shown in the following table.

Term	Definition
Packets Received	<ul style="list-style-type: none"> <li>• <b>Total Packets Received (Octets)</b> - The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including Frame Check Sequence (FCS) octets). This object can be used as a reasonable estimate of Ethernet utilization. If greater precision is desired, the etherStatsPkts and etherStatsOctets objects should be sampled before and after a common interval. The result of this equation is the value Utilization which is the percent utilization of the Ethernet segment on a scale of 0–100 percent.</li> <li>• <b>Packets Received 64 Octets</b> - The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Received 65–127 Octets</b> - The total number of packets (including bad packets) received that were from 65 through 127 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Received 128–255 Octets</b> - The total number of packets (including bad packets) received that were from 128 through 255 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Received 256–511 Octets</b> - The total number of packets (including bad packets) received that were from 256 through 511 octets in length inclusive (excluding framing bits but including FCS octets).</li> </ul>

## M4100 Series ProSAFE Managed Switches

Term	Definition
(continued)	<ul style="list-style-type: none"> <li>• <b>Packets Received 512–1023 Octets</b> - The total number of packets (including bad packets) received that were from 512 through 1023 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Received 1024–1518 Octets</b> - The total number of packets (including bad packets) received that were from 1024 through 1518 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Received &gt; 1518 Octets</b> - The total number of packets received that were longer than 1522 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.</li> <li>• <b>Packets RX and TX 64 Octets</b> - The total number of packets (including bad packets) received and transmitted that were 64 octets in length (excluding framing bits but including FCS octets).</li> <li>• <b>Packets RX and TX 65–127 Octets</b> - The total number of packets (including bad packets) received and transmitted that were from 65 through 127 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets RX and TX 128–255 Octets</b> - The total number of packets (including bad packets) received and transmitted that were from 128 through 255 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets RX and TX 256–511 Octets</b> - The total number of packets (including bad packets) received and transmitted that were from 256 through 511 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets RX and TX 512–1023 Octets</b> - The total number of packets (including bad packets) received and transmitted that were from 512 through 1023 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets RX and TX 1024–1518 Octets</b> - The total number of packets (including bad packets) received and transmitted that were from 1024 through 1518 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets RX and TX 1519–1522 Octets</b> - The total number of packets (including bad packets) received and transmitted that were from 1519 through 1522 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets RX and TX 1523–2047 Octets</b> - The total number of packets received and transmitted that were from 1523 through 2047 octets in length inclusive (excluding framing bits, but including FCS octets) and were otherwise well formed.</li> <li>• <b>Packets RX and TX 2048–4095 Octets</b> - The total number of packets received that were from 2048 through 4095 octets in length inclusive (excluding framing bits, but including FCS octets) and were otherwise well formed.</li> <li>• <b>Packets RX and TX 4096–9216 Octets</b> - The total number of packets received that were from 4096 through 9216 octets in length inclusive (excluding framing bits, but including FCS octets) and were otherwise well formed.</li> </ul>
Packets Received Successfully	<ul style="list-style-type: none"> <li>• <b>Total Packets Received Without Error</b> - The total number of packets received that were without errors.</li> <li>• <b>Unicast Packets Received</b> - The number of subnetwork-unicast packets delivered to a higher-layer protocol.</li> <li>• <b>Multicast Packets Received</b> - The total number of good packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.</li> <li>• <b>Broadcast Packets Received</b> - The total number of good packets received that were directed to the broadcast address. Note that this does not include multicast packets.</li> </ul>

## M4100 Series ProSAFE Managed Switches

Term	Definition
Receive Packets Discarded	The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space.
Packets Received with MAC Errors	<ul style="list-style-type: none"> <li>• <b>Total Packets Received with MAC Errors</b> - The total number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.</li> <li>• <b>Jabbers Received</b> - The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). Note that this definition of jabber is different than the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is 20–150 ms.</li> <li>• <b>Fragments/Undersize Received</b> - The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets).</li> <li>• <b>Alignment Errors</b> - The total number of packets received that had a length (excluding framing bits, but including FCS octets) of from 64 through 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with a non-integral number of octets.</li> <li>• <b>Rx FCS Errors</b> - The total number of packets received that had a length (excluding framing bits, but including FCS octets) of from 64 through 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with an integral number of octets.</li> <li>• <b>Overruns</b> - The total number of frames discarded as this port was overloaded with incoming packets, and could not keep up with the inflow.</li> </ul>
Received Packets Not Forwarded	<ul style="list-style-type: none"> <li>• <b>Total Received Packets Not Forwarded</b> - A count of valid frames received which were discarded (in other words, filtered) by the forwarding process</li> <li>• <b>Local Traffic Frames</b> - The total number of frames dropped in the forwarding process because the destination address was located off of this port.</li> <li>• <b>802.3x Pause Frames Received</b> - A count of MAC Control frames received on this interface with an opcode indicating the PAUSE operation. This counter does not increment when the interface is operating in half-duplex mode.</li> <li>• <b>Unacceptable Frame Type</b> - The number of frames discarded from this port due to being an unacceptable frame type.</li> <li>• <b>Multicast Tree Viable Discards</b> - The number of frames discarded when a lookup in the multicast tree for a VLAN occurs while that tree is being modified.</li> <li>• <b>Reserved Address Discards</b> - The number of frames discarded that are destined to an IEEE 802.1 reserved address and are not supported by the system.</li> <li>• <b>Broadcast Storm Recovery</b> - The number of frames discarded that are destined for FF:FF:FF:FF:FF:FF when Broadcast Storm Recovery is enabled.</li> <li>• <b>CFI Discards</b> - The number of frames discarded that have CFI bit set and the addresses in RIF are in non-canonical format.</li> <li>• <b>Upstream Threshold</b> - The number of frames discarded due to lack of cell descriptors available for that packet's priority level.</li> </ul>

Term	Definition
Packets Transmitted Octets	<ul style="list-style-type: none"> <li>• <b>Total Packets Transmitted (Octets)</b> - The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets). This object can be used as a reasonable estimate of Ethernet utilization. If greater precision is desired, the etherStatsPkts and etherStatsOctets objects should be sampled before and after a common interval. ----</li> <li>• <b>Packets Transmitted 64 Octets</b> - The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Transmitted 65-127 Octets</b> - The total number of packets (including bad packets) received that were from 65 through 127 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Transmitted 128-255 Octets</b> - The total number of packets (including bad packets) received that were from 128 through 255 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Transmitted 256-511 Octets</b> - The total number of packets (including bad packets) received that were from 256 through 511 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Transmitted 512-1023 Octets</b> - The total number of packets (including bad packets) received that were from 512 through 1023 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Transmitted 1024-1518 Octets</b> - The total number of packets (including bad packets) received that were from 1024 through 1518 octets in length inclusive (excluding framing bits but including FCS octets).</li> <li>• <b>Packets Transmitted &gt; 1518 Octets</b> - The total number of packets transmitted that were longer than 1518 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.</li> <li>• <b>Max Frame Size</b> - The maximum size of the Info (non-MAC) field that this port will receive or transmit.</li> </ul>
Packets Transmitted Successfully	<ul style="list-style-type: none"> <li>• <b>Total Packets Transmitted Successfully</b>- The number of frames that have been transmitted by this port to its segment.</li> <li>• <b>Unicast Packets Transmitted</b> - The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.</li> <li>• <b>Multicast Packets Transmitted</b> - The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.</li> <li>• <b>Broadcast Packets Transmitted</b> - The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.</li> </ul>
Transmit Packets Discarded	<p>The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.</p>
Transmit Errors	<ul style="list-style-type: none"> <li>• <b>Total Transmit Errors</b> - The sum of Single, Multiple, and Excessive Collisions.</li> <li>• <b>Tx FCS Errors</b> - The total number of packets transmitted that had a length (excluding framing bits, but including FCS octets) of from 64 through 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with an integral number of octets.</li> <li>• <b>Oversized</b> - The total number of frames that exceeded the max permitted frame size. This counter has a max increment rate of 815 counts per sec. at 10 Mb/s.</li> <li>• <b>Underrun Errors</b> - The total number of frames discarded because the transmit FIFO buffer became empty during frame transmission.</li> </ul>

Term	Definition
Transmit Discards	<ul style="list-style-type: none"> <li>• <b>Total Transmit Packets Discards</b> - The sum of single collision frames discarded, multiple collision frames discarded, and excessive frames discarded.</li> <li>• <b>Single Collision Frames</b> - A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision.</li> <li>• <b>Multiple Collision Frames</b> - A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.</li> <li>• <b>Excessive Collisions</b> - A count of frames for which transmission on a particular interface fails due to excessive collisions.</li> <li>• <b>Port Membership Discards</b> - The number of frames discarded on egress for this port due to egress filtering being enabled.</li> </ul>
Protocol Statistics	<ul style="list-style-type: none"> <li>• <b>802.3x Pause Frames Transmitted</b> - A count of MAC Control frames transmitted on this interface with an opcode indicating the PAUSE operation. This counter does not increment when the interface is operating in half-duplex mode.</li> <li>• <b>GVRP PDUs Received</b> - The count of GVRP PDUs received in the GARP layer.</li> <li>• <b>GVRP PDUs Transmitted</b> - The count of GVRP PDUs transmitted from the GARP layer.</li> <li>• <b>GVRP Failed Registrations</b> - The number of times attempted GVRP registrations could not be completed.</li> <li>• <b>GMRP PDUs Received</b> - The count of GMRP PDUs received in the GARP layer.</li> <li>• <b>GMRP PDUs Transmitted</b> - The count of GMRP PDUs transmitted from the GARP layer.</li> <li>• <b>GMRP Failed Registrations</b> - The number of times attempted GMRP registrations could not be completed.</li> <li>• <b>STP BPDUs Transmitted</b> - Spanning Tree Protocol Bridge Protocol Data Units sent.</li> <li>• <b>STP BPDUs Received</b> - Spanning Tree Protocol Bridge Protocol Data Units received.</li> <li>• <b>RST BPDUs Transmitted</b> - Rapid Spanning Tree Protocol Bridge Protocol Data Units sent.</li> <li>• <b>RSTP BPDUs Received</b> - Rapid Spanning Tree Protocol Bridge Protocol Data Units received.</li> <li>• <b>MSTP BPDUs Transmitted</b> - Multiple Spanning Tree Protocol Bridge Protocol Data Units sent.</li> <li>• <b>MSTP BPDUs Received</b> - Multiple Spanning Tree Protocol Bridge Protocol Data Units received.</li> </ul>
Dot1x Statistics	<ul style="list-style-type: none"> <li>• <b>EAPOL Frames Transmitted</b> - The number of EAPOL frames of any type that have been transmitted by this authenticator.</li> <li>• <b>EAPOL Frames Received</b> - The number of valid EAPOL frames of any type that have been received by this authenticator.</li> </ul>
Time Since Counters Last Cleared	The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

When you specify **switchport**, the command output displays the information that is shown in the following table.

Term	Definition
Octets Received	The total number of octets of data received by the processor (excluding framing bits but including FCS octets).
Total Packets Received Without Error	The total number of packets (including broadcast packets and multicast packets) received by the processor.
Unicast Packets Received	The number of subnetwork-unicast packets delivered to a higher-layer protocol.
Multicast Packets Received	The total number of packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.
Broadcast Packets Received	The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.
Receive Packets Discarded	The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.
Octets Transmitted	The total number of octets transmitted out of the interface, including framing characters.
Packets Transmitted without Errors	The total number of packets transmitted out of the interface.
Unicast Packets Transmitted	The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.
Multicast Packets Transmitted	The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.
Broadcast Packets Transmitted	The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.
Most Address Entries Ever Used	The highest number of Forwarding Database Address Table entries that have been learned by this switch since the most recent reboot.
Address Entries in Use	The number of Learned and static entries in the Forwarding Database Address Table for this switch.
Maximum VLAN Entries	The maximum number of Virtual LANs (VLANs) allowed on this switch.
Most VLAN Entries Ever Used	The largest number of VLANs that have been active on this switch since the last reboot.
Static VLAN Entries	The number of presently active VLAN entries on this switch that have been created statically.
Dynamic VLAN Entries	The number of presently active VLAN entries on this switch that have been created by GVRP registration.

Term	Definition
VLAN Deletes	The number of VLANs on this switch that have been created and then deleted since the last reboot.
Time Since Counters Last Cleared	The elapsed time, in days, hours, minutes, and seconds since the statistics for this switch were last cleared.

## show fiber-ports optics

This command displays the diagnostics information of the SFP such as temperature, voltage, current, input power, output power, Tx fault, and LOS. The values are derived from the SFP's A2 (Diagnostics) table using the I<sup>2</sup>C interface.

Format	show fiber-ports optics {all   <slot/port>}
Mode	Privileged EXEC

Field	Description
Temp	Internally measured transceiver temperature.
Voltage	Internally measured supply voltage.
Current	Measured TX bias current.
Output Power	Measured optical output power relative to 1mW.
Input Power	Measured optical power received relative to 1mW.
TX Fault	Transmitter fault.
LOS	Loss of signal.

### Command example:

```
(NETGEAR Switch) #show fiber-ports optics all
```

Port	Temp [C]	Voltage [Volt]	Current [mA]	Output Power [dBm]	Input Power [dBm]	TX Fault	LOS
0/49	39.3	3.256	5.0	-2.234	-2.465	No	No
0/50	33.9	3.260	5.3	-2.374	-40.000	No	Yes
0/51	32.2	3.256	5.6	-2.300	-2.897	No	No

## show fiber-ports optics-info

This command displays the SFP vendor related information such as vendor name, serial number of the SFP, part number of the SFP. The values are derived from the SFP's A0 table using the I<sup>2</sup>C interface.

Format	show fiber-ports optics-info {all   <slot/port>}
Mode	Privileged EXEC

Field	Description
Vendor Name	The vendor name is a 16 character field that contains ASCII characters, left-aligned and padded on the right with ASCII spaces (20h). The vendor name shall be the full name of the corporation, a commonly accepted abbreviation of the name of the corporation, the SCSI company code for the corporation, or the stock exchange code for the corporation.
Length (50um, OM2)	This value specifies link length that is supported by the transceiver while operating in compliance with applicable standards using 50 micron multimode OM2 [500MHz*km at 850nm] fiber. A value of zero means that the transceiver does not support 50 micron multimode fiber or that the length information must be determined from the transceiver technology.
Length (62.5um, OM1)	This value specifies link length that is supported by the transceiver while operating in compliance with applicable standards using 62.5 micron multimode OM1 [200 MHz*km at 850nm, 500 MHz*km at 1310nm] fiber. A value of zero means that the transceiver does not support 62.5 micron multimode fiber or that the length information must be determined from the transceiver technology
Vendor SN	The vendor serial number (vendor SN) is a 16 character field that contains ASCII characters, left-aligned and padded on the right with ASCII spaces (20h), defining the vendor's serial number for the transceiver. A value of all zero in the 16-byte field indicates that the vendor SN is unspecified.
Vendor PN	The vendor part number (vendor PN) is a 16-byte field that contains ASCII characters, left aligned and added on the right with ASCII spaces (20h), defining the vendor part number or product name. A value of all zero in the 16-byte field indicates that the vendor PN is unspecified.



Field	Description
BR, nominal	The nominal bit (signaling) rate (BR, nominal) is specified in units of 100 MBd, rounded off to the nearest 100 MBd. The bit rate includes those bits necessary to encode and delimit the signal as well as those bits carrying data information. A value of 0 indicates that the bit rate is not specified and must be determined from the transceiver technology. The actual information transfer rate will depend on the encoding of the data, as defined by the encoding value.
Vendor Rev	The vendor revision number (vendor rev) contains ASCII characters, left aligned and padded on the right with ASCII spaces (20h), defining the vendor's product revision number. A value of all zero in this field indicates that the vendor revision is unspecified.

**Command example:**

```
(NETGEAR Switch) #show fiber-ports optics-info all
```

Port	Vendor Name	Link Length		Serial Number	Part Number	Nominal Bit Rate	
		50um [m]	62.5um [m]			[Mbps]	Rev
0/49	NETGEAR	8	3	A7N2018414	AXM761	10300	10
0/51	NETGEAR	8	3	A7N2018472	AXM761	10300	10
0/52	NETGEAR	8	3	A7N2018501	AXM761	10300	10

**show mac-addr-table**

This command displays the forwarding database entries. These entries are used by the transparent bridging function to determine how to forward a received frame.

Enter **all** or no parameter to display the entire table. Enter a MAC Address and VLAN ID to display the table entry for the requested MAC address on the specified VLAN. Enter the **count** parameter to view summary information about the forwarding database table. Use the **interface** *<slot/port>* parameter to view MAC addresses on a specific interface. Use the **vlan** *<vlan-id>* parameter to display information about MAC addresses on a specified VLAN.

Format	show mac-addr-table [{<macaddr> <vlan-id>   all   count   interface <slot/port>   vlan <vlan-id>}]
Mode	Privileged EXEC

The information that is shown in the following table displays if you do not enter a parameter, the keyword **a11**, or the MAC address and VLAN ID. If you enter **vlan <vlan-id>**, only the Mac Address, Interface, and Status fields display.

Term	Definition
Mac Address	A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes.
Interface	The port through which this address was learned.
Interface Index	This object indicates the ifIndex of the interface table entry associated with this port.
Status	The status of this entry. The meanings of the values are: <ul style="list-style-type: none"> <li>• <b>Static.</b> The value of the corresponding instance was added by the system or a user when a static MAC filter was defined. It cannot be relearned.</li> <li>• <b>Learned.</b> The value of the corresponding instance was learned by observing the source MAC addresses of incoming traffic, and is currently in use.</li> <li>• <b>Management.</b> The value of the corresponding instance (system MAC address) is also the value of an existing instance of dot1dStaticAddress. It is identified with interface 0/1. and is currently used when enabling VLANs for routing.</li> <li>• <b>Self.</b> The value of the corresponding instance is the address of one of the switch's physical interfaces (the system's own MAC address).</li> <li>• <b>GMRP Learned.</b> The value of the corresponding was learned via GMRP and applies to Multicast.</li> <li>• <b>Other.</b> The value of the corresponding instance does not fall into one of the other categories.</li> </ul>

If you enter the **interface <slot/port>** parameter, in addition to the MAC Address and Status fields, the VLAN ID field displays.

Term	Definition
VLAN ID	The VLAN on which the MAC address was learned.

The information that is shown in the following table displays if you enter the **count** parameter.

Term	Definition
Dynamic Address count	Number of MAC addresses in the forwarding database that were automatically learned.
Static Address (User-defined) count	Number of MAC addresses in the forwarding database that were manually entered by a user.

Term	Definition
Total MAC Addresses in use	Number of MAC addresses currently in the forwarding database.
Total MAC Addresses available	Number of MAC addresses the forwarding database can handle.

## process cpu threshold

Use this command to configure the CPU utilization thresholds. The Rising and Falling thresholds are specified as a percentage of CPU resources. The utilization monitoring time period can be configured from 5 seconds to 86,400 seconds in multiples of 5 seconds. The CPU utilization threshold configuration is saved across a switch reboot. Configuring the falling utilization threshold is optional. If the falling CPU utilization parameters are not configured, they take the same value as the rising CPU utilization parameters.

Format	<code>process cpu threshold type total rising &lt;1-100&gt; interval &lt;5-86400&gt; {falling &lt;1-100&gt; interval &lt;5-86400&gt;}</code>
Mode	Global Config

Parameter	Description
rising threshold	The percentage of CPU resources that, when exceeded for the configured rising interval, triggers a notification. The range is 1–100. The default is 0 (disabled).
rising interval	The duration of the CPU rising threshold violation, in seconds, that must be met to trigger a notification. The range is 5–86,400. The default is 0 (disabled).
falling threshold	The percentage of CPU resources that, when usage falls below this level for the configured interval, triggers a notification. The range is 1–100. The default is 0 (disabled). A notification is triggered when the total CPU utilization falls below this level for a configured period of time. The falling utilization threshold notification is made only if a rising threshold notification was previously done. The falling utilization threshold must always be equal or less than the rising threshold value. The CLI does not allow setting the falling threshold to be greater than the rising threshold.
falling interval	The duration of the CPU falling threshold, in seconds, that must be met to trigger a notification. The range is 5–86,400. The default is 0 (disabled).

## show process cpu

This command provides the percentage utilization of the CPU by different tasks.

---

**Note:** It is not necessarily the traffic to the CPU, but different tasks that keep the CPU busy.

---

Format	show process cpu
Mode	Privileged EXEC

**Command example:**

```
(NETGEAR Switch) #show process cpu
```

```
Memory Utilization Report
status      bytes
-----
free 192980480
alloc 53409968
Task Utilization Report
Task                Utilization
-----
bcmL2X.0            0.75%
bcmCNTR.0           0.20%
bcmLINK.0           0.35%
DHCP snoop          0.10%
Dynamic ARP Inspection 0.10%
dot1s_timer_task    0.10%
dhcpsPingTask       0.20%
```

**show mbuf total**

This command shows the total system buffer pools status.

Format	show mbuf total
Mode	Privileged EXEC

**Command example:**

```
(NETGEAR Switch) #show mbuf total
```

```
mbufSize          9284 (0x2444)
Current Time      0x1897fa
MbufsFree         150
MbufsRxUsed       0
Total Rx Norm Alloc Attempts 26212
Total Rx Mid2 Alloc Attempts 4087
Total Rx Mid1 Alloc Attempts 188943
```

```

Total Rx High Alloc Attempts    384555
Total Tx Alloc Attempts         2478536
Total Rx Norm Alloc Failures    0
Total Rx Mid2 Alloc Failures    0
Total Rx Mid1 Alloc Failures    0
Total Rx High Alloc Failures    0
Total Tx Alloc Failures         0

```

## show running-config

Use this command to display or capture the current setting of different protocol packages supported on the switch. This command displays or captures commands with settings and configurations that differ from the default value. To display or capture the commands with settings and configurations that are equal to the default value, include the [ **a11** ] option.

---

**Note:** The output of the **show running-config** command does not display the user password, even if you set one different from the default.

---

The output is displayed in the script format, which can be used to configure another switch with same configuration. If the optional *<scriptname>* is provided with a file name extension of *.scr*, the output is redirected to a script file.

---

**Note:** If you issue the **show running-config** command from a serial connection, access to the switch through remote connections (such as Telnet) is suspended while the output is being generated and displayed.

---



---

**Note:** If you use a text-based configuration file, the **show running-config** command displays only configured physical interfaces, that is, if any interface only contains the default configuration, that interface will be skipped from the **show running-config** command output. This is true for any configuration mode that contains nothing but default configuration. That is, the command to enter a particular config mode, followed immediately by its **exit** command, are both omitted from the output of the **show running-config** command (and hence from the startup-config file when the system configuration is saved.)

---

This command captures the current settings of the trapflag status:

- If all the flags are enabled, then the command displays `trapflags all`.
- If all the flags in a particular group are enabled, then the command displays `trapflags group name all`.

- If some, but not all, of the flags in that group are enabled, the command displays `trapflags groupname flag-name`.

Format	<code>show running-config [all   &lt;scriptname&gt;]</code>
Mode	Privileged EXEC

### show running-config interface

This command shows the current configuration on a particular interface. The interface could be a physical port or a virtual port—like a LAG or VLAN. The output captures how the configuration differs from the factory default value.

Format	<code>show running-config interface {&lt;slot/port&gt;}   vlan &lt;vlan-id&gt;   lag &lt;lag-id&gt;}</code>
Mode	Interface Config

### show sysinfo

This command displays switch information.

Format	<code>show sysinfo</code>
Mode	Privileged EXEC

Term	Definition
Switch Description	Text used to identify this switch.
System Name	Name used to identify the switch. The factory default is blank. To configure the system name, see <a href="#">snmp-server</a> on page 491.
System Location	Text used to identify the location of the switch. The factory default is blank. To configure the system location, see <a href="#">snmp-server</a> on page 491.
System Contact	Text used to identify a contact person for this switch. The factory default is blank. To configure the system location, see <a href="#">snmp-server</a> on page 491.
System Object ID	The base object ID for the switch's enterprise MIB.
System Up Time	The time in days, hours, and minutes since the last switch reboot.
MIBs Supported	A list of MIBs supported by this agent.

### show tech-support

Use this command to display system and configuration information when you contact technical support. The output of this command combines the output of the following commands:

- `show version`
- `show sysinfo`
- `show port all`
- `show isdp neighbors`
- `show logging`
- `show event log`
- `show logging buffered`
- `show trap log`

Format	<code>show tech-support</code>
Mode	Privileged EXEC

## length

Use this command to set the pagination length to value number of lines for the sessions specified by configuring on different Line Config modes (telnet, ssh, and console) and is persistent. The *<number>* argument is a number in the range of 5–48 lines. Enter 0 to specify no pagination.

Default	24
Format	<code>length &lt;number&gt;</code>
Mode	Line Config

## no length value

Use this command to set the pagination length to the default value of 24 number of lines.

Format	<code>no length</code>
Mode	Line Config

## terminal length

Use this command to set the number of lines of output to be displayed on the screen, i.e. pagination, for the `show running-config` and `show running-config all` commands. The terminal length size is either zero or a number in the range of 5–48. After the user-configured number of lines is displayed in one page, the system prompts the user “--More-- or (q)uit.” Press `q` or `Q` to quit, or press any key to display the next set of 5–48 lines. The command `terminal length 0` disables pagination and, as a result, the output of the `show running-config` command is displayed immediately.

Default	24 lines per page
---------	-------------------

Format	<code>terminal length &lt;number&gt;</code>
Mode	Privileged EXEC

### no terminal length

Use this command to set the terminal length to the default value of 24 lines.

Format	<code>no terminal length</code>
Mode	Privileged EXEC

### show terminal length

Use this command to display the value of the user-configured terminal length size.

Format	<code>show terminal length</code>
Mode	Privileged EXEC

### memory free low-watermark processor

Use this command to get notifications when the CPU free memory falls below the configured threshold. A notification is generated when the free memory falls below the threshold. Another notification is generated once the available free memory rises to 10 percent above the specified threshold. To prevent generation of excessive notifications when the CPU free memory fluctuates around the configured threshold, only one Rising or Falling memory notification is generated over a period of 60 seconds. The threshold is specified in kilobytes. The CPU free memory threshold configuration is saved across a switch reboot.

Format	<code>memory free low-watermark processor &lt;1-1034956&gt;</code>
Mode	Global Config

Parameter	Description
low-watermark	When CPU free memory falls below this threshold, a notification message is triggered. The range is 1 to the maximum available memory on the switch. The default is 0 (disabled).



## Logging Commands

This section describes the commands you use to configure system logging, and to view logs and the logging settings.

### logging buffered

This command enables logging to an in-memory log that keeps up to 128 logs.

Default	disabled; critical when enabled
Format	logging buffered
Mode	Global Config

### no logging buffered

This command disables logging to in-memory log.

Format	no logging buffered
Mode	Global Config

### logging buffered wrap

This command enables wrapping of in-memory logging when the log file reaches full capacity. Otherwise when the log file reaches full capacity, logging stops.

Default	enabled
Format	logging buffered wrap
Mode	Privileged EXEC

### no logging buffered wrap

This command disables wrapping of in-memory logging and configures logging to stop when the log file capacity is full.

Format	no logging buffered wrap
Mode	Privileged EXEC

## logging cli-command

This command enables the CLI command logging feature, which enables logging of all CLI commands issued on the system.

Default	enabled
Format	logging cli-command
Mode	Global Config

## no logging cli-command

This command disables the CLI command Logging feature.

Format	no logging cli-command
Mode	Global Config

## logging console

This command enables logging to the console. You can specify the *<severitylevel>* value as either an integer from 0 to 7 or symbolically through one of the following keywords: **emergency** (0), **alert** (1), **critical** (2), **error** (3), **warning** (4), **notice** (5), **info** (6), or **debug** (7).

Default	disabled; critical when enabled
Format	logging console [ <i>&lt;severitylevel&gt;</i> ]
Mode	Global Config

## no logging console

This command disables logging to the console.

Format	no logging console
Mode	Global Config

## logging host

This command enables logging to a host. You can configure up to eight hosts.

Default	<ul style="list-style-type: none"> <li>port—514</li> <li>level—critical (2)</li> </ul>
Format	logging host { <i>&lt;ipaddress&gt;</i>   <i>&lt;hostname&gt;</i> } <i>&lt;addresstype&gt;</i> { <i>&lt;port-number&gt;</i> <i>&lt;severitylevel&gt;</i> }
Mode	Global Config

Parameter	Description
<code>&lt;ipaddress&gt;   &lt;hostname&gt;</code>	The IP address or name of the logging host.
<code>&lt;addresstype&gt;</code>	Indicates the type of address (IPv4, IPv6, or DNS). You can configure either an IPv4 or IPv6 address or a host name for a syslog collector among the list of servers.
<code>&lt;port-number&gt;</code>	A port number from 1 to 65535.
<code>&lt;severitylevel&gt;</code>	Specify this value as either an integer from 0 to 7, or symbolically through one of the following keywords: <b>emergency</b> (0), <b>alert</b> (1), <b>critical</b> (2), <b>error</b> (3), <b>warning</b> (4), <b>notice</b> (5), <b>info</b> (6), or <b>debug</b> (7).

### logging host remove

This command disables logging to host. See [show logging hosts](#) on page 357 for a list of host indexes.

Format	<code>logging host remove &lt;hostindex&gt;</code>
Mode	Global Config

### logging syslog

This command enables syslog logging. The `<portid>` parameter is an integer with a range of 1-65535.

Default	disabled
Format	<code>logging syslog [port &lt;portid&gt;]</code>
Mode	Global Config

### no logging syslog

This command disables syslog logging.

Format	<code>no logging syslog</code>
Mode	Global Config

### logging syslog source-interface

This command configures the syslog source interface (source IP address) for the syslog server configuration. The IP address of the selected source interface is used for filling the IP header of management protocol packets. This allows security devices (firewalls) to identify the source packets coming from the specific switch. If a source interface is not specified, the primary IP address of the originating (outbound) interface is used as the source address.

Format	logging syslog source-interface {<slot/port>   {loopback <loopback-id>}   {vlan <vlan-id>}}
Mode	Global Config

Parameter	Description
<slot/port>	VLAN or port-based routing interface.
loopback <loopback-id>	Configures the loopback interface to use as the source IP address. The range of the loopback ID is 0 to 7.
vlan <vlan-id>	Configures the VLAN interface to use as the source IP address. The range of the VLAN ID is 1 to 4093.

## show logging

This command displays logging configuration information.

Format	show logging
Mode	Privileged EXEC

Term	Definition
Logging Client Local Port	The port on the collector/relay to which syslog messages are sent.
CLI Command Logging	Shows whether CLI Command logging is enabled.
Console Logging	Shows whether console logging is enabled.
Console Logging Severity Filter	The minimum severity to log to the console log. Messages with an equal or lower numerical severity are logged.
Buffered Logging	Shows whether buffered logging is enabled.
Syslog Logging	Shows whether syslog logging is enabled.
Log Messages Received	Number of messages received by the log process. This includes messages that are dropped or ignored.
Log Messages Dropped	Number of messages that could not be processed due to error or lack of resources.
Log Messages Relayed	Number of messages sent to the collector/relay.

## show logging buffered

This command displays buffered logging (system startup and system operation logs).

Format	show logging buffered
Mode	Privileged EXEC

Term	Definition
Buffered (In-Memory) Logging	Shows whether the In-Memory log is enabled or disabled.
Buffered Logging Wrapping Behavior	The behavior of the In Memory log when faced with a log full situation.
Buffered Log Count	The count of valid entries in the buffered log.

## show logging hosts

This command displays all configured logging hosts.

Format	show logging hosts
Mode	Privileged EXEC

Term	Definition
Host Index	(Used for deleting hosts.)
IP Address / Hostname	IP address or hostname of the logging host.
Severity Level	The minimum severity to log to the specified address. The possible values are emergency (0), alert (1), critical (2), error (3), warning (4), notice (5), info (6), or debug (7).
Port	The server port number, which is the port on the local host from which syslog messages are sent.
Host Status	The state of logging to configured syslog hosts. If the status is disable, no logging occurs.

## show logging traplogs

This command displays SNMP trap events and statistics.

Format	show logging traplogs
Mode	Privileged EXEC

Term	Definition
Number of Traps Since Last Reset	The number of traps since the last boot.
Trap Log Capacity	The number of traps the system can retain.
Number of Traps Since Log Last Viewed	The number of new traps since the command was last executed.
Log	The log number.
System Time Up	How long the system had been running at the time the trap was sent.
Trap	The text of the trap message.

### logging persistent

Use this command to configure the persistent logging for the switch. You can specify the *<severitylevel>* value as either an integer from 0 to 7 or symbolically through one of the following keywords: **emergency** (0), **alert** (1), **critical** (2), **error** (3), **warning** (4), **notice** (5), **info** (6), or **debug** (7).

Default	Disable
Format	<code>logging persistent &lt;severitylevel&gt;</code>
Mode	Global Config

### no logging persistent

Use this command to disable the persistent logging in the switch.

Format	<code>no logging persistent</code>
Mode	Global Config

## Email Alerting and Mail Server Commands

### logging email

This command enables email alerting and sets the lowest severity level for which log messages are emailed. If you specify a severity level, log messages at or above this severity level, but below the urgent severity level, are emailed in a non-urgent manner by collecting them together until the log time expires. You can specify the *<severitylevel>* value as either an integer from 0 to 7 or symbolically through one of the following keywords: **emergency** (0), **alert** (1), **critical** (2), **error** (3), **warning** (4), **notice** (5), **info** (6), or **debug** (7).

Default	Disabled; when enabled, log messages at or above severity warning (4) are emailed
Format	logging email [<severitylevel>]
Mode	Global Config

### no logging email

This command disables email alerting.

Format	no logging email
Mode	Global Config

### logging email urgent

This command sets the lowest severity level at which log messages are emailed immediately in a single email message. You can specify the <severitylevel> value as either an integer from 0 to 7 or symbolically through one of the following keywords: **emergency** (0), **alert** (1), **critical** (2), **error** (3), **warning** (4), **notice** (5), **info** (6), or **debug** (7). Specify **none** to indicate that log messages are collected and sent in a batch email at a specified interval.

Default	Alert (1) and emergency (0) messages are sent immediately
Format	logging email urgent {<severitylevel>   none}
Mode	Global Config

### no logging email urgent

This command resets the urgent severity level to the default value.

Format	no logging email urgent
Mode	Global Config

### logging email message-type to-addr

This command configures the email address to which messages are sent. The message types supported are **urgent**, **non-urgent**, or **both**. For each supported severity level, multiple email addresses can be configured. The <to-email-addr> variable is a standard email address, for example admin@yourcompany.com.

Format	logging email message-type {urgent   non-urgent   both} to-addr <to-email-addr>
Mode	Global Config

**no logging email message-type to-addr**

This command removes the configured to-addr field of email.

Format	no logging email message-type {urgent  non-urgent  both} to-addr <to-email-addr>
Mode	Global Config

**logging email from-addr**

This command configures the email address of the sender (that is, the switch).

Default	switch@netgear.com
Format	logging email from-addr <from-email-addr>
Mode	Global Config

**no logging email from-addr**

This command removes the configured email source address.

Format	no logging email from-addr <from-email-addr>
Mode	Global Config

**logging email message-type subject**

This command configures the subject line of the email for the specified type.

Default	<ul style="list-style-type: none"> <li>• For urgent messages: Urgent Log Messages</li> <li>• For non-urgent messages: Non-Urgent Log Messages</li> </ul>
Format	logging email message-type {urgent  non-urgent  both} subject <subject>
Mode	Global Config

**no logging email message-type subject**

This command removes the configured email subject for the specified message type and restores it to the default email subject.

Format	no logging email message-type {urgent  non-urgent  both} subject
Mode	Global Config



### logging email logtime

This command configures how frequently non-urgent email messages are sent. Non-urgent messages are collected and sent in a batch email at the specified interval. The valid range is every 30- 440 minutes.

Default	30 minutes
Format	logging email logtime <minutes>
Mode	Global Config

### no logging email logtime

This command resets the non-urgent log time to the default value.

Format	no logging email logtime
Mode	Global Config

### logging traps

This command sets the severity at which SNMP traps are logged and sent in an email. You can specify the <severitylevel> value as either an integer from 0 to 7 or symbolically through one of the following keywords: **emergency** (0), **alert** (1), **critical** (2), **error** (3), **warning** (4), **notice** (5), **info** (6), or **debug** (7).

Default	Info (6) messages and higher are logged.
Format	logging traps <severitylevel>
Mode	Global Config

### no logging traps

This command resets the SNMP trap logging severity level to the default value.

Format	no logging traps
Mode	Global Config

### logging email test message-type

This command sends an email to the SMTP server to test the email alerting function.

Format	logging email test message-type {urgent  non-urgent  both} message-body <message-body>
Mode	Global Config

## show logging email config

This command displays information about the email alert configuration.

Format	show logging email config
Mode	Privileged EXEC

Term	Definition
Email Alert Logging	The administrative status of the feature: enabled or disabled
Email Alert From Address	The email address of the sender (the switch).
Email Alert Urgent Severity Level	The lowest severity level that is considered urgent. Messages of this type are sent immediately.
Email Alert Non Urgent Severity Level	The lowest severity level that is considered non-urgent. Messages of this type, up to the urgent level, are collected and sent in a batch email. Log messages that are less severe are not sent in an email message at all.
Email Alert Trap Severity Level	The lowest severity level at which traps are logged.
Email Alert Notification Period	The amount of time to wait between non-urgent messages.
Email Alert To Address Table	The configured email recipients.
Email Alert Subject Table	The subject lines included in urgent (Type 1) and non-urgent (Type 2) messages.
For Msg Type urgent, subject is	The configured email subject for sending urgent messages.
For Msg Type non-urgent, subject is	The configured email subject for sending non-urgent messages.

## show logging email statistics

This command displays email alerting statistics.

Format	show logging email statistics
Mode	Privileged EXEC

Term	Definition
Email Alert Operation Status	The operational status of the email alerting feature.
No of Email Failures	The number of email messages that have attempted to be sent but were unsuccessful.

Term	Definition
No of Email Sent	The number of email messages that were sent from the switch since the counter was cleared.
Time Since Last Email Sent	The amount of time that has passed since the last email was sent from the switch.

### clear logging email statistics

This command resets the email alerting statistics.

Format	<code>clear logging email statistics</code>
Mode	Privileged EXEC

### mail-server

Use this command to configure the SMTP server to which the switch sends email alert messages and change the mode to Mail Server Configuration mode. The server address can be in the IPv4, IPv6, or DNS name format.

Format	<code>mail-server {&lt;ip-address&gt;   &lt;ipv6-address&gt;   &lt;hostname&gt;}</code>
Mode	Global Config

### no mail-server

Use this command to remove the specified SMTP server from the configuration.

Format	<code>no mail-server {&lt;ip-address&gt;   &lt;ipv6-address&gt;   &lt;hostname&gt;}</code>
Mode	Global Config

### security (Mail Server Config)

Use this command to set the email alerting security protocol by enabling the switch to use TLS authentication with the SMTP Server. If the TLS mode is enabled on the switch but the SMTP server does not support TLS mode, no email is sent to the SMTP server.

Default	none
Format	<code>security {tlsv1   none}</code>
Mode	Mail Server Config

### port (Mail Server Config)

Use this command to configure the TCP port to use for communication with the SMTP server. For *<portid>*, you enter any nonstandard port in the range 1–65535. For TLSv1, the recommended port is number 465. If you do not use security, the recommended port is number 25.

Default	25
Format	port <i>&lt;portid&gt;</i>
Mode	Mail Server Config

### username (Mail Server Config)

Use this command to configure the login ID that the switch uses to authenticate with the SMTP server.

Default	admin
Format	username <i>&lt;name&gt;</i>
Mode	Mail Server Config

### password (Mail Server Config)

Use this command to configure the password that the switch uses to authenticate with the SMTP server.

Format	password <i>&lt;password&gt;</i>
Mode	Mail Server Config

### show mail-server config

Use this command to display information about the email alert configuration.

Format	show mail-server { <i>&lt;ip-address&gt;</i>   <i>&lt;hostname&gt;</i>   all} config
Mode	Privileged EXEC

Term	Definition
No of mail servers configured	The number of SMTP servers configured on the switch.
Email Alert Mail Server Address	The IPv4/IPv6 address or DNS host name of the configured SMTP server.
Email Alert Mail Server Port	The TCP port the switch uses to send email to the SMTP server.

Term	Definition
Email Alert Security Protocol	The security protocol (TLS or none) the switch uses to authenticate with the SMTP server.
Email Alert Username	The username the switch uses to authenticate with the SMTP server.
Email Alert Password	The password the switch uses to authenticate with the SMTP server.

## System Utility and Clear Commands

This section describes the commands you use to help troubleshoot connectivity issues and to restore various configurations to their factory defaults.

### traceroute

Use the this command to discover the routes that packets actually take when traveling to their destination through the network on a hop-by-hop basis. Traceroute continues to provide a synchronous response when initiated from the CLI.

Default	<ul style="list-style-type: none"> <li>count: 3 probes</li> <li>interval: 3 seconds</li> <li>size: 0 bytes</li> <li>port: 33434</li> <li>maxTtl: 30 hops</li> <li>maxFail: 5 probes</li> <li>initTtl: 1 hop</li> </ul>
Format	<pre>traceroute {&lt;ip-address&gt;   &lt;hostname&gt;} [initTtl &lt;initTtl&gt;] [maxTtl &lt;maxTtl&gt;] [maxFail &lt;maxFail&gt;] [interval &lt;interval&gt;] [count &lt;count&gt;] [port &lt;port&gt;] [size &lt;size&gt;] [source {&lt;ip-address&gt;   &lt;slot/port&gt;   loopback &lt;0-7&gt;}]</pre>
Mode	Privileged EXEC

Using the options described below, you can specify the initial and maximum time-to-live (TTL) in probe packets, the maximum number of failures before termination, the number of probes sent for each TTL, and the size of each probe.

Parameter	Description
{<ip-address>   <hostname>}	The <ip-address> value must be a valid IP address. The <hostname> value must be a a valid host name.
[initTtl <initTtl>]	As an option, specify the initial time-to-live (TTL), the maximum number of router hops between the local and remote system. Range is 0–255.
[maxTtl <maxTtl>]	As an option, specify the maximum TTL. Range is 1–255.

Parameter	Description
[maxFail <maxFail>]	As an option, specify when the traceroute is terminated after failing to receive a response for the number of consecutive probes. Range is 0–255.
[interval <interval>]	As an option, specify the time between probes, in seconds. Range is 1–60 seconds.
[count <count>]	As an option, specify the number of probes to send for each TTL value. Range is 1–10 probes.
[port <port>]	As an option, specify destination UDP port of the probe. This should be an unused port on the remote destination system. Range is 1–65,535.
[size <size>]	As an option, specify the size, in bytes, of the payload of the Echo Requests sent. Range is 0–65507 bytes.
[source {<ip-address>   <slot/port>   loopback <0-7>}]	As an option, specify the source IP address or interface for the traceroute.

**Command example:****The traceroute succeeds:**

```
(NETGEAR Switch) # traceroute 10.240.10.115 initTtl 1 maxTtl 4 maxFail 0 interval 1 count
3 port 33434 size 43
Traceroute to 10.240.10.115 ,4 hops max 43 byte packets:
1 10.240.4.1    708 msec    41 msec    11 msec
2 10.240.10.115  0 msec     0 msec     0 msec

Hop Count = 1 Last TTL = 2 Test attempt = 6 Test Success = 6
```

**Command example:****The traceroute fails:**

```
(NETGEAR Switch) # traceroute 10.40.1.1 initTtl 1 maxFail 0 interval 1 count 3
port 33434 size 43
Traceroute to 10.40.1.1 ,30 hops max 43 byte packets:
1 10.240.4.1    19 msec    18 msec    9 msec
2 10.240.1.252  0 msec     0 msec     1 msec
3 172.31.0.9    277 msec   276 msec   277 msec
4 10.254.1.1    289 msec   327 msec   282 msec
5 10.254.21.2   287 msec   293 msec   296 msec
6 192.168.76.2  290 msec   291 msec   289 msec
7 0.0.0.0      0 msec *

Hop Count = 6 Last TTL = 7 Test attempt = 19 Test Success = 18
```

## traceroute ipv6

Use the **traceroute** command to discover the routes that packets actually take when traveling to their destination through the network on a hop-by-hop basis. The IPv6 address or host name must be a valid. The optional *<port>* parameter is the UDP port used as the destination of packets sent as part of the traceroute. This port should be an unused port on the destination system. The range for *<port>* is zero (0) to 65535. The default value is 33434.

Default	port: 33434
Format	traceroute ipv6 {<ipv6-address>   <hostname>} [port <port>]
Mode	Privileged EXEC

## clear config

This command resets the configuration to the factory defaults without powering off the switch. When you issue this command, a prompt appears to confirm that the reset should proceed. When you enter **y**, you automatically reset the current configuration on the switch to the default values. It does not reset the switch.

Format	clear config
Mode	Privileged EXEC

## clear eventlog

This command clears all event messages maintained in the switch.

Format	clear eventlog
Mode	Privileged EXEC

## clear mac-addr-table

This command clears the dynamically learned MAC addresses of the switch.

Format	clear mac-addr-table
Mode	Privileged EXEC

## clear logging buffered

This command clears the messages maintained in the system log.

Format	clear logging buffered
Mode	Privileged EXEC

## clear counters

This command clears the statistics for a specified *<slot/port>*, for all the ports, or for the entire switch based upon the argument.

Format	<code>clear counters {&lt;slot/port&gt;   all}</code>
Mode	Privileged EXEC

## clear igmpsnooping

This command clears the tables managed by the IGMP Snooping function and attempts to delete these entries from the Multicast Forwarding Database.

Format	<code>clear igmpsnooping</code>
Mode	Privileged EXEC

## clear pass

This command resets all user passwords to the factory defaults without powering off the switch. You are prompted to confirm that the password reset should proceed.

Format	<code>clear pass</code>
Mode	Privileged EXEC

## clear port-channel

This command clears all port-channels (LAGs).

Format	<code>clear port-channel</code>
Mode	Privileged EXEC

## clear traplog

This command clears the trap log.

Format	<code>clear traplog</code>
Mode	Privileged EXEC

## clear vlan

This command resets VLAN configuration parameters to the factory defaults.

Format	<code>clear vlan</code>
Mode	Privileged EXEC



## enable password

This command prompts you to change the Privileged EXEC password. Passwords are a maximum of 64 alphanumeric characters. The password is case-sensitive. The **encrypted** option allows you to transfer the enable password between devices without needing to know the password. In this case, the `<password>` parameter must be exactly 128 hexadecimal characters.

Format	<code>enable password &lt;password&gt; [encrypted]</code>
Mode	Privileged EXEC

## logout

This command closes the current telnet connection or resets the current serial connection.

---

**Note:** Save configuration changes before logging out.

---

Format	<code>logout</code>
Modes	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

## ping

Use this command to determine whether another computer is on the network. Ping provides a synchronous response when initiated from the CLI and web interfaces.

Default	<ul style="list-style-type: none"> <li>The default count is 1.</li> <li>The default interval is 3 seconds.</li> <li>The default size is 0 bytes.</li> </ul>
Format	<code>ping {&lt;ipaddress&gt;   &lt;hostname&gt;} [count &lt;count&gt;] [interval &lt;interval&gt;] [size &lt;size&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Using the options described below, you can specify the number and size of Echo Requests and the interval between Echo Requests.

Parameter	Description
<code>[count &lt;count&gt;]</code>	As an option, specify the number of ping packets (ICMP Echo requests) that are sent to the destination address. The range is 1–15 requests.

Parameter	Description
[interval <interval>]	As an option, specify the time between Echo Requests, in seconds. The range is 1–60 seconds.
[size <size>]	As an option, specify the size, in bytes, of the payload of the Echo Requests sent. The range is 0–65507 bytes.

**Command example:**

The ping succeeds:

```
(NETGEAR Switch) #ping 10.254.2.160 count 3 interval 1 size 255
Pinging 10.254.2.160 with 255 bytes of data:

Received response for icmp_seq = 0. time= 275268 usec
Received response for icmp_seq = 1. time= 274009 usec
Received response for icmp_seq = 2. time= 279459 usec

----10.254.2.160 PING statistics----
3 packets transmitted, 3 packets received, 0% packet loss
round-trip (msec) min/avg/max = 274/279/276
```

**Command example:**

The ping fails because the destination is unreachable:

```
(NETGEAR Switch) # ping 192.168.254.222 count 3 interval 1 size 255
Pinging 192.168.254.222 with 255 bytes of data:
Received Response: Unreachable Destination
Received Response :Unreachable Destination
Received Response :Unreachable Destination
----192.168.254.222 PING statistics----
3 packets transmitted,3 packets received, 0% packet loss
round-trip (msec) min/avg/max = 0/0/0
```

**Command example:**

The ping fails because the request times out:

```
(NETGEAR Switch) # ping 1.1.1.1 count 1 interval 3
Pinging 1.1.1.1 with 0 bytes of data:

----1.1.1.1 PING statistics----
1 packets transmitted,0 packets received, 100% packet loss
round-trip (msec) min/avg/max = 0/0/0
```

## quit

This command closes the current telnet connection or resets the current serial connection. The system asks you whether to save configuration changes before quitting.

Format	quit
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

## reload

This command resets the switch without powering it off. Reset means that all network connections are terminated and the boot code executes. The switch uses the stored configuration to initialize the switch. You are prompted to confirm that the reset should proceed. The LEDs on the switch indicate a successful reset.

Format	reload
Mode	Privileged EXEC

## save

This command makes the current configuration changes permanent by writing the configuration changes to system NVRAM.

Format	save
Mode	Privileged EXEC

## copy

The **copy** command uploads and downloads files to and from the switch. You can also use the copy command to manage the dual images (*image1* and *image2*) on the file system. Upload and download files from a server by using TFTP or Xmodem. SFTP and SCP are available as additional transfer methods if the software package supports secure management.

Format	copy <source> <destination>
Mode	Privileged EXEC

Replace the <source> and <destination> parameters with the options in [Table 1](#) on page 373.

You can use the `copy` command with the following options:

```
copy {<url> | image1 | image2 | nvram:backup-config | nvram:clibanner |
nvram:cpu-pkt-capture.pcap | nvram:errorlog | nvram:factory-defaults | nvram:log |
nvram:script | nvram:startup-config | nvram:tech-support | nvram:traplog |
system:running-config} {<url> | isa-users | image1 | image2 | nvram:startup-config |
nvram:backup-config | nvram:startup-config | nvram:clibanner | nvram:script
<destfilename> | nvram:script <destfilename> noval | nvram:sshkey-dsa |
nvram:sshkey-rsa1 | nvram:sshkey-rsa2 | nvram:sslpem-dhweak | nvram:sslpem-dhstrong |
nvram:sslpem-root | nvram:sslpem-server:nvram:startup-config}
```

Use the `ias-users` keyword to download the IAS user database file. When the IAS user's file is downloaded, the switch IAS user's database is replaced with the users and their attributes in the downloaded file.

In the `copy <url> ias-users` command, for `<url>`, use one of the following values for the IAS user's file:

```
{{tftp://<ipaddr> | <ipv6address> | <hostname>/<filepath>/<filename>} |
{sftp | scp://<username>@<ipaddress>/<filepath>/<filename>}}
```

---

**Note:** The maximum length for the file path is 160 characters, and the maximum length for the file name is 31 characters.

---

For TFTP, SFTP, and SCP, the `<ipaddr>` or `<hostname>` parameter is the IP address or host name of the server, `<filepath>` is the path to the file, and `<filename>` is the name of the file that you want to upload or download. For SFTP and SCP, the `<username>` parameter is the user name for logging into the remote server via SSH.

---

**Note:** `<ip6address>` is also a valid parameter for routing packages that support IPv6.

---

For switches that support a USB device, the `copy` command can be used to transfer files from and to the USB device. The syntax for the USB file is: `usb://<filename>`. The USB device can be either a source or destination in the `copy` command. It cannot be used as both source and destination in a `copy` command.



**CAUTION:**

Before you load a new release image to make a backup, upload the existing `startup-config.cfg` file to the server.

Parameters for the `copy` command are listed in the following table.

**Table 1.** Parameters for the `copy` command

Source	Destination	Description
<code>nvrām:techsupport</code>	<code>&lt;url&gt;</code>	Uploads the Technical Support file.
<code>nvrām:backup-config</code>	<code>nvrām:startup-config</code>	Copies the backup configuration to the startup configuration.
<code>nvrām:clibanner</code>	<code>&lt;url&gt;</code>	Copies the CLI banner to a server.
<code>nvrām:cpupktcapture.pcap</code>	<code>&lt;url&gt;</code>	Uploads the CPU packets capture file.
<code>nvrām:errorlog</code>	<code>&lt;url&gt;</code>	Copies the error log file to a server
<code>nvrām:log</code>	<code>&lt;url&gt;</code>	Copies the log file to a server.
<code>nvrām:script &lt;scriptname&gt;</code>	<code>&lt;url&gt;</code>	Copies a specified configuration script file to a server.
<code>nvrām:startup-config</code>	<code>nvrām:backup-config</code>	Copies the startup configuration to the backup configuration.
<code>nvrām:startup-config</code>	<code>&lt;url&gt;</code>	Copies the startup configuration to a server.
<code>nvrām:traplog</code>	<code>&lt;url&gt;</code>	Copies the trap log file to a server.
<code>system:running-config</code>	<code>nvrām:startup-config</code>	Saves the running configuration to nvrām.
<code>&lt;url&gt;</code>	<code>nvrām:clibanner</code>	Downloads the CLI banner to the system.
<code>&lt;url&gt;</code>	<code>nvrām:script &lt;destfilename&gt;</code>	Downloads a configuration script file to the system. During the download of a configuration script, the copy command validates the script. In case of any error, the command lists all the lines at the end of the validation process and prompts you to confirm before copying the script file.
<code>&lt;url&gt;</code>	<code>nvrām:script &lt;destfilename&gt; noval</code>	When you use this option, the copy command does not validate the downloaded script file. An example of the CLI command follows: (NETGEAR Switch) #copy tftp://1.1.1.1/file.scr nvrām:script file.scr
<code>&lt;url&gt;</code>	<code>nvrām:sshkey-dsa</code>	Downloads an SSH key file. For more information, see <a href="#">Secure Shell (SSH) Commands</a> on page 457.
<code>&lt;url&gt;</code>	<code>nvrām:sshkey-rsa1</code>	Downloads an SSH key file.
<code>&lt;url&gt;</code>	<code>nvrām:sshkey-rsa2</code>	Downloads an SSH key file.

Table 1. Parameters for the `copy` command (continued)

Source	Destination	Description
<url>	nvram:sslpem-dhweak	Downloads an HTTP secure-server certificate.
<url>	nvram:sslpem-dhstrong	Downloads an HTTP secure-server certificate.
<url>	nvram:sslpem-root	Downloads an HTTP secure-server certificate. For more information, see <a href="#">Hypertext Transfer Protocol (HTTP) Commands</a> on page 460.
<url>	nvram:sslpem-server	Downloads an HTTP secure-server certificate.
<url>	nvram:startup-config	Downloads the startup configuration file to the system.
<url>	nvram:license-key	Download the license data to the system.
<url>	ias-users	Downloads IAS users file by SFTP, SCP, or TFTP.
<url>	{image1   image2}	Download an image from the remote server to either image. In a stacking environment, the downloaded image is distributed to the stack nodes.
{image1   image2}	<url>	Upload either image to the remote server.
image1	image2	Copy <b>image1</b> to <b>image2</b> .
image2	image1	Copy <b>image2</b> to <b>image1</b> .

## write memory

Use this command to save running configuration changes to NVRAM so that the changes you make will persist across a reboot. This command is the same as the `copy system:running config nvram:startup-config` command.

Format	write memory
Mode	Privileged EXEC

## Simple Network Time Protocol (SNTP) Commands

This section describes the commands you use to automatically configure the system time and date by using SNTP.

### sntp broadcast client poll-interval

This command sets the poll interval for SNTP broadcast clients in seconds as a power of two where *<poll-interval>* can be a value from 6 to 10.

Default	6
Format	sntp broadcast client poll-interval <i>&lt;poll-interval&gt;</i>
Mode	Global Config

### no sntp broadcast client poll-interval

This command resets the poll interval for SNTP broadcast client back to the default value.

Format	no sntp broadcast client poll-interval
Mode	Global Config

### sntp client mode

This command enables Simple Network Time Protocol (SNTP) client mode and might set the mode to either broadcast or unicast.

Default	disabled
Format	sntp client mode [broadcast   unicast]
Mode	Global Config

### no sntp client mode

This command disables Simple Network Time Protocol (SNTP) client mode.

Format	no sntp client mode
Mode	Global Config

### sntp client port

This command sets the SNTP client port id to a value from 1-65,535.

Default	123
Format	sntp client port <portid>
Mode	Global Config

### no sntp client port

This command resets the SNTP client port back to its default value.

Format	no sntp client port
Mode	Global Config

### sntp unicast client poll-interval

This command sets the poll interval for SNTP unicast clients in seconds as a power of two where <poll-interval> can be a value from 6 to 10.

Default	6
Format	sntp unicast client poll-interval <poll-interval>
Mode	Global Config

### no sntp unicast client poll-interval

This command resets the poll interval for SNTP unicast clients to its default value.

Format	no sntp unicast client poll-interval
Mode	Global Config

### sntp unicast client poll-timeout

This command will set the poll timeout for SNTP unicast clients in seconds to a value from 1-30.

Default	5
Format	sntp unicast client poll-timeout <poll-timeout>
Mode	Global Config



**no sntp unicast client poll-timeout**

This command will reset the poll timeout for SNTP unicast clients to its default value.

Format	<code>no sntp unicast client poll-timeout</code>
Mode	Global Config

**sntp unicast client poll-retry**

This command will set the poll retry for SNTP unicast clients to a value from 0 to 10.

Default	1
Format	<code>sntp unicast client poll-retry &lt;poll-retry&gt;</code>
Mode	Global Config

**no sntp unicast client poll-retry**

This command will reset the poll retry for SNTP unicast clients to its default value.

Format	<code>no sntp unicast client poll-retry</code>
Mode	Global Config

**sntp server**

This command configures an SNTP server (a maximum of three). The optional priority can be a value of 1-3, the version a value of 1-4, and the port id a value of 1-65535.

Format	<code>sntp server {&lt;ipaddress&gt;   &lt;ipv6address&gt;   &lt;hostname&gt;} [&lt;priority&gt; [&lt;version&gt; [&lt;portid&gt;]]]</code>
Mode	Global Config

**no sntp server**

This command deletes a server from the configured SNTP servers.

Format	<code>no sntp server remove {&lt;ipaddress&gt;   &lt;ipv6address&gt;   &lt;hostname&gt;}</code>
Mode	Global Config

## clock timezone

When using SNTP/NTP time servers to update the switch's clock, the time data received from the server is based on Coordinated Universal Time (UTC) which is the same as Greenwich Mean Time (GMT). This might not be the time zone in which the switch is located. Use the `clock timezone` command to configure a time zone specifying the number of hours and optionally the number of minutes difference from UTC. To set the switch clock to UTC, use the `no` form of the command.

Default	no clock timezone
Format	clock timezone <zone-name> <+/-hours-offset> [<+/-minutes-offset>]
Mode	Global Config

Term	Definition
<zone-name>	A name to associate with the time zone
<hours-offset>	Number of hours difference with UTC
<minutes-offset>	Number of minutes difference with UTC

## no clock timezone

This command sets the switch to UTC time.

Format	no clock timezone
Mode	Global Config

## clock set

This command sets the system time and date.

Format	clock set <hh:mm:ss> clock set <mm/dd/yyyy>
Mode	Global Config

## clock summer-time recurring

Use this command to set the summertime offset to UTC recursively every year. If the optional parameters are not specified, they are read as either 0 or \0, as appropriate.

Use the following parameters to configure the summer-time.

- USA—the US Daylight saving time setting is used (Start --- March, 2nd sunday 02:00 AM, End --- Nov, 1st sunday, 2:00 AM)
- EU—the European Union Daylight savings time is used (Start --- March, 5th Sunday 02:00 AM, End --- October, 5th Sunday, 3:00 AM)

- week—Week of the month. (Range: 1-5, first, last)
- day—Day of the week. (Range: The first three letters by name; sun, for example.)
- month—Month. (Range: The first three letters by name; jan, for example.)
- hh:mm—Time in 24-hour format in hours and minutes. (Range: hh:0-23, mm: 0-59)
- offset—Number of minutes to add during the summertime. (Range:1-1440)
- acronym—The acronym for the time zone to be displayed when summertime is in effect. (Range: Up to four characters)

Format	clock summer-time recurring {USA   EU   {<week> <day> <month> <hh:mm> <week> <day> <month> <hh:mm>}} [offset <offset>] [zone <acronym>]
Mode	Global Config

**Command example:**

```
(NETGEAR Switch)(Config)# clock summer-time recurring 1 sun jan
00:10 2 mon mar 10:00 offset 1 zone ABC
```

**clock summer-time date**

Use this command to set the summertime offset to UTC. If the optional parameters are not specified, they are read as either 0 or \0, as appropriate.

- date—Day of the month. (Range: 1-31)
- month—Month. (Range: The first three letters by name; jan, for example.)
- year—Year. (Range: 2000-2097)
- hh:mm—Time in 24-hour format in hours and minutes. (Range: hh: 0-23, mm: 0-59)
- offset—Number of minutes to add during the summertime. (Range:1-1440)
- acronym—The acronym for the time zone to be displayed when summertime is in effect. (Range: Up to four characters)

Format	clock summer-time date {<day> <month> <year> <hh:mm> <day> <month> <year> <hh:mm>} [offset <offset>] [zone <acronym>]
Mode	Global Config

**Command example:**

```
(NETGEAR Switch)(config)# clock summer-time date 1 Apr 2007 02:00 28 Oct 2007 offset 90
zone EST
```

## no clock summer-time

Use this command to reset the summertime offset.

<b>Format</b>	no clock summer-time
<b>Mode</b>	Global Config

### Command example:

```
(NETGEAR Switch)(config)#no clock summer-time
```

## show sntp

This command is used to display SNTP settings and status.

Format	show sntp
Mode	Privileged EXEC

Term	Definition
Last Update Time	Time of last clock update.
Last Unicast Attempt Time	Time of last transmit query (in unicast mode).
Last Attempt Status	Status of the last SNTP request (in unicast mode) or unsolicited message (in broadcast mode).
Broadcast Count	Current number of unsolicited broadcast messages that have been received and processed by the SNTP client since last reboot.
Multicast Count	Current number of unsolicited multicast messages that have been received and processed by the SNTP client since last reboot.

## show sntp client

This command is used to display SNTP client settings.

Format	show sntp client
Mode	Privileged EXEC

Term	Definition
Client Supported Modes	Supported SNTP Modes (Broadcast, Unicast, or Multicast).
SNTP Version	The highest SNTP version the client supports.

Term	Definition
Port	SNTP Client Port.
Client Mode	Configured SNTP Client Mode.

## show sntp server

This command is used to display SNTP server settings and configured servers.

Format	<code>show sntp server</code>
Mode	Privileged EXEC

Term	Definition
Server Host Address	IP address or hostname of configured SNTP Server.
Server Type	Address Type of Server.
Server Stratum	Claimed stratum of the server for the last received valid packet.
Server Reference ID	Reference clock identifier of the server for the last received valid packet.
Server Mode	SNTP Server mode.
Server Maximum Entries	Total number of SNTP Servers allowed.
Server Current Entries	Total number of SNTP configured.

For each configured server, the information that is shown in the following table is displayed.

Term	Definition
Host Address	IP address or hostname of configured SNTP Server.
Address Type	Address Type of configured SNTP server.
Priority	IP priority type of the configured server.
Version	SNTP Version number of the server. The protocol version used to query the server in unicast mode.
Port	Server Port Number.
Last Attempt Time	Last server attempt time for the specified server.
Last Update Status	Last server attempt status for the server.

Term	Definition
Total Unicast Requests	Number of requests to the server.
Failed Unicast Requests	Number of failed requests from server.

## show clock

Use the `show clock` command in Privileged EXEC or User EXEC mode to display the time and date from the system clock. Use the `show clock detail` command to show the time zone and summertime configuration.

Format	<code>show clock [detail]</code>
Mode	<ul style="list-style-type: none"> <li>User EXEC</li> <li>Privileged EXEC</li> </ul>

Term	Definition
Time	The time provided by the time source.
Time Source	The time source type.
If you specify the <code>detail</code> keyword, the following information is also displayed.	
Time Zone	The time zone configured.
Summer Time	Indicate if the summer time is enabled.

## DHCP Server Commands

This section describes the commands you to configure the DHCP server settings for the switch. DHCP uses UDP as its transport protocol and supports a number of features that facilitate in administration address allocations.

### ip dhcp pool

This command configures a DHCP address pool name on a DHCP server and enters DHCP pool configuration mode.

Default	none
Format	<code>ip dhcp pool &lt;name&gt;</code>
Mode	Global Config

### no ip dhcp pool

This command removes the DHCP address pool. The name should be previously configured pool name.

Format	<code>no ip dhcp pool &lt;name&gt;</code>
Mode	Global Config

### client-identifier

This command specifies the unique identifier for a DHCP client. Unique-identifier is a valid notation in hexadecimal format. In some systems, such as Microsoft DHCP clients, the client identifier is required instead of hardware addresses. The unique-identifier is a concatenation of the media type and the MAC address.

For example, the Microsoft client identifier for Ethernet address c819.2488.f177 is 01c8.1924.88f1.77 where 01 represents the Ethernet media type. For more information, refer to the “Address Resolution Protocol Parameters” section of RFC 1700, Assigned Numbers for a list of media type codes.

Default	none
Format	<code>client-identifier &lt;uniqueidentifier&gt;</code>
Mode	DHCP Pool Config

### no client-identifier

This command deletes the client identifier.

Format	<code>no client-identifier</code>
Mode	DHCP Pool Config

### client-name

This command specifies the name for a DHCP client. Name is a string consisting of standard ASCII characters.

Default	none
Format	<code>client-name &lt;name&gt;</code>
Mode	DHCP Pool Config

**no client-name**

This command removes the client name.

Format	no client-name
Mode	DHCP Pool Config

**default-router**

This command specifies the default router list for a DHCP client.

*<address1>* and *<address2>...<address8>* must be valid IP addresses, each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Default	none
Format	default-router <i>&lt;address1&gt;</i> [ <i>&lt;address2&gt;...&lt;address8&gt;</i> ]
Mode	DHCP Pool Config

**no default-router**

This command removes the default router list.

Format	no default-router
Mode	DHCP Pool Config

**dns-server**

This command specifies the IP servers available to a DHCP client. Address parameters are valid IP addresses; each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Default	none
Format	dns-server <i>&lt;address1&gt;</i> [ <i>&lt;address2&gt;...&lt;address8&gt;</i> ]
Mode	DHCP Pool Config

**no dns-server**

This command removes the DNS Server list.

Format	no dns-server
Mode	DHCP Pool Config



## hardware-address

This command specifies the hardware address of a DHCP client. Hardware-address is the MAC address of the hardware platform of the client consisting of 6 bytes in dotted hexadecimal format. Type indicates the protocol of the hardware platform. It is 1 for 10 MB Ethernet and 6 for IEEE 802.

Default	ethernet
Format	hardware-address <hardwareaddress> <type>
Mode	DHCP Pool Config

## no hardware-address

This command removes the hardware address of the DHCP client.

Format	no hardware-address
Mode	DHCP Pool Config

## host

This command specifies the IP address and network mask for a manual binding to a DHCP client. Address and Mask are valid IP addresses; each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid. The prefix length is an integer from 0 to 32.

Default	none
Format	host <address> [<mask>   <prefix-length>]
Mode	DHCP Pool Config

## no host

This command removes the IP address of the DHCP client.

Format	no host
Mode	DHCP Pool Config

## lease

This command configures the duration of the lease for an IP address that is assigned from a DHCP server to a DHCP client. The overall lease time should be between 1-86400 minutes. If you specify **infinite**, the lease is set for 60 days. You can also specify a lease duration. <days> is an integer from 0 to 59. <hours> is an integer from 0 to 23. <minutes> is an integer from 0 to 59.

Default	1 (day)
Format	lease [{<days> [<hours>] [<minutes>]   infinite}]
Mode	DHCP Pool Config

### no lease

This command restores the default value of the lease time for DHCP Server.

Format	no lease
Mode	DHCP Pool Config

### network (DHCP Pool Config)

Use this command to configure the subnet number and mask for a DHCP address pool on the server. Network-number is a valid IP address, made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid. Mask is the IP subnet mask for the specified address pool. The prefix-length is an integer from 0 to 32.

Default	none
Format	network <networknumber> [<mask>   <prefixlength>]
Mode	DHCP Pool Config

### no network

This command removes the subnet number and mask.

Format	no network
Mode	DHCP Pool Config

### bootfile

The command specifies the name of the default boot image for a DHCP client. The <filename> specifies the boot image file.

Format	bootfile <filename>
Mode	DHCP Pool Config

**no bootfile**

This command deletes the boot image name.

Format	no bootfile
Mode	DHCP Pool Config

**domain-name (DHCP Pool Config)**

This command specifies the domain name for a DHCP client. The *<domain>* argument specifies the domain name string of the client.

Default	none
Format	domain-name <i>&lt;domain&gt;</i>
Mode	DHCP Pool Config

**no domain-name**

This command removes the domain name.

Format	no domain-name
Mode	DHCP Pool Config

**netbios-name-server**

This command configures NetBIOS Windows Internet Naming Service (WINS) name servers that are available to DHCP clients.

One IP address is required, although one can specify up to eight addresses in one command line. Servers are listed in order of preference (address1 is the most preferred server, address2 is the next most preferred server, and so on).

Default	none
Format	netbios-name-server <i>&lt;address&gt;</i> [ <i>&lt;address2&gt;</i> . . . <i>&lt;address8&gt;</i> ]
Mode	DHCP Pool Config

**no netbios-name-server**

This command removes the NetBIOS name server list.

Format	no netbios-name-server
Mode	DHCP Pool Config

### netbios-node-type

The command configures the NetBIOS node type for Microsoft Dynamic Host Configuration Protocol (DHCP) clients. The *<type>* parameter specifies the NetBIOS node type. Valid types are:

- b-node—Broadcast
- p-node—Peer-to-peer
- m-node—Mixed
- h-node—Hybrid (recommended)

Default	none
Format	netbios-node-type <i>&lt;type&gt;</i>
Mode	DHCP Pool Config

### no netbios-node-type

This command removes the NetBIOS node Type.

Format	no netbios-node-type
Mode	DHCP Pool Config

### next-server

This command configures the next server in the boot process of a DHCP client. The *<address>* parameter is the IP address of the next server in the boot process, which is typically a TFTP server.

Default	inbound interface helper addresses
Format	next-server <i>&lt;address&gt;</i>
Mode	DHCP Pool Config

### no next-server

This command removes the boot server list.

Format	no next-server
Mode	DHCP Pool Config

## option

The **option** command configures DHCP server options. The *<code>* parameter specifies the DHCP option code and ranges from 1-254. The *<ascii string>* parameter specifies an NVT ASCII character string. ASCII character strings that contain white space must be delimited by quotation marks. The **hex** *<string>* parameter specifies hexadecimal data. In hexadecimal, character strings are two hexadecimal digits. You can separate each byte by a period (for example, **a3.4f.22.0c**), colon (for example, **a3:4f:22:0c**), or white space (for example, **a3 4f 22 0c**).

Default	none
Format	option <i>&lt;code&gt;</i> { <i>&lt;ascii string&gt;</i>   hex <i>&lt;string1&gt;</i> [ <i>&lt;string2&gt;</i> ... <i>&lt;string8&gt;</i> ]   ip <i>&lt;address1&gt;</i> [ <i>&lt;address2&gt;</i> ... <i>&lt;address8&gt;</i> ]}
Mode	DHCP Pool Config

## no option

This command removes the DHCP Server options. The *<code>* parameter specifies the DHCP option code.

Format	no option <i>&lt;code&gt;</i>
Mode	DHCP Pool Config

## ip dhcp excluded-address

This command specifies the IP addresses that a DHCP server should not assign to DHCP clients. Low-address and high-address are valid IP addresses; each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Default	none
Format	ip dhcp excluded-address <i>&lt;lowaddress&gt;</i> [ <i>&lt;highaddress&gt;</i> ]
Mode	Global Config

## no ip dhcp excluded-address

This command removes the excluded IP addresses for a DHCP client. Low-address and high-address are valid IP addresses; each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Format	no ip dhcp excluded-address <i>&lt;lowaddress&gt;</i> [ <i>&lt;highaddress&gt;</i> ]
Mode	Global Config

### ip dhcp ping packets

Use this command to specify the number of packets, in a range from 2-10, that a DHCP server sends to a pool address as part of a ping operation. By default, the number of packets sent to a pool address is 2, which is the smallest allowed number when sending packets. Setting the number of packets to 0 disables this command.

Default	2
Format	<code>ip dhcp ping packets &lt;range&gt;</code>
Mode	Global Config

### no ip dhcp ping packets

This command prevents the server from pinging pool addresses and sets the number of packets to 0.

Default	0
Format	<code>no ip dhcp ping packets</code>
Mode	Global Config

### service dhcp

This command enables the DHCP server.

Default	disabled
Format	<code>service dhcp</code>
Mode	Global Config

### no service dhcp

This command disables the DHCP server.

Format	<code>no service dhcp</code>
Mode	Global Config

### ip dhcp bootp automatic

This command enables the allocation of the addresses to the bootp client. The addresses are from the automatic address pool.

Default	disabled
Format	<code>ip dhcp bootp automatic</code>
Mode	Global Config

### no ip dhcp bootp automatic

This command disables the allocation of the addresses to the bootp client. The address are from the automatic address pool.

Format	<code>no ip dhcp bootp automatic</code>
Mode	Global Config

### ip dhcp conflict logging

This command enables conflict logging on DHCP server.

Default	enabled
Format	<code>ip dhcp conflict logging</code>
Mode	Global Config

### no ip dhcp conflict logging

This command disables conflict logging on DHCP server.

Format	<code>no ip dhcp conflict logging</code>
Mode	Global Config

### clear ip dhcp binding

This command deletes an automatic address binding from the DHCP server database. If you specify \*, the bindings corresponding to all the addresses are deleted. *<address>* is a valid IP address made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Format	<code>clear ip dhcp binding {&lt;address&gt;   *}</code>
Mode	Privileged EXEC

### clear ip dhcp server statistics

This command clears DHCP server statistics counters.

Format	<code>clear ip dhcp server statistics</code>
Mode	Privileged EXEC

## clear ip dhcp conflict

The command is used to clear an address conflict from the DHCP Server database. The server detects conflicts using a ping. DHCP server clears all conflicts If the asterisk (\*) character is used as the address parameter.

Default	none
Format	<code>clear ip dhcp conflict {&lt;address&gt;   *}</code>
Mode	Privileged EXEC

## show ip dhcp binding

This command displays address bindings for the specific IP address on the DHCP server. If no IP address is specified, the bindings corresponding to all the addresses are displayed.

Format	<code>show ip dhcp binding [&lt;address&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
IP address	The IP address of the client.
Hardware Address	The MAC Address or the client identifier.
Lease expiration	The lease expiration time of the IP address assigned to the client.
Type	The manner in which IP address was assigned to the client.

## show ip dhcp global configuration

This command displays address bindings for the specific IP address on the DHCP server. If no IP address is specified, the bindings corresponding to all the addresses are displayed.

Format	<code>show ip dhcp global configuration</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Service DHCP	The field to display the status of dhcp protocol.
Number of Ping Packets	The maximum number of Ping Packets that will be sent to verify that an ip address id not already assigned.
Conflict Logging	Shows whether conflict logging is enabled or disabled.
BootP Automatic	Shows whether BootP for dynamic pools is enabled or disabled.



## show ip dhcp pool configuration

This command displays pool configuration. If **a11** is specified, configuration for all the pools is displayed.

Format	<code>show ip dhcp pool configuration {&lt;name&gt;   all}</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Field	Definition
Pool Name	The name of the configured pool.
Pool Type	The pool type.
Lease Time	The lease expiration time of the IP address assigned to the client.
DNS Servers	The list of DNS servers available to the DHCP client.
Default Routers	The list of the default routers available to the DHCP client.

For the dynamic pool type, the fields that are shown in the following table are displayed.

Field	Definition
Network	The network number and the mask for the DHCP address pool.

For the manual pool type, the fields that are shown in the following table are displayed.

Field	Definition
Client Name	The name of a DHCP client.
Client Identifier	The unique identifier of a DHCP client.
Hardware Address	The hardware address of a DHCP client.
Hardware Address Type	The protocol of the hardware platform.
Host	The IP address and the mask for a manual binding to a DHCP client.

## show ip dhcp server statistics

This command displays DHCP server statistics.

Format	<code>show ip dhcp server statistics</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Field	Definition
Automatic Bindings	The number of IP addresses that have been automatically mapped to the MAC addresses of hosts that are found in the DHCP database.
Expired Bindings	The number of expired leases.
Malformed Bindings	The number of truncated or corrupted messages that were received by the DHCP server.

For Message Received, the fields that are shown in the following table are displayed.

Message	Definition
DHCP DISCOVER	The number of DHCPDISCOVER messages the server has received.
DHCP REQUEST	The number of DHCPREQUEST messages the server has received.
DHCP DECLINE	The number of DHCPDECLINE messages the server has received.
DHCP RELEASE	The number of DHCPRELEASE messages the server has received.
DHCP INFORM	The number of DHCPINFORM messages the server has received.

For Message Sent, the fields that are shown in the following table are displayed.

Message	Definition
DHCP OFFER	The number of DHCPOFFER messages the server sent.
DHCP ACK	The number of DHCPACK messages the server sent.
DHCP NACK	The number of DHCPNACK messages the server sent.

### show ip dhcp conflict

This command displays address conflicts logged by the DHCP Server. If no IP address is specified, all the conflicting addresses are displayed.

Format	<code>show ip dhcp conflict [&lt;ip-address&gt;]</code>
Modes	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

Term	Definition
IP address	The IP address of the host as recorded on the DHCP server.
Reporting Host Hardware Address	The hardware address of the host that reported the conflict.

Term	Definition
Detection Method	The manner in which the IP address of the hosts were found on the DHCP Server.
Detection time	The time when the conflict was found.

## DNS Client Commands

These commands are used in the Domain Name System (DNS), an Internet directory service. DNS is how domain names are translated into IP addresses. When enabled, the DNS client provides a hostname lookup service to other components.

### ip domain lookup

Use this command to enable the DNS client.

Default	enabled
Format	ip domain lookup
Mode	Global Config

### no ip domain lookup

Use this command to disable the DNS client.

Format	no ip domain lookup
Mode	Global Config

### ip domain name

Use this command to define a default domain name that the software uses to complete unqualified host names (names with a domain name). By default, no default domain name is configured in the system. *<name>* may not be longer than 255 characters and should not include an initial period. This *<name>* should be used only when the default domain name list, configured using the **ip domain list** command, is empty.

Default	none
Format	ip domain name <i>&lt;name&gt;</i>
Mode	Global Config

#### Command example:

The CLI command **ip domain name yahoo.com** configures yahoo.com as a default domain name. For an unqualified hostname **xxx**, a DNS query is made to find the IP address corresponding to xxx.yahoo.com.

### no ip domain name

Use this command to remove the default domain name configured using the `ip domain name` command.

Format	<code>no ip domain name</code>
Mode	Global Config

### ip domain list

Use this command to define a list of default domain names to complete unqualified names. By default, the list is empty. Each name must be no more than 256 characters, and should not include an initial period. The default domain name, configured using the `ip domain name` command, is used only when the default domain name list is empty. A maximum of 32 names can be entered in to this list.

Default	none
Format	<code>ip domain list &lt;name&gt;</code>
Mode	Global Config

### no ip domain list

Use this command to delete a name from a list.

Format	<code>no ip domain list &lt;name&gt;</code>
Mode	Global Config

### ip name server

Use this command to configure the available name servers. Up to eight servers can be defined in one command or by using multiple commands. The parameter `<server-address>` is a valid IPv4 or IPv6 address of the server. The preference of the servers is determined by the order they were entered.

Format	<code>ip name-server &lt;server-address1&gt; [&lt;server-address2&gt;...&lt;server-address8&gt;]</code>
Mode	Global Config

### no ip name server

Use this command to remove a name server.

Format	<code>no ip name-server [&lt;server-address1&gt;...&lt;server-address8&gt;]</code>
Mode	Global Config

## ip host

Use this command to define static host name-to-address mapping in the host cache. The *<name>* parameter is the host name. The *<ip address>* parameter is the IP address of the host.

Default	none
Format	ip host <i>&lt;name&gt;</i> <i>&lt;ipaddress&gt;</i>
Mode	Global Config

## no ip host

Use this command to remove the name-to-address mapping.

Format	no ip host <i>&lt;name&gt;</i>
Mode	Global Config

## ipv6 host

Use this command to define static host name-to-IPv6 address mapping in the host cache. The *<name>* parameter is the host name. The *<ipv6-address>* parameter is the IPv6 address of the host.

Default	none
Format	ipv6 host <i>&lt;name&gt;</i> <i>&lt;ipv6-address&gt;</i>
Mode	Global Config

## no ipv6 host

Use this command to remove the static host name-to-IPv6 address mapping in the host cache.

Format	no ipv6 host <i>&lt;name&gt;</i>
Mode	Global Config

## ip domain retry

Use this command to specify the number of times to retry sending Domain Name System (DNS) queries. The parameter *<number>* indicates the number of times to retry sending a DNS query to the DNS server. This number ranges from 0 to 100.

Default	2
Format	ip domain retry <i>&lt;number&gt;</i>
Mode	Global Config

### no ip domain retry

Use this command to return to the default.

Format	no ip domain retry <number>
Mode	Global Config

### ip domain timeout

Use this command to specify the amount of time to wait for a response to a DNS query. The <seconds> parameter specifies the time in seconds to wait for a response to a DNS query and ranges from 0 to 3600.

Default	3
Format	ip domain timeout <seconds>
Mode	Global Config

### no ip domain timeout

Use this command to return to the default setting.

Format	no ip domain timeout
Mode	Global Config

### clear host

Use this command to delete entries from the host name-to-address cache. This command clears the entries from the DNS cache maintained by the software. This command clears both IPv4 and IPv6 entries.

Format	clear host {<name>   all}
Mode	Privileged EXEC

Field	Description
name	A particular host entry to remove. <name> ranges from 1-255 characters.
all	Removes all entries.

## show hosts

Use this command to display the default domain name, a list of name server hosts, the static and the cached list of host names and addresses <name> ranges from 1-255 characters. This command displays both IPv4 and IPv6 entries.

Format	show hosts [<name>]
Mode	User EXEC

Field	Description
Host Name	Domain host name.
Default Domain	Default domain name.
Default Domain List	Default domain list.
Domain Name Lookup	DNS client enabled/disabled.
Number of Retries	Number of time to retry sending Domain Name System (DNS) queries.
Retry Timeout Period	Amount of time to wait for a response to a DNS query.
Name Servers	Configured name servers.

### Command example:

```
<NETGEAR Switching> show hosts
```

```
Host name..... Device
Default domain..... gm.com
Default domain list..... yahoo.com, Stanford.edu, rediff.com
Domain Name lookup..... Enabled
Number of retries..... 5
Retry timeout period..... 1500
Name servers (Preference order)... 176.16.1.18 176.16.1.19
DNS Client Source Interface..... (not configured)
```

Configured host name-to-address mapping:

```
Host                      Addresses
-----
accounting.gm.com         176.16.8.8
```

```
Host          Total    Elapsed    Type    Addresses
-----
www.stanford.edu    72      3         IP     171.64.14.203
```

## Packet Capture Commands

Packet capture commands assist in troubleshooting protocol-related problems with the management CPU. The packets to and from the management CPU can be captured in an internally allocated buffer area for export to a PC host for protocol analysis. Public domain packet analysis tools like Ethereal can be used to decode and review the packets in detail. Capturing can be performed in a variety of modes, either transmit-side only, receive-side only, or both. The number of packets captured will depend on the size of the captured packets.

### capture {start | stop}

Use the **capture start** command to manually start capturing CPU packets for packet trace. Capturing packets is stopped automatically when 128 packets are captured and have not yet been displayed during a capture session. It is guaranteed that packets not displayed and not saved will not be lost when capturing is in progress. Use the **capture stop** command to manually stop capturing CPU packets for packet trace before the moment when 128 packets are captured and capturing packets is stopped automatically. The packet capture operates in three modes:

- Capture file
- Remote capture
- Capture line

The command is not persistent across a reboot cycle.

Format	capture {start   stop} {transmit   receive   all}
Mode	Privileged EXEC

### capture {file | remote | line}

Use this command to configure file capture options. The command is persistent across a reboot cycle.

Default	Remote
Format	capture {file   remote   line}
Mode	Global Config

Parameter	Description
file	In capture file mode, the captured packets are stored in a file on NVRAM. The maximum file size defaults to 524,288 bytes. The switch can transfer the file to a TFTP server via TFTP, SFTP, SCP via CLI, web and SNMP. The file is formatted in pcap format, is named <code>cpuPktCapture.pcap</code> , and can be examined using network analyzer tools such as Wireshark® by Ethereal®. Starting a file capture automatically terminates any remote capture sessions and line capturing. After the packet capture is activated, the capture proceeds until the capture file reaches its maximum size, or until the capture is stopped manually using the CLI command <b>capture stop</b> .



Parameter	Description
remote	In remote capture mode, the captured packets are redirected in real time to an external computer running the Wireshark tool for Microsoft® Windows®. A packet capture server runs on the switch side and sends the captured packets via a TCP connection to the Wireshark tool. The remote capture can be enabled or disabled using the CLI. There should be a Windows computer with the Wireshark tool to display the captured file. When using the remote capture mode, the switch does not store any captured data locally on its file system. You can configure the IP port number for connecting Wireshark to the switch. The default port number is 2002. If a firewall is installed between the Wireshark PC and the switch, these ports must be allowed to pass through the firewall. You must configure the firewall to allow the Wireshark computer to initiate TCP connections to the switch. If the socket connection to Wireshark has been established, the captured CPU packets are written to the data socket. Wireshark receives the packets and processes it to display. This continues until the session is terminated by either end. Starting a remote capture session automatically terminates the file capture and line capturing.
line	In capture line mode, the captured packets are saved in real-time mode into the RAM and can be displayed on the CLI. Starting a line capture automatically terminates any remote capture session and capturing into a file.

### no capture

Use this command to reset the capture mode to remote mode.

Format	no capture
Mode	Global Config

### capture remote port

Use this command to configure file capture options. The command is persistent across a reboot cycle.

Default	2002
Format	capture remote port <port-id>
Mode	Global Config

### no capture remote port

Use this command to reset the remote port to the default (2002).

Format	no capture report port
Mode	Global Config

### capture file size

Use this command to configure file capture options. The command is persistent across a reboot cycle. The range is from 2 to 512 Kbytes.

Default	512 Kbytes
Format	capture file size <file-size>
Mode	Global Config

### no capture file size

Use this command to reset the file size to the default (512 Kbytes).

Format	no capture file size
Mode	Global Config

### capture line wrap

This command enables wrapping of captured packets in line mode when the captured packets reaches full capacity.

Default	Disabled
Format	capture line wrap
Mode	Global Config

### no capture line wrap

This command disables wrapping of captured packets and configures capture packet to stop when the captured packet capacity is full.

Format	no capture line wrap
Mode	Global Config

### show capture packets

Use this command to display packets captured and saved to RAM. It is possible to capture and save into RAM, packets that are received or transmitted through the CPU. A maximum 128 packets can be saved into RAM per capturing session. A maximum 128 bytes per packet can be saved into the RAM. If a packet holds more than 128 bytes, only the first 128 bytes are saved; data more than 128 bytes is skipped and cannot be displayed in the CLI.

Capturing packets is stopped automatically when 128 packets are captured and have not yet been displayed during a capture session. Captured packets are not retained after a reload cycle.

Format	show capture packets
Mode	Privileged EXEC

## Serviceability Packet Tracing Commands

These commands improve the capability of network engineers to diagnose conditions affecting their managed switch product.



### CAUTION:

The output of the `debug` commands can be long and might adversely affect system performance.

### debug arp

Use this command to enable ARP debug protocol messages.

Default	disabled
Format	debug arp
Mode	Privileged EXEC

### no debug arp

Use this command to disable ARP debug protocol messages.

Format	no debug arp
Mode	Privileged EXEC

### debug auto-voip

Use this command to enable Auto VoIP debug messages. Use the optional parameters to trace H323, SCCP, or SIP packets respectively.

Default	disabled
Format	debug auto-voip [H323   SCCP   SIP]
Mode	Privileged EXEC

### no debug auto-voip

Use this command to disable Auto VoIP debug messages.

Format	no debug auto-voip
Mode	Privileged EXEC

### debug clear

This command disables all previously enabled debug traces.

Default	disabled
Format	debug clear
Mode	Privileged EXEC

### debug console

This command enables the display of debug trace output on the login session in which it is executed. Debug console display must be enabled in order to view any trace output. The output of debug trace commands will appear on all login sessions for which debug console has been enabled. The configuration of this command remains in effect for the life of the login session. The effect of this command is not persistent across resets.

Default	disabled
Format	debug console
Mode	Privileged EXEC

### no debug console

This command disables the display of “debug” trace output on the login session in which it is executed.

Format	no debug console
Mode	Privileged EXEC

### debug crashlog

Use this command to view information contained in the crash log file that the system maintains when it experiences an unexpected reset. The crash log file contains the following information:

- Call stack information in both primitive and verbose forms
- Log Status
- Buffered logging

- Event logging
- Persistent logging
- System Information (output of sysapiMbufDump)
- Message Queue Debug Information
- Memory Debug Information
- Memory Debug Status
- OS Information (output of osapiShowTasks)
- /proc information (meminfo, cpuinfo, interrupts, version and net/sockstat)

Format	debug crashlog {[kernel] <crashlog-number> [upload <url>]   proc   verbose   deleteall}
Mode	Privileged EXEC
Default	Disabled

Parameter	Definition
kernel	View the crash log file for the kernel.
<crashlog-number>	Specifies the file number to view. The system maintains up to four copies, and the valid range is 1–4.
upload <url>	To upload the crash log to a TFTP server, use the upload keyword and specify the required TFTP server information.
proc	View the application process crashlog.
verbose	Enable the verbose crashlog
deleteall	Delete all crash log files on the system.

### debug dhcp packet

Use this command to display debug information about DHCPv4 client activities and trace DHCPv4 packets to and from the local DHCPv4 client.

Default	disabled
Format	debug dhcp packet [transmit   receive]
Mode	Privileged EXEC

### no debug dhcp

Use this command to disable the display of debug trace output for DHCPv4 client activity.

Format	no debug dhcp packet [transmit   receive]
Mode	Privileged EXEC

**debug dot1x packet**

Use this command to enable dot1x packet debug trace.

Default	disabled
Format	debug dot1x
Mode	Privileged EXEC

**no debug dot1x packet**

Use this command to disable dot1x packet debug trace.

Format	no debug dot1x
Mode	Privileged EXEC

**debug igmpsnooping packet**

This command enables tracing of IGMP Snooping packets received and transmitted by the switch.

Default	disabled
Format	debug igmpsnooping packet
Mode	Privileged EXEC

**no debug igmpsnooping packet**

This command disables tracing of IGMP Snooping packets.

Format	no debug igmpsnooping packet
Mode	Privileged EXEC

**debug igmpsnooping packet transmit**

This command enables tracing of IGMP Snooping packets transmitted by the switch. Snooping should be enabled on the device and the interface in order to monitor packets for a particular interface.

Default	disabled
Format	debug igmpsnooping packet transmit
Mode	Privileged EXEC

**Command example:**

```
(NETGEAR Switch) #debug igmpsnooping packet transmit
<15> JAN 01 02:45:06 192.168.17.29-1 IGMP Snoop[185429992]: igmp_snooping_debug.c(116)
908 % Pkt TX - Intf: 0/20(20), Vlan_Id:1 Src_Mac: 00:03:0e:00:00:00 Dest_Mac:
01:00:5e:00:00:01 Src_IP: 9.1.1.1 Dest_IP: 225.0.0.1 Type: V2_Membership_Report Group:
225.0.0.1
```

The parameters that are shown in the following table are displayed in the trace message.

Parameter	Definition
TX	A packet transmitted by the device.
Intf	The interface that the packet went out on. Format used is slot/port (internal interface number). Unit is always shown as 1 for interfaces on a non-stacking device.
Src_Mac	Source MAC address of the packet.
Dest_Mac	Destination multicast MAC address of the packet.
Src_IP	The source IP address in the IP header in the packet.
Dest_IP	The destination multicast IP address in the packet.
Type	The type of IGMP packet. Type can be one of the following: <ul style="list-style-type: none"> <li>• Membership Query. IGMP Membership Query</li> <li>• V1_Membership_Report. IGMP Version 1 Membership Report</li> <li>• V2_Membership_Report. IGMP Version 2 Membership Report</li> <li>• V3_Membership_Report. IGMP Version 3 Membership Report</li> <li>• V2_Leave_Group. IGMP Version 2 Leave Group</li> </ul>
Group	Multicast group address in the IGMP header.

**no debug igmpsnooping transmit**

This command disables tracing of transmitted IGMP snooping packets.

Format	no debug igmpsnooping transmit
Mode	Privileged EXEC

**debug igmpsnooping packet receive**

This command enables tracing of IGMP Snooping packets received by the switch. Snooping should be enabled on the device and the interface in order to monitor packets for a particular interface.

Default	disabled
Format	debug igmpsnooping packet receive
Mode	Privileged EXEC

**Command example:**

```
(NETGEAR Switch) #debug igmpsnooping packet receive
<15> JAN 01 02:45:06 192.168.17.29-1 IGMP_SNOOP[185429992]: igmp_snooping_debug.c(116)
908 % Pkt RX - Intf: 0/20(20), Vlan_Id:1 Src_Mac: 00:03:0e:00:00:10 Dest_Mac:
01:00:5e:00:00:05 Src_IP: 11.1.1.1 Dest_IP: 225.0.0.5 Type: Membership_Query Group:
225.0.0.5
```

The parameters that are shown in the following table are displayed in the trace message.

Parameter	Definition
RX	A packet received by the device.
Intf	The interface that the packet went out on. Format used is slot/port (internal interface number). Unit is always shown as 1 for interfaces on a non-stacking device.
Src_Mac	Source MAC address of the packet.
Dest_Mac	Destination multicast MAC address of the packet.
Src_IP	The source IP address in the ip header in the packet.
Dest_IP	The destination multicast ip address in the packet.
Type	The type of IGMP packet. Type can be one of the following: <ul style="list-style-type: none"> <li>• Membership_Query. IGMP Membership Query</li> <li>• V1_Membership_Report. IGMP Version 1 Membership Report</li> <li>• V2_Membership_Report. IGMP Version 2 Membership Report</li> <li>• V3_Membership_Report. IGMP Version 3 Membership Report</li> <li>• V2_Leave_Group. IGMP Version 2 Leave Group</li> </ul>
Group	Multicast group address in the IGMP header.

**no debug igmpsnooping receive**

This command disables tracing of received IGMP Snooping packets.

Format	no debug igmpsnooping receive
Mode	Privileged EXEC

**debug ip acl**

Use this command to enable debug of IP Protocol packets matching the ACL criteria.

Default	disabled
Format	debug ip acl <acl-number>
Mode	Privileged EXEC



### no debug ip acl

Use this command to disable debug of IP Protocol packets matching the ACL criteria.

Format	no debug ip acl <acl-number>
Mode	Privileged EXEC

### debug ip dvmrp packet

Use this command to trace DVMRP packet reception and transmission. If you use the **receive** option, only received DVMRP packets are traced. If you use the **transmit** option, only transmitted DVMRP packets are traced. When neither keyword is used in the command, then all DVMRP packet traces are dumped. Vital information such as source address, destination address, control packet type, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ip dvmrp packet [receive   transmit]
Mode	Privileged EXEC

### no debug ip dvmrp packet

Use this command to disable debug tracing of DVMRP packet reception and transmission.

Format	no debug ip dvmrp packet [receive   transmit]
Mode	Privileged EXEC

### debug ip igmp packet

Use this command to trace IGMP packet reception and transmission. If you use the **receive** option, only received IGMP packets are traced. If you use the **transmit** option, only transmitted IGMP packets are traced. When neither keyword is used in the command, then all IGMP packet traces are dumped. Vital information such as source address, destination address, control packet type, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ip igmp packet [receive   transmit]
Mode	Privileged EXEC

### no debug ip igmp packet

Use this command to disable debug tracing of IGMP packet reception and transmission.

Format	no debug ip igmp packet [receive   transmit]
Mode	Privileged EXEC

### debug ip mcache packet

Use this command for tracing MDATA packet reception and transmission. If you use the **receive** option, only received MDATA packets are traced. If you use the **transmit** option, only transmitted MDATA packets are traced. When neither keyword is used in the command, then all data packet traces are dumped. Vital information such as source address, destination address, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ip mcache packet [receive   transmit]
Mode	Privileged EXEC

### no debug ip mcache packet

Use this command to disable debug tracing of MDATA packet reception and transmission.

Format	no debug ip mcache packet [receive   transmit]
Mode	Privileged EXEC

### debug ip pimdm packet

Use this command to trace PIMDM packet reception and transmission. If you use the **receive** option, only received PIMDM packets are traced. If you use the **transmit** option, only transmitted PIMDM packets are traced. When neither keyword is used in the command, then all PIMDM packet traces are dumped. Vital information such as source address, destination address, control packet type, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ip pimdm packet [receive   transmit]
Mode	Privileged EXEC

### no debug ip pimdm packet

Use this command to disable debug tracing of PIMDM packet reception and transmission.

Format	no debug ip pimdm packet [receive   transmit]
Mode	Privileged EXEC

### debug ip pimsm packet

Use this command to trace PIMSM packet reception and transmission. Use this command to trace PIMSM packet reception and transmission. If you use the **receive** option, only received PIMSM packets are traced. If you use the **transmit** option, only transmitted PIMDM packets are traced. When neither keyword is used in the command, then all PIMSM packet traces are dumped. Vital information such as source address, destination address, control packet type, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ip pimsm packet [receive   transmit]
Mode	Privileged EXEC

### no debug ip pimsm packet

Use this command to disable debug tracing of PIMSM packet reception and transmission.

Format	no debug ip pimsm packet [receive   transmit]
Mode	Privileged EXEC

### debug ip vrrp

Use this command to enable VRRP debug protocol messages.

Default	disabled
Format	debug ip vrrp
Mode	Privileged EXEC

### no debug ip vrrp

Use this command to disable VRRP debug protocol messages.

Format	no debug ip vrrp
Mode	Privileged EXEC

### debug ipv6 dhcp

Use this command to display debug information about DHCPv6 client activities and trace DHCPv6 packets to and from the local DHCPv6 client.

Default	disabled
Format	debug ipv6 dhcp
Mode	Privileged EXEC

### no ipv6 debug dhcp

Use this command to disable the display of debug trace output for DHCPv6 client activity.

Format	no debug ipv6 dhcp
Mode	Privileged EXEC

### debug ipv6 mcache packet

Use this command to trace MDATAv6 packet reception and transmission. If you use the **receive** option, only received MDATAv6 packets are traced. If you use the **transmit** option, only transmitted MDATAv6 packets are traced. When neither keyword is used in the command, then all data packet traces are dumped. Vital information such as source address, destination address, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ipv6 mcache packet [receive   transmit]
Mode	Privileged EXEC

### no debug ipv6 mcache packet

Use this command to disable debug tracing of MDATAv6 packet reception and transmission.

Format	no debug ipv6 mcache packet [receive   transmit]
Mode	Privileged EXEC

### debug ipv6 mld packet

Use this command to trace MLDv6 packet reception and transmission. If you use the **receive** option, only received MLDv66 packets are traced. If you use the **transmit** option, only transmitted MLDv6 packets are traced. When neither keyword is used in the command, then all MLDv6 packet traces are dumped. Vital information such as source address, destination address, control packet type, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ipv6 mld packet [receive   transmit]
Mode	Privileged EXEC

### no debug ipv6 mld packet

Use this command to disable debug tracing of MLDv6 packet reception and transmission.

Format	no debug ipv6 mld packet [receive   transmit]
Mode	Privileged EXEC

### debug ipv6 pimdm packet

Use this command to trace PIMDMv6 packet reception and transmission. If you use the **receive** option, only received PIMDMv6 packets are traced. If you use the **transmit** option, only transmitted PIMDMv6 packets are traced. When neither keyword is used in the command, then all PIMDMv6 packet traces are dumped. Vital information such as source address, destination address, control packet type, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ipv6 pimdm packet [receive   transmit]
Mode	Privileged EXEC

### no debug ipv6 pimdm packet

Use this command to disable debug tracing of PIMDMv6 packet reception and transmission.

Format	no debug ipv6 pimdm packet [receive   transmit]
Mode	Privileged EXEC

### debug ipv6 pimsm packet

Use this command to trace PIMSMv6 packet reception and transmission. If you use the **receive** option, only received PIMSMv6 packets are traced. If you use the **transmit** option, only transmitted PIMSMv6 packets are traced. When neither keyword is used in the command, then all PIMSMv6 packet traces are dumped. Vital information such as source address, destination address, control packet type, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug ipv6 pimsm packet [receive   transmit]
Mode	Privileged EXEC

### no debug ipv6 pimsm packet

Use this command to disable debug tracing of PIMSMv6 packet reception and transmission.

Format	no debug ipv6 pimsm packet [receive   transmit]
Mode	Privileged EXEC

### debug lacp packet

This command enables tracing of LACP packets received and transmitted by the switch.

Default	disabled
Format	debug lacp packet
Mode	Privileged EXEC

#### Command example:

```
(NETGEAR Switch) #debug lacp packet
```

```
<15> JAN 01 14:04:51 10.254.24.31-1 DOT3AD[183697744]: dot3ad_debug.c(385) 58 %%  
  Pkt TX - Intf: 0/1(1), Type: LACP, Sys: 00:11:88:14:62:e1, State: 0x47, Key:  
0x36
```

### no debug lacp packet

This command disables tracing of LACP packets.

Format	no debug lacp packet
Mode	Privileged EXEC

### debug mldsnopping packet

Use this command to trace MLD snooping packet reception and transmission. If you use the **receive** option, only received MLD packets are traced. If you use the **transmit** option, only transmitted MLD packets are traced. When neither keyword is used in the command, then all MLD snooping packet traces are dumped. Vital information such as source address, destination address, control packet type, packet length, and the interface on which the packet is received or transmitted is displayed on the console.

Default	disabled
Format	debug mldsnoping packet [receive   transmit]
Mode	Privileged EXEC

### no debug mldsnoping packet

Use this command to disable debug tracing of MLD snooping packet reception and transmission.

Format	no debug mldsnoping packet [receive   transmit]
Mode	Privileged EXEC

### debug ospf packet

This command enables tracing of OSPF packets received and transmitted by the switch.

Default	disabled
Format	debug ospf packet
Mode	Privileged EXEC

#### Command example:

```
(NETGEAR Switch) #debug ospf packet
```

```
<15> JAN 02 11:03:31 10.50.50.1-2 OSPF[46300472]: ospf_debug.c(297) 25430 % Pkt RX -
Intf:2/0/48 Src
```

```
Ip:192.168.50.2 DestIp:224.0.0.5 AreaId:0.0.0.0 Type:HELLO NetMask:255.255.255.0
DesigRouter:0.0.0.0 Backup:0.0.0.0
```

```
<15> JAN 02 11:03:35 10.50.50.1-2 OSPF[46300472]: ospf_debug.c(293) 25431 % Pkt TX -
Intf:2/0/48 Src
```

```
Ip:10.50.50.1 DestIp:192.168.50.2 AreaId:0.0.0.0 Type:DB_DSCR Mtu:1500 Options:E
Flags: I/M/MS Seq:126166
```

```
<15> JAN 02 11:03:36 10.50.50.1-2 OSPF[46300472]: ospf_debug.c(297) 25434 % Pkt RX -
Intf:2/0/48 Src
```

```
Ip:192.168.50.2 DestIp:192.168.50.1 AreaId:0.0.0.0 Type:LS_REQ Length: 1500
```

```
<15> JAN 02 11:03:36 10.50.50.1-2 OSPF[46300472]: ospf_debug.c(293) 25435 % Pkt TX -
Intf:2/0/48 Src
```

```
Ip:10.50.50.1 DestIp:192.168.50.2 AreaId:0.0.0.0 Type:LS_UPD Length: 1500
```

The parameters that are shown in the following table are displayed in the trace message.

Parameter	Definition
TX/RX	TX refers to a packet transmitted by the device. RX refers to packets received by the device.
Intf	The interface that the packet came in or went out on. Format used is slot/port (internal interface number).
Srclp	The source IP address in the IP header of the packet.
Destlp	The destination IP address in the IP header of the packet.
Areald	The area ID in the OSPF header of the packet.
Type	Could be one of the following: <ul style="list-style-type: none"> <li>• HELLO. Hello packet</li> <li>• DB_DSCR. Database descriptor</li> <li>• LS_REQ. LS Request</li> <li>• LS_UPD. LS Update</li> <li>• LS_ACK. LS Acknowledge</li> </ul>

The remaining fields in the trace message are specific to the OSPF packets.

For HELLO packet field definitions, the parameters that are shown in the following table are displayed in the trace message.

Parameter	Definition
Netmask	The netmask in the hello packet.
DesignRouter	Designated Router IP address.
Backup	Backup router IP address.

For DB\_DSCR packet field definitions, the parameters that are shown in the following table are displayed in the trace message.

Field	Definition
MTU	MTU
Options	Options in the OSPF packet.
Flags	Could be one or more of the following: <ul style="list-style-type: none"> <li>• I. Init</li> <li>• M. More</li> <li>• MS. Master/Slave</li> </ul>
Seq	Sequence Number of the DD packet.



For LS\_REQ packet field definitions, the parameter that is shown in the following table is displayed in the trace message.

Field	Definition
Length	Length of packet

For LS\_UPD packet field definitions, the parameter that is shown in the following table is displayed in the trace message.

Field	Definition
Length	Length of packet

For LS\_ACK packet field definitions, the parameter that is shown in the following table is displayed in the trace message.

Field	Definition
Length	Length of packet

### no debug ospf packet

This command disables tracing of OSPF packets.

Format	no debug ospf packet
Mode	Privileged EXEC

### debug ipv6 ospfv3 packet

Use this command to enable OSPFv3 packet debug trace.

Default	disabled
Format	debug ipv6 ospfv3 packet
Mode	Privileged EXEC

### no debug ipv6 ospfv3 packet

Use this command to disable tracing of OSPFv3 packets.

Format	no debug ipv6 ospfv3 packet
Mode	Privileged EXEC

## debug ping packet

This command enables tracing of ICMP echo requests and responses. The command traces pings on the network port or service port for switching packages. For routing packages, pings are traced on the routing ports as well.

Default	disabled
Format	debug ping packet
Mode	Privileged EXEC

### Command example:

```
(NETGEAR Switch) #debug ping packet
```

```
<15> JAN 01 00:21:22 192.168.17.29-1 SIM[181040176]: sim_debug.c(128) 20 % Pkt TX - Intf:
0/1(1),
SRC_IP:10.50.50.2, DEST_IP:10.50.50.1, Type:ECHO_REQUEST
```

```
<15> JAN 01 00:21:22 192.168.17.29-1 SIM[182813968]: sim_debug.c(82) 21 % Pkt RX - Intf:
0/1(1), S
RC_IP:10.50.50.1, DEST_IP:10.50.50.2, Type:ECHO_REPLY
```

The parameters that are shown in the following table are displayed in the trace message.

Parameter	Definition
TX/RX	TX refers to a packet transmitted by the device. RX refers to packets received by the device.
Intf	The interface that the packet came in or went out on. Format used is slot/port (internal interface number). Unit is always shown as 1 for interfaces on a non-stacking device.
SRC_IP	The source IP address in the IP header in the packet.
DEST_IP	The destination IP address in the IP header in the packet.
Type	Type determines whether or not the ICMP message is a REQUEST or a RESPONSE.

## no debug ping packet

This command disables tracing of ICMP echo requests and responses.

Format	no debug ping packet
Mode	Privileged EXEC

## debug rip packet

This command turns on tracing of RIP requests and responses. This command takes no options. The output is directed to the log file.

Default	disabled
Format	debug rip packet
Mode	Privileged EXEC

### Command example:

```
(NETGEAR Switch) #debug rip packet
```

```
<15> JAN 01 00:35:15 192.168.17.29-1 RIP[181783160]: rip_map_debug.c(96) 775 %
Pkt RX on Intf: 0/1(1), Src_IP:43.1.1.1 Dest_IP:43.1.1.2
Rip_Version: RIPv2 Packet_Type:RIP_RESPONSE
ROUTE 1): Network: 10.1.1.0 Mask: 255.255.255.0 Metric: 1
ROUTE 2): Network: 40.1.0.0 Mask: 255.255.0.0 Metric: 1
ROUTE 3): Network: 10.50.50.0 Mask: 255.255.255.0 Metric: 1
ROUTE 4): Network: 41.1.0.0 Mask: 255.255.0.0 Metric: 1
ROUTE 5): Network:42.0.0.0 Mask:255.0.0.0 Metric:1
Another 6 routes present in packet not displayed.
```

The parameters that are shown in the following table are displayed in the trace message.

Parameter	Definition
TX/RX	TX refers to a packet transmitted by the device. RX refers to packets received by the device.
Intf	The interface that the packet came in or went out on. Format used is slot/port (internal interface number). Unit is always shown as 1 for interfaces on a non-stacking device.
Src_IP	The source IP address in the IP header of the packet.
Dest_IP	The destination IP address in the IP header of the packet.
Rip_Version	RIP version used <RIPv1 or RIPv2>.
Packet_Type	Type of RIP packet. <RIP_REQUEST or RIP_RESPONSE>.
Routes	Up to 5 routes in the packet are displayed in the following format: Network: <a.b.c.d> Mask <a.b.c.d> Next_Hop <a.b.c.d> Metric <a> The next hop is only displayed if it is different from 0.0.0.0. For RIPv1 packets, Mask is always 0.0.0.0.
Number of routes not printed	Only the first five routes present in the packet are included in the trace. There is another notification of the number of additional routes present in the packet that were not included in the trace.

**no debug rip packet**

This command disables tracing of RIP requests and responses.

Format	no debug rip packet
Mode	Privileged EXEC

**debug sflow packet**

Use this command to enable sFlow debug packet trace.

Default	disabled
Format	debug sflow packet
Mode	Privileged EXEC

**no debug sflow packet**

Use this command to disable sFlow debug packet trace.

Format	no debug sflow packet
Mode	Privileged EXEC

**debug spanning-tree bpdu**

This command enables tracing of spanning tree BPDUs received and transmitted by the switch.

Default	disabled
Format	debug spanning-tree bpdu
Mode	Privileged EXEC

**no debug spanning-tree bpdu**

This command disables tracing of spanning tree BPDUs.

Format	no debug spanning-tree bpdu
Mode	Privileged EXEC

## debug spanning-tree bpdud receive

This command enables tracing of spanning tree BPDUs received by the switch. Spanning tree should be enabled on the device and on the interface in order to monitor packets for a particular interface.

Default	disabled
Format	debug spanning-tree bpdud receive
Mode	Privileged EXEC

### Command example:

```
(NETGEAR Switch) #debug spanning-tree bpdud receive
```

```
<15> JAN 01 01:02:04 192.168.17.29-1 DOT1S[191096896]: dot1s_debug.c(1249) 101 % Pkt RX
- Intf: 0/9(9), Source_Mac: 00:11:88:4e:c2:10 Version: 3, Root Mac: 00:11:88:4e:c2:00,
Root Priority: 0x8000 Path Cost: 0
```

The parameters that are shown in the following table are displayed in the trace message.

Parameter	Definition
RX	A packet received by the device.
Intf	The interface that the packet came in on. Format used is slot/port (internal interface number). Unit is always shown as 1 for interfaces on a non-stacking device.
Source_Mac	Source MAC address of the packet.
Version	Spanning tree protocol version (0-3). 0 refers to STP, 2 RSTP and 3 MSTP.
Root_Mac	MAC address of the CIST root bridge.
Root_Priority	Priority of the CIST root bridge. The value is between 0 and 61440. It is displayed in hex in multiples of 4096.
Path_Cost	External root path cost component of the BPDUD.

## no debug spanning-tree bpdud receive

This command disables tracing of received spanning tree BPDUs.

Format	no debug spanning-tree bpdud receive
Mode	Privileged EXEC

## debug spanning-tree bpdu transmit

This command enables tracing of spanning tree BPDUs transmitted by the switch. Spanning tree should be enabled on the device and on the interface in order to monitor packets on a particular interface.

Default	disabled
Format	debug spanning-tree bpdu transmit
Mode	Privileged EXEC

### Command example:

```
(NETGEAR Switch) #debug spanning-tree bpdu transmit
```

```
<15> JAN 01 01:02:04 192.168.17.29-1 DOT1S[191096896]: dot1s_debug.c(1249) 101 % Pkt TX
- Intf: 0/7(7), Source_Mac: 00:11:88:4e:c2:00 Version: 3, Root_Mac: 00:11:88:4e:c2:00,
Root_Priority: 0x8000 Path_Cost: 0
```

The parameters that are shown in the following table are displayed in the trace message.

Parameter	Definition
TX	A packet transmitted by the device.
Intf	The interface that the packet went out on. Format used is slot/port (internal interface number). Unit is always shown as 1 for interfaces on a non-stacking device.
Source_Mac	Source MAC address of the packet.
Version	Spanning tree protocol version (0-3). 0 refers to STP, 2 RSTP and 3 MSTP.
Root_Mac	MAC address of the CIST root bridge.
Root_Priority	Priority of the CIST root bridge. The value is from 0 through 61,440. It is displayed in hex in multiples of 4096.
Path_Cost	External root path cost component of the BPDU.

## no debug spanning-tree bpdu transmit

This command disables tracing of transmitted spanning tree BPDUs.

Format	no debug spanning-tree bpdu transmit
Mode	Privileged EXEC

**debug udd packet**

This command enables debugging on the received and transmitted UDLD PDUs.

Default	Disabled
Format	default udd packet receive
Mode	Privileged EXEC

**no debug udd packet**

This command disables debugging on the received and transmitted UDLD PDUs.

Format	debug udd packet receive
Mode	Privileged EXEC

**debug udd packet receive**

This command enables debugging on the received UDLD PDUs.

Default	Disabled
Format	default udd packet receive
Mode	Privileged EXEC

**no debug udd packet receive**

This command disables debugging on the received UDLD PDUs.

Format	debug udd packet receive
Mode	Privileged EXEC

**debug udd packet transmit**

This command enables debugging on the transmitted UDLD PDUs.

Default	Disabled
Format	default udd packet transmit
Mode	Privileged EXEC

**no debug udld packet transmit**

This command enables debugging on the transmitted UDLD PDUs.

Format	<code>debug udld packet transmit</code>
Mode	Privileged EXEC

**debug aaa accounting**

This command is useful for debugging accounting configuration and functionality in User Manager.

Format	<code>debug aaa accounting</code>
Mode	Privileged EXEC

**no debug aaa accounting**

Use this command to turn off debugging of User Manager accounting functionality.

Format	<code>no debug aaa accounting</code>
Mode	Privileged EXEC

**debug aaa authorization**

This command is useful for debugging authorization configuration and functionality in User Manager.

Format	<code>debug aaa authorization [commands   exec]</code>
Mode	Privileged EXEC

**no debug aaa authorization**

Use this command to turn off debugging of User Manager authorization functionality.

Format	<code>no debug aaa authorization</code>
Mode	Privileged EXEC



## Cable Test Command

The cable test feature enables you to determine the cable connection status on a selected port.

---

**Note:** The cable test feature is supported only for copper cable. It is not supported for optical fiber cable. If the port has an active link while the cable test is run, the link can go down for the duration of the test.

---

### cablstatus

This command returns the status of the specified port.

Format	cablstatus <slot/port>
Mode	Privileged EXEC

Field	Description
Cable Status	One of the following statuses is returned: <ul style="list-style-type: none"> <li>• Normal. The cable is working correctly.</li> <li>• Open. The cable is disconnected or there is a faulty connector.</li> <li>• Short. There is an electrical short in the cable.</li> <li>• Cable Test Failed. The cable status could not be determined. The cable may in fact be working.</li> </ul>
Cable Length	If this feature is supported by the PHY for the current link speed, the cable length is displayed as a range between the shortest estimated length and the longest estimated length. Note that if the link is down and a cable is attached to a 10/100 Ethernet adapter, then the cable status may display as Open or Short because some Ethernet adapters leave unused wire pairs unterminated or grounded. Unknown is displayed if the cable length could not be determined.

## sFlow Commands

sFlow is the standard for monitoring high-speed switched and routed networks. sFlow technology is built into network equipment and gives complete visibility into network activity, enabling effective management and control of network resources.

## sflow receiver

Use this command to configure the sFlow collector parameters (owner string, receiver time-out, maximum datagram size, IP address, and port) for a poller.

Format	<code>sflow receiver &lt;rcvr_idx&gt; {owner &lt;owner-string&gt; {timeout &lt;rcvr_timeout&gt;   notimeout}   maxdatagram &lt;size&gt;   ip &lt;ip&gt;   port &lt;port&gt;}</code>
Mode	Global Config

Field	Description
Receiver Index	The sFlow Receiver for this sFlow sampler to which flow samples are to be sent. A value of zero (0) means that no receiver is configured, no packets will be sampled. Only active receivers can be set. If a receiver expires, then all samplers associated with the receiver will also expire. Possible values are 1-8. The default is 0.
Receiver Owner	The identity string for the receiver, the entity making use of this sFlowRcvrTable entry. The range is 127 characters. The default is a null string. The empty string indicates that the entry is currently unclaimed and the receiver configuration is reset to the default values. An entity wishing to claim an sFlowRcvrTable entry must ensure that the entry is unclaimed before trying to claim it. The entry is claimed by setting the owner string to a non-null value. The entry must be claimed before assigning a receiver to a sampler or poller.
Receiver Timeout	The time, in seconds, remaining before the sampler or poller is released and stops sending samples to receiver. A management entity wanting to maintain control of the sampler is responsible for setting a new value before the old one expires. The allowed range is 0-4294967295 seconds. The default is zero (0).
Receiver Max Datagram Size	The maximum number of data bytes that can be sent in a single sample datagram. The management entity should set this value to avoid fragmentation of the sFlow datagrams. The allowed range is 200 –9,116). The default is 1400.
Receiver IP	The sFlow receiver IP address. If set to 0.0.0.0, no sFlow datagrams will be sent. The default is 0.0.0.0.
Receiver Port	The destination Layer4 UDP port for sFlow datagrams. The range is 1-65535. The default is 6343.

## no sflow receiver

Use this command to set the sFlow collector parameters back to the defaults.

Format	<code>no sflow receiver &lt;rcvr_idx&gt; [owner   maxdatagram   ip   port]</code>
Mode	Global Config

## sflow sampler

A data source configured to collect flow samples is called a poller. Use this command to configure a new sFlow sampler instance for this data source if `<rcvr-idx>` is valid.

Format	<code>sflow sampler {&lt;rcvr-idx&gt;   rate &lt;sampling-rate&gt;   maxheadersize &lt;size&gt;}</code>
Mode	Interface Config

Field	Description
Receiver Index	The sFlow Receiver for this sFlow sampler to which flow samples are to be sent. A value of zero (0) means that no receiver is configured, no packets will be sampled. Only active receivers can be set. If a receiver expires, then all samplers associated with the receiver will also expire. Possible values are 1-8. The default is 0.
Sampling Rate	<p>The statistical sampling rate for packet sampling from this source. A value of zero (0) disables sampling. A value of N means that out of N incoming packets, 1 packet will be sampled. The range is 1024-65536 and 0. The default is 0.</p> <p>When you issue a <b>show</b> command for the sampling rate, the configured sampling rate on an interface changes. Each time that you configure a sampling rate, a threshold value is calculated. This threshold value is configured in the hardware register. When you issue a <b>show</b> command for the sampling rate, the threshold value is queried from the hardware and the sampling rate is calculated in the following way:</p> <pre>threshold value = 2^24 / (sampling rate)</pre> <p>Because only an integer operation is supported, the sampling rate is not the same as the configured value.</p> <p>The following is an example:</p> <pre>configured sampling rate is 60000 threshold value = 2^24 / (60000) = 279 (from integer division) recalculated sampling rate = 2^24 / (279) = 60133</pre>
Maxheadersize	The maximum number of bytes that should be copied from the sampler packet. The range is 20-256. The default is 128. When set to zero (0), all the sampler parameters are set to their corresponding default value.

## no sflow sampler

Use this command to reset the sFlow sampler instance to the default settings.

Format	<code>no sflow sampler {&lt;rcvr-idx&gt;   rate &lt;sampling-rate&gt;   maxheadersize &lt;size&gt;}</code>
Mode	Interface Config

## sflow poller

A data source configured to collect counter samples is called a poller. Use this command to enable a new sFlow poller instance for this data source if *<rcvr-idx>* is valid.

Format	<code>sflow poller {&lt;rcvr-idx&gt;   interval &lt;poll-interval&gt;}</code>
Mode	Interface Config

Field	Description
Receiver Index	Enter the sFlow Receiver associated with the sampler/poller. A value of zero (0) means that no receiver is configured. The range is 1-8. The default is 0.
Poll Interval	Enter the sFlow instance polling interval. A poll interval of zero (0) disables counter sampling. When set to zero (0), all the poller parameters are set to their corresponding default value. The range is 0-86400. The default is 0. A value of N means once in N seconds a counter sample is generated.

## no sflow poller

Use this command to reset the sFlow poller instance to the default settings.

Format	<code>no sflow poller {&lt;rcvr-idx&gt;   interval &lt;poll-interval&gt;}</code>
Mode	Interface Config

## show sflow agent

The sFlow agent collects time-based sampling of network interface statistics and flow-based samples. These are sent to the configured sFlow receivers. Use this command to display the sFlow agent information.

Format	<code>show sflow agent</code>
Mode	Privileged EXEC

Field	Description
sFlow Version	Uniquely identifies the version and implementation of this MIB. The version string must have the following structure: MIB Version; Organization; Software Revision where: <ul style="list-style-type: none"> <li>• MIB Version: '1.3', the version of this MIB.</li> <li>• Organization: Netgear.</li> <li>• Revision: 1.0</li> </ul>
IP Address	The IP address associated with this agent.

**Command example:**

```
(NETGEAR Switch) #show sflow agent
```

```
sFlow Version..... 1.3;Netgear;1.0
IP Address..... 10.131.12.66
```

**show sflow pollers**

Use this command to display the sFlow polling instances created on the switch. Use “-” for range.

Format	show sflow pollers
Mode	Privileged EXEC

Field	Description
Poller Data Source	The sFlowDataSource (slot/port) for this sFlow sampler. This agent will support Physical ports only.
Receiver Index	The sFlowReceiver associated with this sFlow counter poller.
Poller Interval	The number of seconds between successive samples of the counters associated with this data source.

**show sflow receivers**

Use this command to display configuration information related to the sFlow receivers.

Format	show sflow receivers [<index>]
Mode	Privileged EXEC

Field	Description
Receiver Index	The sFlow Receiver associated with the sampler/poller.
Owner String	The identity string for receiver, the entity making use of this sFlowRcvrTable entry.
Time Out	The time (in seconds) remaining before the receiver is released and stops sending samples to sFlow receiver.
Max Datagram Size	The maximum number of bytes that can be sent in a single sFlow datagram.
Port	The destination Layer4 UDP port for sFlow datagrams.
IP Address	The sFlow receiver IP address.

Field	Description
Address Type	The sFlow receiver IP address type. For an IPv4 address, the value is 1 and for an IPv6 address, the value is 2.
Datagram Version	The sFlow protocol version to be used while sending samples to sFlow receiver.

**Command example:**

```
(NETGEAR Switch) #show sflow receivers 1
Receiver Index..... 1
Owner String.....
Time out..... 0
IP Address:..... 0.0.0.0
Address Type..... 1
Port..... 6343
Datagram Version..... 5
Maximum Datagram Size..... 1400
```

**show sflow samplers**

Use this command to display the sFlow sampling instances created on the switch.

Format	show sflow samplers
Mode	Privileged EXEC

Field	Description
Sampler Data Source	The sFlowDataSource (slot/port) for this sFlow sampler. This agent will support Physical ports only.
Receiver Index	The sFlowReceiver configured for this sFlow sampler.
Packet Sampling Rate	The statistical sampling rate for packet sampling from this source.
Max Header Size	The maximum number of bytes that should be copied from a sampled packet to form a flow sample.

## IP Address Conflict Commands

### ip address-conflict-detect run

This command triggers the switch to run active address conflict detection by sending gratuitous ARP packets for IPv4 addresses on the switch.

---

**Note:** This command takes effect only once after it is executed and cannot be saved across power cycles.

---

Format	<code>ip address-conflict-detect run</code>
Mode	Global Config

### show ip address-conflict

This command displays the status information corresponding to the last detected address conflict.

Format	<code>show ip address-conflict</code>
Modes	Privileged EXEC

Term	Definition
Address Conflict Detection Status	Identifies whether the switch has detected an address conflict on any IP address.
Last Conflicting IP Address	The IP Address that was last detected as conflicting on any interface.
Last Conflicting MAC Address	The MAC Address of the conflicting host that was last detected on any interface.
Time Since Conflict Detected	The time in days, hours, minutes and seconds since the last address conflict was detected.

### clear ip address-conflict-detect

This command clears the detected address conflict status information.

Format	<code>clear ip address-conflict-detect</code>
Mode	Privileged EXEC

## RMON Stats and History Commands

The various MIBs within RFC 2819, 3273, and 3434 are arranged into groups. The managed switch supports some of the groups in these RFCs but not all. The managed switch complies with MODULE-COMPLIANCE and OBJECT-GROUP definitions within these RFCs for supporting individual groups.

The managed switch supports the following groups:

- **RFC 2819**
  - Group 1 - Statistics  
Contains cumulative traffic and error statistics.
  - Group 2 - History  
Generates reports from periodic traffic sampling that are useful for analyzing trends. This group includes History Control Group and Ethernet History Group.
  - Group 3 - Alarm  
Enables the definition and setting of thresholds for various counters. Thresholds can be passed in either a rising or falling direction on existing MIB objects, primarily those in the Statistics group. An alarm is triggered when a threshold is crossed and the alarm is passed to the Event group. The Alarm requires the Event Group.
  - Group 9 - Event  
Controls the actions that are taken when an event occurs. RMON events occur when:
    - A threshold (alarm) is exceeded
    - There is a match on certain filters.
- **RFC 3273**
  - Group 1 - Media Independent Group  
Contains media-independent statistics that provide information for full and/or half-duplex links as well as high capacity links.
  - Group 2 - Ether Stats High Capacity Group  
Contains the High Capacity RMON extensions to RMON-1 etherStatsTable (RFC 2819 Group 1).
  - Group 3 - Ether History High Capacity Group  
Contains the High Capacity RMON extensions to RMON-1 etherHistoryTable (RFC 2819 Group 2).
- **RFC 3434**
  - Group 1 - High Capacity Alarm Control Group  
Controls the configuration of alarms for high capacity MIB object instances.



- Group 2 - High Capacity Alarm Capabilities Group  
Describes the high capacity alarm capabilities provided by the agent.
- Group 3 - High Capacity Alarm Notifications Group  
Provides new rising and falling threshold notifications for high capacity objects.

### rmon alarm

This command sets the RMON alarm entry in the RMON alarm MIB group.

Format	<code>rmon alarm &lt;alarm-number&gt; &lt;variable&gt; &lt;sample-interval&gt; &lt;sampling-type&gt; {rising-threshold &lt;value&gt;} {falling-threshold &lt;value&gt;} [startup {rising   falling   rising-falling}] [owner &lt;string&gt;]</code>
Mode	Global Config

Parameter	Description
<code>&lt;alarm-number&gt;</code>	The alarm number that identifies the alarm.
<code>&lt;variable&gt;</code>	The object identifier of the particular variable to be sampled. Only variables that resolve to an ASN.1 primitive type of integer.
<code>&lt;sample-interval&gt;</code>	The interval in seconds over which the data is sampled and compared with the rising and falling thresholds. The range is 0 to 2147483647. The default is 0.
<code>&lt;sampling-type&gt;</code>	The alarm sample type. The method of sampling the selected variable and calculating the value to be compared against thresholds. Possible types are Absolute or Delta.
<code>rising-threshold &lt;value&gt;</code>	The alarm rising threshold for the sample statistics.
<code>falling-threshold &lt;value&gt;</code>	The alarm falling threshold for the sample statistics.
<code>[startup {rising   falling   rising-falling}]</code>	The alarm that may be sent. Possible values are Rising Alarm, Falling Alarm, or both.
<code>owner &lt;string&gt;</code>	The alarm owner. The owner string associated with the alarm entry.

### no rmon alarm

This command deletes the RMON alarm entry.

Format	<code>no rmon alarm &lt;alarm number&gt;</code>
Mode	Global Config

**rmon hcalarm**

This command sets the RMON hcalarm entry in the High Capacity RMON alarm MIN group.

Format	<code>rmon hcalarm &lt;alarm-number&gt; &lt;variable&gt; &lt;sample-interval&gt; &lt;sampling-type&gt; {rising-threshold high &lt;value&gt;} {rising-threshold low &lt;value&gt;} {falling-threshold high &lt;value&gt;} {falling-threshold low &lt;value&gt;} [startup {rising   falling   rising-falling}] [owner &lt;string&gt;]</code>
Mode	Global Config

Parameter	Description
<code>&lt;alarm-number&gt;</code>	The identifier of the hcalarm instance.
<code>&lt;variable&gt;</code>	The object identifier of the particular variable to be sampled. Only variables that resolve to an ASN.1 primitive type of integer.
<code>&lt;sample-interval&gt;</code>	The interval in seconds over which the data is sampled and compared with the rising and falling thresholds. The range is 1 to 2147483647.
<code>&lt;sampling-type&gt;alarm Sample Type</code>	The method of sampling the selected variable and calculating the value to be compared against thresholds. Possible types are Absolute or Delta.
<code>rising-threshold high &lt;value&gt;</code>	High capacity alarm rising threshold absolute value high. The upper 32 bits of the absolute value for threshold for the sampled statistics.
<code>rising-threshold low &lt;value&gt;</code>	High capacity alarm rising threshold absolute value low. The lower 32 bits of the absolute value for threshold for the sampled statistics.
<code>falling-threshold high &lt;value&gt;</code>	High capacity alarm falling threshold absolute value high. The upper 32 bits of the absolute value for threshold for the sampled statistic.
<code>falling-threshold low &lt;value&gt;</code>	High capacity alarm falling threshold absolute value high. The upper 32 bits of the absolute value for threshold for the sampled statistic.
<code>[startup {rising   falling   rising-falling}]</code>	High capacity alarm startup alarm that may be sent. Possible values are Rising Alarm, Falling Alarm or both.
<code>[owner &lt;string&gt;]</code>	High capacity alarm owner. The owner string associated with the entry.

**no rmon hcalarm**

This command deletes the RMON hcalarm entry.

Format	<code>no rmon hcalarm &lt;alarm number&gt;</code>
Mode	Global Config

## rmon event

This command sets the RMON event entry in the RMON event MIB group.

Format	rmon event <i>&lt;event-number&gt;</i> [ <i>description &lt;string&gt;</i>   log   owner <i>&lt;string&gt;</i>   trap <i>&lt;community&gt;</i> ]
Mode	Global Config

Parameter	Description
<i>&lt;event number&gt;</i>	An index number that uniquely identifies an entry in the event table. Each such entry defines one event that is to be generated when the appropriate conditions occur. The range is 1 to 65535.
description <i>&lt;string&gt;</i>	A comment describing the event entry. The default is alarmEvent.
log	Creates a log entry
owner <i>&lt;string&gt;</i>	The owner string that is associated with the entry. The default is monitorEvent.
trap <i>&lt;community&gt;</i>	The SNMP community, which is specified by an octet string that is used to send an SNMP trap. The default is public.

## no rmon event

This command deletes the RMON event entry.

Format	no rmon event <i>&lt;event number&gt;</i>
Mode	Global Config

## rmon collection history

This command sets the history control parameters of the RMON historyControl MIB group.

Format	rmon collection history <i>&lt;index number&gt;</i> buckets <i>&lt;1-65535&gt;</i>   interval <i>&lt;1-3600&gt;</i>   owner <i>&lt;owner&gt;</i>
Mode	Interface Config

## no rmon collection history

This command deletes the history control group entry with the specified index number.

Format	no rmon collection history <i>&lt;index number&gt;</i>
Mode	Interface Config

## show rmon

This command displays the entries in the RMON alarm table.

Format	show rmon {alarms   alarm <alarm-index>}
Mode	Privileged Exec

## show rmon collection history

This command displays the entries in the RMON history control table.

Format	show rmon collection history
Mode	Privileged Exec

## show rmon events

This command displays the entries in the RMON event table.

Format	show rmon events
Mode	Privileged Exec

### Command example:

```
(NETGEAR Switch) # show rmon events
```

```

Index  Description          Type      Community  Owner      Last time sent
-----
1      test                  log       public     MIB        0 days 0 h:0 m:0 s

```

## show rmon history

This command displays the specified entry in the RMON history table.

Format	show rmon history <index> {errors   other   throughput}
Mode	Privileged Exec

### Command example:

```
(NETGEAR Switch) # show rmon history 1 throughput
```

```
Sample set: 1
```

```
Maximum table size: 270
```

```

Time          Octets      Packets    Broadcast Multicast  Util
-----

```

## show rmon log

This command displays the entries in the RMON log table.

Format	show rmon log
Mode	Privileged Exec

### Command example:

```
(NETGEAR Switch) # show rmon log
```

```
Maximum table size: 100
```

```
Event   Description                               Time
-----
```

## show rmon statistics interface

This command displays the RMON statistics for the interface.

Format	show rmon statistics interface <slot/port>
Mode	Privileged Exec

### Command example:

```
(NETGEAR Switch) # show rmon statistics interface 0/1
```

```
Interface: 0/1
```

```
Dropped: 0
```

```
Octets: 0  Packets: 0
```

```
Broadcast: 0  Multicast: 0
```

```
CRC Align Errors: 0  Collisions: 0
```

```
Undersize Pkts: 0  Oversize Pkts: 0
```

```
Fragments: 0  Jabbers: 0
```

```
64 Octets: 0  65 - 127 Octets: 0
```

```
128 - 255 Octets: 0  256 - 511 Octets: 0
```

```
512 - 1023 Octets: 0  1024 - 1518 Octets: 0
```

## show rmon hcalarms

This command displays the entries in the RMON hcAlarmTable.

Format	show rmon hcalarms [<alarm index>]
Mode	Privileged Exec

## UniDirectional Link Detection Commands

The UDLD feature detects unidirectional links physical ports. A unidirectional link is a forwarding anomaly in a Layer 2 communication channel in which a bidirectional link stops passing traffic in one direction. UDLD must be enabled on both sides of the link in order to detect a unidirectional link. The UDLD protocol operates by exchanging packets containing information about neighboring devices.

### udld enable (Global Config)

This command enables UDLD globally on the switch.

Default	disabled
Format	udld enable
Mode	Global Config

### no udld enable (Global Config)

This command disables UDLD globally on the switch.

Format	no udld enable
Mode	Global Config

### udld message time

This command configures the interval between UDLD probe messages on ports that are in the advertisement phase. The range is from 7 to 90 seconds.

Default	15
Format	udld message time <i>&lt;interval&gt;</i>
Mode	Global Config

### udld timeout interval

This command configures the time interval after which UDLD link is considered to be unidirectional. The range is from 5 to 60 seconds.

Default	5
Format	udld timeout interval <i>&lt;interval&gt;</i>
Mode	Global Config

### udld enable (Interface Config)

This command enables UDLD on the specified interface.

Default	disabled
Format	udld enable
Mode	Interface Config

### no udld enable (Interface Config)

This command disables UDLD on the specified interface.

Format	no udld enable
Mode	Interface Config

### udld port

This command selects the UDLD mode operating on this interface. If you do not enter the **aggressive** keyword, the port operates in normal mode.

Default	normal
Format	udld port [aggressive]
Mode	Interface Config

### udld reset

This command resets all interfaces that have been shutdown by UDLD.

Format	udld reset
Mode	Privileged EXEC

### show udld

This command displays either the global UDLD settings or the UDLD settings for a specified *<slot/port>*. If the **all** keyword is entered, the command displays information for all ports.

Format	show udld [ <i>&lt;slot/port&gt;</i>   all]
Mode	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

If you do not enter a value for the `<slot/port>` parameter, the command output displays the fields that are shown in the following table.

Term	Definition
Admin Mode	The global administrative mode of UDLD.
Message Interval	The time period (in seconds) between the transmission of UDLD probe packets.
Timeout Interval	The time period (in seconds) before making decision that link is unidirectional.

If you enter a value for the `<slot/port>` parameter or you use the `all` keyword, the command output displays the fields that are shown in the following table.

Term	Definition
Slot/Port	The identifying slot and port of the interface.
Admin Mode	The administrative mode of UDLD configured on this interface. This is either Enabled or Disabled.
UDLD Mode	The UDLD mode configured on this interface. This is either Normal or Aggressive.
UDLD Status	The status of the link as determined by UDLD. The options are: <ul style="list-style-type: none"> <li>• Undetermined. UDLD has not collected enough information to determine the state of the port.</li> <li>• Not applicable. UDLD is disabled, either globally or on the port</li> <li>• Shutdown. UDLD has detected a unidirectional link and shutdown the port, That is, the port is in an errDisabled state.</li> <li>• Bidirectional. UDLD has detected a bidirectional link.</li> <li>• Undetermined(Link Down). The port would transition into this state when the port link physically goes down due to any reasons other than the port been put into D-Disable mode by UDLD protocol on the switch.</li> </ul>

## USB Commands

If there is an USB flash device in the USB slot, the commands display the device status and content.

### show usb device

This command displays USB flash device details.

Format	show USB device
Mode	Privileged EXEC



Parameter	Description
Device Status	This field specifies the current status of device. Following are possible device status states: <ul style="list-style-type: none"> <li>• Active. Device is plugged in and the device is recognized if device is not mounted.</li> <li>• Inactive. Device is not mounted.</li> <li>• Invalid. Device is not present or invalid device is plugged in.</li> </ul>
Manufacturer	Manufacturer details.
Serial Number	Serial number of the device.
USB Version Compliance	Version of the USB device.
Class Code	Device Class
Subclass Code	Device SubClass
Protocol	Device Protocol
Vendor ID	Vendor specifies details of device-Vendor ID
Product ID	Vendor specifies details of device-Product ID

**Command example:**

The following is the output if the device is plugged into the USB slot.

```
(NETGEAR Switch) #show USB device

Device Status..... Active
Manufacturer..... xxxx
Serial Number..... YYYYY
USB Version Compliance..... 2.0
Class Code..... abc
Subclass Code..... acb
Protocol..... 0x0
Vendor ID..... zzzzz
Product ID..... aaaaa
```

**dir usb**

This command displays USB device contents and memory statistics.

Format	dir usb
Mode	Privileged EXEC

Parameter	Description
Filename	File name
Filesize	File size
Total Size	USB flash device storage size
Bytes Used	Indicates size of memory used on the device.
Bytes Free	Indicates size of memory free on the device

**Command example:**

```
(NETGEAR Switch) #dir USB:  
Filename Filesize Modification Time  
F1.cfg 256 4/22/2009 8:00:12
```

Total Size: xxxx

Bytes Used: yyyy

Bytes Free: zzzz

# 8 Management Commands

---

# 8

This chapter describes the management commands available in the managed switch CLI.

The chapter contains the following sections:

- *Switch Management CPU Commands*
- *Management Interface Commands*
- *Console Port Access Commands*
- *Telnet Commands*
- *Secure Shell (SSH) Commands*
- *Management Security Commands*
- *Hypertext Transfer Protocol (HTTP) Commands*
- *Access Commands*
- *User Account Commands*
- *SNMP Commands*
- *RADIUS Commands*
- *TACACS+ Commands*
- *Configuration Scripting Commands*
- *Pre-Login Banner and System Prompt Commands*

The commands in this chapter are in three functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. Every switch command has a show command that displays the configuration setting.
- Clear commands clear some or all of the settings to factory defaults.

## Switch Management CPU Commands

To manage the switch via the web GUI or telnet, an IP address needs to be assigned to the switch management CPU. Whereas there are CLI commands that can be used to do this, **ezconfig** simplifies the task. The tool allows you to configure the following parameters:

1. The administrator's user password and administrator-enable password
2. Management CPU IP address and network mask
3. System name and location information

The tool is interactive and uses questions to guide you through the steps required to perform its task. At the end of the session, it will ask you if you want to save the changed information. To see exactly what has been changed by ezconfig at the end of the session, use the **show running-config** command.

To perform any switch configuration other than the items listed above, use other CLI commands or the web GUI.

### ezconfig

This command sets the IP address, subnet mask, and gateway of the device. The IP address and the gateway must be on the same subnet.

Format	ezconfig
Mode	Privileged EXEC

The following is an example of an **ezconfig** session.

```
NETGEAR EZ Configuration Utility
-----
Hello and Welcome!

This utility will walk you thru assigning the IP address for the switch
management CPU. It will allow you to save the changes at the end. After
the session, simply use the newly assigned IP address to access the Web
GUI using any public domain Web browser.

Admin password not defined. Do you want to change the password?
(Y/N/Q) y
Enter new password:*****
Confirm new password:*****
Password Changed!

The 'enable' password required for switch configuration via the command
line interface is currently not configured. Do you wish to change it
(Y/N/Q)? y

Enter new password:*****
Confirm new password:*****
Password Changed!

Assigning an IP address to your switch management

Current IP Address Configuration
-----
IP address: 0.0.0.0
Subnet mask: 0.0.0.0
Gateway address: 0.0.0.0

Would you like to assign an IP address now (Y/N/Q)? y

IP Address: 10.10.10.1
Subnet mask: 255.255.255.0
Gateway address: 10.10.10.10

Do you want to assign switch name and location information (Y/N/Q)? y

System Name: testunit1
System Location: testlab
System Contact: Bud Lightyear
```

```
There are changes detected, do you wish to save the changes permanently
(Y/N)? y

The configuration changes have been saved successfully. Please enter
'show running-config' to see the final configuration.

Thanks for using EzConfig!
```

## Management Interface Commands

This section describes the commands you use to configure a logical interface for management access.

### enable (Privileged EXEC access)

Use this command to access the Privileged EXEC mode. From the Privileged EXEC mode, you can configure the network interface.

Format	enable
Mode	User EXEC

### ip management

Use this command to specify the source IP address for all applications (syslog, SNMP client, and so on).

Default	vlan 1
Format	ip management [ <i>serviceport</i>   vlan <number>   port <slot/port>   loopback <number>]
Mode	User EXEC

### no ip management

Use this command to specify the IP address of the management VLAN (VLAN 1) as the source IP address for all applications (syslog, SNMP client, and so on).

Format	no ip management [ <i>serviceport</i>   vlan <number>   port <slot/port>   loopback <number>]
Mode	User EXEC

### network mac-address

Use this command to set locally administered MAC addresses. The following rules apply:

- Bit 6 of byte 0 (called the U/L bit) indicates whether the address is universally administered (b'0') or locally administered (b'1').
- Bit 7 of byte 0 (called the I/G bit) indicates whether the destination address is an individual address (b'0') or a group address (b'1').
- The second character, of the twelve character macaddr, must be 2, 6, A or E.

A locally administered address must have bit 6 On (b'1') and bit 7 Off (b'0').

Format	<code>network mac-address &lt;macaddr&gt;</code>
Mode	Privileged EXEC

### network mac-type

Use this command to specify whether the switch uses the burned in MAC address or the locally administered MAC address.

Default	burnedin
Format	<code>network mac-type {local   burnedin}</code>
Mode	Privileged EXEC

### no network mac-type

Use this command to reset the value of MAC address to its default.

Format	<code>no network mac-type</code>
Mode	Privileged EXEC

### network javamode

Use this command to specify whether the switch should allow access to the Java applet in the header frame of the Web interface. When access is enabled, the Java applet can be viewed from the Web interface. When access is disabled, the user cannot view the Java applet.

Default	enabled
Format	<code>network javamode</code>
Mode	Privileged EXEC

### no network javamode

Use this command to disallow access to the Java applet in the header frame of the Web interface. When access is disabled, the user cannot view the Java applet.

Format	<code>no network javamode</code>
Mode	Privileged EXEC

## show network

Use this command to display configuration settings associated with the switch's network interface. The network interface is the logical interface used for in-band connectivity with the switch via any of the switch's front panel ports. The configuration parameters associated with the switch's network interface do not affect the configuration of the front panel ports through which traffic is switched or routed. The network interface is always considered to be up, whether any member ports are up; therefore, the show network command will always show "Interface Status" as "up".

Format	show network
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Interface Status	The network interface status; it is always considered to be "up".
IP Address	The IP address of the interface. The factory default value is 0.0.0.0.
Subnet Mask	The IP subnet mask for this interface. The factory default value is 0.0.0.0.
Default Gateway	The default gateway for this IP interface. The factory default value is 0.0.0.0.
IPv6 Administrative Mode	Whether enabled or disabled.
IPv6 Address/Length	The IPv6 address and length.
IPv6 Default Router	The IPv6 default router address.
Burned In MAC Address	The burned in MAC address used for in-band connectivity.
Locally Administered MAC Address	If desired, a locally administered MAC address can be configured for in-band connectivity. To take effect, 'MAC Address Type' must be set to 'Locally Administered'. Enter the address as twelve hexadecimal digits (6 bytes) with a colon between each byte. Bit 1 of byte 0 must be set to a 1 and bit 0 to a 0, that is, byte 0 should have the following mask "xxxx xx10". The MAC address used by this bridge when it must be referred to in a unique fashion. It is recommended that this be the numerically smallest MAC address of all ports that belong to this bridge. However it is only required to be unique. When concatenated with dot1dStpPriority a unique BridgIdentifier is formed which is used in the Spanning Tree Protocol.
MAC Address Type	The MAC address which should be used for in-band connectivity. The choices are the burned in or the Locally Administered address. The factory default is to use the burned in MAC address.



**Command example:**

This output is for the network port:

```
(NETGEAR Switch) #show network

Interface Status..... Always Up
IP Address..... 10.250.3.1
Subnet Mask..... 255.255.255.0
Default Gateway..... 10.250.3.3
IPv6 Administrative Mode..... Enabled
IPv6 Address/Length is ..... FE80::210:18FF:FE82:337/64
IPv6 Address/Length is ..... 3099::1/64
IPv6 Address/Length is ..... 3099::210:18FF:FE82:337/64
IPv6 Default Router is ..... FE80::204:76FF:FE73:423A
Burned In MAC Address..... 00:10:18:82:03:37
Locally Administered MAC Address..... 00:00:00:00:00:00
MAC Address Type..... Burned In
Network Configuration Protocol Current..... None
Management VLAN ID..... 1
Web Mode..... Enable
Java Mode..... Enable
```

## Console Port Access Commands

This section describes the commands you use to configure the console port. You can use a serial cable to connect a management host directly to the console port of the switch.

### configuration

Use this command to access Global Config mode. From Global Config mode, you can configure various system settings, including user accounts. You can also enter other command modes, including Line Config mode.

Format	configuration
Mode	Privileged EXEC

### line

Use this command to access Line Config mode, which allows you to configure various Telnet settings, ssh settings, and the console port.

Format	line {console   telnet   ssh}
Mode	Global Config

### serial baudrate

Use this command to specify the communication rate of the terminal interface. The supported rates are 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200.

Default	115200
Format	<code>serial baudrate {1200   2400   4800   9600   19200   38400   57600   115200}</code>
Mode	Line Config

### no serial baudrate

Use this command to set the communication rate of the terminal interface.

Format	<code>no serial baudrate</code>
Mode	Line Config

### serial timeout

Use this command to specify the maximum connect time (in minutes) without console activity. A value of 0 indicates that a console can be connected indefinitely. The time range is 0–160.

Default	5
Format	<code>serial timeout &lt;0-160&gt;</code>
Mode	Line Config

### no serial timeout

Use this command to set the maximum connect time (in minutes) without console activity.

Format	<code>no serial timeout</code>
Mode	Line Config

### login authentication

Use this command in line configuration mode to specify a login authentication method list for remote telnet or console.

Format	<code>login authentication {default   &lt;list-name&gt;}</code>
Mode	Line Config

### no login authentication

Use this command to return to the default specified by the `login authentication` command.

Format	<code>no login authentication {default   &lt;list-name&gt;}</code>
Mode	Line Config

### enable authentication

Use this command in line configuration mode to specify an authentication method list when the user accesses a higher privilege level in remote telnet or console.

Format	<code>enable authentication {default   &lt;list-name&gt;}</code>
Mode	Line Config

### no enable authentication

Use this command to return to the default specified by the `enable authentication` command.

Format	<code>no enable authentication {default   &lt;list-name&gt;}</code>
Mode	Line Config

### show serial

Use this command to display serial communication settings for the switch.

Format	<code>show serial</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Serial Port Login Timeout (minutes)	The time, in minutes, of inactivity on a Serial port connection, after which the Switch will close the connection. Any numeric value from 0 through 160 is allowed, the factory default is 5. A value of 0 disables the timeout.
Baud Rate (bps)	The default baud rate at which the serial port will try to connect. The available values are 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115,200 baud. The factory default is 9600 baud.
Character Size (bits)	The number of bits in a character. The number of bits is always 8.
Flow Control	Whether Hardware Flow-Control is enabled or disabled. Hardware Flow Control is always disabled.

Term	Definition
Stop Bits	The number of Stop bits per character. The number of Stop bits is always 1.
Parity Type	The parity method used on the serial port. The parity method is always None.

## Telnet Commands

This section describes the commands you use to configure and view Telnet settings. You can use Telnet to manage the device from a remote management host.

### ip telnet server enable

Use this command to enable Telnet connections to the system and to enable the Telnet Server Admin Mode. This command opens the Telnet listening port.

Default	enabled
Format	<code>ip telnet server enable</code>
Mode	Privileged EXEC

### no ip telnet server enable

Use this command to disable Telnet access to the system and to disable the Telnet Server Admin Mode. This command closes the Telnet listening port and disconnects all open Telnet sessions.

Format	<code>no ip telnet server enable</code>
Mode	Privileged EXEC

### telnet

Use this command to establish a new outbound Telnet connection to a remote host. The host must be a valid IP address or host name. The value for `<port>` is a valid decimal integer in the range of 0–65,535, where the default value is 23. If the optional `debug` parameter is used, the current Telnet options enabled is displayed. The optional `line` parameter sets the outbound Telnet operational mode as linemode (by default, the operational mode is character mode). The optional `noecho` parameter disables local echo.

Format	<code>telnet {&lt;ip-address&gt;   &lt;hostname&gt;} &lt;port&gt; [debug] [line] [noecho]</code>
Modes	<ul style="list-style-type: none"> <li>Privileged EXEC</li> <li>User EXEC</li> </ul>

### transport input telnet

Use this command to regulate new Telnet sessions. If enabled, new Telnet sessions can be established until there are no more sessions available. An established session remains active until the session is ended or an abnormal network error ends the session.

---

**Note:** If the Telnet Server Admin Mode is disabled, Telnet sessions cannot be established. Use the `ip telnet server enable` command to enable Telnet Server Admin Mode.

---

Default	enabled
Format	transport input telnet
Mode	Line Config

### no transport input telnet

Use this command to prevent new Telnet sessions from being established.

Format	no transport input telnet
Mode	Line Config

### transport output telnet

Use this command to regulate new outbound Telnet connections. If enabled, new outbound Telnet sessions can be established until the system reaches the maximum number of simultaneous outbound Telnet sessions allowed. An established session remains active until the session is ended or an abnormal network error ends it.

Default	enabled
Format	transport output telnet
Mode	Line Config

### no transport output telnet

Use this command to prevent new outbound Telnet connection from being established.

Format	no transport output telnet
Mode	Line Config

**session-limit**

Use this command to specify the maximum number of simultaneous outbound Telnet sessions. A value of 0 indicates that no outbound Telnet session can be established.

Default	5
Format	<code>session-limit &lt;0-5&gt;</code>
Mode	Line Config

**no session-limit**

Use this command to set the maximum number of simultaneous outbound Telnet sessions to the default value.

Format	<code>no session-limit</code>
Mode	Line Config

**session-timeout**

Use this command to set the Telnet session timeout value. The timeout value unit of time is minutes.

Default	5
Format	<code>session-timeout &lt;1-160&gt;</code>
Mode	Line Config

**no session-timeout**

Use this command to set the Telnet session timeout value to the default. The timeout value unit of time is minutes.

Format	<code>no session-timeout</code>
Mode	Line Config

**telnetcon maxsessions**

Use this command to specify the maximum number of Telnet connection sessions that can be established. A value of 0 indicates that no Telnet connection can be established. The range is 0-5.

Default	4
Format	<code>telnetcon maxsessions &lt;0-4&gt;</code>
Mode	Privileged EXEC

**no telnetcon maxsessions**

Use this command to set the maximum number of Telnet connection sessions that can be established to the default value.

Format	no telnetcon maxsessions
Mode	Privileged EXEC

**telnetcon timeout**

Use this command to set the Telnet connection session time-out value, in minutes. A session is active as long as the session has not been idle for the value set. The time is a decimal value from 1 to 160.

---

**Note:** When you change the time-out value, the new value is applied to all active and inactive sessions immediately. Any sessions that have been idle longer than the new time-out value are disconnected immediately.

---

Default	5
Format	telnetcon timeout <1-160>
Mode	Privileged EXEC

**no telnetcon timeout**

Use this command to set the Telnet connection session timeout value to the default.

---

**Note:** Changing the time-out value for active sessions does not become effective until the session is reaccessed. Also, any keystroke activates the new time-out duration.

---

Format	no telnetcon timeout
Mode	Privileged EXEC

## show telnet

Use this command to display the current outbound Telnet settings. In other words, these settings apply to Telnet connections initiated from the switch to a remote system.

Format	<code>show telnet</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Outbound Telnet Login Timeout	The number of minutes an outbound Telnet session is allowed to remain inactive before being logged off.
Maximum Number of Outbound Telnet Sessions	The number of simultaneous outbound Telnet connections allowed.
Allow New Outbound Telnet Sessions	Indicates whether outbound Telnet sessions will be allowed.

## show telnetcon

Use this command to display the current inbound Telnet settings. In other words, these settings apply to Telnet connections initiated from a remote system to the switch.

Format	<code>show telnetcon</code>
Modes	<ul style="list-style-type: none"> <li>• Privileged EXEC</li> <li>• User EXEC</li> </ul>

Term	Definition
Remote Connection Login Timeout (minutes)	This object indicates the number of minutes a remote connection session is allowed to remain inactive before being logged off. Might be specified as a number from 1 to 160. The factory default is 5.
Maximum Number of Remote Connection Sessions	This object indicates the number of simultaneous remote connection sessions allowed. The factory default is 5.
Allow New Telnet Sessions	New Telnet sessions will not be allowed when this field is set to no. The factory default value is yes.



## Secure Shell (SSH) Commands

This section describes the commands you use to configure SSH access to the switch. Use SSH to access the switch from a remote management host.

---

**Note:** The system allows a maximum of five SSH sessions.

---

### ip ssh

Use this command to enable SSH access to the system. (This command is the short form of the `ip ssh server enable` command.)

Default	disabled
Format	<code>ip ssh</code>
Mode	Privileged EXEC

### ip ssh protocol

Use this command to set or remove protocol levels (or versions) for SSH. Either SSH1 (1), SSH2 (2), or both SSH 1 and SSH 2 (1 and 2) can be set.

Default	1 and 2
Format	<code>ip ssh protocol [1] [2]</code>
Mode	Privileged EXEC

### ip ssh server enable

Use this command to enable the IP secure shell server.

Default	disabled
Format	<code>ip ssh server enable</code>
Mode	Privileged EXEC

### no ip ssh server enable

Use this command to disable the IP secure shell server.

Format	<code>no ip ssh server enable</code>
Mode	Privileged EXEC

### sshcon maxsessions

Use this command to specify the maximum number of SSH connection sessions that can be established. A value of 0 indicates that no ssh connection can be established. The range is 0–5.

Default	5
Format	sshcon maxsessions <0-5>
Mode	Privileged EXEC

### no sshcon maxsessions

Use this command to set the maximum number of allowed SSH connection sessions to the default value.

Format	no sshcon maxsessions
Mode	Privileged EXEC

### sshcon timeout

Use this command to set the SSH connection session time-out value, in minutes. A session is active as long as the session has been idle for the value set. The time is a decimal value from 1 to 160.

Changing the time-out value for active sessions does not become effective until the session is re accessed. Also, any keystroke activates the new time-out duration.

Default	5
Format	sshcon timeout <1-160>
Mode	Privileged EXEC

### no sshcon timeout

Use this command to set the SSH connection session timeout value, in minutes, to the default.

Changing the timeout value for active sessions does not become effective until the session is re accessed. Also, any keystroke activates the new timeout duration.

Format	no sshcon timeout
Mode	Privileged EXEC

## show ip ssh

Use this command to display the ssh settings.

Format	show ip ssh
Mode	Privileged EXEC

Term	Definition
Administrative Mode	This field indicates whether the administrative mode of SSH is enabled or disabled.
Protocol Level	The protocol level might have the values of version 1, version 2 or both versions 1 and version 2.
SSH Sessions Currently Active	The number of SSH sessions currently active.
Max SSH Sessions Allowed	The maximum number of SSH sessions allowed.
SSH Timeout	The SSH time-out value in minutes.
Keys Present	Indicates whether the SSH RSA and DSA key files are present on the device.
Key Generation in Progress	Indicates whether RSA or DSA key files generation is currently in progress.

## Management Security Commands

This section describes commands you use to generate keys and certificates, which you can do in addition to loading them as before.

### crypto certificate generate

Use this command to generate self-signed certificate for HTTPS. The generate RSA key for SSL has a length of 1024 bits. The resulting certificate is generated with a common name equal to the lowest IP address of the device and a duration of 365 days.

Format	crypto certificate generate
Mode	Global Config

### no crypto certificate generate

Use this command to delete the HTTPS certificate files from the device, regardless of whether they are self-signed or downloaded from an outside source.

Format	<code>no crypto certificate generate</code>
Mode	Global Config

### crypto key generate rsa

Use this command to generate an RSA key pair for SSH. The new key files will overwrite any existing generated or downloaded RSA key files.

Format	<code>crypto key generate rsa</code>
Mode	Global Config

### no crypto key generate rsa

Use this command to delete the RSA key files from the device.

Format	<code>no crypto key generate rsa</code>
Mode	Global Config

### crypto key generate dsa

Use this command to generate a DSA key pair for SSH. The new key files will overwrite any existing generated or downloaded DSA key files.

Format	<code>crypto key generate dsa</code>
Mode	Global Config

### no crypto key generate dsa

Use this command to delete the DSA key files from the device.

Format	<code>no crypto key generate dsa</code>
Mode	Global Config

## Hypertext Transfer Protocol (HTTP) Commands

This section describes the commands you use to configure HTTP and secure HTTP access to the switch. Access to the switch by using a Web browser is enabled by default. Everything you can view and configure by using the CLI is also available by using the Web.

### ip http server

Use this command to enable access to the switch through the Web interface. When access is enabled, the user can login to the switch from the Web interface. When access is disabled, the user cannot login to the switch's web server. Disabling the Web interface takes effect immediately. All interfaces are affected.

Default	enabled
Format	<code>ip http server</code>
Mode	Privileged EXEC

### no ip http server

Use this command to disable access to the switch through the Web interface. When access is disabled, the user cannot login to the switch's Web server.

Format	<code>no ip http server</code>
Mode	Privileged EXEC

### ip http secure-server

Use this command to enable the secure socket layer for secure HTTP.

Default	disabled
Format	<code>ip http secure-server</code>
Mode	Privileged EXEC

### no ip http secure-server

Use this command to disable the secure socket layer for secure HTTP.

Format	<code>no ip http secure-server</code>
Mode	Privileged EXEC

### ip http java

Use this command to enable the Web Java mode. The Java mode applies to both secure and unsecure web connections.

Default	Enabled
Format	<code>ip http java</code>
Mode	Privileged EXEC

### no ip http java

Use this command to disable the Web Java mode. The Java mode applies to both secure and unsecure web connections.

Format	no ip http java
Mode	Privileged EXEC

### ip http session hard-timeout

Use this command to configure the hard time-out for unsecure HTTP sessions in hours. Configuring this value to zero sets an infinite hard time-out. When this time-out expires, the user must reauthenticate. This timer begins on initiation of the web session and is unaffected by the activity level of the connection.

Default	24
Format	ip http session hard-timeout <0-168>
Mode	Privileged EXEC

### no ip http session hard-timeout

Use this command to restore the hard timeout for unsecure HTTP sessions to the default value.

Format	no ip http session hard-timeout
Mode	Privileged EXEC

### ip http authentication

Use this command to specify the authentication methods for http server users. The additional methods of authentication are used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify none as the final method in the command line. For example If none specified as an authentication method after RADIUS, no authentication is used if the RADIUS server is down.

Format	ip http authentication <method1> [<method2> ...]
Mode	Global ConfigC

Term	Definition
Local	Uses the local user name database for authentication.
Radius	Uses the list of all RADIUS servers for authentication.

Term	Definition
Tacacs	Uses the list of all TACACS servers for authentication.
None	Uses no authentication.

### no ip http authentication

Use this command to restore the authentication methods to the default.

Format	<code>no ip http authentication &lt;method1&gt; [&lt;method2&gt; ...]</code>
Mode	Global Config

### ip http session maxsessions

Use this command to limit the number of allowable unsecure HTTP sessions. Zero is the configurable minimum.

Default	16
Format	<code>ip http session maxsessions &lt;0-16&gt;</code>
Mode	Privileged EXEC

### no ip http session maxsessions

Use this command to restore the number of allowable unsecure HTTP sessions to the default value.

Format	<code>no ip http session maxsessions</code>
Mode	Privileged EXEC

### ip http session soft-timeout

Use this command to configure the soft time-out for unsecure HTTP sessions in minutes. Configuring this value to zero sets an infinite soft time-out. When this time-out expires the user must reauthenticate. This timer begins on initiation of the web session and is restarted with each access to the switch.

Default	5
Format	<code>ip http session soft-timeout &lt;0-60&gt;</code>
Mode	Privileged EXEC

**no ip http session soft-timeout**

Use this command to reset the soft time-out for unsecure HTTP sessions to the default value.

Format	<code>no ip http session soft-timeout</code>
Mode	Privileged EXEC

**ip http secure-session maxsessions**

Use this command to limit the number of secure HTTP sessions. Zero is the configurable minimum.

Default	16
Format	<code>ip http secure-session maxsessions &lt;0-16&gt;</code>
Mode	Privileged EXEC

**no ip http secure-session maxsessions**

Use this command to restore the number of allowable secure HTTP sessions to the default value.

Format	<code>no ip http secure-session maxsessions</code>
Mode	Privileged EXEC

**ip http secure-session soft-timeout**

Use this command to configure the soft time-out for secure HTTP sessions in minutes. When this time-out expires, you must reauthenticate. This timer begins on initiation of the web session and is restarted with each access to the switch. The secure session soft time-out cannot be set to zero (infinite).

Default	5
Format	<code>ip http secure-session soft-timeout &lt;1-60&gt;</code>
Mode	Privileged EXEC

**no ip http secure-session soft-timeout**

Use this command to restore the soft time-out for secure HTTP sessions to the default value.

Format	<code>no ip http secure-session soft-timeout</code>
Mode	Privileged EXEC



### ip http secure-session hard-timeout

Use this command to configure the hard time-out for secure HTTP sessions in hours. When the time-out expires, the user must reauthenticate. This timer begins on initiation of the web session and is unaffected by the activity level of the connection. The secure session hard time-out cannot be set to zero (infinite).

Default	24
Format	ip http secure-session hard-timeout <1-168>
Mode	Privileged EXEC

### no ip http secure-session hard-timeout

Use this command to reset the hard time-out for secure HTTP sessions to the default value.

Format	no ip http secure-session hard-timeout
Mode	Privileged EXEC

### ip https authentication

Use this command to specify the authentication methods for http server users. The additional methods of authentication are used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify **none** as the final method in the command line. If **none** is specified as an authentication method after **radius**, no authentication is used if the RADIUS server is down.

Format	ip https authentication <method1> [<method2> ...]
Mode	Global Config

Term	Definition
Local	Uses the local user name database for authentication.
Radius	Uses the list of all RADIUS servers for authentication.
Tacacs	Uses the list of all TACACS servers for authentication.
None	Uses no authentication.

### no ip https authentication

Use this command to restore the authentication methods to the default for http server users.

Format	no ip https authentication <method1> [<method2> ...]
Mode	Global Config

## ip http secure-port

Use this command to set the SSL port where port can be 1-65535 and the default is port 443.

Default	443
Format	<code>ip http secure-port &lt;portid&gt;</code>
Mode	Privileged EXEC

## no ip http secure-port

Use this command to reset the SSL port to the default value.

Format	<code>no ip http secure-port</code>
Mode	Privileged EXEC

## ip http secure-protocol

Use this command to set protocol levels (versions). The protocol level can be set to TLS1, SSL3 or to both TLS1 and SSL3.

Default	SSL3 and TLS1
Format	<code>ip http secure-protocol [SSL3] [TLS1]</code>
Mode	Privileged EXEC

## show ip http

Use this command to display the http settings for the switch.

Format	<code>show ip http</code>
Mode	Privileged EXEC

Term	Definition
HTTP Mode (Unsecure)	The unsecure HTTP server administrative mode.
Java Mode	The java applet administrative mode which applies to both secure and unsecure web connections.
Maximum Allowable HTTP Sessions	The number of allowable unsecure http sessions.
HTTP Session Hard Timeout	The hard time-out for unsecure http sessions in hours.
HTTP Session Soft Timeout	The soft time-out for unsecure http sessions in minutes.
HTTP Mode (Secure)	The secure HTTP server administrative mode.

Term	Definition
Secure Port	The secure HTTP server port number.
Secure Protocol Level(s)	The protocol level might have the values of SSL3, TSL1, or both SSL3 and TSL1.
Maximum Allowable HTTPS Sessions	The number of allowable secure http sessions.
HTTPS Session Hard Timeout	The hard time-out for secure http sessions in hours.
HTTPS Session Soft Timeout	The soft time-out for secure http sessions in minutes.
Certificate Present	Indicates whether the secure-server certificate files are present on the device.
Certificate Generation in Progress	Indicates whether certificate generation is currently in progress.

## Access Commands

Use the commands in this section to close remote connections or to view information about connections to the system.

### disconnect

Use the **disconnect** command to close HTTP, HTTPS, Telnet, or SSH sessions. Use **all** to close all active sessions, or use *<session-id>* to specify the session ID to close. To view the possible values for *<session-id>*, use the **show loginsession** command.

Format	<code>disconnect {&lt;session-id&gt;   all}</code>
Mode	Privileged EXEC

### show loginsession

Use this command to display current Telnet and serial port connections to the switch.

Format	<code>show loginsession</code>
Mode	Privileged EXEC

Field	Definition
ID	Login Session ID.
User Name	The name the user entered to log on to the system.
Connection From	IP address of the remote client machine or EIA-232 for the serial port connection.
Idle Time	Time this session has been idle.

Field	Definition
Session Time	Total time this session has been connected.
Session Type	Shows the type of session, which can be HTTP, HTTPS, telnet, serial, or SSH.

## User Account Commands

This section describes the commands you use to add, manage, and delete system users. The software has two default users: admin and guest. The admin user can view and configure system settings, and the guest user can view settings.

---

**Note:** You cannot delete the admin user. There is only one user allowed with read/write privileges. You can configure up to five read-only users on the system.

---

### username (Global Config)

Use this command to add a new user to the local user database. The default privilege level is 1. Using the **encrypted** keyword allows the administrator to transfer local user passwords between devices without having to know the passwords. When the password parameter is used along with encrypted parameter, the password must be exactly 128 hexadecimal characters in length. If the password strength feature is enabled, this command checks for password strength and returns an appropriate error if it fails to meet the password strength criteria. The optional **override-complexity-check** parameter disables the validation of the password strength.

Format	<code>username &lt;name&gt; {password &lt;password&gt; [encrypted [override-complexity-check]   level &lt;level&gt; [encrypted [override-complexity-check]]   override-complexity-check}   {level &lt;level&gt; [override-complexity-check] password}</code>
Mode	Global Config

Term	Definition
Name	The name of the user, up to 32 characters.
Password	The password for the users 8-64 characters. This value can be zero if the no passwords min-length command has been executed. The special characters allowed in the password include: ! # \$ % & ' ( ) * + , - . / : ; < = > @ [ \ ] ^ _ ` {   } ~.
level	Specifies the user level. If not specified, the privilege level is 1. Level 0 can be assigned by a level 15 user to another user to suspend that user's access. Range 0-15. Enter access level 1 for Read Access or 15 for Read/Write Access.

Term	Definition
encrypted	Encrypted password you enter, copied from another device configuration.
override-complexity-check	Disables the validation of the password strength.

### no username

Use this command to remove a user account.

Format	no username <username>
Mode	Global Config

---

**Note:** You cannot delete the “admin” user account.

---

### username name nopassword

Use this command to remove an existing user’s password (NULL password).

Format	username <i>name</i> nopassword [ <i>level level</i> ]
Mode	Global Config

Parameter	Description
name	The name of the user. Range: 1-32 characters.
password	The authentication password for the user. Range 8-64 characters.
level	The user level. Level 0 can be assigned by a level 15 user to another user to suspend that user's access. Range 0-15.

### username unlock

Use this command to unlock a user’s account. Only a user with read/write access can reactivate a locked user account.

Format	username <username> unlock
Mode	Global Config

### username snmpv3 accessmode

Use this command to specify the SNMPv3 access privileges for the specified login user. The valid accessmode values are **readonly** and **readwrite**. The `<username>` is the login user name for which the specified access mode applies. The default is **readwrite** for the “admin” user and **readonly** for all other users. You must enter the `<username>` in the same case you used when you added the user. To see the case of the `<username>`, enter the **show users** command.

Defaults	<ul style="list-style-type: none"> <li>admin - readwrite</li> <li>other - readonly</li> </ul>
Format	<code>username snmpv3 accessmode &lt;username&gt; {readonly   readwrite}</code>
Mode	Global Config

### no username snmpv3 accessmode

Use this command to set the SNMPv3 access privileges for the specified user as **readwrite** for the “admin” user and **readonly** for all other users. The `<username>` value is the user name to which the specified access mode applies.

Format	<code>no username snmpv3 accessmode &lt;username&gt;</code>
Mode	Global Config

### username snmpv3 authentication

Use this command to specify the authentication protocol to be used for the specified user. The valid authentication protocols are **none**, **md5**, and **sha**. If you specify **md5** or **sha**, the login password is also used as the SNMPv3 authentication password and therefore must be at least eight characters in length. The `<username>` is the user name associated with the authentication protocol. You must enter the `<username>` in the same case you used when you added the user. To see the case of the `<username>`, enter the **show users** command.

Default	no authentication
Format	<code>username snmpv3 authentication &lt;username&gt; {none   md5   sha}</code>
Mode	Global Config

### no username snmpv3 authentication

Use this command to set the authentication protocol to be used for the specified user to **none**. The `<username>` is the user name for which the specified authentication protocol is used.

Format	<code>no username snmpv3 authentication &lt;username&gt;</code>
Mode	Global Config

## username snmpv3 encryption

Use this command to specify the encryption protocol used for the specified user. The valid encryption protocols are **des** and **none**.

If you select **des**, you can specify the required key on the command line. The encryption key must be 8–64 characters long. If you select the **des** protocol but do not provide a key, the user is prompted for the key. When you use the **des** protocol, the login password is also used as the SNMPv3 encryption password, so it must be a minimum of eight characters. If you select **none**, you do not need to provide a key.

The `<username>` value is the login user name associated with the specified encryption. You must enter the `<username>` in the same case you used when you added the user. To see the case of the `<username>`, enter the **show users** command.

Default	no encryption
Format	username snmpv3 encryption <code>&lt;username&gt;</code> {none   des [ <code>&lt;key&gt;</code> ]}
Mode	Global Config

## no username snmpv3 encryption

Use this command to set the encryption protocol to **none**. The `<username>` is the login user name for which the specified encryption protocol will be used.

Format	no username snmpv3 encryption <code>&lt;username&gt;</code>
Mode	Global Config

## show users

Use this command to display the configured user names and their settings. This command is available only for users with read/write privileges. The SNMPv3 fields is displayed only if SNMP is available on the system.

Format	show users
Mode	Privileged EXEC

Term	Definition
User Name	The name the user enters to login using the serial port, Telnet, or web.
Access Mode	Shows whether the user is able to change parameters on the switch (Read/Write) or is only able to view them (Read Only). As a factory default, the “admin” user has Read/Write access and the “guest” has Read Only access. There can only be one Read/Write user and up to five Read Only users.
SNMPv3 Access Mode	The SNMPv3 Access Mode. If the value is set to ReadWrite, the SNMPv3 user is able to set and retrieve parameters on the system. If the value is set to ReadOnly, the SNMPv3 user is only able to retrieve parameter information. The SNMPv3 access mode might be different than the CLI and Web access mode.

Term	Definition
SNMPv3 Authentication	The authentication protocol to be used for the specified login user.
SNMPv3 Encryption	The encryption protocol to be used for the specified login user.

### show users accounts

Use this command to display the local user status about user account lockout and password aging.

Format	show users accounts
Mode	Privileged EXEC

Term	Definition
User Name	The local user account's user name.
Privilege	The user's privilege level (1-15).
Password aging	The password aging time for the local users.
Lockout Status	Indicates whether the user account is locked out (true or false).
Password Expiration Date	The current password expiration date in date format.

### show users accounts detail

This command displays the local user status about user account lockout and password aging. It also includes information about Password strength and complexity.

Format	show users accounts detail
Mode	Privileged EXEC

#### Command example:

```
(NETGEAR Switch) #show users accounts detail
UserName..... admin
Privilege..... 15
Password Aging..... ---
Password Expiry..... ---
Lockout..... False
Override Complexity Check..... Disable
Password Strength..... ---
UserName..... guest
Privilege..... 1
Password Aging..... ---
```



```

Password Expiry..... ---
Lockout..... False
Override Complexity Check..... Disable
Password Strength..... ---

```

## show users long

Use this command to display the user's full name.

Format	show users long
Mode	Privileged EXEC

Term	Definition
User Name	The full name of the user.

## show users login-history

Use this command to display the users who have logged in previously.

Format	show users login-history [<username>]
Mode	Privileged EXEC

Term	Definition
Login Time	The time at which the user logged in.
Username	The user name used to login.
Protocol	The protocol that the user used to login.
Location	The location of the user.

## passwords min-length

Use this command to enforce a minimum password length for local users. The value also applies to the enable password. The valid range is 0–64.

Default	8
Format	passwords min-length <0-64>
Mode	Global Config

**no passwords min-length**

Use this command to set the minimum password length to the default value.

Format	<code>no passwords min-length</code>
Mode	Global Config

**passwords history**

Use this command to set the number of previous passwords that shall be stored for each user account. When a local user changes his or her password, the user will not be able to reuse any password stored in password history. This ensures that users do not reuse their passwords often. The valid range is 0-10.

Default	0
Format	<code>passwords history &lt;0-10&gt;</code>
Mode	Global Config

**no passwords history**

Use this command to set the password history to the default value.

Format	<code>no passwords history</code>
Mode	Global Config

**passwords aging**

Use this command to implement aging on passwords for local users. When a user's password expires, the user will be prompted to change it before logging in again. The valid range is 1-365. The default is 0, or no aging.

Default	0
Format	<code>passwords aging &lt;1-365&gt;</code>
Mode	Global Config

**no passwords aging**

Use this command to set the password aging to the default value.

Format	<code>no passwords aging</code>
Mode	Global Config

### passwords lock-out

Use this command to strengthen the security of the switch by locking user accounts that have failed login due to wrong passwords. When a lockout count is configured, a user that is logged in must enter the correct password within that count. Otherwise the user will be locked out from further switch access. Only a user with read/write access can reactivate a locked user account. Password lockout does not apply to logins from the serial console. The valid range is 1-5. The default is 0, or no lockout count enforced.

Default	0
Format	passwords lock-out <1-5>
Mode	Global Config

### no passwords lock-out

Use this command to set the password lock-out count to the default value.

Format	no passwords lock-out
Mode	Global Config

### passwords strength-check

Use this command to enable the password strength feature. It is used to verify the strength of a password during configuration.

Default	Disable
Format	passwords strength-check
Mode	Global Config

### no passwords strength-check

Use this command to disable the password strength-check.

Format	no passwords strength-check
Mode	Global Config

### passwords strength minimum uppercase-letters

Use this command to enforce a minimum number of uppercase letters that a password should contain. The valid range is 0-16. The default is 2. Minimum of 0 means no restriction on that set of characters.

Default	2
Format	<code>passwords strength minimum uppercase-letters &lt;number&gt;</code>
Mode	Global Config

### no passwords strength minimum uppercase-letters

Use this command to reset the minimum number of uppercase letters to the default value.

Format	<code>no passwords strength minimum uppercase-characters</code>
Mode	Global Config

### passwords strength minimum lowercase-letters

Use this command to enforce a minimum number of lowercase letters that a password should contain. The valid range is 0-16. The default is 2. Minimum of 0 means no restriction on that set of characters.

Default	2
Format	<code>passwords strength minimum lowercase-letters &lt;number&gt;</code>
Mode	Global Config

### no passwords strength minimum lowercase-letters

Use this command to reset the minimum number of lowercase letters to the default value.

Format	<code>no passwords strength minimum lowercase-characters</code>
Mode	Global Config

### passwords strength minimum numeric-characters

Use this command to enforce a minimum number of numeric characters that a password should contain. The valid range is 0-16. The default is 2. Minimum of 0 means no restriction on that set of characters.

Default	2
Format	<code>passwords strength minimum numeric-letters &lt;number&gt;</code>
Mode	Global Config

**no passwords strength minimum numeric-characters**

Use this command to reset the minimum number of numeric characters to the default value.

Format	<code>no passwords strength minimum numeric-characters</code>
Mode	Global Config

**passwords strength minimum special-characters**

Use this command to enforce a minimum number of special characters that a password should contain. The valid range is 0-16. The default is 2. Minimum of 0 means no restriction on that set of characters.

Default	2
Format	<code>passwords strength minimum special-letters &lt;number&gt;</code>
Mode	Global Config

**no passwords strength minimum special-letters**

Use this command to reset the minimum number of special letters to the default value.

Format	<code>no passwords strength minimum special-letters</code>
Mode	Global Config

**passwords strength maximum consecutive-characters**

Use this command to enforce a maximum number of consecutive characters that a password should contain. An example of consecutive characters is abcd. The valid range is 0-16. If a password has consecutive characters more than the configured limit, it fails to configure. The default is 0. A maximum of 0 means no restriction on that set of characters.

Default	0
Format	<code>passwords strength maximum consecutive-characters &lt;number&gt;</code>
Mode	Global Config

**no passwords strength maximum consecutive-characters**

Use this command to reset the maximum number of consecutive characters to the default value.

Format	<code>no passwords strength maximum consecutive-characters</code>
Mode	Global Config

### passwords strength maximum repeated-characters

Use this command to enforce a maximum number of repeated characters that a password should contain. An example of repeated characters is aaaa. The valid range is 0-16. If a password has a repetition of characters more than the configured limit, it fails to configure. The default is 0. A maximum of 0 means no restriction on that set of characters.

Default	0
Format	<code>passwords strength maximum repeated-characters &lt;number&gt;</code>
Mode	Global Config

### no passwords strength maximum repeated-characters

Use this command to reset the maximum number of repeated-characters to the default value.

Format	<code>no passwords strength maximum repeated-characters</code>
Mode	Global Config

### passwords strength minimum character-classes

Use this command to enforce a minimum number of characters classes that a password should contain. Character classes are uppercase letters, lowercase letters, numeric characters, and special characters. The valid range is 0-4. The default is 4.

Default	4
Format	<code>passwords strength minimum character-classes &lt;number&gt;</code>
Mode	Global Config

### no passwords strength minimum character-classes

Use this command to reset the minimum number of character classes to the default value.

Format	<code>no passwords strength minimum character-classes</code>
Mode	Global Config

### passwords strength exclude-keyword

Use this command to exclude the specified keyword while configuring the password. The password does not accept the keyword in any form (in between the string, case insensitive and reverse) as a substring. User can configure up to a maximum of three keywords.

Format	<code>passwords strength exclude-keyword &lt;keyword&gt;</code>
Mode	Global Config

**no passwords strength exclude-keyword**

Use this command to reset the restriction for the specified keyword or all the keywords configured.

Format	<code>no passwords strength exclude-keyword [&lt;keyword&gt;]</code>
Mode	Global Config

**show passwords configuration**

Use this command to display the configured password management settings.

Format	<code>show passwords configuration</code>
Mode	Privileged EXEC

Term	Definition
Minimum Password Length	Minimum number of characters required when changing passwords.
Password History	Number of passwords to store for reuse prevention.
Password Aging	Length in days that a password is valid.
Lockout Attempts	Number of failed password login attempts before lockout.
Minimum Password Uppercase Letters	Minimum number of uppercase characters required when configuring passwords.
Minimum Password Lowercase Letters	Minimum number of lowercase characters required when configuring passwords.
Minimum Password Numeric Characters	Minimum number of numeric characters required when configuring passwords.
Maximum Password Consecutive Characters	Maximum number of consecutive characters required that the password should contain when configuring passwords.
Maximum Password Repeated Characters	Maximum number of repetitions of characters that the password should contain when configuring passwords.
Minimum Password Character Classes	Minimum number of character classes (uppercase, lowercase, numeric, and special) required when configuring passwords.
Password Exclude-Keywords	The set of keywords to be excluded from the configured password when strength checking is enabled.

## show passwords result

Use this command to display the last password set result information.

Format	show passwords result
Mode	Privileged EXEC

Term	Definition
Last User Whose Password Is Set	Shows the name of the user with the most recently set password.
Password Strength Check	Shows whether password strength checking is enabled.
Last Password Set Result	Shows whether the attempt to set a password was successful. If the attempt failed, the reason for the failure is included.

## aaa authentication login

Use this command to set authentication at login. The default and optional list names created with the command are used with the `aaa authentication login` command. Create a list by entering the `aaa authentication login list-name method` command, where **list-name** is any character string used to name this list. The **method** argument identifies the list of methods that the authentication algorithm tries in the sequence.

The additional methods of authentication are used only if the previous method returns an error, not if an authentication failure occurs. To ensure that the authentication succeeds even if all methods return an error, specify **none** as the final method in the command line. For example, if **none** is specified as an authentication method after **radius**, no authentication is used if the RADIUS server is down.

If you configure **local** as the first method in the list, the switch tries no other methods.

Default	<ul style="list-style-type: none"> <li>defaultList. Used by the console and only contains the method none.</li> <li>networkList. Used by telnet and SSH and only contains the method local.</li> </ul>
Format	aaa authentication login {default   <list-name>} <method1> [<method2>...]
Mode	Global Config

Parameter	Definition
default	Uses the listed authentication methods that follow this argument as the default list of methods when a user logs in.
<list-name>	Character string of up to 12 characters used to name the list of authentication methods activated when a user logs in.



Parameter	Definition
<code>&lt;method1&gt;</code> [ <code>&lt;method2&gt;...</code> ]	At least one from the following: <ul style="list-style-type: none"> <li>• <code>enable</code>. Uses the enable password for authentication.</li> <li>• <code>line</code>. Uses the line password for authentication.</li> <li>• <code>local</code>. Uses the local username database for authentication.</li> <li>• <code>none</code>. Uses no authentication.</li> <li>• <code>radius</code>. Uses the list of all RADIUS servers for authentication.</li> <li>• <code>tacacs</code>. Uses the list of all TACACS servers for authentication.</li> </ul>

**Command example:**

```
(NETGEAR Switch)(config)# aaa authentication login default radius local enable none
```

**no aaa authentication login**

Use this command to remove authentication at login.

Format	<code>no aaa authentication login {default   &lt;list-name&gt;}</code>
Mode	Global Config

**aaa authentication enable**

Use this command to set authentication for accessing higher privilege levels. The default and optional list names that you can create with this command are used with the **enable authentication** command.

Create a list by specifying the `<list-name>` argument, using any character string to name this list. The `<method>` arguments identify the list of methods that the authentication algorithm tries in the sequence. The additional methods of authentication are used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify **none** as the final method in the command line. For example, if **none** is specified as an authentication method after **radius**, no authentication is used if the RADIUS server is down. \

---

**Note:** Requests sent by the switch to a RADIUS or TACACS server include the username `$enablex$`, in which **x** is the requested privilege level.

---

Format	<code>aaa authentication enable {default   &lt;list-name&gt;} &lt;method1&gt;</code> [ <code>&lt;method2&gt;...</code> ]
Mode	Global Config

Parameter	Description
default	Uses the listed authentication methods that follow this argument as the default list of methods, when using higher privilege levels.
<list-name>	Character string used to name the list of authentication methods activated, when using access higher privilege levels. Range: 1-12 characters.
<method1> [<method2>...]	Specify at least one from the following: <ul style="list-style-type: none"> <li>deny. Used to deny access.</li> <li>enable. Uses the enable password for authentication.</li> <li>line. Uses the line password for authentication.</li> <li>none. Uses no authentication.</li> <li>radius. Uses the list of all RADIUS servers for authentication. Uses the user name \$enabx\$, in which x is the requested privilege level.</li> <li>tacacs. Uses the list of all TACACS+ servers for authentication. Uses the user name \$enabx\$, in which x is the requested privilege level.</li> </ul>

### no aaa authentication enable

Use this command to remove the authentication method.

Format	no aaa authentication enable {default   <list-name>} <method1> [<method2>...]
Mode	Global Config

### aaa authentication dot1x

Use this command to set authentication for dot1x users. The method argument identifies the list of methods that the authentication algorithm tries in the sequence. The additional methods of authentication are used only if the previous method returns an error, not if there is an authentication failure. To ensure that the authentication succeeds even if all methods return an error, specify **none** as the final method in the command line. For example if **none** is specified as an authentication method after **radius**, no authentication is used if the RADIUS server is down.

The possible methods are as follows:

- **ias**. Uses the internal authentication server users database for authentication. This method can be used in conjunction with any one of the existing methods such as **local** or **radius**.
- **local**. Uses the local user name database for authentication.
- **none**. Uses no authentication.
- **radius**. Uses the list of all RADIUS servers for authentication.

Format	aaa authentication dot1x default <method1> [<method2>...]
Mode	Global Config

## no aaa authentication dot1x

Use this command to remove the authentication at login.

Format	no aaa authentication dot1x default
Mode	Global Config

## aaa accounting

The command creates an accounting method list. This list is identified by the **default** keyword or by a user-specified *<list-name>*. Accounting records, when enabled for a line-mode, can be sent at both the beginning and at the end (**start-stop**) or only at the end (**stop-only**). If **none** is specified, accounting is disabled for the specified list. If **tacacs** is specified as the accounting method, accounting records are notified to a TACACS+ server. If **radius** is the specified accounting method, accounting records are notified to a RADIUS server.

For the same set of accounting type and list name, the administrator can change the record type or the methods list without having to first delete the previous configuration.

Note the following:

- A maximum of five accounting method lists can be created for each exec and commands type.
- The same list-name can be used for both exec and commands accounting type.
- AAA accounting for commands with RADIUS as the accounting method is not supported.

Format	aaa accounting {exec   commands} {default   <i>&lt;list-name&gt;</i> } {start-stop   stop-only   none} <i>&lt;method1&gt;</i> [ <i>&lt;method2&gt;</i> ...]
Mode	Global Config

Term	Definition
exec	Provides accounting for user EXEC terminal sessions.
commands	Provides accounting for all user-executed commands.
default	The default list of methods for accounting services.
<i>&lt;list-name&gt;</i>	Character string used to name the list of accounting methods.
start-stop	Sends a start accounting notice at the beginning of a process and a stop accounting notice at the end of a process.
stop-only	Sends a stop accounting notice at the end of the requested user process.
none	Disables accounting services on this line.
<i>&lt;method1&gt;</i> [ <i>&lt;method2&gt;</i> ...]	Use either <b>tacacs</b> or <b>radius</b> for accounting purpose.

### no aaa accounting

This command deletes the accounting method list.

Format	no aaa accounting {exec   commands} {default   <list-name>}
Mode	Global Config

### accounting (console/Telnet/SSH)

This command applies the accounting method list to a line configuration (console/Telnet/SSH). Apply this command in Line Config mode.

Format	accounting {exec   commands} [default   <list-name>]
Mode	Line Config

Term	Definition
exec	Configures accounting for an EXEC session.
commands	Configures accounting for each command execution attempt. <b>Note:</b> If a user is enabling accounting for exec mode for the current type of line configuration, they are logged out.
default	The default list of methods for authorization services.
<list-name>	Alphanumeric character string used to name the list of authorization methods.

### no accounting (console/Telnet/SSH)

This command is used to remove accounting from a line configuration mode.

Format	no accounting {exec   commands}
Mode	Line Config

### ip accounting exec

This command applies user exec accounting list to the line methods HTTP and HTTPs methods.

Format	ip {http   https} accounting exec {default   <list-name>}
Mode	Global Config

Term	Definition
{http   https}	Line method for which the list needs to be applied.

Term	Definition
default	The default list of methods for authorization services.
<list-name>	Alphanumeric character string used to name the list of authorization methods.

### no ip http/https accounting exec

This command deletes the authorization method list.

Format	no ip {http   https} accounting exec {default   <list-name>}
Mode	Global Config

### show accounting

Use this command to display ordered methods for accounting lists.

Format	show accounting
Mode	Privileged EXEC

#### Command example:

```
(NETGEAR Switch) #show accounting
Number of Accounting Notifications sent at beginning of an EXEC session:
Errors when sending Accounting Notifications beginning of an EXEC session:
Number of Accounting Notifications at end of an EXEC session:
Errors when sending Accounting Notifications at end of an EXEC session:
Number of Accounting Notifications sent at beginning of a command execution:
Errors when sending Accounting Notifications at beginning of a command execution:
Number of Accounting Notifications sent at end of a command execution:
Errors when sending Accounting Notifications at end of a command execution:
```

### show accounting methods

This command displays the configured accounting method lists.

Format	show accounting methods
Mode	Privileged EXEC

#### Command example:

```
(NETGEAR Switch) #show accounting methods
```

Acct Type	Method Name	Record Type	Method Type
-----	-----	-----	-----
Exec	dfltExecList	start-stop	TACACS
Commands	dfltCmdsList	stop-only	TACACS

Commands	UserCmdAudit	start-stop	TACACS
Line	EXEC Method List	Command Method List	
-----	-----	-----	
Console	none	none	
Telnet	none	none	
SSH	none	none	
HTTPS	none	none	
HTTP	none	none	

### aaa authorization

The command creates an authorization method list. This list is identified by the **default** keyword or by a user-specified *<list-name>*. If **tacacs** is specified as the authorization method, authorization commands are notified to a TACACS+ server. If **radius** is the specified authorization method, authorization commands are notified to a RADIUS server. If **none** is specified, command authorization is not applicable. You can create up to five authorization method lists for the **commands** type.

---

**Note:** The local method is not supported for command authorization. Command authorization with RADIUS works only if the applied authentication method is also RADIUS.

---

Format	aaa authorization {exec   commands} {default   <i>&lt;list-name&gt;</i> } <i>&lt;method1&gt;</i> [ <i>&lt;method2&gt;</i> ...]
Mode	Global Config

Term	Definition
exec	Provides authorization for user EXEC terminal sessions.
commands	Provides authorization for all user-executed commands.
default	The default list of methods for authorization services.
<i>&lt;list-name&gt;</i>	Character string used to name the list of authorization methods.
<i>&lt;method1&gt;</i> [ <i>&lt;method2&gt;</i> ...]	Use either <b>tacacs</b> or <b>radius</b> for authorization purpose.

**no aaa authorization**

This command deletes the authorization method list.

Format	no aaa authorization {exec   commands} {default   <list-name>} <method1> [<method2>...]
Mode	Global Config

**authorization (console/Telnet/SSH)**

To apply the command authorization method list to an access method (console/Telnet/SSH). Apply this command in the line configuration mode.

Format	authorization {commands   exec} {default   <list-name>}
Mode	<ul style="list-style-type: none"> <li>• Line console</li> <li>• Line telnet</li> <li>• Line SSH</li> </ul>

**no authorization (console/Telnet/SSH)**

This command is used to remove command authorization from a line configuration mode.

Format	no authorization {commands  exec}
Mode	<ul style="list-style-type: none"> <li>• Line console</li> <li>• Line telnet</li> <li>• Line SSH</li> </ul>

**show authorization methods**

This command displays the configured authorization method lists.

Format	show authorization methods
Mode	Privileged EXEC

**Command example:**

```
(NETGEAR Switch) #show authorization methods
```

```
Command Authorization List          Method
-----
dfltCmdAuthList                    none          undefined    undefined    undefined
```

```
Line          Command Method List
-----
Console      dfltCmdAuthList
Telnet       dfltCmdAuthList
SSH          dfltCmdAuthList
```

```

Exec Authorization List          Method
-----
dfltExecAuthList                none          undefined   undefined   undefined

```

```

Line          Exec Method List
-----
Console      dfltExecAuthList
Telnet       dfltExecAuthList
SSH          dfltExecAuthList

```

## domain-name (Global Config)

The managed switch supports authentication based on domain name, in addition to the user name and password. This command allows the switch to be configured in a domain. Users can enable or disable domain functionality:

- **Domain enabled.** In this case, when the user enters only the user name, the managed switch sends the domain name that is configured on the switch and the user name that the user enters in the format "domainname\username" to the RADIUS server. If the user enters the domain name and user name, the managed switch sends the domain name and user name that the user enters in the format "domainname\username" to the RADIUS server.
- **Domain disabled.** In this case, the domain name is not included when the user name is sent to the RADIUS server.

Format	domain-name <name>
Mode	Global Config

## no domain-name

This command is used to disable the domain-name in the managed switch.

Format	no domain-name
Mode	Global Config

## domain-name enable (Global Config)

This command enables the domain name functionality.

Format	domain-name enable
Mode	Global Config



**no domain-name enable**

This command disables the domain name functionality.

Format	no domain-name enable
Mode	Global Config

**show domain-name**

This command displays the configured domain-name.

Format	show domain-name
Mode	Privileged EXEC

**Command example:**

```
(NETGEAR Switch) #show domain-name
Domain           : Enable
Domain-name      : abc
```

**aaa ias-user username**

The Internal Authentication Server (IAS) database is a dedicated internal database used for local authentication of users for network access through the IEEE 802.1X feature. Use this command to add the specified user to the internal user database. This command also changes the mode to AAA User Config mode.

Format	aaa ias-username <user>
Mode	Global Config

**no aaa ias-user username**

Use this command to remove an ias user.

Format	no aaa ias-username <user>
Mode	Global Config

**aaa session-id**

This global **aaa** command specifies whether the same session ID is used for authentication, authorization, and accounting service type within a session.s

Default	common
Format	aaa session-id [common   unique]
Mode	Global Config

Parameter	Definition
common	Use the same session ID for all AAA Service types.
unique	Use a unique session ID for AAA Service types.

### no aaa session-id

This command resets the AAA session ID behavior to default.

Format	no aaa session-id [unique]
Mode	Global Config

### password (AAA IAS User Configuration)

Use this command to specify a password for a user in the IAS database.

Format	password <password> [encrypted]
Mode	AAA IAS User Config

Parameter	Definition
<password>	Password for this level. Range: 8-64 characters.
encrypted	Encrypted password to be entered, copied from another switch configuration.

### no password (AAA IAS User Configuration)

Use this command to remove a password for a user in the IAS database.

Format	no password
Mode	AAA IAS User Config

### clear aaa ias-users

Use this command to remove all users from the IAS database.

Format	clear aaa ias-users
Mode	Privileged EXEC

## show aaa ias-users

Use this command to display configured IAS users and their attributes. Passwords configured are not shown in the show command output.

Format	show aaa ias-users
Mode	Privileged EXEC

## SNMP Commands

This section describes the commands you use to configure Simple Network Management Protocol (SNMP) on the switch. You can configure the switch to act as an SNMP agent so that it can communicate with SNMP managers on your network.

### snmp-server

Use this command to set the name and the physical location of the switch and the organization responsible for the network. The range for *<name>*, *<loc>* and *<con>* is from 1 to 31 alphanumeric characters.

Default	none
Format	snmp-server {sysname <i>&lt;name&gt;</i>   location <i>&lt;loc&gt;</i>   contact <i>&lt;con&gt;</i> }
Mode	Global Config

### snmp-server community

Use this command to add (and name) a new SNMP community. A community *<name>* is a name associated with the switch and with a set of SNMP managers that manage it with a specified privileged level. The length of *<name>* can be up to 16 case-sensitive characters.

---

**Note:** Community names in the SNMP community table must be unique. When making multiple entries using the same community name, the first entry is kept and processed and all duplicate entries are ignored.

---

Default	<ul style="list-style-type: none"> <li>Public and private, which you can rename.</li> <li>Default values for the remaining four community names are blank.</li> </ul>
Format	snmp-server community <i>&lt;name&gt;</i>
Mode	Global Config

**no snmp-server community**

Use this command to remove this community name from the table. The *<name>* is the community name to be deleted.

Format	<code>no snmp-server community &lt;name&gt;</code>
Mode	Global Config

**snmp-server community ipaddr**

Use this command to set a client IP address for an SNMP community. The address is the associated community SNMP packet sending address and is used along with the client IP mask value to denote a range of IP addresses from which SNMP clients might use that community to access the device. A value of 0.0.0.0 allows access from any IP address. Otherwise, this value is ANDed with the mask to determine the range of allowed client IP addresses. The name is the applicable community name.

Default	0.0.0.0
Format	<code>snmp-server community ipaddr &lt;ipaddr&gt; &lt;name&gt;</code>
Mode	Global Config

**no snmp-server community ipaddr**

Use this command to set a client IP address for an SNMP community to 0.0.0.0. The name is the applicable community name.

Format	<code>no snmp-server community ipaddr &lt;name&gt;</code>
Mode	Global Config

**snmp-server community ipmask**

Use this command to set a client IP mask for an SNMP community. The address is the associated community SNMP packet sending address and is used along with the client IP address value to denote a range of IP addresses from which SNMP clients might use that community to access the device. A value of 255.255.255.255 allows access from only one station and uses that machine's IP address for the client IP address. A value of 0.0.0.0 allows access from any IP address. The name is the applicable community name.

Default	0.0.0.0
Format	<code>snmp-server community ipmask &lt;ipmask&gt; &lt;name&gt;</code>
Mode	Global Config

**no snmp-server community ipmask**

Use this command to set a client IP mask for an SNMP community to 0.0.0.0. The name is the applicable community name. The community name might be up to 16 alphanumeric characters.

Format	<code>no snmp-server community ipmask &lt;name&gt;</code>
Mode	Global Config

**snmp-server community mode**

Use this command to activate an SNMP community. If a community is enabled, an SNMP manager associated with this community manages the switch according to its access right. If the community is disabled, no SNMP requests using this community are accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable.

Default	<ul style="list-style-type: none"> <li>• private and public communities - enabled</li> <li>• other four - disabled</li> </ul>
Format	<code>snmp-server community mode &lt;name&gt;</code>
Mode	Global Config

**no snmp-server community mode**

Use this command to deactivate an SNMP community. If the community is disabled, no SNMP requests using this community are accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable.

Format	<code>no snmp-server community mode &lt;name&gt;</code>
Mode	Global Config

**snmp-server community ro**

Use this command to restrict access to switch information. The access mode is read-only (also called public).

Format	<code>snmp-server community ro &lt;name&gt;</code>
Mode	Global Config

### snmp-server community rw

Use this command to restrict access to switch information. The access mode is read/write (also called private).

Format	<code>snmp-server community rw &lt;name&gt;</code>
Mode	Global Config

### snmp-server enable traps violation

Use this command to enable sending new violation traps designating when a packet with a disallowed MAC address is received on a locked port.

---

**Note:** For other port security commands, see *Protected Ports Commands* on page 68.

---

Default	disabled
Format	<code>snmp-server enable traps violation</code>
Mode	Interface Config

### no snmp-server enable traps violation

Use this command to disable sending new violation traps.

Format	<code>no snmp-server enable traps violation</code>
Mode	Interface Config

### snmp-server enable traps

Use this command to enable the Authentication Flag.

Default	enabled
Format	<code>snmp-server enable traps</code>
Mode	Global Config

### no snmp-server enable traps

Use this command to disable the Authentication Flag.

Format	<code>no snmp-server enable traps</code>
Mode	Global Config

**snmp-server enable traps linkmode**

Use this command to enable Link Up/Down traps for the entire switch. When enabled, link traps are sent only if the Link Trap flag setting associated with the port is enabled. For more information, see *snmp trap link-status* on page 498.

Default	enabled
Format	snmp-server enable traps linkmode
Mode	Global Config

**no snmp-server enable traps linkmode**

Use this command to disable Link Up/Down traps for the entire switch.

Format	no snmp-server enable traps linkmode
Mode	Global Config

**snmp-server enable traps multiusers**

Use this command to enable Multiple User traps. When the traps are enabled, a Multiple User Trap is sent when a user logs in to the terminal interface (EIA 232 or Telnet) and there is an existing terminal interface session.

Default	enabled
Format	snmp-server enable traps multiusers
Mode	Global Config

**no snmp-server enable traps multiusers**

Use this command to disable Multiple User traps.

Format	no snmp-server enable traps multiusers
Mode	Global Config

**snmp-server enable traps stpmode**

Use this command to enable sending new root traps and topology change notification traps.

Default	enabled
Format	snmp-server enable traps stpmode
Mode	Global Config

### no snmp-server enable traps stpmode

Use this command to disable sending new root traps and topology change notification traps.

Format	no snmp-server enable traps stpmode
Mode	Global Config

### snmptrap

Use this command to add an SNMP trap receiver. The maximum length of *<name>* is 16 case-sensitive alphanumeric characters. The *<snmpversion>* is the version of SNMP. The version parameter options are SNMPv1 or SNMPv2. The SNMP trap address can be set using both an IPv4 address format as well as an IPv6 global address format.

The *<name>* parameter does not need to be unique. However, the combination of the name and IP address or host name must be unique. Multiple entries can exist with the same *<name>* parameter, as long as they are associated with a different IP address or host name. The reverse scenario is also acceptable. The *<name>* parameter is the community name that is used when the trap is sent to the receiver, but the *<name>* parameter is not directly associated with the SNMP Community Table (see *snmp-server community* on page 491).

Default	snmpv2
Format	snmptrap <i>&lt;name&gt;</i> {ipaddr { <i>&lt;ipaddr&gt;</i>   <i>&lt;hostname&gt;</i>   ip6addr { <i>&lt;ip6addr&gt;</i>   <i>&lt;hostname&gt;</i> } [snmpversion <i>&lt;snmpversion&gt;</i> ]
Mode	Global Config

#### Command example:

```
(Netgear Switch)# snmptrap mytrap ip6addr 3099::2
```

### no snmptrap

Use this command to delete trap receivers for a community.

Format	no snmptrap <i>&lt;name&gt;</i> {ipaddr { <i>&lt;ipaddr&gt;</i>   <i>&lt;hostname&gt;</i>   ip6addr { <i>&lt;ip6addr&gt;</i>   <i>&lt;hostname&gt;</i> }
Mode	Global Config

### snmptrap snmpversion

Use this command to modify the SNMP version of a trap. The maximum length of *<name>* is 16 case-sensitive alphanumeric characters. The *<snmpversion>* parameter options are snmpv1 or snmpv2.



---

**Note:** This command does not support a `no` form.

---

Default	snmpv2
Format	snmptrap snmpversion <name> {<ipaddr>   <hostname>}   {<ip6addr>   <hostname>} {snmpv1   snmpv2}
Mode	Global Config

### snmptrap ipaddr

Use this command to assign an IP address to a specified community name. The name can use up to 16 case-sensitive alphanumeric characters.

---

**Note:** IP addresses in the SNMP trap receiver table must be unique. If you make multiple entries using the same IP address, the first entry is retained and processed. All duplicate entries are ignored.

---

Format	snmptrap ipaddr <name> <ipaddrold> {<ipaddrnew   hostnamenew>}
Mode	Global Config

### snmptrap mode

Use this command to activate or deactivate an SNMP trap. Enabled trap receivers are active (able to receive traps). Disabled trap receivers are inactive (not able to receive traps).

Format	snmptrap mode <name> {<ipaddr>   <ip6addr>   <hostname>}
Mode	Global Config

### no snmptrap mode

Use this command to deactivate an SNMP trap. Disabled trap receivers are unable to receive traps.

Format	no snmptrap mode <name> {<ipaddr>   <ip6addr>   <hostname>}
Mode	Global Config

## snmp trap link-status

Use this command to enable link status traps by interface.

---

**Note:** This command is valid only when the Link Up/Down Flag is enabled. For more information, see *snmp-server enable traps linkmode* on page 495.

---

Format	snmp trap link-status
Mode	Interface Config

## no snmp trap link-status

Use this command to disable link status traps by interface.

---

**Note:** This command is valid only when the Link Up/Down Flag is enabled.

---

Format	no snmp trap link-status
Mode	Interface Config

## snmp trap link-status all

Use this command to enable link status traps for all interfaces.

---

**Note:** This command is valid only when the Link Up/Down Flag is enabled. For more information, see *snmp-server enable traps linkmode* on page 495.

---

Format	snmp trap link-status all
Mode	Global Config

## no snmp trap link-status all

Use this command to disable link status traps for all interfaces.

---

**Note:** This command is valid only when the Link Up/Down Flag is enabled. For more information, see *snmp-server enable traps linkmode* on page 495.

---

Format	<code>no snmp trap link-status all</code>
Mode	Global Config

### show snmpcommunity

Use this command to display SNMP community information. Six communities are supported. You can add, change, or delete communities. The switch does not need to be reset for changes to take effect.

The SNMP agent of the switch complies with SNMP versions 1, 2 or 3. For more information about the SNMP specification, see the SNMP RFCs. The SNMP agent sends traps through TCP/IP to an external SNMP manager based on the SNMP configuration (the trap receiver and other SNMP community parameters).

Format	<code>show snmpcommunity</code>
Mode	Privileged EXEC

Field	Definition
SNMP Community Name	The community string to which this entry grants access. A valid entry is a case-sensitive alphanumeric string of up to 16 characters. Each row of this table must contain a unique community name.
Client IP Address	An IP address (or portion thereof) from which this device will accept SNMP packets with the associated community. The requesting entity's IP address is ANDed with the Subnet Mask before being compared to the IP address. Note: If the Subnet Mask is set to 0.0.0.0, an IP address of 0.0.0.0 matches all IP addresses. The default value is 0.0.0.0.
Client IP Mask	A mask to be ANDed with the requesting entity's IP address before comparison with IP address. If the result matches with IP address then the address is an authenticated IP address. For example, if the IP address = 9.47.128.0 and the corresponding Subnet Mask = 255.255.255.0 a range of incoming IP addresses would match, i.e. the incoming IP address could equal 9.47.128.0 - 9.47.128.255. The default value is 0.0.0.0.
Access Mode	The access level for this community string.
Status	The status of this community access entry.

### show snmptrap

Use this command to display SNMP trap receivers. Trap messages are sent across a network to an SNMP network manager. These messages alert the manager to events occurring within the switch or on the network. Six trap receivers are simultaneously supported.

Format	<code>show snmptrap</code>
Mode	Privileged EXEC

Field	Definition
SNMP Trap Name	The community string of the SNMP trap packet sent to the trap manager. The string is case-sensitive and can be up to 16 alphanumeric characters.
IP Address	The IPv4 address to receive SNMP traps from this device.
IPv6 Address	The IPv6 address to receive SNMP traps from this device.
SNMP Version	SNMPv2
Status	The receiver's status (enabled or disabled).

**Command example:**

```
(Netgear Switch)#show snmptrap
```

```
Community Name   IpAddress      IPv6 Address    Snmp Version    Mode
Mytrap           0.0.0.0       2001:::1       SNMPv2          Enable show trapflags
```

**show trapflags**

Use this command to display trap conditions. The command's display shows all the enabled OSPFv2 and OSPFv3 trap flags. Configure which traps the switch should generate by enabling or disabling the trap condition. If a trap condition is enabled and the condition is detected, the SNMP agent on the switch sends the trap to all enabled trap receivers. You do not have to reset the switch to implement the changes. Cold and warm start traps are always generated and cannot be disabled.

Format	show trapflags
Mode	Privileged EXEC

Field	Definition
Authentication Flag	Can be enabled or disabled. The factory default is enabled. Indicates whether authentication failure traps will be sent.
Link Up/Down Flag	Can be enabled or disabled. The factory default is enabled. Indicates whether link status traps will be sent.
Multiple Users Flag	Can be enabled or disabled. The factory default is enabled. Indicates whether a trap will be sent when the same user ID is logged into the switch more than once at the same time (either through Telnet or the serial port).
Spanning Tree Flag	Can be enabled or disabled. The factory default is enabled. Indicates whether spanning tree traps are sent.
ACL Traps	Might be enabled or disabled. The factory default is disabled. Indicates whether ACL traps are sent.
DVMRP Traps	Can be enabled or disabled. The factory default is disabled. Indicates whether DVMRP traps are sent.

Field	Definition
OSPFv2 Traps	Can be enabled or disabled. The factory default is disabled. Indicates whether OSPF traps are sent. If any of the OSPF trap flags are not enabled, the command displays <code>disabled</code> . Otherwise, the command shows all the enabled OSPF traps' information.
OSPFv3 Traps	Can be enabled or disabled. The factory default is disabled. Indicates whether OSPF traps are sent. If any of the OSPFv3 trap flags are not enabled, the command displays <code>disabled</code> . Otherwise, the command shows all the enabled OSPFv3 traps' information.
PIM Traps	Can be enabled or disabled. The factory default is disabled. Indicates whether PIM traps are sent.

## RADIUS Commands

This section describes the commands you use to configure the switch to use a Remote Authentication Dial-In User Service (RADIUS) server on your network for authentication and accounting.

### authorization network radius

Use this command to enable the switch to accept VLAN assignment by the radius server.

Default	<code>disable</code>
Format	<code>authorization network radius</code>
Mode	Global Config

### no authorization network radius

Use this command to disable the switch to accept VLAN assignment by the radius server.

Format	<code>no authorization network radius</code>
Mode	Global Config

### radius accounting mode

Use this command to enable the RADIUS accounting function.

Default	<code>disabled</code>
Format	<code>radius accounting mode</code>
Mode	Global Config

### no radius accounting mode

Use this command to set the RADIUS accounting function to the default value (disabled).

Format	no radius accounting mode
Mode	Global Config

### radius server attribute

Use this command to specify the RADIUS client to use the NAS-IP Address attribute in the RADIUS requests. If the specific IP address is configured while enabling this attribute, the RADIUS client uses that IP address while sending NAS-IP-Address attribute in RADIUS communication.

Format	radius server attribute 4 [<ipaddr>]
Mode	Global Config

Parameter	Definition
4	NAS-IP-Address attribute to be used in RADIUS requests.
<i>ipaddr</i>	The IP address of the server.

### no radius server attribute

Use this command to disable the NAS-IP-Address attribute global parameter for RADIUS client. When this parameter is disabled, the RADIUS client does not send the NAS-IP-Address attribute in RADIUS requests.

Format	no radius server attribute 4 [<ipaddr>]
Mode	Global Config

#### Command example:

```
(NETGEAR Switch) (Config) #radius server attribute 4 192.168.37.60
```

#### Command example:

```
(NETGEAR Switch) (Config) #radius server attribute 4
```

### radius server host

This command configures the IP address or DNS name to use for communicating with the RADIUS server of a selected server type. While configuring the IP address or DNS name for the authenticating or accounting servers, you can also configure the port number and server name. If the authenticating and accounting servers are configured without a name, the command uses the Default\_RADIUS\_Auth\_Server and Default\_RADIUS\_Acct\_Server as the

default names, respectively. The same name can be configured for more than one authenticating servers and the name should be unique for accounting servers. The RADIUS client allows the configuration of a maximum 32 authenticating and accounting servers.

If you use the **auth** parameter, the command configures the IP address or host name to use to connect to a RADIUS authentication server. You can configure up to three servers per RADIUS client. If the maximum number of configured servers is reached, the command fails until you remove one of the servers by issuing the **no** form of the command. If you use the optional **port** parameter, the command configures the UDP port number to use when connecting to the configured RADIUS server. For the **port** keyword, the *<number>* argument must be a value in the range 0–65535, with 1813 being the default.

---

**Note:** To reconfigure a RADIUS authentication server to use the default UDP port, set the *<number>* argument to 1812.

---

If you use the **acct** token, the command configures the IP address or host name to use for the RADIUS accounting server. You can only configure one accounting server. If an accounting server is currently configured, use the **no** form of the command to remove it from the configuration. The IP address or host name you specify must match that of a previously configured accounting server. If you use the optional **port** parameter, the command configures the UDP port to use when connecting to the RADIUS accounting server. If a port is already configured for the accounting server, the new port replaces the previously configured port. For the **port** keyword, the *<number>* argument must be a value in the range 0–65535, with 1813 being the default.

---

**Note:** To reconfigure a RADIUS accounting server to use the default UDP port, set the *<number>* argument to 1813.

---

Format	radius server host {auth   acct} {<ipaddr>   <dnsname>} [name <servername>] [port <number>] [type <server-type>]
Mode	Global Config

Parameter	Description
<ipaddr>	The IP address of the server.
<dnsname>	The DNS name of the server.
<servername>	The alias name to identify the server.
<number>	The port number in the range 0–65535 to use to connect to the specified RADIUS server.
<server-type>	Enter one of the following options: <ul style="list-style-type: none"> <li>0. Specifies a standard server.</li> <li>1. Specifies a NETGEAR server.</li> </ul>

### no radius server host

Use this command to delete the configured server entry from the list of configured RADIUS servers. If the RADIUS authenticating server being removed is the active server in the servers that are identified by the same server name, then the RADIUS client selects another server for making RADIUS transactions. If you use the **auth** parameter, the previously configured RADIUS authentication server is removed from the configuration. Similarly, If you use the **acct** parameter, the previously configured RADIUS accounting server is removed from the configuration. The *<ipaddr>* or *<dnsname>* parameter must match the IP address or DSN name of the previously configured RADIUS authentication or accounting server.

Format	no radius server host {auth   acct} {<ipaddr>   <dnsname>}
Mode	Global Config

#### Command example:

```
(NETGEAR Switch) (Config) #radius server host acct 192.168.37.60
(NETGEAR Switch) (Config) #radius server host acct 192.168.37.60 port 1813
(NETGEAR Switch) (Config) #radius server host auth 192.168.37.60 name
Network1_RADIUS_Auth_Server port 1813
(NETGEAR Switch) (Config) #radius server host acct 192.168.37.60 name
Network2_RADIUS_Auth_Server
(NETGEAR Switch) (Config) #no radius server host acct 192.168.37.60
```

### radius server key

Use this command to configure the key to be used in RADIUS client communication with the specified server. Depending on whether the **auth** or **acct** keyword is used, the shared secret is configured for the RADIUS authentication or RADIUS accounting server. The IP address or host name provided must match a previously configured server. When this command is executed, the secret is prompted.

Text-based configuration supports RADIUS server's secrets in encrypted and non-encrypted format. When you save the configuration, these secret keys are stored in encrypted format only. If you want to enter the key in encrypted format, enter the key along with the encrypted keyword. In the output of the **show running config** command, these secret keys are displayed in encrypted format. You cannot show these keys in plain text format.

---

**Note:** The secret must be an alphanumeric value not exceeding 16 characters.

---

Format	radius server key {auth   acct} {<ipaddr>   <dnsname>} encrypted <password>
Mode	Global Config



Parameter	Description
<ipaddr>	The IP address of the server.
<dnsname>	The DNS name of the server.
<password>	The password in encrypted format.

**Command example:**

```
radius server key acct 10.240.4.10 encrypted <encrypt-string>
```

**radius server msgauth**

Use this command to enable the message authenticator attribute to be used for the specified RADIUS Authenticating server.

Format	radius server msgauth {<ipaddr>   <dnsname>}
Mode	Global Config

Parameter	Description
<ipaddr>	The IP address of the server.
<dnsname>	The DNS name of the server.

**no radius server msgauth**

Use this command to disable the message authenticator attribute to be used for the specified RADIUS Authenticating server.

Format	no radius server msgauth {<ipaddr>   <dnsname>}
Mode	Global Config

**radius server primary**

Use this command to designate a configured server as the primary server in the group of servers that have the same server name. Multiple primary servers can be configured for each number of servers that have the same name. When the RADIUS client must perform transactions with an authenticating RADIUS server of specified name, the client uses the primary server that has the specified server name by default. If the RADIUS client fails to communicate with the primary server for any reason, the client uses the backup servers configured with the same server name. These backup servers are identified as the secondary type.

Format	radius server primary {<ipaddr>   <dnsname>}
Mode	Global Config

Parameter	Description
<code>&lt;ipaddr&gt;</code>	The IP address of the RADIUS Authenticating server.
<code>&lt;dnsname&gt;</code>	The DNS name of the server.

### radius server retransmit

Use this command to configure the global parameter for the RADIUS client that specifies the number of transmissions of the messages to be made before attempting the fall back server upon unsuccessful communication with the current RADIUS authenticating server. When the maximum number of retries are exhausted for the RADIUS accounting server and no response is received, the client does not communicate with any other server.

Default	4
Format	<code>radius server retransmit &lt;retries&gt;</code>
Mode	Global Config

Parameter	Description
<code>&lt;retries&gt;</code>	The maximum number of transmission attempts in the range of 1–15.

### no radius server retransmit

Use this command to set the value of this global parameter to the default value.

Format	<code>no radius server retransmit</code>
Mode	Global Config

### radius server timeout

Use this command to configure the global parameter for the RADIUS client that specifies the time-out value (in seconds) after which a request must be retransmitted to the RADIUS server if no response is received. The time-out value is an integer in the range of 1–30 seconds.

Default	5
Format	<code>radius server timeout &lt;seconds&gt;</code>
Mode	Global Config

**no radius server timeout**

Use this command to set the timeout global parameter to the default value.

Format	no radius server timeout
Mode	Global Config

**show radius**

Use this command to display the values configured for the global parameters of the RADIUS client.

Format	show radius
Mode	Privileged EXEC

Field	Definition
Number of Configured Authentication Servers	The number of RADIUS Authentication servers that have been configured.
Number of Configured Accounting Servers	The number of RADIUS Accounting servers that have been configured.
Number of Named Authentication Server Groups	The number of configured named RADIUS server groups.
Number of Named Accounting Server Groups	The number of configured named RADIUS server groups.
Number of Retransmits	The configured value of the maximum number of times a request packet is retransmitted.
Time Duration	The configured timeout value, in seconds, for request retransmissions.
RADIUS Accounting Mode	A global parameter to indicate whether the accounting mode for all the servers is enabled or not.
RADIUS Attribute 4 Mode	A global parameter to indicate whether the NAS-IP-Address attribute has been enabled to use in RADIUS requests.
RADIUS Attribute 4 Value	A global parameter that specifies the IP address to be used in the NAS-IP-Address attribute to be used in RADIUS requests.

**Command example:**

```
(NETGEAR Switch)#show radius
```

```
Number of Configured Authentication Servers..... 32
Number of Configured Accounting Servers..... 32
Number of Named Authentication Server Groups..... 15
Number of Named Accounting Server Groups..... 3
Number of Retransmits..... 4
```

```

Time Duration..... 10
RADIUS Accounting Mode..... Disable
RADIUS Attribute 4 Mode..... Enable
RADIUS Attribute 4 Value ..... 192.168.37.60
    
```

### show radius servers

Use this command to display the summary and details of RADIUS authenticating servers configured for the RADIUS client.

Format	show radius servers [<ipaddr>   <dnsname>   name [<servername>]]
Mode	Privileged EXEC

Field	Description
Current	The '*' symbol preceding the server host address specifies that the server is currently active.
Host Address	The IP address of the host.
Server Name	The name of the authenticating server.
Port	The port used for communication with the authenticating server.
Type	Specifies whether this server is a primary or secondary type.
Current Host Address	The IP address of the currently active authenticating server.
Secret Configured	Yes or No Boolean value that indicates whether this server is configured with a secret.
Number of Retransmits	The configured value of the maximum number of times a request packet is retransmitted.
Message Authenticator	A global parameter to indicate whether the Message Authenticator attribute is enabled or disabled.
Time Duration	The configured timeout value, in seconds, for request retransmissions.
RADIUS Accounting Mode	A global parameter to indicate whether the accounting mode for all the servers is enabled or not.
RADIUS Attribute 4 Mode	A global parameter to indicate whether the NAS-IP-Address attribute has been enabled to use in RADIUS requests.
RADIUS Attribute 4 Value	A global parameter that specifies the IP address to be used in NAS-IP-Address attribute used in RADIUS requests.

**Command example:**

(NETGEAR Switch) #show radius servers

Cur	Host Address	Server Name	Port	Type
rent				
*	192.168.37.200	Network1_RADIUS_Server	1813	Primary
	192.168.37.201	Network2_RADIUS_Server	1813	Secondary
	192.168.37.202	Network3_RADIUS_Server	1813	Primary
	192.168.37.203	Network4_RADIUS_Server	1813	Secondary

**Command example:**

(NETGEAR Switch) #show radius servers name

Current Host Address	Server Name	Type
		-----192.168.37.200
Network1_RADIUS_Server	Secondary	
192.168.37.201	Network2_RADIUS_Server	Primary
192.168.37.202	Network3_RADIUS_Server	Secondary
192.168.37.203	Network4_RADIUS_Server	Primary

**Command example:**

(NETGEAR Switch) #show radius servers name Default\_RADIUS\_Server

```

Server Name..... Default_RADIUS_Server
Host Address..... 192.168.37.58
Secret Configured..... No
Message Authenticator ..... Enable
Number of Retransmits..... 4
Time Duration..... 10
RADIUS Accounting Mode..... Disable
RADIUS Attribute 4 Mode..... Enable
RADIUS Attribute 4 Value ..... 192.168.37.60
    
```

**Command example:**

(NETGEAR Switch) #show radius servers 192.168.37.58

```

Server Name..... Default_RADIUS_Server
Host Address..... 192.168.37.58
Secret Configured..... No
Message Authenticator ..... Enable
Number of Retransmits..... 4
Time Duration..... 10
RADIUS Accounting Mode..... Disable
RADIUS Attribute 4 Mode..... Enable
    
```

RADIUS Attribute 4 Value ..... 192.168.37.60

## show radius accounting

Use this command to display a summary of configured RADIUS accounting servers.

Format	show radius accounting name [<servername>]
Mode	Privileged EXEC

Field	Description
RADIUS Accounting Mode	A global parameter to indicate whether the accounting mode for all the servers is enabled or not.

If you do not specify any parameters, only the accounting mode and the RADIUS accounting server details are displayed.

Field	Definition
Host Address	The IP address of the host.
Server Name	The name of the accounting server.
Port	The port used for communication with the accounting server.
Secret Configured	Yes or No Boolean value indicating whether this server is configured with a secret.

### Command example:

```
(NETGEAR Switch) #show radius accounting name
```

```
Host Address          Server Name          Port      Secret
                   Configured
-----
192.168.37.200       Network1_RADIUS_Server  1813     Yes
192.168.37.201       Network2_RADIUS_Server  1813     No
192.168.37.202       Network3_RADIUS_Server  1813     Yes
192.168.37.203       Network4_RADIUS_Server  1813     No
```

### Command example:

```
(NETGEAR Switch) #show radius accounting name Default_RADIUS_Server
```

```
Server Name..... Default_RADIUS_Server
Host Address..... 192.168.37.200
RADIUS Accounting Mode..... Disable
Port ..... 1813
Secret Configured ..... Yes
```

## show radius accounting statistics

Use this command to display a summary of statistics for the configured RADIUS accounting servers.

Format	show radius accounting statistics {<ipaddr>   <dnsname>   name <servername>}
Mode	Privileged EXEC

Field	Definition
RADIUS Accounting Server Name	The name of the accounting server.
Server Host Address	The IP address of the host.
Round Trip Time	The time interval, in hundredths of a second, between the most recent Accounting-Response and the Accounting-Request that matched it from this RADIUS accounting server.
Requests	The number of RADIUS Accounting-Request packets sent to this server. This number does not include retransmissions.
Retransmission	The number of RADIUS Accounting-Request packets retransmitted to this RADIUS accounting server.
Responses	The number of RADIUS packets received on the accounting port from this server.
Malformed Responses	The number of malformed RADIUS Accounting-Response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators or signature attributes or unknown types are not included as malformed accounting responses.
Bad Authenticators	The number of RADIUS Accounting-Response packets containing invalid authenticators received from this accounting server.
Pending Requests	The number of RADIUS Accounting-Request packets sent to this server that have not yet timed out or received a response.
Timeouts	The number of accounting time-outs to this server.
Unknown Types	The number of RADIUS packets of unknown types, which were received from this server on the accounting port.
Packets Dropped	The number of RADIUS packets received from this server on the accounting port and dropped for some other reason.

### Command example:

```
(NETGEAR Switch) #show radius accounting statistics 192.168.37.200

RADIUS Accounting Server Name..... Default_RADIUS_Server
Host Address..... 192.168.37.200
Round Trip Time..... 0.00
Requests..... 0
Retransmissions..... 0
```

```
Responses..... 0
Malformed Responses..... 0
Bad Authenticators..... 0
Pending Requests..... 0
Timeouts..... 0
Unknown Types..... 0
Packets Dropped..... 0
```

**Command example:**

```
(NETGEAR Switch) #show radius accounting statistics name Default_RADIUS_Server
```

```
RADIUS Accounting Server Name..... Default_RADIUS_Server
Host Address..... 192.168.37.200
Round Trip Time..... 0.00
Requests..... 0
Retransmissions..... 0
Responses..... 0
Malformed Responses..... 0
Bad Authenticators..... 0
Pending Requests..... 0
Timeouts..... 0
Unknown Types..... 0
Packets Dropped..... 0
```

**show radius statistics**

Use this command to display the summary statistics of configured RADIUS Authenticating servers.

Format	show radius statistics {<ipaddr>   <dnsname>   name <servername>}
Mode	Privileged EXEC

Field	Definition
servername	The alias name to identify the server.
RADIUS Server Name	The name of the authenticating server.
Server Host Address	The IP address of the host.
Access Requests	The number of RADIUS Access-Request packets sent to this server. This number does not include retransmissions.
Access Retransmissions	The number of RADIUS Access-Request packets retransmitted to this RADIUS authentication server.
Access Accepts	The number of RADIUS Access-Accept packets, including both valid and invalid packets, that were received from this server.



Field	Definition
Access Rejects	The number of RADIUS Access-Reject packets, including both valid and invalid packets, that were received from this server.
Access Challenges	The number of RADIUS Access-Challenge packets, including both valid and invalid packets, that were received from this server.
Malformed Access Responses	The number of malformed RADIUS Access-Response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators or signature attributes or unknown types are not included as malformed access responses.
Bad Authenticators	The number of RADIUS Access-Response packets containing invalid authenticators or signature attributes received from this server.
Pending Requests	The number of RADIUS Access-Request packets destined for this server that have not yet timed out or received a response.
Timeouts	The number of authentication time-outs to this server.
Unknown Types	The number of packets of unknown type that were received from this server on the authentication port.
Packets Dropped	The number of RADIUS packets received from this server on the authentication port and dropped for some other reason.

**Command example:**

```
(NETGEAR Switch) #show radius statistics 192.168.37.200
```

```
RADIUS Server Name..... Default_RADIUS_Server
Server Host Address..... 192.168.37.200
Access Requests..... 0.00
Access Retransmissions..... 0
Access Accepts..... 0
Access Rejects..... 0
Access Challenges..... 0
Malformed Access Responses..... 0
Bad Authenticators..... 0
Pending Requests..... 0
Timeouts..... 0
Unknown Types..... 0
Packets Dropped..... 0
```

**Command example:**

```
(NETGEAR Switch) #show radius statistics name Default_RADIUS_Server
```

```
RADIUS Server Name..... Default_RADIUS_Server
Server Host Address..... 192.168.37.200
Access Requests..... 0.00
Access Retransmissions..... 0
```

```

Access Accepts..... 0
Access Rejects..... 0
Access Challenges..... 0
Malformed Access Responses..... 0
Bad Authenticators..... 0
Pending Requests..... 0
Timeouts..... 0
Unknown Types..... 0
Packets Dropped..... 0

```

## TACACS+ Commands

TACACS+ provides access control for networked devices via one or more centralized servers. Similar to RADIUS, this protocol simplifies authentication by making use of a single database that can be shared by many clients on a large network. TACACS+ is based on the TACACS protocol (described in RFC1492) but additionally provides for separate authentication, authorization, and accounting services. The original protocol was UDP based with messages passed in clear text over the network. TACACS+ uses TCP to ensure reliable delivery and a shared key configured on the client and daemon server to encrypt all messages.

### debug tacacs packet

Use this command to enable TACACS+ packet debugging.

Default	Disabled
Format	debug tacacs packet [receive   transmit]
Mode	Global Config

### no debug tacacs packet

Use this command to disable TACACS+ packet debugging.

Format	no debug tacacs packet
Mode	Global Config

### tacacs-server host

Use this command to configure a TACACS+ server. This command enters into the TACACS+ configuration mode. The *<ip-address>* or *<hostname>* parameter is the IP address or host name of the TACACS+ server. To specify multiple hosts, repeat this command.

Format	tacacs-server host { <i>&lt;ip-address&gt;</i>   <i>&lt;hostname&gt;</i> }
Mode	Global Config

### no tacacs-server host

Use this command to delete the specified TACACS+ server. The *<ip-address>* or *<hostname>* parameter is the IP address or host name of the TACACS+ server.

Format	no tacacs-server host { <i>&lt;ip-address&gt;</i>   <i>&lt;hostname&gt;</i> }
Mode	Global Config

### tacacs-server key

Use this command to set the authentication and encryption key for all TACACS+ communications between the switch and the TACACS+ daemon. The *<key-string>* parameter has a range of 0–128 characters and specifies the authentication and encryption key for all TACACS communications between the switch and the TACACS+ server. This key must match the key used on the TACACS+ daemon.

Text-based configuration supports TACACS server's secrets in encrypted and non-encrypted format. When you save the configuration, these secret keys are stored in encrypted format only. If you want to enter the key in encrypted format, enter the key along with the encrypted keyword. In the output of the **show running config** command, these secret keys are displayed in encrypted format. You cannot show these keys in plain text format.

Format	tacacs-server key [ <i>&lt;key-string&gt;</i>   encrypted <i>&lt;key-string&gt;</i> ]
Mode	Global Config

### no tacacs-server key

Use this command to disable the authentication and encryption key for all TACACS+ communications between the switch and the TACACS+ daemon. The *<key-string>* parameter has a range of 0–128 characters. This key must match the key used on the TACACS+ daemon.

Format	no tacacs-server key <i>&lt;key-string&gt;</i>
Mode	Global Config

### tacacs-server keystring

Use this command to set the global authentication encryption key used for all TACACS+ communications between the TACACS+ server and the client.

Format	tacacs-server keystring
Mode	Global Config

### tacacs-server source interface

Use this command in Global Configuration mode to configure the global source interface (source IP selection) for all TACACS+ communications between the TACACS+ client and the server.

Format	<code>tacacs-server source-interface {&lt;slot/port&gt;   loopback &lt;loopback-id&gt;   vlan &lt;vlan-id&gt;}</code>
Mode	Global Config

Parameter	Description
<code>&lt;slot/port&gt;</code>	The unit identifier assigned to the switch.
<code>&lt;loopback-id&gt;</code>	The loopback interface. The range is 0–7.
<code>&lt;vlan-id&gt;</code>	The VLAN ID. The range is 1–4,093.

### no tacacs-server source interface

Use this command in Global Configuration mode to remove the global source interface (source IP selection) for all TACACS+ communications between the TACACS+ client and the server.

Format	<code>no tacacs-server source-interface</code>
Mode	Privileged Exec

### tacacs-server timeout

Use this command to set the timeout value for communication with the TACACS+ servers. The `<timeout>` parameter has a range of 1-30 and is the time-out value in seconds.

Default	5
Format	<code>tacacs-server timeout &lt;timeout&gt;</code>
Mode	Global Config

### no tacacs-server timeout

Use this command to restore the default time-out value for all TACACS servers.

Format	<code>no tacacs-server timeout</code>
Mode	Global Config

### key (TACACS Config)

Use the **key** command in TACACS Configuration mode to specify the authentication and encryption key for all TACACS communications between the device and the TACACS server. This key must match the key used on the TACACS daemon. The *<key-string>* parameter specifies the key name. For an empty string use "". The range is 0–128 characters.

Text-based configuration supports TACACS server's secrets in encrypted and non-encrypted format. When you save the configuration, these secret keys are stored in encrypted format only. If you want to enter the key in encrypted format, enter the key along with the encrypted keyword. In the output of the **show running config** command, these secret keys are displayed in encrypted format. You cannot show these keys in plain text format.

Format	<code>key [<i>&lt;key-string&gt;</i>   encrypted <i>&lt;key-string&gt;</i>]</code>
Mode	TACACS Config

### port (TACACS Config)

Use this command in TACACS Configuration mode to specify a server port number. The server *<number>* range is 0–65535.

Default	49
Format	<code>port <i>&lt;number&gt;</i></code>
Mode	TACACS Config

### priority (TACACS Config)

Use this command in TACACS Configuration mode to specify the order in which servers are used, where 0 (zero) is the highest priority. The *<priority>* parameter specifies the priority for servers. The highest priority is 0 (zero), and the range is 0 - 65535.

Default	0
Format	<code>priority <i>&lt;priority&gt;</i></code>
Mode	TACACS Config

### timeout (TACACS Config)

Use this command in TACACS Configuration mode to specify the time-out value in seconds. If no time-out value is specified, the global value is used. The *<timeout>* parameter has a range of 1-30 seconds.

Format	<code>timeout <i>&lt;timeout&gt;</i></code>
Mode	TACACS Config

## show tacacs

Use this command to display the configuration and statistics of a TACACS+ server.

Format	<code>show tacacs [&lt;ip-address&gt;   &lt;hostname&gt;]</code>
Mode	Privileged EXEC

Field	Definition
Host Address	The IP address or hostname of the configured TACACS+ server.
Port	The configured TACACS+ server port number.
TimeOut	The timeout in seconds for establishing a TCP connection.
Priority	The preference order in which TACACS+ servers are contacted. If a server connection fails, the next highest priority server is contacted.

## Configuration Scripting Commands

Configuration Scripting allows you to generate text-formatted script files representing the current configuration of a system. You can upload these configuration script files to a computer or UNIX system and edit them. Then, you can download the edited files to the system and apply the new configuration. You can apply configuration scripts to one or more switches with no or minor modifications.

Use the `show running-config` command (see [show running-config](#) on page 349) to capture the running configuration into a script. Use the `copy` command (see [copy](#) on page 371) to transfer the configuration script to or from the switch.

You should use scripts on systems with default configuration; however, you are not prevented from applying scripts on systems with non-default configurations.

Scripts must conform to the following rules:

- Script files are not distributed across the stack, and only live in the unit that is the master unit at the time of the file download.
- The file extension must be “.scr”.
- A maximum of ten scripts are allowed on the switch.
- The combined size of all script files on the switch shall not exceed 2048 KB.
- The maximum number of configuration file command lines is 2000.

You can type single-line annotations at the command prompt to use when you write test or configuration scripts to improve script readability. The exclamation point (!) character flags the beginning of a comment. The comment flag character can begin a word anywhere on the command line, and all input following this character is ignored. Any command line that begins with the “!” character is recognized as a comment line and ignored by the parser.

The following lines show an example of a script:

```
! Script file for displaying management access

show telnet !Displays the information about remote connections

! Display information about direct connections

show serial

! End of the script file!
```

To specify a blank password for a user in the configuration script, you must specify it as a space within quotes. For example, to change the password for user `jane` from a blank password to `hello`, the script entry is as follows:

```
users passwd jane
" "
hello
hello
```

### script apply

Use this command to apply the commands in the script to the switch. The `<scriptname>` parameter is the name of the script to apply.

Format	<code>script apply &lt;scriptname&gt;</code>
Mode	Privileged EXEC

### script delete

Use this command to delete a specified script, where the `<scriptname>` parameter is the name of the script to delete. The `all` option deletes all the scripts present on the switch.

Format	<code>script delete {&lt;scriptname&gt;   all}</code>
Mode	Privileged EXEC

### script list

Use this command to list all scripts present on the switch as well as the remaining available space.

Format	<code>script list</code>
Mode	Global Config

Term	Definition
Configuration Script	Name of the script.
Size	Privileged EXEC

### script show

Use this command to display the contents of a script file, which is named *<scriptname>*.

Format	<code>script show &lt;scriptname&gt;</code>
Mode	Privileged EXEC

Term	Definition
Output Format	line <number>: <line contents>

### script validate

Use this command to validate a script file by parsing each line in the script file, where *<scriptname>* is the name of the script to validate. The validate option is intended to be used as a tool for script development. Validation identifies potential problems. It might not identify all problems with a script on a device.

Format	<code>script validate &lt;scriptname&gt;</code>
Mode	Privileged EXEC

## Pre-Login Banner and System Prompt Commands

This section describes the commands you use to configure the pre-login banner and the system prompt. The pre-login banner is the text that displays before you login at the `User:` prompt.

### copy (pre-login banner)

Use the `copy` command to upload or download the CLI banner from the switch. You can specify local URLs by using TFTP, Xmodem, Ymodem, or Zmodem.

---

**Note:** *<ip6address>* is also a valid parameter for routing packages that support IPv6.

---



Format	<code>copy &lt;url&gt; nvram:clibanner</code> or <code>copy nvram:clibanner &lt;url&gt;</code>
Mode	Privileged EXEC

### set prompt

Use this command to change the name of the prompt. The length of name might be up to 64 alphanumeric characters.

Format	<code>set prompt &lt;prompt_string&gt;</code>
Mode	Privileged EXEC

### set clibanner

Use this command to add the CLI Banner. The banner message supports up to 2000 characters.

Format	<code>set clibanner &lt;line&gt;</code>
Mode	Global Config

### no set clibanner

Use this command to remove the CLI Banner downloaded through TFTP.

Format	<code>no set clibanner</code>
Mode	Global Config

## 9. Green Ethernet Commands

---

# 9

This chapter describes the green Ethernet commands available in the managed switch CLI.

The chapter contains the following sections:

- *Green Feature Support*
- *Energy-Detect Mode*
- *Energy Efficient Ethernet (EEE)*
- *Green Ethernet Commands*

## Green Feature Support

The NETGEAR Managed switch supports the following green Ethernet power saving modes:

- Energy Detect Mode
- EEE Mode

The green Ethernet commands supported depends on the switch model.

**Table 2. Green feature support**

Model	Energy-Detect	EEE
M4100-D10-POE	Yes	No
M4100-D12G	Yes	Yes
M4100-50G-POE+	Yes	Yes
M4100-26G-POE	Yes	Yes
M4100-50G	Yes	Yes
M4100-26G	Yes	Yes
M4100-50-POE	Yes	No
M4100-26-POE	Yes	No
M7100-24x	No	Yes
M4100-12GF	Yes	No
M4100-D12G-POE+	Yes	No
M4100-24G-POE+	Yes	No
M4100-12G-POE+	Yes	No

## Energy-Detect Mode

When Energy-Detect mode is enabled, if communication on a port stops, the port circuitry automatically shuts down for a short period. The port wakes up periodically to check for link activity. If activity is detected, the port circuitry remains active. This allows performing autonegotiation and saving power when there is no active link.

---

**Note:** Combination ports support both copper and fiber media. Energy Detect mode only applies to copper media. If Energy Detect mode is configured on a combination port, it will only function when a copper media is active.

---

## Energy Efficient Ethernet (EEE)

Energy Efficient Ethernet (EEE) combines MAC with ports that support operation in a Low-Power Mode. This feature is defined by the IEEE 802.3az Energy Efficient Ethernet Task Force. Lower Power Mode enables both send and receive sides of a link to disable some port functionality to save power when the port is lightly loaded. Transition to Low-Power Mode does not change the link status. Frames in transit are not dropped or corrupted during transition to and from Low-Power Mode. This transition time is transparent to upper layer protocols and applications.

EEE operation is subject to the following conditions:

- Autonegotiation must be enabled to use any of the EEE modes. EEE mode is disabled automatically when autonegotiation is disabled.
- Enabling or Disabling EEE mode causes the port link to flap once as EEE capability needs to be advertised. This restarts autonegotiation.
- EEE must be disabled while running hardware or software cable diagnostics.
- Combo (Combination) ports: Combo ports support both copper and fiber media. EEE mode only applies to copper media. If Energy Detect mode is configured on a combination port, it will only function when a copper media is active. EEE LPI statistics are only collected if a copper media is used on the port. If the media on a port changes from copper to fiber while EEE is enabled, LPI statistics collection stops until the media changes back to copper. The outputs of the **show green-mode <slot/port>** and **show green-mode eee-lpi-history interface <slot/port>** commands display updated LPI statistics only if the medium is copper.

## Green Ethernet Commands

### green-mode energy-detect

Use this command enables energy-detect mode on an interface or on all the interfaces.

Default	Disabled
Format	<code>green-mode energy-detect</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Interface Range Config</li> </ul>

### no green-mode energy-detect

This command disables energy-detect mode on an interface or on all the interfaces.

Format	<code>no green-mode energy-detect</code>
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Interface Range Config</li> </ul>

### green-mode eee

This command enables EEE low-power idle mode on an interface or on all interfaces. It allows both send and receive sides of a link to disable some functionality for power savings when the port is lightly loaded. Transition to Low-Power Mode does not change the link status. Frames in transit are not dropped or corrupted in transition to and from Low-Power Mode.

Default	Disabled
Format	green-mode eee
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Interface Range Config</li> </ul>

### no green-mode eee

This command disables EEE.

Format	no green-mode eee
Mode	<ul style="list-style-type: none"> <li>• Interface Config</li> <li>• Interface Range Config</li> </ul>

### clear green-mode statistics

This command to clears the following for a specified *<slot/port>*, or for all ports:

- EEE LPI event count, and LPI duration
- EEE LPI history table entries
- Cumulative Power savings estimates

Format	clear green-mode statistics {<slot/port>   all}
Mode	Privileged Exec

#### Command example:

```
(NETGEAR Switch) #clear green-mode statistics 0/1
Are you sure you want to clear the green mode port stats? (y/n)y
Green Mode Stats Cleared.
(NETGEAR Switch) #clear green-mode statistics all
Are you sure you want to clear the green mode port stats? (y/n)y
Green Mode Stats Cleared.
```

## show green-mode

This command displays the green mode configuration and operational status either for the whole system or for a port. This command can display the per-port configuration and operational status of the green mode. The status is shown only for the modes supported on the switch.

Format	show green-mode [<slot/port>]
Mode	Privileged Exec

The following table shows the fields that display if you do not specify a slot and port.

Field	Definition
Energy Detect	
Energy-detect Config	Energy-detect Admin mode is enabled or disabled
Energy-detect Opr	Energy detect mode is currently active or inactive. The energy detect mode might be administratively enabled, but the operational status might be inactive.
EEE	
EEE Config	EEE Admin Mode is enabled or disabled.
Global	
Cumulative Energy Saving per Stack	Estimated cumulative energy saved per stack in (watts * hours) due to all green modes enabled
Current Power Consumption per Stack	Power consumption by all ports in stack in mWatts.
Power Saving	Estimated percentage power saved on all ports in stack due to green mode(s) enabled.
Unit	Unit index of the stack member
Green Ethernet Features supported	List of green features supported on the unit which could be one or more of the following: Energy-Detect (Energy Detect), Short-Reach (Short Reach), EEE (Energy Efficient Ethernet), LPI-History (EEE Low Power Idle History), LLDP-Cap-Exchg (EEE LLDP Capability Exchange), Pwr-Usg-Est (Power Usage Estimates).

The following table shows the fields that display if you specify a slot and port.

Field	Definition
Energy-detect admin mode	Energy-detect mode is enabled or disabled.
Energy-detect operational status	Energy detect mode is currently active or inactive. The energy detect mode might be administratively enabled, but the operational status might be inactive. The reasons for the same are described below.

## M4100 Series ProSAFE Managed Switches

Field	Definition
Reason for Energy-detect current operational status	<p>The energy detect mode might be administratively enabled, but the operational status might be inactive. The reasons for the same are:</p> <ul style="list-style-type: none"> <li>- Port is currently operating in the fiber mode</li> <li>- Link is up.</li> <li>- Admin Mode Disabled</li> <li>- Interface Not Attached</li> </ul> <p>If the energy-detect operational status is active, the reason field displays No energy Detected</p>
EEE Admin Mode	EEE Admin Mode is enabled or disabled.
Transmit Idle Time	It is the time for which condition to move to LPI state is satisfied, at the end of which MAC TX transitions to LPI state. The Range is (0 to 0xffffffff).The default value is 0.
Transmit Wake Time	It is the time for which MAC / switch has to wait to go back to ACTIVE state from LPI state when it receives packet for transmission. The Range is (0 to 0xffff).The default value is 0.
Rx Low Power Idle Event Count	This field is incremented each time MAC RX enters LP IDLE state. Shows the total number of Rx LPI Events since EEE counters are last cleared
Rx Low Power Idle Duration (microsec)	This field indicates duration of Rx LPI state in 10-microsecond increments. Shows the total duration of Rx LPI since the EEE counters are last cleared.
Tx Low Power Idle Event Count	This field is incremented each time MAC TX enters LP IDLE state. Shows the total number of Tx LPI Events since EEE counters are last cleared.
Tx Low Power Idle Duration (microsec)	This field indicates duration of Tx LPI state in 10us increments. Shows the total duration of Tx LPI since the EEE counters are last cleared.
Tw_sys_tx (microsec)	Integer that indicates the value of Tw_sys that the local system can support. This value is updated by the EEE DLL Transmitter state diagram. This variable maps into the aLldpXdot3LocTxTwSys attribute.
Tw_sys Echo (microsec)	Integer that indicates the remote system's Transmit Tw_sys that was used by the local system to compute the Tw_sys that it wants to request from the remote system. This value maps into the aLldpXdot3LocTxTwSysEcho attribute.
Tw_sys_rx (microsec)	Integer that indicates the value of Tw_sys that the local system requests from the remote system. This value is updated by the EEE Receiver L2 state diagram. This variable maps into the aLldpXdot3LocRxTwSys attribute.
Tw_sys_rx Echo (microsec)	Integer that indicates the remote systems Receive Tw_sys that was used by the local system to compute the Tw_sys that it can support. This value maps into the aLldpXdot3LocRxTwSysEcho attribute.
Fallback Tw_sys (microsec)	Integer that indicates the value of fallback Tw_sys that the local system requests from the remote system. This value is updated by the local system software.
Remote Tw_sys_tx (microsec)	Integer that indicates the value of Tw_sys that the remote system can support. This value maps from the aLldpXdot3RemTxTwSys attribute.
Remote Tw_sys Echo (microsec)	Integer that indicates the value Transmit Tw_sys echoed back by the remote system. This value maps from the aLldpXdot3RemTxTwSysEcho attribute.

Field	Definition
Remote Tw_sys_rx (microsec)	Integer that indicates the value of Tw_sys that the remote system requests from the local system. This value maps from the aLldpXdot3RemRxTwSys attribute.
Remote Tw_sys_rx Echo (microsec)	Integer that indicates the value of Receive Tw_sys echoed back by the remote system. This value maps from the aLldpXdot3RemRxTwSysEcho attribute.
Remote Fallback Tw_sys (microsec)	Integer that indicates the value of fallback Tw_sys that the remote system is advertising. This attribute maps to the variable RemFbSystemValue as defined in 78.4.2.3.
Tx_dll_enabled	Initialization status of the EEE transmit Data Link Layer management function on the local system.
Tx_dll_ready	Data Link Layer ready: This variable indicates that the tx system initialization is complete and is ready to update/receive LLDPDU containing EEE TLV. This variable is updated by the local system software.
Rx_dll_enabled	Status of the EEE capability negotiation on the local system.
Rx_dll_ready	Data Link Layer ready: This variable indicates that the rx system initialization is complete and is ready to update/receive LLDPDU containing EEE TLV. This variable is updated by the local system software.
Cumulative Energy Saving	Estimated Cumulative energy saved on this port in (Watts * hours) due to all green modes enabled
Time Since Counters Last Cleared	Time Since Counters Last Cleared (since the time of power up, or after 'clear eee counters' is executed)

---

**Note:** Executing the `clear green-mode statistics` command clears only the EEE Transmit, Receive LPI event count, LPI duration, and Cumulative Energy Savings Estimates of the port. Other status parameters listed in the previous table remain unaffected after you executed the `clear green-mode statistics` command.

---

**Command example:**

```
(NETGEAR Switch) #show green-mode

Current Power Consumption (mW)..... XX
Power Saving (%)..... XX
Cumulative Energy Saving /Stack (W * H)... XX

Unit   Green Ethernet Features Supported
-----
1      Energy-Detect EEE LPI-History LLDP-Cap-Exchg Pwr-Usg-Est
```



## M4100 Series ProSAFE Managed Switches

Interface	Energy-Detect		Short-Reach-Config		Short-Reach	EEE
	Config	Opr	Auto	Forced	Opr	Config
0/1	Disabled	Inactive				Disabled
0/2	Disabled	Inactive				Disabled
0/3	Disabled	Inactive				Disabled
0/4	Disabled	Inactive				Disabled
0/5	Disabled	Inactive				Disabled
0/6	Disabled	Inactive				Disabled
0/7	Disabled	Inactive				Disabled
0/8	Disabled	Inactive				Disabled
0/9	Disabled	Inactive				Disabled
0/10	Disabled	Inactive				Disabled
0/11	Disabled	Inactive				Disabled
0/12	Disabled	Inactive				Disabled
0/13	Disabled	Inactive				Disabled
0/14	Disabled	Inactive				Disabled
0/15	Disabled	Inactive				Disabled
0/16	Disabled	Inactive				Disabled
0/17	Disabled	Inactive				Disabled
0/18	Disabled	Inactive				Disabled
0/19	Disabled	Inactive				Disabled
0/20	Disabled	Inactive				Disabled
0/21	Disabled	Inactive				Disabled
0/22	Disabled	Inactive				Disabled
0/23	Disabled	Inactive				Disabled
0/24	Disabled	Inactive				Disabled
0/25	Disabled	Inactive				Disabled

### Command example:

```
(NETGEAR Switch) #show green-mode 0/25
```

```
EEE Admin Mode..... Enabled
  Transmit Idle Time..... 0
  Transmit Wake Time..... 0
  Rx Low Power Idle Event Count..... 0
  Rx Low Power Idle Duration (uSec)..... 0
  Tx Low Power Idle Event Count..... 0
  Tx Low Power Idle Duration (uSec)..... 0
  Tw_sys_tx (usec)..... XX
  Tw_sys_tx Echo (usec)..... XX
  Tw_sys_rx (usec)..... XX
  Tw_sys_rx Echo (usec)..... XX
  Fallback Tw_sys (usec)..... XX
  Tx DLL enabled..... Yes
  Tx DLL ready..... Yes
```

```
Rx DLL enabled..... Yes
Rx DLL ready..... Yes
```

```
Cumulative Energy Saving (W * H)..... XX
Time Since Counters Last Cleared..... 1 day 20 hr 47 min 34 sec
```

### green-mode eee-lpi-history

Configure the global EEE LPI history collection interval and buffer size using this command. This value is applied globally on all interfaces on the stack.

---

**Note:** The sampling interval configured by the user takes effect immediately. The current and future samples are collected at this new sampling interval.

---

Default	sampling-interval = 3600; max-samples = 168
Format	green-mode eee-lpi-history {sampling-interval <30-36000sec>   max-samples <1-168>}
Mode	Global Config

### no green-mode eee-lpi-history

Use this command to set the sampling interval or max-samples values to defaults:

- sampling-interval = 3600
- max-samples = 168

Format	no green-mode eee-lpi-history {sampling-interval   max-samples}
Mode	Global Config

### show green-mode eee-lpi-history interface

This command displays the interface green-mode EEE LPI history.

Format	show green-mode eee-lpi-history interface <slot/port>
Mode	Privileged Exec

Field	Description
Sampling Interval	Interval at which EEE LPI statistics is collected.
Total No. of Samples to Keep	Maximum number of samples to keep

Field	Description
Percentage LPI time per stack	Percentage of Total time spent in LPI mode by all port in stack when compared to total time since reset.
Sample No	Sample Index
Sample Time	Time since last reset
%time spent in LPI mode since last sample	Percentage of time spent in LPI mode on this port when compared to sampling interval
%time spent in LPI mode since last reset	Percentage of total time spent in LPI mode on this port when compared to time since reset.

**Command example:**

```
(NETGEAR Switch)#show green-mode eee-lpi-history interface 0/1
Sampling Interval (sec)..... 30
Total No. of Samples to Keep..... 168
Percentage LPI time per stack..... 29
```

Sample No.	Time Since The Sample Was Recorded	Percentage of Time spent in LPI mode since last sample	Percentage of Time spent in LPI mode since last reset
10	0d:00:00:13	3	2
9	0d:00:00:44	3	2
8	0d:00:01:15	3	2
7	0d:00:01:46	3	2
6	0d:00:02:18	3	2
5	0d:00:02:49	3	2
4	0d:00:03:20	3	2
3	0d:00:03:51	3	1
2	0d:00:04:22	3	1
1	0d:00:04:53	3	1

This chapter lists common log messages, along with information regarding the cause of each message. There is no specific action that can be taken per message. If a problem is being diagnosed, a set of these messages in the event log, along with an understanding of the system configuration and details of the problem, can assist NETGEAR technical support in determining the root cause of such a problem.

---

**Note:** This chapter does not contain a complete list of all syslog messages.

---

The chapter contains the following sections:

- *Core*
- *Utilities*
- *Management*
- *Switching*
- *QoS*
- *Routing/IPv6 Routing*
- *Multicast*
- *Stacking*
- *Technologies*
- *O/S Support*

## Core

Table 3. BSP Log Messages

Component	Message	Cause
BSP	Event(0xaaaaaaaa)	Switch has restarted.
BSP	Starting code...	BSP initialization complete, starting application.

Table 4. NIM Log Messages

Component	Message	Cause
NIM	NIM: L7_ATTACH out of order for intfNum(x) unit x slot x port x	Interface creation out of order
NIM	NIM: Failed to find interface at unit x slot x port x for event(x)	There is no mapping between the USP and Interface number
NIM	NIM: L7_DETACH out of order for intfNum(x) unit x slot x port x	Interface creation out of order
NIM	NIM: L7_DELETE out of order for intfNum(x) unit x slot x port x	Interface creation out of order
NIM	NIM: event(x),intf(x),component(x), in wrong phase	An event was issued to NIM during the wrong configuration phase (probably Phase 1, 2, or WMU)
NIM	NIM: Failed to notify users of interface change	Event was not propagated to the system
NIM	NIM: failed to send message to NIM message Queue.	NIM message queue full or non-existent
NIM	NIM: Failed to notify the components of L7_CREATE event	Interface not created
NIM	NIM: Attempted event (x), on USP x.x.x before phase 3	A component issued an interface event during the wrong initialization phase
NIM	NIM: incorrect phase for operation	An API call was made during the wrong initialization phase
NIM	NIM: Component(x) failed on event(x) for intfNum(x)	A component responded with a fail indication for an interface event
NIM	NIM: Timeout event(x), intfNum(x) remainingMask = "xxxx"	A component did not respond before the NIM timeout occurred

Table 5. System Log Messages

Component	Message	Cause
SYSTEM	Configuration file Switch CLI.cfg size is 0 (zero) bytes	The configuration file could not be read. This message might occur on a system for which no configuration has ever been saved or for which configuration has been erased.
SYSTEM	could not separate SYSAPI_CONFIG_FILENAME	The configuration file could not be read. This message might occur on a system for which no configuration has ever been saved or for which configuration has been erased.
SYSTEM	Building defaults for file <file name> version <version num>	Configuration did not exist or could not be read for the specified feature or file. Default configuration values will be used. The file name and version are indicated.
SYSTEM	File <filename>: same version (version num) but the sizes (<version size>-><expected version size) differ	The configuration file which was loaded was of a different size than expected for the version number. This message indicates the configuration file needed to be migrated to the version number appropriate for the code image. This message might appear after upgrading the code image to a more current release.
SYSTEM	Migrating config file <filename> from version <version num> to <version num>	The configuration file identified was migrated from a previous version number. Both the old and new version number are specified. This message might appear after upgrading the code image to a more current release.
SYSTEM	Building Defaults	Configuration did not exist or could not be read for the specified feature. Default configuration values will be used.
SYSTEM	sysapiCfgFileGet failed size = <expected size of file> version = <expected version>	Configuration did not exist or could not be read for the specified feature. This message is usually followed by a message indicating that default configuration values will be used.

## Utilities

**Table 6. Trap Mgr Log Message**

Component	Message	Cause
Trap Mgr	Link Up/Down: slot/port	An interface changed link state.

**Table 7. DHCP Filtering Log Messages**

Component	Message	Cause
DHCP Filtering	Unable to create r/w lock for DHCP Filtering	Unable to create semaphore used for dhcp filtering configuration structure .
DHCP Filtering	Failed to register with nv Store.	Unable to register save and restore functions for configuration save
DHCP Filtering	Failed to register with NIM	Unable to register with NIM for interface callback functions
DHCP Filtering	Error on call to sysapiCfgFileWrite file	Error on trying to save configuration .

**Table 8. NVStore Log Messages**

Component	Message	Cause
NVStore	Building defaults for file XXX	A component's configuration file does not exist or the file's checksum is incorrect so the component's default configuration file is built.
NVStore	Error on call to osapiFsWrite routine on file XXX	Either the file cannot be opened or the OS's file I/O returned an error trying to write to the file.
NVStore	File XXX corrupted from file system. Checksum mismatch.	The calculated checksum of a component's configuration file in the file system did not match the checksum of the file in memory.
NVStore	Migrating config file XXX from version Y to Z	A configuration file version mismatch was detected so a configuration file migration has started.

Table 9. RADIUS Log Messages

Component	Message	Cause
RADIUS	RADIUS: Invalid data length - xxx	The RADIUS Client received an invalid message from the server.
RADIUS	RADIUS: Failed to send the request	A problem communicating with the RADIUS server.
RADIUS	RADIUS: Failed to send all of the request	A problem communicating with the RADIUS server during transmit.
RADIUS	RADIUS: Could not get the Task Sync semaphore!	Resource issue with RADIUS Client service.
RADIUS	RADIUS: Buffer is too small for response processing	RADIUS Client attempted to build a response larger than resources allow.
RADIUS	RADIUS: Could not allocate accounting requestInfo	Resource issue with RADIUS Client service.
RADIUS	RADIUS: Could not allocate requestInfo	Resource issue with RADIUS Client service.
RADIUS	RADIUS: osapiSocketRecvFrom returned error	Error while attempting to read data from the RADIUS server.
RADIUS	RADIUS: Accounting-Response failed to validate, id=xxx	The RADIUS Client received an invalid message from the server.
RADIUS	RADIUS: User (xxx) needs to respond for challenge	An unexpected challenge was received for a configured user.
RADIUS	RADIUS: Could not allocate a buffer for the packet	Resource issue with RADIUS Client service.
RADIUS	RADIUS: Access-Challenge failed to validate, id=xxx	The RADIUS Client received an invalid message from the server.
RADIUS	RADIUS: Failed to validate Message-Authenticator, id=xxx	The RADIUS Client received an invalid message from the server.
RADIUS	RADIUS: Access-Accept failed to validate, id=xxx	The RADIUS Client received an invalid message from the server.
RADIUS	RADIUS: Invalid packet length – xxx	The RADIUS Client received an invalid message from the server.
RADIUS	RADIUS: Response is missing Message-Authenticator, id=xxx	The RADIUS Client received an invalid message from the server.
RADIUS	RADIUS: Server address does not match configured server	RADIUS Client received a server response from an unconfigured server.



**Table 10. TACACS+ Log Messages**

Component	Message	Cause
TACACS+	TACACS+: authentication error, no server to contact	TACACS+ request needed, but no servers are configured.
TACACS+	TACACS+: connection failed to server x.x.x.x	TACACS+ request sent to server x.x.x.x but no response was received.
TACACS+	TACACS+: no key configured to encrypt packet for server x.x.x.x	No key configured for the specified server.
TACACS+	TACACS+: received invalid packet type from server.	Received packet type that is not supported.
TACACS+	TACACS+: invalid major version in received packet.	Major version mismatch.
TACACS+	TACACS+: invalid minor version in received packet.	Minor version mismatch.

**Table 11. LLDP Log Message**

Component	Message	Cause
LLDP	lldpTask(): invalid message type:xx. xxxxxx:xx	Unsupported LLDP packet received.

**Table 12. SNTP Log Message**

Component	Message	Cause
SNTP	SNTP: system clock synchronized on %s UTC	Indicates that SNTP has successfully synchronized the time of the box with the server.

## Management

**Table 13. SNMP Log Message**

Component	Message	Cause
SNMP	EDB Callback: Unit Join: x.	A new unit has joined the stack.

Table 14. EmWeb Log Messages

Component	Message	Cause
EmWeb	EMWEB (Telnet): Max number of Telnet login sessions exceeded	A user attempted to connect via telnet when the maximum number of telnet sessions were already active.
EmWeb	EMWEB (SSH): Max number of SSH login sessions exceeded	A user attempted to connect via SSH when the maximum number of SSH sessions were already active.
EmWeb	Handle table overflow	All the available EmWeb connection handles are being used and the connection could not be made.
EmWeb	<i>ConnectionType</i> EmWeb socket accept() failed: errno	Socket accept failure for the specified connection type.
EmWeb	ewsNetHTTPReceive failure in NetReceiveLoop() - closing connection.	Socket receive failure.
EmWeb	EmWeb: connection allocation failed	Memory allocation failure for the new connection.
EmWeb	EMWEB TransmitPending : EWOULDBLOCK error sending data	Socket error on send.
EmWeb	ewaNetHTTPEnd: internal error - handle not in Handle table	EmWeb handle index not valid.
EmWeb	ewsNetHTTPReceive:rcvBufCnt exceeds MAX_QUEUED_RECV_BUFS!	The receive buffer limit has been reached. Bad request or DoS attack.
EmWeb	EmWeb accept: XXXX	Accept function for new SSH connection failed. XXXX indicates the error info.

Table 15. CLI\_UTIL Log Messages

Component	Message	Cause
CLI_UTIL	Telnet Send Failed errno = 0x%x	Failed to send text string to the telnet client.
CLI_UTIL	osapiFsDir failed	Failed to obtain the directory information from a volume's directory.

Table 16. WEB Log Messages

Component	Message	Cause
WEB	Max clients exceeded	This message is shown when the maximum allowed java client connections to the switch is exceeded.
WEB	Error on send to sockfd XXXX, closing connection	Failed to send data to the java clients through the socket.
WEB	# (XXXX) Form Submission Failed. No Action Taken.	The form submission failed and no action is taken. XXXX indicates the file under consideration.
WEB	ewaFormServe_file_download() - WEB Unknown return code from tftp download result	Unknown error returned while downloading file using TFTP from web interface
WEB	ewaFormServe_file_upload() - Unknown return code from tftp upload result	Unknown error returned while uploading file using TFTP from web interface.
WEB	Web UI Screen with unspecified access attempted to be brought up	Failed to get application-specific authorization handle provided to EmWeb/Server by the application in ewsAuthRegister(). The specified web page will be served in read-only mode.

Table 17. CLI\_WEB\_MGR Log Messages

Component	Message	Cause
CLI_WEB_MGR	File size is greater than 2K	The banner file size is greater than 2K bytes.
CLI_WEB_MGR	No. of rows greater than allowed maximum of XXXX	When the number of rows exceeds the maximum allowed rows

Table 18. SSHD Log Messages

Component	Message	Cause
SSHD	SSHD: Unable to create the global (data) semaphore	Failed to create semaphore for global data protection.
SSHD	SSHD: Msg Queue is full, event = XXXX	Failed to send the message to the SSHD message queue as message queue is full. XXXX indicates the event to be sent

Table 18. SSHD Log Messages

Component	Message	Cause
SSHD	SSHD: Unknown UI event in message, event=XXXX	Failed to dispatch the UI event to the appropriate SSHD function as it's an invalid event. XXXX indicates the event to be dispatched.
SSHD	sshdApiCnfgrCommand: Failed calling sshdIssueCmd.	Failed to send the message to the SSHD message queue

Table 19. SSLT Log Messages

Component	Message	Cause
SSLT	SSLT: Exceeded maximum, ssltConnectionTask	Exceeded maximum allowed SSLT connections.
SSLT	SSLT: Error creating Secure server socket6	Failed to create secure server socket for IPV6.
SSLT	SSLT: Can't connect to unsecure server at XXXX, result = YYYY, errno = ZZZZ	Failed to open connection to unsecure server. XXXX is the unsecure server socket address. YYYY is the result returned from connect function and ZZZZ is the error code.
SSLT	SSLT: Msg Queue is full, event=XXXX	Failed to send the received message to the SSLT message queue as message queue is full. XXXX indicates the event to be sent.
SSLT	SSLT: Unknown UI event in message, event=XXXX	Failed to dispatch the received UI event to the appropriate SSLT function as it's an invalid event. XXXX indicates the event to be dispatched.
SSLT	ssltApiCnfgrCommand: Failed calling ssltIssueCmd.	Failed to send the message to the SSLT message queue.
SSLT	SSLT: Error loading certificate from file XXXX	Failed while loading the SSLcertificate from specified file. XXXX indicates the file from where the certificate is being read.
SSLT	SSLT: Error loading private key from file	Failed while loading private key for SSL connection.
SSLT	SSLT: Error setting cipher list (no valid ciphers)	Failed while setting cipher list.
SSLT	SSLT: Could not delete the SSL semaphores	Failed to delete SSL semaphores during cleanup.of all resources associated with the OpenSSL Locking semaphores.

**Table 20. User\_Manager Log Messages**

Component	Message	Cause
User_Manager	User Login Failed for XXXX	Failed to authenticate user login. XXXX indicates the user name to be authenticated.
User_Manager	Access level for user XXXX could not be determined. Setting to READ_ONLY.	Invalid access level specified for the user. The access level is set to READ_ONLY. XXXX indicates the user name.
User_Manager	Could not migrate config file XXXX from version YYYY to ZZZZ. Using defaults.	Failed to migrate the config file. XXXX is the config file name. YYYY is the old version number and ZZZZ is the new version number.

## Switching

**Table 21. Protected Ports Log Messages**

Component	Message	Cause
Protected Ports	Protected Port: failed to save configuration	Appears when the protected port configuration cannot be saved
Protected Ports	protectedPortCnfrInitPhase1Process: Unable to create r/w lock for protectedPort	Appears when protectedPortCfgRWLock Fails
Protected Ports	protectedPortCnfrInitPhase2Process: Unable to register for VLAN change callback	Appears when nimRegisterIntfChange with VLAN fails
Protected Ports	Cannot add intfNum xxx to group yyy	Appears when an interface could not be added to a particular group.
Protected Ports	Unable to set protected port group	Appears when a dtl call fails to add interface mask at the driver level
Protected Ports	Cannot delete intfNum xxx from group yyy	Appears when a dtl call to delete an interface from a group fails
Protected Ports	Cannot update group YYY after deleting interface XXX	This message appears when an update group for an interface deletion fails
Protected Ports	Received an interface change callback while not ready to receive it	Appears when an interface change callback has come before the protected port component is ready.

**Table 22. IP Subnet VLANS Log Messages**

Component	Message	Cause
IPsubnet vlans	ERROR vlanIpSubnetSubnetValid :Invalid subnet	Occurs when an invalid pair of subnet and netmask has come from the CLI
IPsubnet vlans	IP Subnet Vlans: failed to save configuration	This message appears when save configuration of subnet vlans failed
IPsubnet vlans	vlanIpSubnetCnfrInitPhase1Process: Unable to create r/w lock for vlanIpSubnet	Appears when a read/write lock creations fails
IPsubnet vlans	vlanIpSubnetCnfrInitPhase2Process: Unable to register for VLAN change callback	Appears when this component unable to register for VLAN change notifications
IPsubnet vlans	vlanIpSubnetCnfrFiniPhase1Process: could not delete avl semaphore	Appears when a semaphore deletion of this component fails.
IPsubnet vlans	vlanIpSubnetDtlVlanCreate: Failed	Appears when a dtl call fails to add an entry into the table
IPsubnet vlans	vlanIpSubnetSubnetDeleteApply: Failed	Appears when a dtl fails to delete an entry from the table
IPsubnet vlans	vlanIpSubnetVlanChangeCallback: Failed to add an Entry	Appears when a dtl fails to add an entry for a VLAN add notify event.
IPsubnet vlans	vlanIpSubnetVlanChangeCallback: Failed to delete an Entry	Appears when a dtl fails to delete an entry for a VLAN delete notify event.

**Table 23. Mac-based VLANs Log Messages**

Component	Message	Cause
Mac based VLANS	MAC VLANs: Failed to save configuration	This message appears when save configuration of Mac VLANs failed
Mac based VLANS	vlanMacCnfrInitPhase1Process: Unable to create r/w lock for vlanMac	Appears when a read/write lock creations fails
Mac based VLANS	Unable to register for VLAN change callback	Appears when this component unable to register for VLAN change notifications
Mac based VLANS	vlanMacCnfrFiniPhase1Process: could not delete avl semaphore	Appears when a semaphore deletion of this component fails.
Mac based VLANS	vlanMacAddApply: Failed to add an entry	Appears when a dtl call fails to add an entry into the table
Mac based VLANS	vlanMacDeleteApply: Unable to delete an Entry	Appears when a dtl fails to delete an entry from the table

**Table 23. Mac-based VLANs Log Messages**

Component	Message	Cause
Mac based VLANs	vlanMacVlanChangeCallback: Failed to add an entry	Appears when a dtl fails to add an entry for a VLAN add notify event.
Mac based VLANs	vlanMacVlanChangeCallback: Failed to delete an entry	Appears when a dtl fails to delete an entry for a VLAN delete notify event.

**Table 24. 802.1x Log Messages**

Component	Message	Cause
802.1X	<i>function</i> : Failed calling dot1xIssueCmd	802.1X message queue is full
802.1X	<i>function</i> : EAP message not received from server	RADIUS server did not send required EAP message
802.1X	<i>function</i> : Out of System buffers	802.1X cannot process/transmit message due to lack of internal buffers
802.1X	<i>function</i> : could not set state to <authorized/unauthorized>, intf xxx	DTL call failed setting authorization state of the port
802.1X	dot1xApplyConfigData: Unable to <enable/disable> dot1x in driver	DTL call failed enabling/disabling 802.1X
802.1X	dot1xSendRespToServer: dot1xRadiusAccessRequestSend failed	Failed sending message to RADIUS server
802.1X	dot1xRadiusAcceptProcess: error calling radiusAccountingStart, ifIndex=xxx	Failed sending accounting start to RADIUS server
802.1X	<i>function</i> : failed sending terminate cause, intf xxx	Failed sending accounting stop to RADIUS server

**Table 25. IGMP Snooping Log Messages**

Component	Message	Cause
IGMP Snooping	<i>function</i> : osapiMessageSend failed	IGMP Snooping message queue is full
IGMP Snooping	Failed to set global igmp snooping mode to xxx	Failed to set global IGMP Snooping mode due to message queue being full
IGMP Snooping	Failed to set igmp snooping mode xxx for interface yyy	Failed to set interface IGMP Snooping mode due to message queue being full
IGMP Snooping	Failed to set igmp mrouter mode xxx for interface yyy	Failed to set interface multicast router mode due to IGMP Snooping message queue being full
IGMP Snooping	Failed to set igmp snooping mode xxx for VLAN yyy	Failed to set VLAN IGM Snooping mode due to message queue being full

**Table 25. IGMP Snooping Log Messages**

Component	Message	Cause
IGMP Snooping	Failed to set igmp mrouter mode %d for interface xxx on VLAN yyy	Failed to set VLAN multicast router mode due to IGMP Snooping message queue being full
IGMP Snooping	snoopCnfrInitPhase1Process: Error allocating small buffers	Could not allocate buffers for small IGMP packets
IGMP Snooping	snoopCnfrInitPhase1Process: Error allocating large buffers	Could not allocate buffers for large IGMP packets

**Table 26. GARP/GVRP/GMRP Log Messages**

Component	Message	Cause
GARP/GVRP/ GMRP	garpSpanState, garpIfStateChange, GarpIssueCmd, garpDot1sChangeCallBack, garpApiCnfrCommand, garpLeaveAllTimerCallBack, garpTimerCallBack: QUEUE SEND FAILURE:	The garpQueue is full, logs specifics of the message content like internal interface number, type of message, and so on.
GARP/GVRP/ GMRP	GarpSendPDU: QUEUE SEND FAILURE	The garpPduQueue is full, logs specific of the GPDU, internal interface number, VLAN id, buffer handle, and so on.
GARP/GVRP/ GMRP	garpMapIntfIsConfigurable, gmrpMapIntfIsConfigurable: Error accessing GARP/GMRP config data for interface %d in garpMapIntfIsConfigurable.	A default configuration does not exist for this interface. Typically a case when a new interface is created and has no pre-configuration.
GARP/GVRP/ GMRP	garpTraceMsgQueueUsage: garpQueue usage has exceeded fifty/eighty/ninety percent	Traces the buildup of message queue. Helpful in determining the load on GARP.
GARP/GVRP/ GMRP	gid_destroy_port: Error Removing port %d registration for vlan-mac %d - %02X:%02X:%02X:%02X:%02X:%02X	Mismatch between the gmd (gmrp database) and MFDB.
GARP/GVRP/ GMRP	gmd_create_entry: GMRP failure adding MFDB entry: vlan %d and address %s	MFDB table is full.



**Table 27. 802.3ad Log Messages**

Component	Message	Cause
802.3ad	dot3adReceiveMachine: received default event %x	Received a LAG PDU and the RX state machine is ignoring this LAGPDU
802.3ad	dot3adNimEventCompletionCallback, dot3adNimEventCreateCompletionCallback: DOT3AD: notification failed for event(%d), intf(%d), reason(%d)	The event sent to NIM was not completed successfully

**Table 28. FDB Log Message**

Component	Message	Cause
FDB	fdbSetAddressAgingTimeOut: Failure setting fid %d address aging timeout to %d	Unable to set the age time in the hardware

**Table 29. Double VLAN Tag Log Message**

Component	Message	Cause
Double Vlan Tag	dvlantagIntflsConfigurable: Error accessing dvlantag config data for interface %d	A default configuration does not exist for this interface. Typically a case when a new interface is created and has no pre-configuration.

**Table 30. IPv6 Provisioning Log Message**

Component	Message	Cause
IPv6 Provisioning	ipv6ProvIntflsConfigurable: Error accessing IPv6 Provisioning config data for interface %d	A default configuration does not exist for this interface. Typically a case when a new interface is created and has no pre-configuration.

**Table 31. MFDB Log Message**

Component	Message	Cause
MFDB	mfdbTreeEntryUpdate: entry does not exist	Trying to update a non-existing entry

**Table 32. 802.1Q Log Messages**

Component	Message	Cause
802.1Q	dot1qIssueCmd: Unable to send message %d to dot1qMsgQueue for vlan %d - %d msgs in queue	dot1qMsgQueue is full.
802.1Q	dot1qVlanCreateProcess: Attempt to create a vlan with an invalid vlan id %d ; VLAN %d not in range,	Accommodates for reserved vlan ids. that is, 4094 - x
802.1Q	dot1qMapIntflsConfigurable: Error accessing DOT1Q config data for interface %d in dot1qMapIntflsConfigurable.	A default configuration does not exist for this interface. Typically a case when a new interface is created and has no pre-configuration.
802.1Q	dot1qVlanDeleteProcess: Deleting the default VLAN	Typically encountered during clear Vlan and clear config
802.1Q	dot1qVlanMemberSetModify, dot1qVlanTaggedMemberSetModify: Dynamic entry %d can only be modified after it is converted to static	If this vlan is a learnt via GVRP then, we cannot modify its member set via management.

**Table 33. 802.1S Log Messages**

Component	Message	Cause
802.1S	dot1sIssueCmd: Dot1s Msg Queue is full!!!!Event: %u, on interface: %u, for instance: %u	The message Queue is full.
802.1S	dot1sStateMachineRxBpdu(): Rcvd BPDU Discarded	The current conditions, like port is not enabled or we are currently not finished processing another BPDU on the same interface, does not allow us to process this BPDU
802.1S	dot1sBpduTransmit(): could not get a buffer	Out of system buffers

**Table 34. Port Mac Locking Log Message**

Component	Message	Cause
Port Mac Locking	pmlMapIntflsConfigurable: Error accessing PML config data for interface %d in pmlMapIntflsConfigurable.	A default configuration does not exist for this interface. Typically a case when a new interface is created and has no pre-configuration.

Table 35. Protocol-based VLANs Log Messages

Component	Message	Cause
Protocol Based VLANs	pbVlanCnfgrInitPhase2Process: Unable to register NIM callback	Appears when nimRegisterIntfChange fails to register pbVlan for link state changes.
Protocol Based VLANs	pbVlanCnfgrInitPhase2Process: Unable to register pbVlan callback with vlans	Appears when vlanRegisterForChange fails to register pbVlan for vlan changes.
Protocol Based VLANs	pbVlanCnfgrInitPhase2Process: Unable to register pbVlan callback with nvStore	Appears when nvStoreRegister fails to register save and restore functions for configuration save.

## QoS

Table 36. ACL Log Messages

Component	Message	Cause
ACL	Total number of ACL rules (x) exceeds max (y) on intf i.	The combination of all ACLs applied to an interface has resulted in requiring more rules than the platform supports.
ACL	ACL <i>name</i> , rule x: This rule is not being logged	The ACL configuration has resulted in a requirement for more logging rules than the platform supports. The specified rule is functioning normally except for the logging action.
ACL	aclLogTask: error logging ACL rule trap for correlator <i>number</i>	The system was unable to send an SNMP trap for this ACL rule which contains a logging attribute.
ACL	IP ACL <i>number</i> : Forced truncation of one or more rules during config migration	While processing the saved configuration, the system encountered an ACL with more rules than is supported by the current version. This might happen when code is updated to a version supporting fewer rules per ACL than the previous version.

Table 37. CoS Log Message

Component	Message	Cause
COS	cosCnfgrInitPhase3Process: Unable to apply saved config -- using factory defaults	The COS component was unable to apply the saved configuration and has initialized to the factory default settings.

Table 38. DiffServ Log Messages

Component	Message	Cause
DiffServ	diffserv.c 165: diffServRestore Failed to reset DiffServ. Recommend resetting device	While attempting to clear the running configuration an error was encountered in removing the current settings. This might lead to an inconsistent state in the system and resetting is advised.
DiffServ	Policy invalid for service intf: "policy <i>name</i> , intfNum <i>x</i> , direction <i>y</i>	The DiffServ policy definition is not compatible with the capabilities of the interface specified. Check the platform release notes for information about configuration limitations.

## Routing/IPv6 Routing

Table 39. DHCP Relay Log Messages

Component	Message	Cause
DHCP relay	REQUEST hops field more than config value	The DHCP relay agent has processed a DHCP request whose HOPS field is larger than the maximum value allowed. The relay agent will not forward a message with a hop count greater than 4.
DHCP relay	Request's seconds field less than the config value	The DHCP relay agent has processed a DHCP request whose SECS field is larger than the configured minimum wait time allowed.
DHCP relay	processDhcpPacket: invalid DHCP packet type: %u\n	The DHCP relay agent has processed an invalid DHCP packet. Such packets are discarded by the relay agent.

Table 40. OSPFv2 Log Messages

Component	Message	Cause
OSPFv2	Best route client deregistration failed for OSPF Redist	OSPFv2 registers with the IPv4 routing table manager ("RTO") to be notified of best route changes. There are cases where OSPFv2 deregisters more than once, causing the second deregistration to fail. The failure is harmless.
OSPFv2	XX_Call() failure in _checkTimers for thread 0x869bcc0	An OSPFv2 timer has fired but the message queue that holds the event has filled up. This is normally a fatal error.

Table 40. OSPFv2 Log Messages (continued)

Component	Message	Cause
OSPFv2	Warning: OSPF LSDB is 90% full (22648 LSAs).	OSPFv2 limits the number of Link State Advertisements (LSAs) that can be stored in the link state database (LSDB). When the database becomes 90 or 95 percent full, OSPFv2 logs this warning. The warning includes the current size of the database.
OSPFv2	The number of LSAs, 25165, in the OSPF LSDB has exceeded the LSDB memory allocation.	When the OSPFv2 LSDB becomes full, OSPFv2 logs this message. OSPFv2 reoriginates its router LSAs with the metric of all nonstub links set to the maximum value to encourage other routers to not compute routes through the overloaded router.
OSPFv2	Dropping the DD packet because of MTU mismatch	OSPFv2 ignored a Database Description packet whose MTU is greater than the IP MTU on the interface where the DD was received.
OSPFv2	LSA Checksum error in LsUpdate, dropping LSID 1.2.3.4 checksum 0x1234.	OSPFv2 ignored a received link state advertisement (LSA) whose checksum was incorrect.

Table 41. OSPFv3 Log Messages

Component	Message	Cause
OSPFv3	Best route client deregistration failed for OSPFv3 Redist	OSPFv3 registers with the IPv6 routing table manager ("RTO6") to be notified of best route changes. There are cases where OSPFv3 deregisters more than once, causing the second deregistration to fail. The failure is harmless.
OSPFv3	Warning: OSPF LSDB is 90% full (15292 LSAs).	OSPFv3 limits the number of Link State Advertisements (LSAs) that can be stored in the link state database (LSDB). When the database becomes 90 or 95 percent full, OSPFv3 logs this warning. The warning includes the current size of the database.
OSPFv3	The number of LSAs, 16992, in the OSPF LSDB has exceeded the LSDB memory allocation.	When the OSPFv3 LSDB becomes full, OSPFv3 logs this message. OSPFv3 reoriginates its router LSAs with the R-bit clear indicating that OSPFv3 is overloaded.
OSPFv3	LSA Checksum error detected for LSID 1.2.3.4 checksum 0x34f5. OSPFv3 Database might be corrupted.	OSPFv3 periodically verifies the checksum of each LSA in memory. OSPFv3 logs this.

**Table 42. Routing Table Manager Log Messages**

Component	Message	Cause
Routing Table Manager	RTO is full. Routing table contains 8000 best routes, 8000 total routes.	The routing table manager, also called "RTO," stores a limited number of best routes, based on hardware capacity. When the routing table becomes full, RTO logs this alert. The count of total routes includes alternate routes, which are not installed in hardware.
Routing Table Manager	RTO no longer full. Bad adds: 10. Routing table contains 7999 best routes, 7999 total routes.	When the number of best routes drops below full capacity, RTO logs this notice. The number of bad adds might give an indication of the number of route adds that failed while RTO was full, but a full routing table is only one reason why this count is incremented.

**Table 43. VRRP Log Messages**

Component	Message	Cause
VRRP	Changing priority to 255 for virtual router with VRID 1 on interface 0/1	When the router is configured with the address being used as the virtual router ID, the router's priority is automatically set to the maximum value to ensure that the address owner becomes the VRRP master.
VRRP	Changing priority to 100 for virtual router with VRID 1 on interface 0/1	When the router is no longer the address owner, Switch CLI reverts the router's priority to the default.
VRRP	vrrpPacketValidate: Invalid TTL	VRRP ignored an incoming message whose time to live (TTL) in the IP header was not 255.

**Table 44. ARP Log Message**

Component	Message	Cause
ARP	ARP received mapping for IP address xxx to MAC address yyy. This IP address might be configured on two stations.	When we receive an ARP response with different MAC address from another station with the same IP address as ours. This might be a case of misconfiguration.

Table 45. RIP Log Message

Component	Message	Cause
RIP	RIP : discard response from xxx via unexpected interface	When RIP response is received with a source address not matching the incoming interface's subnet.

Table 46. DHCP6 Log Message

Component	Message	Cause
DHCP6	relay_to_server: Cannot relay to relay server intf xxx: not IPv6 enabled	Relay is enabled but neither the outgoing interface nor the server IP address is specified.

## Multicast

Table 47. Cache Log Messages

Component	Message	Cause
Cache	Out of memory when creating entry.	When we run out of memory while creating a new cache (MFC) entry
Cache	Out of memory when creating cache.	When we run out of memory while creating the cache itself

Table 48. IGMP Log Messages

Component	Message	Cause
IGMP	Error creating IGMP pipe Error opening IGMP pipe	When we fail to create / open IGMP pipe for Mcast control messages
IGMP	Error creating IGMP data pipe Error opening IGMP data pipe	When we fail to create / open IGMP data pipe for Mcast data messages
IGMP	Error getting memory for source record	When we are unable to allocate memory for a source record in the received IGMP V3 report
IGMP	Failed getting memory for new group	When we are unable to allocate memory for a group record in the received IGMP V3/V2/V1 report

**Table 49. IGMP-Proxy Log Messages**

Component	Message	Cause
IGMP-Proxy	Error getting memory for igmp host group record	When we are unable to allocate memory for the IGMP group record in the Host (Proxy) table
IGMP-Proxy	Error getting memory for source record	When we are unable to allocate memory for the IGMP source record in the Host (Proxy) table

**Table 50. PIM-SM Log Messages**

Component	Message	Cause
PIM-SM	PIM-SM not initialized	This message arises when trying to activate pimsm interfaces or receiving pimsm packets when pimsm component is not initialized.
PIM-SM	Unable to take xxx semaphore	This message is logged when failed to acquire semaphore to access source list or group list or candidate Rp list or virtual interface list. The xxx specifies the list for which the access is denied.
PIM-SM	Warning : Could not send packet type xxx (pimsm packet type) on rtrIfNum	this warning is logged when failed to send a pimsm control packet on the specified router interface.
PIM-SM	add_kernel_cache : memory allocation failed	This message is logged when there is insufficient memory to add a mroute entry into cache.
PIM_SM	Config error. Trying to add static RP. Dynamic RP with same ip addr exists	Router learns RP-group mapping through Bootstrap messages received.This message pops when the static RP is configured which conflicts the mapping learnt dynamically through Bootstrap messages.
PIM-SM	Inner xxx(source/group) address of register message is invalid	This log message appears when a register message is received with invalid inner ip source or group address.



**Table 51. PIM-DM Log Messages**

Component	Message	Cause
PIM-DM	Out of memory when creating xxx	This message is logged when there is insufficient memory to accommodate a new neighbor/(S,G) Entry, Prune, Graft, Join etc.
PIM-DM	Error entry->ll_xxx LL creation error	This message is logged when the SLL creation is Failed.
PIM-DM	pim_interface_set: Could not give taskSema	This message is logged when Task synchronization Semaphore release fails.
PIM-DM	Error initializing CACHE	This message is logged when the PIM-DM (S,G) entry Cache table initialization fails.
PIM-DM	Error creating PIM-DM pipe	This message is logged when the PIM-DM Pipe (that receives control messages) creation fails.

**Table 52. DVMRP Log Messages**

Component	Message	Cause
DVMRP	dvmp_send_graft: failed getting memory for graft	Failed to allocate memory while sending a graft
DVMRP	dvmp_register_neighbor: failed getting memory for nbr	Failed to allocate memory while registering a neighbor
DVMRP	dvmp_recv_prune: failed getting memory for prune	Failed to allocate memory while receiving a prune
DVMRP	dvmp_new_route: failed getting memory for route	Failed to get memory for a new route entry
DVMRP	dvmp_prepare_routes: failed getting memory for dvmp_ann_rt	Failed to get memory while announcing a new route entry

## Stacking

**Table 53. EDB Log Message**

Component	Message	Cause
EDB	EDB Callback: Unit Join: <num>.	Unit <num> has joined the stack.

## Technologies

Table 54. System General Error Messages

Component	Message	Cause
OS	Invalid USP unit = x, slot = x, port =x	A port was not able to be translated correctly during the receive.
OS	In hapiBroadSystemMacAddress call to 'bcm_l2_addr_add' - FAILED : x	Failed to add an L2 address to the MAC table. This should only happen when a hash collision occurs or the table is full.
OS	Failed installing mirror action - rest of the policy applied successfully	A previously configured probe port is not being used in the policy. The release notes state that only a single probe port can be configured
OS	Policy x does not contain rule x	The rule was not added to the policy due to a discrepancy in the rule count for this specific policy . Additionally, the message can be displayed when an old rule is being modified, but the old rule is not in the policy
OS	ERROR: policy x, tmpPolicy x, size x, data x x x x x x x x	An issue installing the policy due to a possible duplicate hash
OS	ACL x not found in internal table	Attempting to delete a non-existent ACL
OS	ACL internal table overflow	Attempting to add an ACL to a full table
OS	In hapiBroadQosCosQueueConfig, Failed to configure minimum bandwidth. Available bandwidth x	Attempting to configure the bandwidth beyond its capabilities
OS	USL: failed to put sync response on queue	A response to a sync request was not enqueued. This could indicate that a previous sync request was received after it was timed out
OS	USL: failed to sync ipmc table on unit=x	Either the transport failed or the message was dropped
OS	usl_task_ipmc_msg_send(): failed to send with x	Either the transport failed or the message was dropped
OS	USL: No available entries in the STG table	The Spanning Tree Group table is full in USL
OS	USL: failed to sync stg table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	USL: A Trunk doesn't exist in USL	Attempting to modify a Trunk that doesn't exist

Table 54. System General Error Messages

Component	Message	Cause
OS	USL: A Trunk being created by bcmx already existed in USL	Possible synchronization issue between the application, hardware, and sync layer
OS	USL: A Trunk being destroyed doesn't exist in USL	Possible synchronization issue between the application, hardware, and sync layer.
OS	USL: A Trunk being set doesn't exist in USL	Possible synchronization issue between the application, hardware, and sync layer.
OS	USL: failed to sync trunk table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	USL: Mcast entry not found on a join	Possible synchronization issue between the application, hardware, and sync layer
OS	USL: Mcast entry not found on a leave	Possible synchronization issue between the application, hardware, and sync layer
OS	USL: failed to sync dvlan data on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	USL: failed to sync policy table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	USL: failed to sync VLAN table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	Invalid LAG id x	Possible synchronization issue between the BCM driver and HAPI
OS	Invalid uport calculated from the BCM uport bcmx_l2_addr->lport = x	Uport not valid from BCM driver.
OS	Invalid USP calculated from the BCM uport\nbcmx_l2_addr->lport = x	USP not able to be calculated from the learn event for BCM driver.
OS	Unable to insert route R/P	Route 'R' with prefix 'P' could not be inserted in the hardware route table. A retry will be issued.
OS	Unable to Insert host H	Host 'H' could not be inserted in hardware host table. A retry will be issued.
OS	USL: failed to sync L3 Intf table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	USL: failed to sync L3 Host table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued

Table 54. System General Error Messages

Component	Message	Cause
OS	USL: failed to sync L3 Route table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	USL: failed to sync initiator table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	USL: failed to sync terminator table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued
OS	USL: failed to sync ip-multicast table on unit=x	Could not synchronize unit x due to a transport failure or API issue on remote unit. A synchronization retry will be issued

## O/S Support

Table 55. OSAPI Log Messages

Component	Message	Cause
OSAPI	ftruncate failed – File resides on a read-only file system.	ftruncate is called to correctly set the file's size in the file system after a write. The file system is R/W so this msg indicates that the file system may be corrupted.
OSAPI	ftruncate failed – File is open for reading only.	ftruncate is called to correctly set the file's size in the file system after a write. The file is opened for R/W so this msg indicates that the file system may be corrupted.
OSAPI	ftruncate failed – File descriptor refers to a file on which this operation is impossible.	ftruncate is called to correctly set the file's size in the file system after a write. This msg indicates that the file system may be corrupted.
OSAPI	ftruncate failed – Returned an unknown code in errno.	ftruncate is called to correctly set the file's size in the file system after a write. This msg indicates that the file system may be corrupted.
OSAPI	ping: bad host!	The address requested to ping cannot be converted to an Internet address.
OSAPI	osapiTaskDelete: Failed for (XX) error YYY	The requested task cannot be deleted because: the requested deletion is called from an ISR, the task is already deleted, or the task ID is invalid.

Table 55. OSAPI Log Messages (continued)

Component	Message	Cause
OSAPI	osapiCleanupIf: NetIPGet	During the call to remove the interface from the route table, the attempt to get an ipv4 interface address from the stack failed.
OSAPI	osapiCleanupIf: NetMaskGet	During the call to remove the interface from the route table ,the attempt to get the ipv4 interface mask from the stack failed.
OSAPI	osapiCleanupIf: NetIpDel	During the call to remove the interface from the route table, the attempt to delete the primary ipv4 address from the stack failed.
OSAPI	osapiSemaTake failed	The requested semaphore cannot be taken because: the call is made from an ISR or the semaphore ID is invalid.

# Command List

{deny   permit} (IP ACL) .....	300
{deny   permit} (IPv6) .....	306
{deny   permit} (MAC ACL) .....	294
aaa accounting .....	483
aaa authentication dot1x .....	482
aaa authentication enable .....	481
aaa authentication login .....	480
aaa authorization .....	486
aaa ias-user username .....	489
aaa session-id .....	489
absolute .....	310
access-list .....	298
accounting (console/Telnet/SSH) .....	484
acl-trapflags .....	303
addport .....	109
arp .....	228
arp access-list .....	150
arp cachesize .....	229
arp dynamicrenew .....	229
arp purge .....	230
arp resptime .....	230
arp retries .....	230
arp timeout .....	231
assign-queue .....	281
authorization (console/Telnet/SSH) .....	487
authorization network radius .....	501
auto-negotiate .....	19
auto-negotiate all .....	20
auto-voip .....	312
auto-voip oui .....	313
auto-voip oui-based priority .....	313
auto-voip protocol-based .....	314
auto-voip vlan .....	313
boot autoinstall start .....	330
boot autoinstall stop .....	330
boot host auto-save .....	330
boot host dhcp .....	331
boot host retry-count .....	330

boot system	332
bootfile	386
bootpdhcprelay cidoptmode	252
bootpdhcprelay maxhopcount	253
bootpdhcprelay minwaittime	253
bridge aging-time	211
cablestatus	425
capture {file   remote   line}	400
capture {start   stop}	400
capture file size	402
capture line wrap	402
capture remote port	401
class	282
class-map	272
class-map rename	273
classofservice dot1p-mapping	263
classofservice ip-dscp-mapping	263
classofservice trust	264
clear aaa ias-users	490
clear arp-cache	231
clear arp-switch	231
clear config	367
clear counters	368
clear dot1x authentication-history	87
clear dot1x statistics	80
clear eventlog	367
clear green-mode statistics	525
clear host	398
clear igmpsnooping	368
clear ip address-conflict-detect	431
clear ip arp inspection statistics	153
clear ip dhcp binding	391
clear ip dhcp conflict	392
clear ip dhcp server statistics	391
clear ip dhcp snooping binding	146
clear ip dhcp snooping statistics	146
clear ip helper statistics	254
clear ip route all	240
clear ip route counters	241
clear isdp counters	215
clear isdp table	215
clear lldp remote-data	185
clear lldp statistics	185
clear logging buffered	367
clear logging email statistics	363

clear mac-addr-table .....	367
clear pass .....	368
clear port-channel .....	368
clear radius statistics .....	81
clear traplog .....	368
clear vlan .....	368
client-identifier .....	383
client-name .....	383
clock set .....	378
clock summer-time date .....	379
clock summer-time recurring .....	378
clock timezone .....	378
configuration .....	449
conform-color .....	282
copy .....	371
copy (pre-login banner) .....	520
cos-queue min-bandwidth .....	264
cos-queue random-detect .....	265
cos-queue strict .....	265
crypto certificate generate .....	459
crypto key generate dsa .....	460
crypto key generate rsa .....	460
debug aaa accounting .....	424
debug aaa authorization .....	424
debug arp .....	403
debug auto-voip .....	403
debug clear .....	404
debug console .....	404
debug crashlog .....	404
debug dhcp packet .....	405
debug dot1x packet .....	406
debug igmpsnooping packet .....	406
debug igmpsnooping packet receive .....	407
debug igmpsnooping packet transmit .....	406
debug ip acl .....	408
debug ip dvmrp packet .....	409
debug ip igmp packet .....	409
debug ip mcache packet .....	410
debug ip pimdm packet .....	410
debug ip pimsm packet .....	411
debug ip vrrp .....	411
debug ipv6 dhcp .....	412
debug ipv6 mcache packet .....	412
debug ipv6 mld packet .....	412



debug ipv6 ospfv3 packet .....	417
debug ipv6 pimdm packet .....	413
debug ipv6 pimsm packet .....	413
debug isdp packet .....	218
debug lacp packet .....	414
debug mldsnooping packet .....	414
debug ospf packet .....	415
debug ping packet .....	418
debug rip packet .....	419
debug sflow packet .....	420
debug spanning-tree bpdu .....	420
debug spanning-tree bpdu receive .....	421
debug spanning-tree bpdu transmit .....	422
debug tacacs packet .....	514
debug udd packet .....	423
debug udd packet receive .....	423
debug udd packet transmit .....	423
default-router .....	384
delete .....	332
deleteport (Global Config) .....	110
deleteport (Interface Config) .....	109
description .....	20
dhcp client vendor-id-option .....	137
dhcp client vendor-id-option-string .....	137
dhcp l2relay .....	133
dhcp l2relay circuit-id vlan .....	133
dhcp l2relay remote-id vlan .....	134
dhcp l2relay trust .....	134
dhcp l2relay vlan .....	134
diffserv .....	271
dir usb .....	441
disconnect .....	467
dns-server .....	384
domain-name (DHCP Pool Config) .....	387
domain-name (Global Config) .....	488
domain-name enable (Global Config) .....	488
dos-control all .....	202
dos-control firstfrag .....	203
dos-control icmp .....	205
dos-control icmpfrag .....	209
dos-control icmpv4 .....	209
dos-control icmpv6 .....	209
dos-control l4port .....	204
dos-control sipdip .....	202
dos-control smacdmac .....	205

dos-control tcpfinurgpsh .....	208
dos-control tcpflag .....	204
dos-control tcpflagseq .....	206
dos-control tcpfrag .....	203
dos-control tcpoffset .....	207
dos-control tcpport .....	206
dos-control tcpsyn .....	207
dos-control tcpsynfin .....	208
dos-control udpport .....	206
dot1x dynamic-vlan enable .....	87
dot1x eapolflood .....	81
dot1x guest-vlan .....	81
dot1x initialize .....	82
dot1x mac-auth-bypass .....	82
dot1x max-req .....	82
dot1x max-users .....	83
dot1x pae .....	94
dot1x port-control .....	83
dot1x port-control all .....	83
dot1x re-authenticate .....	84
dot1x re-authentication .....	84
dot1x supplicant max-start .....	95
dot1x supplicant port-control .....	94
dot1x supplicant timeout auth-period .....	96
dot1x supplicant timeout held-period .....	96
dot1x supplicant timeout start-period .....	96
dot1x supplicant user .....	97
dot1x system-auth-control .....	85
dot1x system-auth-control monitor .....	88
dot1x timeout .....	85
dot1x unauthenticated-vlan .....	86
dot1x user .....	87
drop .....	281
dvlan-tunnel ethertype .....	63
enable (Privileged EXEC access) .....	446
enable authentication .....	451
enable password .....	369
encapsulation .....	240
erase startup-config .....	331
ezconfig .....	444
filedescr .....	332
flowcontrol .....	107
green-mode eee .....	525
green-mode eee-lpi-history .....	530

green-mode energy-detect	524
hardware-address	385
host	385
interface	19
interface lag	19
interface loopback	26
interface vlan	19
ip access-group	303
ip access-list	300
ip access-list rename	300
ip accounting exec	484
ip address	234
ip address dhcp	235
ip address-conflict-detect run	431
ip arp inspection filter	150
ip arp inspection limit	149
ip arp inspection trust	149
ip arp inspection validate	148
ip arp inspection vlan	148
ip arp inspection vlan logging	148
ip default-gateway	236
ip dhcp bootp automatic	390
ip dhcp conflict logging	391
ip dhcp excluded-address	389
ip dhcp ping packets	390
ip dhcp pool	382
ip dhcp snooping	138
ip dhcp snooping binding	140
ip dhcp snooping database	139
ip dhcp snooping database write-delay	139
ip dhcp snooping limit	141
ip dhcp snooping log-invalid	141
ip dhcp snooping trust	141
ip dhcp snooping verify mac-address	139
ip dhcp snooping vlan	138
ip domain list	396
ip domain lookup	395
ip domain name	395
ip domain retry	397
ip domain timeout	398
ip helper enable	256
ip helper-address (Global Config)	255
ip helper-address (Interface Config)	256
ip helper-address discard	257
ip host	397

ip http authentication	462
ip http java	461
ip http secure-port	466
ip http secure-protocol	466
ip http secure-server	461
ip http secure-session hard-timeout	465
ip http secure-session maxsessions	464
ip http secure-session soft-timeout	464
ip http server	461
ip http session hard-timeout	462
ip http session maxsessions	463
ip http session soft-timeout	463
ip https authentication	465
ip icmp echo-reply	261
ip icmp error-interval	261
ip local-proxy-arp	228
ip management	446
ip mtu	239
ip name server	396
ip netdirbcast	239
ip proxy-arp	229
ip redirects	260
ip route	237
ip route default	238
ip route distance	238
ip routing	234
ip ssh	457
ip ssh protocol	457
ip ssh server enable	457
ip telnet server enable	452
ip unreachable	260
ip verify binding	140
ip verify source	142
ipv6 access-list	306
ipv6 access-list rename	306
ipv6 host	397
ipv6 traffic-filter	307
isdp advertise-v2	214
isdp enable	214
isdp holdtime	213
isdp run	213
isdp timer	214
key (TACACS Config)	517
lACP actor admin key	111

lacp actor admin state individual	111
lacp actor admin state longtimeout	112
lacp actor admin state passive	112
lacp actor port priority	113
lacp actor system priority	113
lacp admin key	110
lacp collector max-delay	110
lacp partner admin key	114
lacp partner admin state individual	114
lacp partner admin state longtimeout	115
lacp partner admin state passive	115
lacp partner port id	116
lacp partner port priority	116
lacp partner system id	117
lacp partner system priority	117
lease	385
length	351
line	449
lldp med	191
lldp med all	193
lldp med confignotification	192
lldp med confignotification all	193
lldp med faststartrepeatcount	193
lldp med transmit-tlv	192
lldp med transmit-tlv all	194
lldp notification	184
lldp notification-interval	185
lldp receive	183
lldp timers	183
lldp transmit	182
lldp transmit-mgmt	184
lldp transmit-tlv	183
logging buffered	353
logging buffered wrap	353
logging cli-command	354
logging console	354
logging email	358
logging email from-addr	360
logging email logtime	361
logging email message-type subject	360
logging email message-type to-addr	359
logging email test message-type	361
logging email urgent	359
logging host	354
logging host remove	355

logging persistent .....	358
logging syslog .....	355
logging syslog source-interface .....	355
logging traps .....	361
login authentication .....	450
logout .....	369
mac access-group .....	296
mac access-list extended .....	293
mac access-list extended rename .....	294
mac address-table multicast forbidden-unregistered vlan .....	160
mac address-table multicast forward-all vlan .....	161
mac address-table multicast forward-unregistered vlan .....	161
macfilter .....	129
macfilter adddest .....	130
macfilter adddest all .....	130
macfilter addsrc .....	131
macfilter addsrc all .....	131
mail-server .....	363
mark cos .....	283
mark cos-as-sec-cos .....	283
mark ip-dscp .....	283
mark ip-precedence .....	284
match any .....	274
match class-map .....	274
match cos .....	275
match destination-address mac .....	275
match dstip .....	276
match dstip6 .....	276
match dstl4port .....	276
match ethertype .....	273
match ip dscp .....	277
match ip precedence .....	277
match ip tos .....	277
match ip6flowlbl .....	275
match protocol .....	278
match secondary cos .....	275
match secondary-vlan .....	280
match source-address mac .....	279
match srcip .....	279
match srcip6 .....	279
match srcl4port .....	279
match vlan .....	280
memory free low-watermark processor .....	352
mirror .....	281

mode dot1q-tunnel .....	63
mode dvlan-tunnel .....	64
monitor session .....	125
mtu .....	20
mvr .....	220
mvr group .....	220
mvr immediate .....	222
mvr mode .....	221
mvr querytime .....	221
mvr type .....	223
mvr vlan .....	222
mvr vlan group .....	223
netbios-name-server .....	387
netbios-node-type .....	388
network (DHCP Pool Config) .....	386
network javamode .....	447
network mac-address .....	446
network mac-type .....	447
network mgmt_vlan .....	46
next-server .....	388
no clock summer-time .....	380
option .....	389
password (AAA IAS User Configuration) .....	490
password (Mail Server Config) .....	364
passwords aging .....	474
passwords history .....	474
passwords lock-out .....	475
passwords min-length .....	473
passwords strength exclude-keyword .....	478
passwords strength maximum consecutive-characters .....	477
passwords strength maximum repeated-characters .....	478
passwords strength minimum character-classes .....	478
passwords strength minimum lowercase-letters .....	476
passwords strength minimum numeric-characters .....	476
passwords strength minimum special-characters .....	477
passwords strength minimum uppercase-letters .....	475
passwords strength-check .....	475
periodic time .....	311
periodic .....	310
permit ip host mac host .....	151
ping .....	369
poe .....	318
poe detection .....	319
poe high-power .....	319
poe power limit .....	320

poe power management	320
poe priority	321
poe reset	322
poe timer schedule name	322
poe traps	323
poe usagethreshold	323
police-simple	284
police-two-rate	285
policy-map	285
policy-map rename	286
port (Mail Server Config)	364
port (TACACS Config)	517
port lacpmode	118
port lacpmode enable all	119
port lacptimeout (Global Config)	120
port lacptimeout (Interface Config)	119
port-channel adminmode	120
port-channel linktrap	120
port-channel load-balance	121
port-channel local-preference	118
port-channel name	122
port-channel static	118
port-channel system priority	122
port-security	178
port-security mac-address	180
port-security mac-address move	180
port-security mac-address sticky	180
port-security max-dynamic	179
port-security max-static	179
priority (TACACS Config)	517
private-vlan	72
process cpu threshold	347
protocol group	53
protocol vlan group	53
protocol vlan group all	54
quit	371
radius accounting mode	501
radius server attribute	502
radius server host	502
radius server key	504
radius server msgauth	505
radius server primary	505
radius server retransmit	506
radius server timeout	506



random-detect exponential weighting-constant	266
random-detect queue-parms	266
redirect	282
release dhcp	236
reload	371
remote-span	56
renew dhcp	236
rmon alarm	433
rmon collection history	435
rmon event	435
rmon hcalarm	434
routing	234
save	371
script apply	519
script delete	519
script list	519
script show	520
script validate	520
security (Mail Server Config)	363
serial baudrate	450
serial timeout	450
service dhcp	390
service-policy	286
session-limit	454
session-timeout	454
set clbanner	521
set garp timer join	74
set garp timer leave	74
set garp timer leaveall	75
set gmrp adminmode	78
set gmrp interfacemode	78
set gvrp adminmode	76
set gvrp interfacemode	77
set igmp	155
set igmp fast-leave	156
set igmp groupmembership-interval	157
set igmp header-validation	160
set igmp interfacemode	155
set igmp maxresponse	157
set igmp mcrtrexpiretime	158
set igmp mrouter	159
set igmp mrouter interface	159
set igmp querier	164
set igmp querier election participate	166
set igmp querier query-interval	165

set igmp querier timer expiry .....	165
set igmp querier version .....	165
set igmp report-suppression .....	159
set mld .....	168
set mld fast-leave .....	169
set mld groupmembership-interval .....	170
set mld interfacemode .....	169
set mld maxresponse .....	170
set mld mcrtexpiretime .....	171
set mld mrouter .....	171
set mld mrouter interface .....	172
set mld querier .....	175
set mld querier election participate .....	176
set mld querier query_interval .....	176
set mld querier timer expiry .....	176
set prompt .....	521
sflow poller .....	428
sflow receiver .....	426
sflow sampler .....	427
show aaa ias-users .....	491
show access-lists .....	305
show accounting .....	485
show accounting methods .....	485
show arp .....	232
show arp access-list .....	154
show arp brief .....	232
show arp switch (Address Resolution Protocol commands) .....	233
show arp switch (system information and statistics commands) .....	333
show authentication methods .....	89
show authorization methods .....	487
show autoinstall .....	329
show auto-voip .....	314
show auto-voip oui-table .....	316
show bootpdhcprelay .....	254
show bootvar .....	332
show capture packets .....	402
show class-map .....	288
show classofservice dot1p-mapping .....	267
show classofservice ip-dscp-mapping .....	268
show classofservice ip-precedence-mapping .....	268
show classofservice trust .....	269
show clock .....	382
show dhcp client vendor-id-option .....	138
show dhcp I2relay agent-option vlan .....	136

show dhcp l2relay all	135
show dhcp l2relay interface	135
show dhcp l2relay stats interface	136
show dhcp lease	237
show diffserv	289
show diffserv service	291
show diffserv service brief	291
show domain-name	489
show dos-control	210
show dot1q-tunnel	64
show dot1x	89
show dot1x authentication-history	88
show dot1x clients	93
show dot1x users	94
show dvlan-tunnel	65
show eventlog	333
show fiber-ports optics	343
show fiber-ports optics-info	344
show flowcontrol	108
show forwardingdb agetime	212
show garp	76
show gmrp configuration	79
show green-mode	526
show green-mode eee-lpi-history interface	530
show gvrp configuration	77
show hardware	334
show hosts	399
show igmpsnooping	161
show igmpsnooping mrouter interface	162
show igmpsnooping mrouter vlan	163
show igmpsnooping querier	166
show interface	335
show interface counters	336
show interface ethernet	337
show interface ethernet switchport	73
show interface loopback	26
show interfaces cos-queue	269
show interfaces random-detect	270
show interfaces switchport	61
show interfaces switchport (for a group ID)	70
show ip access-lists	304
show ip address-conflict	431
show ip arp inspection	151
show ip arp inspection interfaces	153
show ip arp inspection statistics	152

show ip brief	241
show ip dhcp binding	392
show ip dhcp conflict	394
show ip dhcp global configuration	392
show ip dhcp pool configuration	393
show ip dhcp server statistics	393
show ip dhcp snooping	142
show ip dhcp snooping binding	143
show ip dhcp snooping database	144
show ip dhcp snooping interfaces	144
show ip dhcp snooping statistics	145
show ip helper statistics	259
show ip helper-address	258
show ip http	466
show ip interface	242
show ip interface brief	243
show ip protocols	244
show ip route	245
show ip route ecmp-groups	247
show ip route preferences	250
show ip route summary	248
show ip source binding	147
show ip ssh	459
show ip stats	250
show ip verify source	146
show ip vlan	252
show ipv6 access-lists	308
show isdp	215
show isdp entry	216
show isdp interface	216
show isdp neighbors	216
show isdp traffic	217
show lacp actor	123
show lacp partner	123
show lldp	186
show lldp interface	186
show lldp local-device	190
show lldp local-device detail	190
show lldp med	194
show lldp med interface	195
show lldp med local-device detail	196
show lldp med remote-device	198
show lldp med remote-device detail	199
show lldp remote-device	188

show lldp remote-device detail	189
show lldp statistics	187
show logging	356
show logging buffered	357
show logging email config	362
show logging email statistics	362
show logging hosts	357
show logging traplogs	357
show loginsession	467
show mac access-lists	297
show mac address-table multicast filtering	163
show mac-address-table gmrp	80
show mac-address-table igmpsnooping	163
show mac-address-table mldsnooping	174
show mac-address-table multicast	212
show mac-address-table static	132
show mac-address-table staticfiltering	132
show mac-address-table stats	212
show mac-addr-table	345
show mail-server config	364
show mbuf total	348
show mldsnooping	172
show mldsnooping mrouter interface	173
show mldsnooping mrouter vlan	174
show mldsnooping querier	177
show monitor session	127
show mvr	223
show mvr interface	225
show mvr members	224
show mvr traffic	226
show network	448
show passwords configuration	479
show passwords result	480
show poe	324
show poe pd	327
show poe port configuration	325
show poe port info	326
show policy-map	289
show policy-map interface	292
show port	24
show port advertise	23
show port description	25
show port protocol	24
show port status	25
show port-channel	124

show port-channel brief .....	124
show port-channel system priority .....	125
show port-security .....	181
show port-security dynamic .....	181
show port-security static .....	182
show port-security violation .....	182
show process cpu .....	347
show radius .....	507
show radius accounting .....	510
show radius accounting statistics .....	511
show radius servers .....	508
show radius statistics .....	512
show rmon .....	436
show rmon collection history .....	436
show rmon events .....	436
show rmon hcalarms .....	437
show rmon history .....	436
show rmon log .....	437
show rmon statistics interface .....	437
show routing heap summary .....	251
show running-config .....	349
show running-config interface .....	350
show serial .....	451
show service-policy .....	293
show sflow agent .....	428
show sflow pollers .....	429
show sflow receivers .....	429
show sflow samplers .....	430
show snmpcommunity .....	499
show snmptrap .....	499
show snmp .....	380
show snmp client .....	380
show snmp server .....	381
show spanning-tree .....	38
show spanning-tree brief .....	39
show spanning-tree interface .....	40
show spanning-tree mst port detailed .....	41
show spanning-tree mst port summary .....	43
show spanning-tree mst port summary active .....	44
show spanning-tree mst summary .....	44
show spanning-tree summary .....	45
show spanning-tree vlan .....	46
show storm-control .....	106
show switchport protected .....	69

show sysinfo .....	350
show tacacs .....	518
show tech-support .....	350
show telnet .....	456
show telnetcon .....	456
show terminal length .....	352
show time-range .....	311
show trapflags .....	500
show udd .....	439
show usb device .....	440
show users .....	471
show users accounts .....	472
show users accounts detail .....	472
show users login-history .....	473
show users long .....	473
show version .....	334
show vlan .....	56
show vlan association mac .....	58
show vlan association subnet .....	58
show vlan brief .....	57
show vlan port .....	57
show vlan private-vlan .....	73
show vlan remote-span .....	128
show voice vlan .....	67
shutdown .....	21
shutdown all .....	21
snmp trap link-status .....	498
snmp trap link-status all .....	498
snmp-server .....	491
snmp-server community .....	491
snmp-server community ipaddr .....	492
snmp-server community ipmask .....	492
snmp-server community mode .....	493
snmp-server community ro .....	493
snmp-server community rw .....	494
snmp-server enable traps .....	494
snmp-server enable traps linkmode .....	495
snmp-server enable traps multiusers .....	495
snmp-server enable traps stpmode .....	495
snmp-server enable traps violation .....	494
snmptrap .....	496
snmptrap ipaddr .....	497
snmptrap mode .....	497
snmptrap snmpversion .....	496
sntp broadcast client poll-interval .....	375

snmp client mode .....	375
snmp client port .....	376
snmp server .....	377
snmp unicast client poll-interval .....	376
snmp unicast client poll-retry .....	377
snmp unicast client poll-timeout .....	376
spanning-tree .....	27
spanning-tree auto-edge .....	27
spanning-tree bpdupfilter .....	28
spanning-tree bpdupfilter default .....	28
spanning-tree bpdupflood .....	29
spanning-tree bpdupforwarding .....	37
spanning-tree bpduguard .....	29
spanning-tree bpdumigrationcheck .....	29
spanning-tree configuration name .....	30
spanning-tree configuration revision .....	30
spanning-tree edgeport .....	30
spanning-tree edgeport all .....	37
spanning-tree forceversion .....	31
spanning-tree forward-time .....	31
spanning-tree guard .....	32
spanning-tree max-age .....	33
spanning-tree max-hops .....	33
spanning-tree mst .....	33
spanning-tree mst instance .....	35
spanning-tree mst priority .....	35
spanning-tree mst vlan .....	36
spanning-tree port mode .....	36
spanning-tree port mode all .....	37
spanning-tree tcnguard .....	32
speed .....	22
speed all .....	22
sshcon maxsessions .....	458
sshcon timeout .....	458
storm-control broadcast (Global Config) .....	99
storm-control broadcast (Interface Config) .....	98
storm-control broadcast level (Global Config) .....	99
storm-control broadcast level (Interface Config) .....	98
storm-control broadcast rate (Global Config) .....	100
storm-control broadcast rate (Interface Config) .....	99
storm-control multicast (Global Config) .....	102
storm-control multicast (Interface Config) .....	101
storm-control multicast level (Global Config) .....	102
storm-control multicast level (Interface Config) .....	101



storm-control multicast rate (Global Config) .....	103
storm-control multicast rate (Interface Config) .....	101
storm-control unicast (Global Config) .....	105
storm-control unicast (Interface Config) .....	103
storm-control unicast level (Global Config) .....	105
storm-control unicast level (Interface Config) .....	104
storm-control unicast rate (Global Config) .....	106
storm-control unicast rate (Interface Config) .....	104
switchport access vlan .....	61
switchport mode .....	59
switchport mode private-vlan .....	72
switchport private-vlan .....	71
switchport protected (Global Config) .....	68
switchport protected (Interface Config) .....	69
switchport trunk allowed vlan .....	60
switchport trunk native vlan .....	60
tacacs-server host .....	514
tacacs-server key .....	515
tacacs-server keystring .....	515
tacacs-server source interface .....	516
tacacs-server timeout .....	516
telnet .....	452
telnetcon maxsessions .....	454
telnetcon timeout .....	455
terminal length .....	351
timeout (TACACS Config) .....	517
time-range .....	309
traceroute .....	365
traceroute ipv6 .....	367
traffic-shape .....	267
transport input telnet .....	453
transport output telnet .....	453
udld enable (Global Config) .....	438
udld enable (Interface Config) .....	439
udld message time .....	438
udld port .....	439
udld reset .....	439
udld timeout interval .....	438
update bootcode .....	333
username (Global Config) .....	468
username (Mail Server Config) .....	364
username name nopassword .....	469
username snmpv3 accessmode .....	470
username snmpv3 authentication .....	470
username snmpv3 encryption .....	471

username unlock .....	469
vlan .....	47
vlan (Private VLAN) .....	73
vlan acceptframe .....	47
vlan association mac .....	55
vlan association subnet .....	55
vlan database .....	46
vlan ingressfilter .....	48
vlan makestatic .....	48
vlan name .....	48
vlan participation .....	49
vlan participation all .....	49
vlan port acceptframe all .....	50
vlan port ingressfilter all .....	50
vlan port priority all .....	67
vlan port pvid all .....	51
vlan port tagging all .....	51
vlan priority .....	68
vlan protocol group .....	52
vlan protocol group add protocol .....	52
vlan protocol group name .....	52
vlan pvid .....	54
vlan routing .....	251
vlan tagging .....	55
voice vlan (Global Config) .....	65
voice vlan (Interface Config) .....	66
voice vlan data priority .....	66
write memory .....	374