



Ubiquiti EP-R6 | Router | EdgeMAX EdgePoint, 5x RJ45 1000Mb/s PoE, 1x SFP



link to the product:

<https://www.batna24.com/pt/p/routery/ubiquiti-ep-r6-router-edgemax-edgepoint-5x-rj45-1000mb-s-poe-1x-sfp>

Price: **465,40 zł** gross / 378,37 zł net



Manufacturer: UBIQUITI


Referention number: DNXEKOHQLRMNGI



Full product description


Intelligent WISP Checkpoint com FiberProtect™

EdgePoint by Ubiquiti representa uma série de produtos que foram concebidos para serem os primeiros dispositivos de **pontos de controle WISP** do mercado. Ele possui recursos de roteamento **EdgeMAX**, fornece transferência de informações sobre fibra e recursos abrangentes de energia. O EdgePoint apresenta o **FiberProtect**, que elimina os danos por descarga eletrostática (ESD) e **reduz a interferência eletromagnética** (EMI), melhorando muito a qualidade do sinal de dados para conexões de longa distância.




Interface de usuário intuitiva

O EdgePoint fornece uma interface gráfica projetada para facilitar o uso e a configuração. Pode ser acessado através de uma porta de rede e de uma página web. O gerenciamento intuitivo do dispositivo é fornecido através de uma vista de porta virtual que exibe a conectividade física, velocidade e status.



EdgeOS - o sistema operacional avançado com recursos confiáveis

- Interfaces VLAN para segmentação de rede
- Roteamento estático e suporte a protocolos de roteamento: OSPF, RIP e BGP
- Políticas de Firewall e NAT
- serviços de DHCP
- Qualidade de Serviço (QoS)
- Ferramentas de administração e monitoramento da rede
- Administrador e usuário da conta
- Suporte abrangente a IPv6



Configuração via CLI

CLI fornece uma configuração de linha de comando rápida e flexível. É possível gerenciar configurações, monitorar todas as funcionalidades

avançadas e acessar diretamente ferramentas padrão do Linux, comandos shell, bem como acessar o CLI via **SSH**, **Telnet**.

```
CLI

Welcome to EdgeOS

By logging in, accessing, or using the Ubiquiti product, you
acknowledge that you have read and understood the Ubiquiti
License Agreement (available in the Web UI at, by default,
http://192.168.1.1) and agree to be bound by its terms.

ubnt login: ubnt
Password:
Last login: Sun Jun 1 10:08:30 UTC 2014 on pts/0
Linux 3.10.14-UBNT #1 SMP Mon Dec 15 12:14:34 PST 2014 mips
Welcome to EdgeOS
ubnt#ubnt:~$ show
arp                firewall          login            tech-support
bridge             flow-accounting  set              shot
configuration      hardware         sip              update
conntrack          history          openvpn          upnp2
date               host             pppoe-server     users
debugging          incoming         queuing          version
dhcp               interfaces       reboot           vpa
dhcpv6             ip               route-map        wrp
dhcpv6-pd          ipv6             shutdown         webproxy
disk               lldp             snmp             zebra
dns                load-balance     system
file               log              table

ubnt#ubnt:~$ show
Possible completions:
arp                Show Address Resolution Protocol (ARP) information
bridge             Show bridging information
configuration      Show running configuration
conntrack          Show conntrack entries in the conntrack table
date               Show system date and time
debugging          Show route protocol debugging flags
dhcp               Show Dynamic Host Configuration Protocol (DHCP) information
dhcpv6             Show status related to DHCPv6
dhcpv6-pd          Show status related to DHCPv6 Prefix Delegation
disk               Show status of disk device
dns                Show Domain Name Server (DNS) information
file               Show files for a particular image
firewall           Show firewall information
flow-accounting    Show flow accounting statistics
hardware           Show system hardware details
history            Show command history
host               Show host information
incoming           Show ethernet input-policy information
interfaces         Show network interface information
ip                 Show IPv4 routing information
```