



USER GUIDE

cnPilot Enterprise Wi-Fi Access Points

System Release 3.11



Accuracy

While reasonable efforts have been made to assure the accuracy of this document, Cambium Networks assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. Cambium reserves the right to make changes to any products described herein to improve reliability, function, or design, and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Cambium does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others. It is possible that this publication may contain references to, or information about Cambium products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Cambium intends to announce such Cambium products, programming or services in your country.

Copyrights

This document, Cambium products, and 3rd Party software products described in this document may include or describe copyrighted Cambium and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Cambium, its licensors, and other 3rd Party supplied software certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Cambium, its licensors, or the 3rd Party software supplied material contained in the Cambium products described in this document may not be copied, reproduced, reverse engineered, distributed, merged or modified in any manner without the express written permission of Cambium. Furthermore, the purchase of Cambium products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Cambium or other 3rd Party supplied software, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

Restrictions

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Cambium.

License Agreements

The software described in this document is the property of Cambium and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

High Risk Materials

Cambium and its supplier(s) specifically disclaim any express or implied warranty of fitness for any high-risk activities or uses of its products including, but not limited to, the operation of nuclear facilities, aircraft navigation or aircraft communication systems, air traffic control, life support, or weapons systems ("High Risk Use"). Any High Risk is unauthorized, is made at your own risk and you shall be responsible for any and all losses, damage or claims arising out of any High-Risk Use.

Contents

Chapter 1: About This User Guide	14
Overview of cnPilot products.....	14
Intended audience.....	14
Purpose.....	14
Related documents.....	14
Features and Enhancements.....	15
New Platforms.....	16
Chapter 2: Quick Start - Device Access	17
Powering up the device.....	17
PoE switches (802.3af/802.3at).....	17
PoE adapter.....	18
Accessing the device.....	19
Device access using default/fallback IP.....	19
Device access using zeroconf IP.....	20
Device access using DHCP IP address.....	21
LED status.....	21
Chapter 3: Device Modes	24
cnMaestro managed mode.....	24
Autopilot mode.....	24
Standalone mode.....	24
Chapter 4: cnMaestro Onboarding	25
Overview.....	25
Device Onboarding and Provisioning.....	25
Onboarding to cnMaestro cloud using MSN.....	25
Onboarding to cnMaestro On-Premises.....	26
Auto-Provisioning.....	27
Other options.....	28
Directing devices to the cnMaestro On-Premises server using DHCP.....	30
Claim using Cambium ID.....	32
Claim through static URL without Cambium ID and onboarding key.....	32
Claim through static URL with Cambium ID and onboarding key.....	33
Chapter 5: UI Navigation	34
Login screen.....	34

- Home page (Dashboard) 34
 - Monitor 36
 - Configure 36
 - Operations..... 37
 - Troubleshoot..... 37
- Chapter 6: Configuration - System 38**
 - System 38
 - Management 39
 - Time settings 43
 - Event Logging..... 44
- Chapter 7: Configuration - Radio..... 46**
 - Overview..... 46
 - Configuring Radio parameters..... 46
- Chapter 8: Configuration - Wireless LAN 52**
 - Overview..... 52
 - Configuring WLAN parameters..... 52
- Chapter 9: Configuration - Network..... 89**
 - Overview..... 89
 - Configuring Network parameters..... 89
- Chapter 10: Configuration - Services 105**
 - Overview..... 105
 - Configuring Services 105
 - LDAP 105
 - NAT Logging..... 106
 - Location API..... 107
 - Speed Test..... 108
 - DHCP Option 82 109
- Chapter 11: Operations 111**
 - Overview..... 111
 - Firmware update..... 111
 - System 112
 - Configuration..... 113
- Chapter 12: Troubleshoot 114**
 - Logging 114
 - Events 114
 - Debug Logs 115

RF.....	116
Wi-Fi Analyzer.....	116
Spectrum Analyzer.....	117
Unconnected clients.....	118
Packet capture.....	119
Performance.....	119
Wi-Fi Perf speed test.....	119
Connectivity.....	120
Chapter 13: Management Access.....	121
Local authentication.....	121
Device configuration.....	121
SSH-Key authentication.....	121
Device configuration.....	122
SSH Key Generation.....	122
RADIUS authentication.....	124
Device configuration.....	124
Chapter 14: Mesh.....	126
Mesh configurable parameters.....	126
Mesh link.....	131
VLAN 1 as management interface.....	131
Non-VLAN 1 as management interface.....	134
Chapter 15: Autopilot.....	139
Configuration and Onboarding.....	139
Configure member AP to Autopilot master.....	139
Configuring WLAN in default WLAN Group.....	147
Configuring WLANs with user created WLAN Group.....	149
WLAN group override.....	151
Configuring WPA2-Enterprise WLAN.....	152
Onboard member APs to Autopilot master.....	154
Connect clients to the WLANs and check statistics.....	155
Manage Autopilot.....	156
Firmware.....	156
System.....	159
Access Point Management.....	160
Tools.....	160

- Dashboard..... 160
 - Overview.....161
 - Access Points..... 166
 - Wireless clients 168
 - Wireless LANs 169
- Insight 170
 - Pulse..... 170
 - Timeview.....171
 - Events172
- Glossary174**

List of Figures

Figure 1 Installation of cnPilot to PoE capable switch.....	17
Figure 2 Installation of cnPilot to PoE adapter.....	18
Figure 3 Installation of adapter to power outlet.....	19
Figure 4 Onboarding to cnMaestro cloud using MSN	26
Figure 5 Onboarding to cnMaestro On-Premises.....	26
Figure 6 Auto-Provisioning	27
Figure 7 Claiming the device using MAC address (ESN)	29
Figure 8 Claiming the device using Serial Number (MSN)	29
Figure 9 Claim the device using MAC address	30
Figure 10 Claim the device using MSN	30
Figure 11 DHCP option 43.....	31
Figure 12 DHCP option 15.....	31
Figure 13 Claim through static URL without Cambium ID and onboarding key.....	33
Figure 14 Claim through static URL with Cambium ID and onboarding key	33
Figure 15 UI Login Page	34
Figure 16 cnPilot AP UI Home page.....	35
Figure 17 Configuration: System page.....	39
Figure 18 Configuration: Management page.....	43
Figure 19 Configuration: Time settings page.....	44
Figure 20 Configuration: Event Logging page.....	45
Figure 21 Configure: Radio parameters.....	50
Figure 22 Configure: Radio > Enhanced Roaming parameters	51
Figure 23 Configure: WLAN > Basic parameter.....	57
Figure 24 Configure: WLAN > Advanced parameter.....	61
Figure 25 Configure: WLAN > Radius Server parameter	64
Figure 26 Configure: WLAN > Guest Access > Internal Access Point parameter	69
Figure 27 Configure: WLAN > Guest Access > External Hotspot (Standard) parameter	76
Figure 28 Configure: WLAN > Guest Access > External Hotspot (XWF) parameter	77
Figure 29 Configure: WLAN > Guest Access > cnMaestro parameter	79
Figure 30 Configure: WLAN > Usage Limits parameters.....	80
Figure 31 Configure: WLAN > Scheduled Access parameters	81
Figure 32 Configure: WLAN > Access parameters	85

Figure 33 Configure: WLAN > Passpoint parameters.....	88
Figure 34 Configure: Network > VLAN parameters	92
Figure 35 Configure: Network > Routes parameters	94
Figure 36 Configure: Network > Ethernet Ports parameters.....	96
Figure 37 Configure: Network > Security parameters.....	97
Figure 38 Configure: Network > DHCP parameters	99
Figure 39 Configure: Network > Tunnel parameters.....	101
Figure 40 Configure: Network > PPPoE parameters	102
Figure 41 Configure: Network > VLAN Pool parameters.....	103
Figure 42 Configure: Network > WWAN parameters.....	104
Figure 43 Configure: Services > LDAP parameters	106
Figure 44 Configure: Services > NAT Logging parameters	107
Figure 45 Configure: Services > Location API parameters	108
Figure 46 Configure: Services > Speed Test parameters.....	109
Figure 47 Configure: Services > DHCP Option 82 parameters.....	110
Figure 48 Configure: Operations > Firmware update parameters.....	112
Figure 49 Configure: Operations > System parameters.....	113
Figure 50 Configure: Operations > Configuration parameters.....	113
Figure 51 Troubleshoot > Logs > Events	115
Figure 52 Troubleshoot > Logs > Debug Logs	115
Figure 53 Troubleshoot > Wi-Fi Analyzer > Interference Mode.....	116
Figure 54 Troubleshoot > Wi-Fi Analyzer > Number of APs Mode.....	117
Figure 55 Troubleshoot > Spectrum Analyzer.....	118
Figure 56 Unconnected clients.....	118
Figure 57 Troubleshoot > Packet Capture page.....	119
Figure 58 Troubleshoot > Wi-Fi Perf Speed Test.....	120
Figure 59 configure/update default password of admin user	121
Figure 60 System > Management	122
Figure 61 Generating public/private Key	123
Figure 62 Public and Private Key	123
Figure 63 Public Key location path.....	124
Figure 64 Private Key saved path.....	124
Figure 65 System > Management: RADIUS Server and RADIUS Secret parameters.....	125
Figure 66 UI Login page.....	125
Figure 67 Configure > Mesh > Base parameters	130

Figure 68 Configure > Mesh > Client parameters.....	131
Figure 69 Mesh Base configuration with native VLAN 1.....	131
Figure 70 Mesh Base configuration > Management VLAN 1.....	132
Figure 71 Mesh Base Ethernet configuration > Access VLAN 1.....	132
Figure 72 Mesh Client configuration with VLAN 1.....	133
Figure 73 Mesh Client configuration > Management VLAN 1.....	133
Figure 74 Mesh Client Ethernet configuration > Access VLAN 1.....	134
Figure 75 Configure > WLAN > Mesh Recovery	134
Figure 76 Mesh Base configuration with non-VLAN 1.....	135
Figure 77 Mesh Base configuration > Management non-VLAN 1.....	135
Figure 78 Mesh Base Ethernet configuration > Access non-VLAN 1.....	136
Figure 79 Mesh Client configuration with non-VLAN 1.....	136
Figure 80 Mesh Client configuration > Management non-VLAN 1.....	137
Figure 81 Mesh Client Ethernet configuration > Access non-VLAN 1.....	137
Figure 82 Configure > WLAN > Mesh Recovery	138
Figure 83 Configure > System > Management > Autopilot.....	140
Figure 84 Configuring an AP with Internal DHCP server	141
Figure 85 Configure > Systems	141
Figure 86 Configure > Ethernet Ports	142
Figure 87 Configure > Networks.....	143
Figure 88 Configure > Networks > VLAN 10.....	144
Figure 89 Configure > Networks > VLAN 20.....	145
Figure 90 Configuring an AP with External DHCP server.....	146
Figure 91 Configure > Systems	146
Figure 92 Configure > IP Settings	147
Figure 93 Configure > Wireless LANs	147
Figure 94 Configure > Wireless LANs > VLAN 10	148
Figure 95 Configure > Wireless LANs > VLAN 20	148
Figure 96 Configure > Wireless LANs > VLAN 10 and 20.....	149
Figure 97 Dashboard.....	149
Figure 98 Create a WLAN group.....	150
Figure 99 Configure a new WLAN Group.....	150
Figure 100 Configure WLAN under the newly created WLAN Group	151
Figure 101 Configure > Access Point settings	151
Figure 102 Configure > Access Point settings > WLAN Group	152

Figure 103 Configure > Access Point settings > user created WLAN Group	152
Figure 104 Configure > Wireless LANs > Security	153
Figure 105 Configure > Wireless LANs > Radius Server	154
Figure 106 Login page.....	154
Figure 107 Dashboard > Overview	155
Figure 108 Dashboard > Access points.....	155
Figure 109 Dashboard > Wireless clients	156
Figure 110 Manage > Firmware	156
Figure 111 Manage > Upload Firmware.....	156
Figure 112 To open required Firmware	157
Figure 113 Upload firmware on Master AP	157
Figure 114 To upgrade firmware in all devices.....	157
Figure 115 Firmware upgraded sequence.....	158
Figure 116 Firmware upgraded status.....	158
Figure 117 System.....	159
Figure 118 System > Import/Export Configuration.....	159
Figure 119 Access Point management	160
Figure 120 Tools > Troubleshoot	160
Figure 121 Dashboard	161
Figure 122 Dashboard > Overview > Site information	162
Figure 123 Dashboard > Overview > Discovered devices.....	162
Figure 124 Dashboard > Overview > Events.....	163
Figure 125 Dashboard > Overview > Clients	163
Figure 126 Dashboard > Overview > Throughput.....	164
Figure 127 Dashboard > Overview > Top Aps.....	164
Figure 128 Dashboard > Overview > Top clients	165
Figure 129 Dashboard > Overview > Clients by Band/Radio	165
Figure 130 Dashboard > Overview > Channel distribution.....	165
Figure 131 Dashboard > Overview > Clients by WLANs.....	166
Figure 132 Dashboard > Overview > Clients by device type	166
Figure 133 Dashboard > Access Points > Performance	167
Figure 134 Dashboard > Access Points > System.....	167
Figure 135 Dashboard > Access Points > RF Status.....	168
Figure 136 Dashboard > Wireless clients.....	168
Figure 137 Dashboard > Wireless clients > RF status	169

Figure 138 Dashboard > Wireless LANs 170

Figure 139 Insight > Pulse..... 170

Figure 140 Insight > Timeview172

Figure 141 Insight > Unfiltered Events.....173

Figure 142 Insight > Filtered Events173

List of Tables

Table 1 Related documents	14
Table 2 Features.....	15
Table 3 Enhancements	15
Table 4 New platforms.....	16
Table 5 e410/e430/e600 LED status	22
Table 6 e700 LED status.....	22
Table 7 E400/E500/E501S/e502S LED status	23
Table 8 Auto-Provisioning parameter details	27
Table 9 cnPilot AP web interface elements	36
Table 10 Configuration: System parameters.....	38
Table 11 Configuration: System > Management parameters	39
Table 12 Configuration: System > Time Settings parameters.....	43
Table 13 Configuration: System > Event Logging parameters.....	44
Table 14 Configure: Radio parameters	46
Table 15 Configure: WLAN > Basic parameters.....	52
Table 16 WLAN (Max Clients) parameters.....	56
Table 17 Configure: WLAN > Advanced parameters.....	57
Table 18 Configure: WLAN > Radius Server parameters.....	62
Table 19 Configure: WLAN > Guest Access > Internal Access Point parameters.....	64
Table 20 Configure: WLAN > Guest Access > External Hotspot parameters.....	70
Table 21 Configure: WLAN > Guest Access > cnMaestro parameters	77
Table 22 Configure: WLAN > Usage Limits parameters	80
Table 23 Configure: WLAN > Scheduled Access parameters.....	81
Table 24 Configure: WLAN > Access parameters.....	81
Table 25 Configure: WLAN > Passpoint parameters.....	85
Table 26 Configure: Network > VLAN parameters	89
Table 27 Configure: Network > Routes parameters	92
Table 28 Configure: Network > Ethernet Ports parameters.....	94
Table 29 Configure: Network > Security parameters.....	97
Table 30 Configure: Network > DHCP parameters.....	98
Table 31 Configure: Network > Tunnel parameters.....	99
Table 32 Configure: Network > PPPoE parameters.....	101

Table 33 Configure: Network > VLAN Pool parameters.....	102
Table 34 Configure: Network > WWAN parameters.....	103
Table 35 Configure: Services > LDAP parameters.....	105
Table 36 PDU type code: 0x82.....	106
Table 37 NAT Logging Packet Structure.....	106
Table 38 Configure: Services > NAT Logging parameters.....	107
Table 39 Configure: Services > Location API parameters.....	107
Table 40 Configure: Services > Speed Test parameters.....	108
Table 41 Configure: Services > DHCP Option 82 parameters.....	109
Table 42 Configure: Operations > Firmware update parameters.....	111
Table 43 Configure: Operations > System parameters.....	112
Table 44 Configure: Operations > Configuration parameters.....	113
Table 45 Configure: WLAN > Mesh parameters.....	126

Chapter 1: About This User Guide

This chapter describes the following topics:

- [Overview of cnPilot products](#)
- [Intended audience](#)
- [Purpose](#)
- [Related documents](#)
- [Features and Enhancements](#)
- [New platforms](#)

Overview of cnPilot products

Thank you for choosing Cambium cnPilot Access Point (AP)!

This User Guide describes the features supported by cnPilot Enterprise AP and provides detailed instructions for setting Up and configuring cnPilot Enterprise AP.

cnPilot's are the industry's upcoming feature-rich Wi-Fi APs designed for Indoor/Outdoor which are easy to deploy and configure.

Intended audience

This guide is intended for use by the system designer, system installer and system administrator.

Purpose

Cambium Network's cnPilot Enterprise AP documents are intended to instruct and assist personnel in the operation, installation and maintenance of the Cambium's equipment and ancillary devices. It is recommended that all personnel engaged in such activities be properly trained.

Cambium disclaims all liability whatsoever, implied or expressed, for any risk of damage, loss or reduction in system performance arising directly or indirectly out of the failure of the customer, or anyone acting on the customer's behalf, to abide by the instructions, system parameters, or recommendations made in this document.

Related documents

Table 1 provides details on cnPilot's support information.

Table 1 Related documents

cnPilot Enterprise product details	https://www.cambiumnetworks.com/products/wifi/
cnPilot Enterprise AP User Guide (This document)	https://support.cambiumnetworks.com/files
cnPilot Enterprise AP Release Notes	https://support.cambiumnetworks.com/files
Software Resources	https://support.cambiumnetworks.com/files

Knowledge Base (KB) Articles	http://community.cambiumnetworks.com/t5/cnPilot-E-Series-Enterprise-APs/bd-p/cnPilot_E_Series/
Community	http://community.cambiumnetworks.com/
Support	https://www.cambiumnetworks.com/support/contact-support/
Warranty	https://www.cambiumnetworks.com/support/warranty/
Feedback	For feedback, e-mail to support@cambiumnetworks.com/

Features and Enhancements

System release 3.11 includes the following new features:

Table 2 Features

Features	Platform Support	Summary
Spectrum Analyzer	All	RF tool.
WWAN	e600	LTE support on e600 to provide internet services.

System release 3.11 includes the following enhancements:

Table 3 Enhancements

Features	Platform Support	Summary
Client Isolation - Static Mode	All	Network wide client isolation is enabled. User must manually configure gateway MAC. This mode deprecates gateway keep-alive method.
L2TP - PPP authentication	All	User has provision to configure PPP authentication method.
PPPoE - Service Name	All	Provision to configure service name in PPPoE.

New platforms

System release 3.11 includes the following new Platforms:

Table 4 New platforms

Hardware	Description
Not Applicable	Not Applicable

Chapter 2: Quick Start – Device Access

This chapter describes the following topics:

- [Powering up the device](#)
- [Accessing the device](#)
- [LED status](#)

Powering up the device

This section includes the following topics:

- [PoE switches \(802.3af/802.3at\)](#)
- [PoE adapter](#)

cnPilot product family can be powered either using PoE adapter provided in the package or it can be powered using 802.3af or 802.3at capable switches.

For cnPilot e600 and e430, there is additional provision to power ON device using DC power adapter.


PoE switches (802.3af/802.3at)

All devices can be powered by PoE switches supplying standard 802.3af or 802.3at power. The following restrictions apply if 802.3af power is used:

- On cnPilot E501S and e502S along with E500 and e430, the PoE out feature will not be operational.
- On cnPilot e600, radio transmit power will be limited to 17dBm and the USB port will not be operational.
- On cnPilot e700, the radio transmit power will be limited to 17dBm and PoE out feature will not be operational.

To avoid these restrictions, power the device using 802.3at capable switches. In addition, 802.3af / 802.3at switches do not supply sufficient power to use the PoE out feature on cnPilot e700. Use a power injector such as the 60W Cambium N000065L001C Gigabit power injector when operating with this feature enabled.

To power ON the cnPilot device, connect Eth1 of device to PoE switch port. [Figure 1](#) displays how cnPilot e430 connects to a PoE capable switch.



PoE adapter

Follow the below procedure to power up the device using PoE adapter (**Figure 2**):

1. Connect the Ethernet cable from Eth1/PoE-IN of the device to the PoE port of Gigabit Data + Power.
2. Connect an Ethernet cable from your LAN or Computer to the Gigabit Data port of the PoE adapter.

Figure 2 Installation of cnPilot to PoE adapter




Notes

1. If Auxiliary port is used to power a secondary device, the maximum cable length between AP and the secondary device is 5 meters.
2. Secondary device is allowed to install 0.6 meters below the highest point on the metal mounting pole.
3. If Auxiliary port is used for only LAN connection between AP and secondary device. If cable length exceeds 5 meters or if the secondary device is installed on a different pole, then additional gigabit surge suppressor is recommended between AP and Secondary device.

3. Connect the power cord to the adapter, and then plug the power cord into a power outlet as shown in **Figure 3**. Once powered **ON**, the Power LED should illuminate continuously on the PoE Adapter.

Figure 3 Installation of adapter to power outlet



Accessing the device


This section includes the following topics:

- [Device access using default/fallback IP](#)
- [Device access using zeroconf IP](#)
- [Device access using DHCP IP address](#)

Once the device is powered up ensure the device is up and running before you try to access it based on LED status. Power LED on the cnPilot device should turn Green which indicates that the device is ready for access.


Device access using default/fallback IP

1. Select **Properties** for the Ethernet port. In Windows it is found in:
 - a) Windows 7: **Control Panel > Network and Internet > Network Connections > Local Area Connection**
 - b) Windows 10: **Control Panel > Network and Internet > Network and Sharing Center > Local Area Connection**



2. IP Address Configuration:

The cnPilot AP obtains its IP address from a DHCP server. A default IP address of **192.168.0.1/24** will be used if an IP address is not obtained from the DHCP server.



Open any browser on the PC and browse <http://192.168.0.1> with default credentials as below:


- Username: admin
- Password: admin

Device access using zeroconf IP

To access the device using zeroconf IP, follow the below steps:

For example:

- Convert the last two bytes of ESN of the device to decimal. If ESN is **58:C1:CC:DD:AA:BB**, last two bytes of this ESN is **AA:BB**. Decimal equivalent of AA:BB is **170:187**.
- Zeroconf IP of device with ESN **58:C1:CC:DD:AA:BB** is **169.254.170.187**
- Configure Management PC with **169.254.100.100/16** as below:



d) Access the device UI using <http://169.254.170.187> with default credentials as below:

- Username: admin
- Password: admin



Device access using DHCP IP address

1. Plug in the device to the network.
2. Get the IP address of the device from the System administrator.
3. Access device UI using <http://<IP address>> with default credentials as below:
 - Username: admin
 - Password: admin

LED status



The **e410/e430/e600** AP has single color LED. The power LED will glow Amber as the AP boots up and turn Green once it has booted up successfully. The network/status LED will glow Amber if the connection to cnMaestro controller/manager is down and turns Blue once the AP is connected successfully to cnMaestro.

Table 5 e410/e430/e600 LED status

LED Color	Status Indication
	<ul style="list-style-type: none"> Device is booting up. <div style="display: flex; align-items: center;">  <div style="border: 1px solid black; background-color: #e6f2ff; padding: 5px;"> <p>Note If these LEDs remain 'Amber' for more than 5 minutes, indicates that the device failed to boot.</p> </div> </div>
	<ul style="list-style-type: none"> Device is successfully up and accessible. Wi-Fi services are up if configured.
	<ul style="list-style-type: none"> cnMaestro connection is successful.

The **e700** AP has two multi-colored LEDs. The power LED will glow Amber as the AP boots up and turns Green once it has booted up successfully. The network/status LED will glow Amber if the connection to cnMaestro controller/manager is down and turns Blue once the AP is connected successfully to cnMaestro.

Table 6 e700 LED status

LED Color		Status Indication
		
		<ul style="list-style-type: none"> Device is booting up. <div style="display: flex; align-items: center;">  <div style="border: 1px solid black; background-color: #e6f2ff; padding: 5px;"> <p>Note If these LEDs remain 'Amber' for more than 5 minutes, indicates that the device failed to boot.</p> </div> </div>
		<ul style="list-style-type: none"> Device is successfully up and accessible. Wi-Fi services are up if configured.
		<ul style="list-style-type: none"> Device is successfully up and accessible. Wi-Fi services are up if configured. cnMaestro connection is successful.

The **E400/E500/E501S/e502S** AP has two multi-colored LEDs. The power LED will glow Amber as the AP boots up and turns Green once it has booted up successfully. The network/status LED will glow Amber if the connection to cnMaestro controller/manager is down and turns Green once the AP is connected successfully to cnMaestro.

Table 7 E400/E500/E501S/e502S LED status

LED Color		Status Indication
		
		<ul style="list-style-type: none"> • Device is booting up. <div style="border: 1px solid black; padding: 5px; display: inline-block;">  <p>Note If these LEDs remain 'Amber' for more than 5 minutes, indicates that the device failed to boot.</p> </div>
		<ul style="list-style-type: none"> • Device is successfully up and accessible. • Wi-Fi services are up if configured.
		<ul style="list-style-type: none"> • Device is successfully up and accessible. • Wi-Fi services are up if configured. • cnMaestro connection is successful.

Chapter 3: Device Modes

cnPilot product family supports three modes of operation based on deployment size. Details of mode of operation supported by cnMaestro are given below:

- **cnMaestro managed mode**
- **Autopilot mode**
- **Standalone mode**

cnMaestro managed mode

This mode is also known as controller mode, in which all management traffic is tunneled to cnMaestro and data traffic is offloaded from AP to the network. There are provisions to tunnel data traffic to cnMaestro but has its own limitations w.r.t size of deployment. Device onboarding methods and procedures are explained in further chapters. By default, devices onboard to cnMaestro cloud (<https://cloud.cambiumnetworks.com>), however we can also onboard the devices to cnMaestro On-Premises by mapping the cnMaestro IP address on the device.



Note cnMaestro managed mode is the recommended mode for any cnPilot devices.

Autopilot mode

This is a proprietary mode supported by cnPilot devices. This mode allows one of the cnPilot devices to act as controller, which allows to configure other devices in the network. This mode has its own limitations, which will be explained in detail in the following chapters.

Standalone mode

This is the default mode a cnPilot device operates. In this mode, it is expected that each device has to be configured and managed independently, which is cumbersome if deployment size exceeds 10 devices.

Chapter 4: cnMaestro Onboarding

This chapter describes the following topics:

- [Overview](#)
- [Device Onboarding and Provisioning](#)
- [Directing devices to the cnMaestro On-Premises server](#)
- [Claim using Cambium ID](#)

Overview

cnMaestro is Cambium's next generation network management platform based on cloud technologies. In addition to the cloud-based cnMaestro solution, it can also be installed as a standalone On-Premises server. By default, all devices contact <https://cloud.cambiumnetworks.com>, no user action is required to direct devices to contact cnMaestro cloud. You can onboard and provision devices without any additional setup.

If you are using cnMaestro On-Premises you must direct devices to correct cnMaestro server using DHCP or static URL configuration.

Device Onboarding and Provisioning

This section includes the following topics:


- [Onboarding to cnMaestro cloud using MSN](#)
- [Onboarding to cnMaestro On-Premises](#)
- [Auto-Provisioning](#)
- [Other options](#)

Onboarding to cnMaestro cloud using MSN

This mode is preferable for cnMaestro cloud. In order to claim through MSN Address, follow the below steps:

1. Login to On-Premises server using default username and password (admin/admin) or the username and password set by the Administrator.
2. Navigate to **Home > Onboard Devices > Claim from cnMaestro**.
3. Select the **Device type** that needs to be onboarded and provide the MSN in the combo box and click the **Claim Devices button**. Multiple MSN Addresses of same device type can be claimed using (,) separator between MSN or by entering them in the new line.

Figure 4 Onboarding to cnMaestro cloud using MSN




Onboarding to cnMaestro On-Premises

This mode is preferable for cnMaestro On-Premises. In order to claim through MAC Address (ESN), please follow the below steps:

1. Login to On-Premises server using default username and password (admin/admin) or the username and password set by the Administrator at the time of On-Premises server installation.
2. Navigate to **Home > Onboard Devices > Claim from cnMaestro**.
3. Select the **Device type** for which onboarding is to be done and provide the MAC Address in the combo box and click the **Claim Devices** button. Multiple MAC Addresses of same device type can be claimed using (,) separator between MAC Addresses or by entering them in the new line.

Figure 5 Onboarding to cnMaestro On-Premises



Auto-Provisioning


cnMaestro On-Premises supports Auto-Provisioning for cnPilot devices. This feature not only enables auto onboarding but also configures synchronization and positioning of device in the network architecture. It is triggered only at first instance of device onboarding. It can be configured on cnMaestro as below:

Configuration

It is enabled at **Shared Settings > Auto-Provisioning**, and it allows one to automatically configure and approve devices based upon IP address. To create rules for cnPilot devices:

1. Navigate to **Shared Settings > Auto-Provisioning** page.
2. To create a new rule, click **Add**. The following window appears:

Figure 6 Auto-Provisioning



3. Enter the following details given in **Table 8**:

Table 8 Auto-Provisioning parameter details

Parameter	Description
Subnet (CIDR)	The subnet with CIDR of the devices to which the rule has to be applied. For example, Subnet/CIDR (192.168.100.100/25) maps the devices with the IP addresses ranging from 192.168.100.1 to 192.168.100.126.
Device Type	Select the type of the device from the drop-down list.
Network	Select the network to which the device should be onboarded, once the device contacts the server.
Site	Select the site under which the device should be onboarded, once the device contacts the server.

Parameter	Description
AP Group	Select the AP Group which needs to be applied on the device, once the device contacts the server while onboarding.
Approve	Enables this option to auto-approve onboarding.

- Click **Add**.



Note Auto-Provisioning is supported only for cnMaestro On-Premises and not for cnMaestro cloud.

Other options

This section includes the following topics:

- [AP Group](#)
- [Site dashboard](#)

The device onboarding screen can also be accessed from other locations in the UI. Below options can be used in both cloud cnMaestro and cnMaestro On-Premises. For cnMaestro On-Premises, ESN/MAC Address is required for onboarding/claiming device in an account whereas for cloud cnMaestro MSN is required to claim/onboard device in an account.

AP Group

In order to claim multiple devices from the AP Group in cloud, navigate to the Wi-Fi AP Groups tree view and click the drop-down menu for the selected AP Group.

- Click the **Claim Devices** option.
- In the pop-up dialog, select the **Network and Site** under which these devices needs to be placed and by default the devices claimed under this group will have the configuration settings from this AP Group.
- Specify the MSNs/ESNs (Manufacturing Serial Number) of the devices line-by-line or comma-separated or click **Import .csv** option to **import the MSNs/ESNs** of the devices from a file.
- Click **Claim Devices** to add to the selected AP Group with the configuration applied.



Note In cnMaestro On-Premises the procedure to claim the device using Serial Number is same as cloud, but instead of MSN, the user should use the device MAC Addresses.

Figure 7 Claiming the device using MAC address (ESN)





Figure 8 Claiming the device using Serial Number (MSN)



Site dashboard

In order to claim multiple devices from the Site dashboard in cloud, navigate to the **Manage** section and select a site under a network and click the drop-down menu for the selected site:

1. Click the **Claim Devices** option.
2. In the pop-up dialog, select the **Network and Site** under which these devices need to be placed and by default the devices claimed under this group will have the configuration settings from this AP Group.
3. Specify the MSNs (Manufacturing Serial Number) /ESNs (Equipment Serial Number) of the devices line-by-line or comma-separated or click **Import .csv** option to **import the MSNs/ESNs** of the devices from a file.
4. Click **Claim Devices** to add to the selected AP Group with the configuration applied.



Note Claim using MAC address is supported by cnMaestro On-Premises only.

Figure 9 Claim the device using MAC address





Figure 10 Claim the device using MSN



Directing devices to the cnMaestro On-Premises server using DHCP

This section includes the following topics:

- [DHCP Option 43](#)
- [DHCP Option 15](#)

DHCP Option 43

This mode of onboarding is preferred to use when cnMaestro On-Premises is deployed at customer end. cnPilot reads Option 43 during DHCP transaction and then it connects to respective cnMaestro. This option is given high priority during cnMaestro discovery process. All these devices which have read the Option 43 from DHCP transaction are available in Queue on cnMaestro, which needs to be further approved by end user.

Figure 11 DHCP option 43

Type	Serial Number	Device	MAC	IP Address	Added By	Status	Duration	Configure
cnPilot e400	W8SA01760R4L	E400-AFCAC6	00:04:56:AF:CA:C6	10.110.219.70	-	Waiting for Appr...	0d 3h 50m	[Icons] [Approve] [Delete]
cnPilot e430W	WSTM001KSKFN	E430-369519	58:C1:7A:36:95:19	10.110.219.73	-	Waiting for Appr...	0d 5h 27m	[Icons] [Approve] [Delete]
cnPilot e700	W8UC0CCXTGHF	E700-2609B0	58:C1:7A:26:09:B0	10.110.219.69	-	Waiting for Appr...	0d 7h 5m	[Icons] [Approve] [Delete]
cnPilot e510	W8UJ04N2KH10	E510-C18B33	58:C1:7A:C1:8B:33	10.110.219.78	-	Waiting for Appr...	0d 8h 44m	[Icons] [Approve] [Delete]
cnPilot e410	W8TC008M4MF4	E410-93F17E	00:04:56:93:F1:7E	10.110.219.76	-	Waiting for Appr...	0d 10h 22m	[Icons] [Approve] [Delete]
cnPilot e500	W8SG18792132	E500-B99DDC	00:04:56:B9:9D:DC	10.110.219.71	-	Waiting for Appr...	0d 14h 20m	[Icons] [Approve] [Delete]
cnPilot e510	W8VA0118Z40D	E510-C84429	58:C1:7A:C8:44:29	10.110.214.91	-	Waiting for Appr...	1d 16h 36m	[Icons] [Approve] [Delete]

DHCP Option 15

This mode of onboarding is preferred to use when cnMaestro On-Premises is deployed at customer end. cnPilot reads Option 15 during DHCP transaction and then it connects to respective cnMaestro. All these devices which have read the Option 15 from DHCP transaction are available in Queue on cnMaestro, which needs to be further approved by end user.

Figure 12 DHCP option 15

Type	Serial Number	Device	MAC	IP Address	Added By	Status	Duration	Configure
cnPilot e400	W8SA01760R4L	E400-AFCAC6	00:04:56:AF:CA:C6	10.110.219.70	-	Waiting for Appr...	0d 3h 50m	[Icons] [Approve] [Delete]
cnPilot e430W	WSTM001KSKFN	E430-369519	58:C1:7A:36:95:19	10.110.219.73	-	Waiting for Appr...	0d 5h 27m	[Icons] [Approve] [Delete]
cnPilot e700	W8UC0CCXTGHF	E700-2609B0	58:C1:7A:26:09:B0	10.110.219.69	-	Waiting for Appr...	0d 7h 5m	[Icons] [Approve] [Delete]
cnPilot e510	W8UJ04N2KH10	E510-C18B33	58:C1:7A:C1:8B:33	10.110.219.78	-	Waiting for Appr...	0d 8h 44m	[Icons] [Approve] [Delete]
cnPilot e410	W8TC008M4MF4	E410-93F17E	00:04:56:93:F1:7E	10.110.219.76	-	Waiting for Appr...	0d 10h 22m	[Icons] [Approve] [Delete]
cnPilot e500	W8SG18792132	E500-B99DDC	00:04:56:B9:9D:DC	10.110.219.71	-	Waiting for Appr...	0d 14h 20m	[Icons] [Approve] [Delete]
cnPilot e510	W8VA0118Z40D	E510-C84429	58:C1:7A:C8:44:29	10.110.214.91	-	Waiting for Appr...	1d 16h 36m	[Icons] [Approve] [Delete]

DHCP server configuration

More details on various DHCP server configuration for Option 43 is available in Cambium Knowledge Base (KB) section.

Windows server configuration

For Windows server configuration for onboarding devices to cnMaestro On-Premises server, please click the below URL.

<http://community.cambiumnetworks.com/t5/cnMaestro/Device-Onboarding-and-Windows-DHCP-Options-for-cnMaestro-On/m-p/55199>

Linux server configuration

A DHCP Server can be used to configure the IP Address, Gateway, and DNS servers for Cambium devices. If you administer the DHCP Server, you can also configure DHCP Options that will tell the devices how to access the cnMaestro (so the URL doesn't need to be set on each device).

<http://community.cambiumnetworks.com/t5/cnMaestro/Device-Onboarding-and-Linux-DHCP-Options-for-cnMaestro-On/m-p/55187>

Microtik server configuration

For Microtik Routerboard DHCP configuration for onboarding devices to cnMaestro On-Premises server, please click the below link.

<http://community.cambiumnetworks.com/t5/cnMaestro/Microtik-Routerboard-DHCP-configuration-for-Onboarding-devices/m-p/56012>

Claim using Cambium ID

This section includes the following topics:

- [Claim through static URL without Cambium ID and onboarding key](#)
- [Claim through static URL with Cambium ID and onboarding key](#)

Claim through static URL without Cambium ID and onboarding key

In order to claim the devices using the static URL without Cambium ID and onboarding key please follow the below steps:

1. Login to device UI and navigate to **Configure > System > Management > cnMaestro**.
2. Provide static URL of On-Premises <https://ON-PREMISESIPADDRESSORHOSTNAME> and click **Save**.
3. Device will come to the onboarding queue in the cnMaestro **Home > Onboard Devices > Onboard** page and the user can approve the device.

Figure 13 Claim through static URL without Cambium ID and onboarding key

Type	Serial Number	Device	MAC	IP Address	Managed Account	Added By	Status	Duration	Configure	Actions
cnPilot E500		Rajesh		10.110.208.167	Base Infrastructure	Administrator Unsolicited	Onboarded	3d 22h 8m	Summary	ONBOARDED
cnPilot E400		E400-cnPilot-182-RGVN		10.110.212.182	BesKOM	Unsolicited	Onboarded	4d 2h 45m	Summary	ONBOARDED
cnPilot E400		E400-BSADE0		10.110.202.103	BesKOM	Administrator Using MAC Address	Onboarded	6d 5h 17m	Summary	ONBOARDED

Claim through static URL with Cambium ID and onboarding key

In order to claim the devices using the static URL with Cambium ID and onboarding key, please follow the below steps:

1. Login to On-Premises server using default username and password (admin/admin) or the username and password set by the Administrator at the time of installation.
2. Navigate to **Home > Onboard Devices > Claim from Device** page.
3. Select the checkbox for “Enable Cambium ID based authentication to onboard devices”.
4. Click on **Add new** and select the username from the drop-down list and specify the onboarding key and click **Save**.
5. Login to device UI and navigate to **Configure > System > Management > cnMaestro**.
6. Provide static URL of On-Premises **https://ON-PREMISESIPADDRESSORHOSTNAME** and Cambium ID (cnMaestro_On-Premises) and onboarding key for that user and click **Save**.
7. Device will come to the onboarding queue in the cnMaestro **Home > Onboard Devices > Onboard** page and the user can approve the device.

Figure 14 Claim through static URL with Cambium ID and onboarding key

Onboard Devices

Claim from cnMaestro Onboard **Claim from Device** Unclaim

Claim Devices Using Cambium ID

Cambium ID: cnmaestro_on_premises

Enable Cambium ID based authentication to onboard devices

Enabling this feature allows a device to be claimed by entering the Cambium ID and Onboarding Key on the device. This information can be set on the device via its user interface (or SNMP or CLI on some devices). Each administrator can have their own Onboarding Key.

The following users can claim devices using the cnMaestro Cambium ID and the user's Onboarding Key.

User: Admin Onboarding Key: [masked] [Delete]

[Add New] [Cancel] [Save]

Chapter 5: UI Navigation

You can manage cnPilot device using User Interface (UI) which is accessible from any network devices such as computer, mobile, tabs, etc. cnPilot device accessibility is explained in [Chapter 3](#).

This chapter describes the following topics:


- [Login screen](#)
- [Home page \(Dashboard\)](#)

Login screen

To log to the UI, enter the following credentials:

- Username: **admin**
- Password: **admin**

Figure 15 UI Login Page



The screenshot shows a login form with a blue header labeled "Login". Below the header, there are two input fields. The first field is labeled "Username" and has a person icon to its left. The second field is labeled "Password" and has a lock icon to its left. Below these fields is a blue button labeled "Sign In".

Home page (Dashboard)

On logging into cnPilot AP login page, the UI Home page is displayed. [Figure 16](#) displays the parameters that are displayed in cnPilot AP Home page.

Figure 16 cnPilot AP UI Home page

The screenshot displays the cnPilot AP UI Home page for a device identified as 'cnPilot E400 - E400-AFA308'. The interface includes a top navigation bar with 'Reboot' and 'Logout' buttons, a breadcrumb trail 'Home / Dashboard', and a 'Refresh 30sec' button. A left sidebar contains navigation options: 'Dashboard', 'Monitor', 'Configure', 'Operations', and 'Troubleshoot'. The main content area is divided into several sections: 'Clients' (showing 1 client), 'Channel' (auto 2.4GHz, 161 5GHz), 'Ethernet' (1000M ETH1), and 'RF Quality' (2.4GHz, 5GHz). Below these are 'Access Point Info' and 'Radio Info' tables. Two line graphs are present: 'Client Count' and 'Throughput'. The 'Wireless LAN' section contains a table with columns for SSID, Security, Guest Access, Rx, Tx, Rx Packets, Tx Packets, 2.4GHz State, and 5GHz State. The 'Wireless Clients' section contains a table with columns for SSID, Name, IP, VLAN, User, Mode, MAC, Band, Vendor, Type, SNR, Rx, and Tx.

Callout 1: Troubleshoot -

Callout 2: Reboot

Callout 3: Logout

Callout 4: Client Count graph

Callout 5: Home / Dashboard

Callout 6: Refresh 30sec

Callout 7: cnPilot E400 - E400-AFA308

Table 9 cnPilot AP web interface elements

Number	Element	Description
1	Menu	This section contains multiple tabs that helps user to configure, monitor and troubleshoot cnPilot device. Menu consists of the following: <ul style="list-style-type: none"> • Dashboard • Monitor • Configure • Operations • Troubleshoot
2	Reboot	Global button to reboot cnPilot device ().
3	Logout	Global button to logout user from cnPilot device ().
4	Content	Information in the area of web interface varies based on the tab selected in Menu section. Usually, this area contains details of configuration or statistics or provision to configure cnPilot device.
5	UI path	Provides UI navigation path information to user.
6	UI refresh interval	Provision to reload updated statistics at regular intervals.
7	Model number	Provides information related to cnPilot model number and configured hostname.

Monitor

The Monitor section provides information such as current configuration, traffic statistics across all interfaces configured on device and device details. Based on information provided in this section, it is categorized and displayed under following categories:

- **System:** Provides information related to cnPilot device such as Software Image, host name, Country code etc.
- **Radio:** Provides information such as RF Statistics, Neighbour list and current radio configuration of device.
- **WLAN:** Provides information on WLANs and Mesh configurations.
- **Network:** Provides information related to interfaces such as, default route, interface statistics, etc.
- **Services:** Provides information related to entities that support Bonjour.

Configure

This section allows user to configure cnPilot device based on deployment requirement. This tab has multiple sections as follows:

- **System:** Provision to configure System UI parameter.

- **Radio:** Provision to configure Radio settings (2.4GHz/5GHz).
- **WLAN:** Provision to configure WLAN parameters as per the end user requirement and type of wireless station.
- **Network:** Provides information related to VLAN, Routes, Ethernet ports etc.
- **Services:** Provides information related to Network and Bonjour Gateway.

Operations

This section allows user to perform maintenance of device such as:

- **Firmware update:** Provision to upgrade cnPilot devices.
- **System:** Provides different methods of debugging field issues and recovering device.
- **Configuration:** Provision to modify configuration of device.

Troubleshoot

The section provides users to debug and troubleshoot remotely. This tab has multiple sections and are as follows:

- **WiFi Analyzer:** When this is initialized, device provides information related to air quality.
- **Spectrum Analyzer:** Provides real-time cumulative distribution format view of RF environment and it is generated by the AP across 2.4 and 5GHz frequency bands.
- **WiFi Perf Speed Test:** Provision for the user to check the speed of link connectivity, either wireless or wired.
- **Connectivity:** Provides different modes network reachability of cnPilot device.
- **Packet Capture:** Provides feasibility for the user to capture packets on operational interfaces.
- **Logs:** Feasibility to check logs of different modules of cnPilot devices which will help support and the customer to debug an issue.
- **Unconnected Clients:** This section displays clients that are not connected/denied connection.

Chapter 6: Configuration - System

This chapter describes the following topics:

- [System](#)
- [Management](#)
- [Time settings](#)
- [Event Logging](#)

System

Table 10 lists configurable parameters that are available under **Configuration > System** UI tab:

Table 10 Configuration: System parameters

Parameter	Description	Range	Default
Name	Hostname of the device. Configurable maximum length of hostname is 64 characters.	–	cnPilot Model Number-Last 3 Bytes of ESN
Location	The location where the device is placed. The maximum length of location is 64 characters.	–	–
Contact	Contact information for the device.	–	–
Country-Code	To be set by the administrator to the country-of-operation of the device. The allowed operating channels and the transmit power levels on those channels depends on the country of operation. Radios remain disabled unless this is set. The list of countries supported depends on the SKU of the device (FCC, ROW etc.).	–	–
Placement	<p>cnPilot device supports both Indoor and Outdoor deployments. Based on deployment user can configure it as follows:</p> <ul style="list-style-type: none"> • Indoor When selected, only Indoor channels for country code configured will be available and operational. • Outdoor When selected, only outdoor channels for country code configured will be available and operational. 	–	Indoor

Parameter	Description	Range	Default
LED	Select the LED checkbox for the device LEDs to be ON during operation.	–	Enabled
LLDP	Provision to advertise device capabilities and information in the L2 network.	–	Enabled

To configure the above parameters, navigate to the **Configuration > System** tab and provide the details as given below:

1. Enter the hostname of the device in the **Name** textbox.
2. Enter the location where this device is placed in the **Location** textbox.
3. Enter the contact details of the device is placed in the **Contact** textbox.
4. Select the appropriate country code for the regulatory configuration from the **Country-Code** drop-down list.
5. Select **Placement** checkbox parameter **Indoor** or **Outdoor** to configure the AP placement details.
6. Enable **LED** checkbox.
7. Enable **LLDP** checkbox.
8. Click **Save**.

Figure 17 Configuration: System page

The screenshot shows the 'System' configuration page with the following fields and options:

- Name:** E400-AFA308 (Hostname of the device (max 64 characters))
- Location:** Cambium-Bengaluru (Location where this device is placed (max 64 characters))
- Contact:** Cambium Support (Contact information for the device (max 64 characters))
- Country-Code:** India (For appropriate regulatory configuration)
- Placement:** Indoor (selected), Outdoor (Configure the AP placement details)
- LED:** Whether the device LEDs should be ON during operation
- LLDP:** Whether the AP should transmit LLDP packets

Management

Table 11 lists configurable fields that are displayed in the **Configuration > System > Management** tab:

Table 11 Configuration: System > Management parameters

Parameter	Description	Range	Default
Admin Password	Password for authentication of UI and CLI sessions.	–	admin
Autopilot	Provision to configure mode of cnPilot device when Autopilot is enabled in network: <ul style="list-style-type: none"> • Default 	–	Default

Parameter	Description	Range	Default
	<p>Every cnPilot device by default operates as Auto-Pilot slave.</p> <ul style="list-style-type: none"> Master When selected, cnPilot device will take the role of controller. Disabled When selected, auto-pilot mode is disabled on the device. 		
Telnet	Enables Telnet access to the device CLI.	–	Disabled
SSH	Enables SSH access to the device CLI.	–	Enabled
SSH Key	Provision to login to device using SSH Keys. User needs to add Public Key in this section. If configured, user has to login to AP using Private Keys. This is applicable for both CLI and GUI.	–	Disabled
HTTP	Enables HTTP access to the device UI.	–	Enabled
HTTP Port	Provision to configure HTTP port number to access device UI.	1-65535	80
HTTPS	Enables HTTPS access to the device UI.	–	Enabled
HTTPS Port	Provision to configure HTTPS port number to access device UI.	1-65535	443
RADIUS Mgmt Auth	User has provision to control login to AP using RADIUS authentication. If enabled, every credential that are provided by user undergo RADIUS authentication. If success, allowed to login to UI of AP. This is applicable for both CLI and GUI.	–	Disabled
RADIUS Server	Provision to configure RADIUS server for Management Authentication.	–	–
RADIUS Secret	Provision to configure RADIUS shared secret for Management authentication.	–	–
cnMaestro			
Cambium Remote Mgmt.	Enables support for Cambium Remote Management of this device.	–	Enabled

Parameter	Description	Range	Default
Validate Server Certificate	This allows HTTPs connection between cnMaestro and cnPilot device.	–	Enabled
cnMaestro URL	Static provision to onboard device.	–	–
Cambium ID	Cambium ID used for provisioning cnMaestro (Cambium Remote Management) of this device.	–	–
Onboarding Key	Password used for onboarding the device to cnMaestro.	–	–
SNMP			
Enabled	Provision to enable SNMPv2 or SNMPv3 support on device	–	–
SNMPv2c RO community	SNMP v2c read-only community string.	–	–
SNMPv2c RW community	SNMP v2c read-write community string.	–	–
Trap Receiver IP	Provision to configure SNMP trap receiver server IP.	–	–
SNMPv3 Username	Enter username for SNMPv3.	–	–
SNMPv3 Password	Enter password for SNMPv3.	–	–
Authentication	choose Authentication type as MD5 or SHA.	–	MD5
Access	Choose Access type as RO or RW.	–	RO
Encryption	Choose ON or OFF.	–	ON

To configure the above parameters, navigate to the **Configuration > System** tab and provide the details as given below:

1. Enter the admin password of the device in the **Admin Password** textbox.
2. Select **Default, Master** or **Disabled** to enable/disable the **Autopilot** management of APs from the drop-down list.
3. Enable the **Telnet** checkbox to enable telnet access to the device CLI.
4. Enable the **SSH** checkbox to enable SSH access to the device CLI.
 - a. If certificate-based login is required, enter **SSH Key** in the textbox else disabled
5. Enable the **HTTP** checkbox to enable HTTP access to the device UI.

6. If custom port other than default is required, enter **HTTP port** number value for HTTP access in the textbox.
7. Enable the **HTTPS** checkbox to enable HTTPS access to the device UI.
8. If custom port other than default is required, enter **HTTP port** number value for HTTP access in the textbox.
9. If RADIUS based login is required, enable **RADIUS Mgmt Auth** checkbox and enter the details of RADIUS server as follows:
 - a. Enter **RADIUS Server** parameter in the textbox.
 - b. Enter **RADIUS Secret** parameter in the textbox.

To configure **cnMaestro**:

1. Enable **Remote Management** checkbox to support for Cambium Remote Management of this device.
2. Enable **Validate Server Certificate** checkbox to support HTTPS connection between cnMaestro and cnPilot.
3. Enter the URL for cnMaestro in the **cnMaestro URL** textbox.
4. Enter the Cambium ID of the user in the **Cambium ID** textbox.
5. Enter the onboarding Key in the **Onboarding Key** textbox.

To configure **SNMP**:

1. Select **Enable** checkbox to enable SNMP functionality.
2. Enter the SNMP v2c read-only community string in the **SNMPv2c RO community** textbox.
3. Enter the SNMP v2c read-write community string in the **SNMPv2c RW community** textbox.
4. Enter the **Trap Receiver IP** (Currently Cambium support SNMP only v1 and v2c Traps) in the textbox.
5. Enter the SNMP V3 username in the **SNMPv3 Username** textbox.
6. Enter the SNMP V3 password in the **SNMPv3 Password** textbox.
7. Select **MD5** or **SHA** from the **Authentication** drop-down list.
8. Select **RO** or **RW** from the **Access** drop-down list.
9. Select **ON** or **OFF** from the **Encryption** drop-down list.
10. Click **Save**.

Figure 18 Configuration: Management page

Management

Admin Password Configure password for authentication of GUI and CLI sessions

Autopilot Autopilot Management of APs

Telnet Enable Telnet access to the device CLI

SSH Enable SSH access to the device CLI

SSH Key Use SSH keys instead of password for authentication

HTTP Enable HTTP access to the device GUI

HTTP Port Port No for HTTP access to the device GUI(1-65535)

HTTPS Enable HTTPS access to the device GUI

HTTPS Port Port No for HTTPS access to the device GUI(1-65535)

RADIUS Mgmt Auth Enable RADIUS authentication of GUI/CLI sessions

RADIUS Server RADIUS server IP/Hostname

RADIUS Secret RADIUS server shared secret

cnMaestro

Remote Management

Validate Server Certificate

cnMaestro URL

Cambium ID

Onboarding Key

SNMP

Enable Enable/Disable SNMP

SNMPv2c RO community SNMP v2c read-only community string (max 64 characters)

SNMPv2c RW community SNMP v2c read-write community string (max 64 characters)

Trap Receiver IP SNMP trap server ip address

SNMPv3 Username SNMPv3 user name (max 32 characters)

SNMPv3 Password SNMPv3 password (8 to 32 characters)

Authentication

Access

Encryption

Time settings

User can configure up to two NTP servers. These are used by the AP to set its internal clock to respective time zones configured on the device. While powering ON the AP, the clock will reset to default and resyncs the time as the cnPilot AP does not have battery backup. The servers can be specified as an IP addresses or as a hostname (Eg: pool.ntp.org). If NTP is not configured on device, device synchronizes time with cnMaestro if onboarded.

Table 12 lists the fields that are displayed in the **Configuration > System > Time Settings** section:

Table 12 Configuration: System > Time Settings parameters

Parameter	Description	Range	Default
NTP Server 1	Name or IP address of a Network Time Protocol server 1.	—	—
NTP Server 2	Name or IP address of a Network Time Protocol server 2.	—	—

Parameter	Description	Range	Default
Time zone	<p>Time zone can be set according to the location where the AP is installed. By selecting the appropriate time zone from the drop-down list, ensures that the device clock is synced with the wall clock time.</p> <div style="display: flex; align-items: center;">  <div style="border: 1px solid #add8e6; padding: 5px; background-color: #e6f2ff;"> <p>Note Accurate time on the AP is critical for features such as WLAN Scheduled Access, Syslogs etc.</p> </div> </div>	–	–

To configure the above parameters, navigate to the **Configuration > System** tab and provide the details as given below:

1. Enter the name or IP address of the NTP server 1 in the **NTP Server 1** textbox.
2. Enter the name or IP address of the NTP server 2 in the **NTP Server 2** textbox.
3. Select the time zone settings for the AP from the **Time Zone** drop-down list.
4. Click **Save**.

Figure 19 Configuration: Time settings page

Time Settings

NTP Server 1 Name or IP address of a Network Time Protocol server

NTP Server 2

Time Zone Asia/Bengaluru Configure Timezone

Current System Time Wed 10 Apr 2019 16:20:49 IST

Event Logging

cnPilot devices supports multiple troubleshooting methods. Event Logging or Syslog is one of the standard troubleshooting processes. If you have Syslog server in your network, you can enable it on cnPilot device.

Table 13 lists the fields that are displayed in the **Configuration > System > Event Logging** section.

Table 13 Configuration: System > Event Logging parameters

Parameter	Description	Range	Default
Syslog Server 1	Hostname or IP address of the Syslog server and respective port number.	–	514
Syslog Server 2	Hostname or IP address of the Syslog server and respective port number.	–	514

To configure the above parameters, navigate to the **Configuration > System** tab and provide the details as given below:

1. Enter the FQDN or IP address of the **Syslog Server 1** along with customized port number in the textbox. If the port number is not entered, AP will take default value as 514.

2. Enter the FQDN or IP address of the **Syslog Server 2** along with customized port number in the textbox. If the port number is not entered, AP will take default value as 514.
3. Click **Save**.

Figure 20 Configuration: Event Logging page



The screenshot shows the 'Event Logging' configuration page. It contains two rows of configuration for Syslog Servers. The first row is for 'Syslog Server 1' with an IP address of '10.110.211.97' and a port of '514'. The second row is for 'Syslog Server 2' with an IP address of '10.110.219.10' and a port of '1234'. A small text label 'IP address of Syslog server' is positioned to the right of the port input fields. At the bottom of the form, there are two buttons: 'Save' and 'Cancel'.

Server Name	IP Address	Port
Syslog Server 1	10.110.211.97	514
Syslog Server 2	10.110.219.10	1234

Maximum of two Syslog servers can be configured on cnPilot device. Events are sent to both configured Syslog servers if they are up and running.

Chapter 7: Configuration – Radio

This chapter describes the following topics:

- [Overview](#)
- [Configuring Radio parameters](#)

Overview

cnPilot devices support numerous configurable radio parameters to enhance the quality of service as per the deployment.

Configuring Radio parameters

All cnPilot devices support dual concurrent radio operations, i.e. both 2.4GHz and 5GHz can be turned on in parallel and hence each radio can be configured independently. **Radio 1** represents configuration of **2.4GHz Wi-Fi radio** and **Radio 2** represents configuration of **5GHz Wi-Fi radio** of cnPilot device. Information of each band radio configurable parameters are listed in [Table 14](#).

Table 14 Configure: Radio parameters

Parameter	Description	Range	Default
Radio			
Enable	Enables operation of radio.	-	-
Channel	User can select the channel from the drop-down list. Channels in drop-down list is populated based on Country selected in Configuration > System UI .	<ul style="list-style-type: none"> • 2.4GHz: 1 - 14 • 5GHz: 36 - 173 	Auto
Channel Width	User can select operating width of the channel. <ul style="list-style-type: none"> • For 2.4GHz: Only 20MHz channel width is supported. • For 5GHz: 20MHz, 40MHz and 80MHz channel width is supported. 	-	<ul style="list-style-type: none"> • 20MHz for 2.4GHz • 80MHz for 5GHz
Transmit Power	User can configure transmit power of each radio based on coverage and SLA. Unit of transmit power is in dBm and its range is from 4 to 30. Maximum transmit power of cnPilot devices varies based on model number. More details of transmit power supported by each cnPilot device is available at https://www.cambiumnetworks.com/products/wifi/ .	<ul style="list-style-type: none"> • 2.4GHz: 4 - 30 • 5GHz: 4 - 30 	Auto

Parameter	Description	Range	Default
	Transmit power drop-down box varies as per the country selected in Configuration > System UI . Default value is AUTO , which means radio transmit power is configured to maximum as per the county configured selected in Configuration > System UI .		
Beacon Interval	User can configure time durations between two consecutive Beacon's. It is termed as Beacon interval.	50ms - 3400ms.	100
Minimum Unicast rate	Provision to adjust the coverage area of cnPilot device. Higher the rate selected, lesser the range. User can configure this value based on SLA in deployment. Drop-down list contains all values that are advertised by cnPilot device which includes legacy, HT and VHT rates.	Standard 802.11b and 802.11g data rates	1Mbps
Multicast data rate	Provision to configure multicast traffic rate. This is modified based on type of wireless station that will be connected to cnPilot device. Drop-down list contains highest-basic, lowest-basic and highest-supported.	–	<ul style="list-style-type: none"> • Highest Basic for 2.4GHz • Lowest Basic for 5GHz
Airtime Fairness	<p>Airtime Fairness is a solution on APs to increase the performance of 11n and 11ac clients (HT clients) in the presence of legacy 11abg clients. Legacy clients need more air time to transmit/receive the data compared to HT clients (11n and 11ac clients). Because of this the overall throughput of the HT clients falls down. Enabling this feature improves the performance of HT clients by throttling the legacy clients.</p> <p>Compared to faster clients (802.11n/802.11ac), the slower clients (802.11a/802.11bg) consumes more airtime to transmit the same size data, in turn the throughput of faster clients fall as they get lesser chance to transmit (lesser airtime). Enabling this feature improves the performance of faster clients in a wireless network which is dominated by slower clients. This is achieved by controlling the airtime of slower clients.</p>	–	Disabled
Candidate Channels	<p>cnPilot provides user to configure selective channels based on their requirement. Options vary based on band of operation and is as follows:</p> <ul style="list-style-type: none"> • For 2.4GHz: <ul style="list-style-type: none"> ○ All ○ Specific • For 5GHz: 	<ul style="list-style-type: none"> • 2.4GHz: 1 - 14 • 5GHz: 36 - 173 	All

Parameter	Description	Range	Default
	<ul style="list-style-type: none"> ○ All ○ Specific ○ Prefer Non-DFS ○ Prefer DFS 		
Mode	All cnPilot devices are either 802.11ac Wave 1 or 802.11ac Wave 2 supported. There are few legacy clients which might not work as expected, hence this parameter can be tuned to backward compatibility based on wireless clients.	<ul style="list-style-type: none"> • 2.4GHz: b, bg, n, gn • 5GHz: a, ac, an, n, n-ac. 	<ul style="list-style-type: none"> • 11n mixed mode for 2.4GHz • 11ac for 5GHz
Short Guard Interval	Standard 802.11 parameter to increase the throughput of cnPilot device.	–	Enabled
Off Channel Scan (OCS)			
Enable	Provision to enable OCS on device to capture neighbour clients and APs.	–	–
Dwell-time	Configure the time period to spend scanning of Wi-Fi devices on a channel.	50-300	50ms
Auto-RF			
Enable	Provision to enable auto-rf on device.	–	Disabled
Channel Selection Mode	AutoRF supports two modes of channel selection: <ul style="list-style-type: none"> • Interference based • Channel Utilization based 	–	Interference
Channel Hold Time	Configure time period for the device to be on same channel selected by auto-rf algorithm, irrespective of quality of channel after selection.	5-1800	120 Min
Channel Utilization Threshold	Configure the utilization thresholds to trigger channel selection by auto-rf.	20-40	25%
Interference Avoidance			

Parameter	Description	Range	Default
Packet Error Rate Threshold	This is a trigger mechanism to move out of current channel when configured threshold is met.	0-100	30%
Enhanced Roaming			
Enable	Provision to enable enhanced roaming on device.	–	Disabled
Roam SNR threshold	cnPilot device triggers de-authentication of wireless station, when the wireless station is seen at configured SNR or below.	1-100	15dB

To configure the above parameters, navigate to the **Configure > Radio** tab and select **Radio 1 (2.4GHz)** or **Radio 2 (5GHz)** tab and provide the details as given below:

1. Select the **Enable** checkbox to enable the operations of this radio.
2. Select the primary operating channel from the **Channel** drop-down list.
3. Select the operating width (20 MHz, 40 MHz, or 80 MHz) of the channel from the **Channel Width** drop-down list for 5 GHz only. cnPilot do not support 40 MHz and 80 MHz in 2.4 GHz.
4. Select radio transmit power from the **Transmit Power** drop-down list.
5. Enter the beacon interval in the **Beacon Interval** textbox.
6. Select **Minimum Unicast Rate** from the drop-down list
7. Select **Highest Basic, Lowest Basic** or **Highest Supported** from the **Multicast data rate** drop-down list.
8. Enable **Airtime Fairness** checkbox.
9. Select the preferred **Candidate Channels** from the drop-down list.
10. Select **Mode** details from the drop-down list.
11. Enable **Short Guard Interval** checkbox.
12. Click **Save**.

To configure **Off Channel Scan**:

1. Select **Enable** checkbox to enable the operations of this radio.
2. Enter **Dwell-Time** in milliseconds in the textbox.
3. Click **Save**.

To configure **Auto-RF**:

1. Select **Enable** checkbox to enable the operations of this radio.
2. Select **Channel Selection Mode** from the drop-down list.
3. Enter **Channel Hold Time** in minutes in the textbox.
4. Enter **Channel Utilization Threshold** parameter in the textbox.
5. Click **Save**.

To configure **Interference Avoidance**:

1. Enter **Packet Error Rate Threshold** parameter in the textbox.
2. Click **Save**.

Figure 21 Configure: Radio parameters

Radio

Enable	<input checked="" type="checkbox"/> <i>Enable operation of this radio</i>	
Channel	Automatic	<i>Primary operating channel</i>
Channel Width	20MHz	<i>Operating width of the channel</i>
Transmit Power	6	<i>Radio transmit power in dBm (4 to 30; Subject to regulatory limit)</i>
Beacon Interval	100	<i>Beacon interval in mSec (50 to 3400)</i>
Minimum Unicast rate	1	<i>Configure the minimum unicast management rate (Mbps)</i>
Multicast data rate	Highest Basic	<i>Data-rate to use for transmission of multicast/broadcast packets</i>
Airtime Fairness	<input type="checkbox"/> <i>Enable Airtime Fairness</i>	
Candidate Channels	All	
Mode	default	<i>All modes clients are allowed</i>
Short Guard Interval	<input checked="" type="checkbox"/> <i>Enable short guard interval</i>	

Off Channel Scan

Enable	<input type="checkbox"/> <i>Enable OCS</i>	
Dwell-time	50	<i>Configure Off-Channel-Scan dwelltime in milliseconds (50-300)</i>

Auto RF

Enable	<input checked="" type="checkbox"/> <i>Enable Auto RF</i>	
Channel Selection Mode	Interference	<i>Channel selection done based on interference</i>
Channel Hold Time	120	<i>Configure channel hold time in minutes (5-1800)</i>
Channel Utilization Threshold	25	<i>Configure channel utilization threshold in % (20-40)</i>

Interference Avoidance

Packet Error Rate Threshold	30	<i>Configure packet error rate threshold in % (0-100)</i>
------------------------------------	----	---

Save
Cancel

To configure **Enhanced Roaming**:

1. Select the **Enable** checkbox to enable the operations of this radio.
2. Enter **Roam SNR threshold** parameter in the textbox.
3. Click **Save**.

Figure 22 Configure: Radio > Enhanced Roaming parameters

Enable *Enable active disconnection of clients with weak signal*

Roam SNR threshold SNR below which clients will be forced to roam (1-100 dB)

Chapter 8: Configuration - Wireless LAN

This chapter describes the following topics:

- [Overview](#)
- [Configuring WLAN parameters](#)

Overview

cnPilot devices support up-to 16 unique WLANs per radio. Each of these WLANs can be configured as per the customer requirement and type of wireless station.

Configuring WLAN parameters

Configurable parameters under WLAN profile are categorized into two sections:

1. Basic
2. Advanced

Table 15 lists the configurable parameters for a WLAN profile which is common across bands.

Table 15 Configure: WLAN > Basic parameters

Parameters	Description	Range	Default
WLAN > Basic			
Enable	Option to enable a WLAN profile. Once enabled, a Beacon is broadcasted with SSID and respective configured parameters in a WLAN profile.	–	–
Mesh	<p>This parameter is required when a WDS connection is established with cnPilot devices. Four options are available under this parameter:</p> <ol style="list-style-type: none"> 1. Base A WLAN profile configured with mesh-base will operate like a normal AP. Its radio will beacon on startup so its SSID can be seen by radios configured as mesh-clients. 2. Client A WLAN profile configured with mesh-client will scan all available channels on startup, looking for a mesh-based AP to connect. 	–	OFF (Access Profile Mode)

Parameters	Description	Range	Default
	<p>3. Recovery</p> <p>A WLAN profile configured as mesh-recovery will broadcast pre-configured SSID upon detection of mesh link failure after a successful connection. This needs to be exclusively configured on mesh-base device. Mesh-client will auto scan for mesh-recovery SSID upon failure of mesh link.</p> <p>4. Off</p> <p>Mesh support disable on WLAN profile.</p>		
SSID	SSID is the unique network name that wireless stations scans and associates.	–	–
VLAN	VLAN is configured to segregate wireless station traffic from AP traffic in the network. Wireless stations obtain IP address from the subnet configured in VLAN field of WLAN profile.	1-4094	1
Security	<p>This parameter determines key values that is encrypted based on selected algorithm. Following security methods are supported by cnPilot devices:</p> <p>1. Open</p> <p>This method is preferred when Layer 2 authentication is built in the network. With this configured on cnPilot device, any wireless station will be able to connect.</p> <p>2. Osen</p> <p>This method is extensively used when Passpoint 2.0 is enabled on cnPilot devices. If Passpoint 2.0 is disabled, this security plays no role in wireless station association.</p> <p>3. WPA2-Pre-Shared Keys</p> <p>This mode is supported with AES encryption.</p> <p>4. WPA2 Enterprise</p> <p>This security type uses 802.1x authentication to associate wireless stations. This is a centralized system of authentication method.</p>	–	Open
Passphrase	String that is a key value to generate keys based on security method configured.	–	12345678
Radios	Each SSID can be configured to be transmitted as per the deployment requirement. For a regular access profile, options available to configure transmit mode of SSID:	–	2.4GHz and 5GHz

Parameters	Description	Range	Default
	<ul style="list-style-type: none"> • 2.4GHz and 5GHz • 2.4GHz • 5GHz <p>For mesh profile, options available are:</p> <ul style="list-style-type: none"> • 2.4GHz • 5GHz 		
VLAN Pooling	<p>This parameter is required when user requires to distribute clients across multiple subnets. Different modes of VLAN pooling is supported by cnPilot devices, based on infrastructure available at deployment site. Modes supported are as follows:</p> <ol style="list-style-type: none"> 1. Disabled This feature is disabled for this WLAN. 2. Radius Based User is expected to configure WPA2 Enterprise for this mode to support. During association phase, cnPilot obtains pool name form RADIUS transaction and based on present distribution of wireless station across VLANs, cnPilot selects appropriate VLAN and wireless station requests a IP address from the VLAN selected by cnPilot device. 3. Static For this mode to support, user requires to configure VLAN Pool details available under Configure > Network > VLAN pool. During association phase, cnPilot obtains pool and based on present distribution of wireless station across VLANs, cnPilot selects appropriate VLAN and wireless station requests an IP address from the VLAN selected by cnPilot device. 	–	Disabled
Max Clients	This specifies the maximum number of wireless stations that can be associated to a WLAN profile. This varies based on cnPilot device model number. Refer Table 16 for more details.	1-512 (Refer Table 16)	127
Client Isolation	This feature needs to be enabled when there is a need for prohibition of wireless station to station communication either over the network or on an AP. Three options are available to configure based on requirement:	–	Disabled

Parameters	Description	Range	Default
	<ol style="list-style-type: none"> Disable This option when selected disables client isolation feature. i.e. any wireless station can communicate to other wireless station. Local This options when selected enables client isolation feature. This option prevents wireless station communications connected to same AP. Network Wide This options when selected enables client isolation feature. It prevents wireless station communications connected to different AP deployed in same network. Static This option when configured enables client isolation feature across network. User has to configure gateway MAC to access device across subnets. 		
cnMaestro Managed Roaming	By default, cnPilot devices support Layer 2 roaming. This option enables Layer 3 roaming. It is mandatory that cnPilot devices are connected to cnMaestro. Layer 3 roaming is valid only for Guest Access.	–	Disabled
Hide SSID	This is the basic security mode of a Wi-Fi device. This parameter when enabled, will not broadcast SSID.	–	Disabled
Session Timeout	This field is specific to non-guest wireless stations. When a wireless station connects, a session timer is triggered. Once session time expires, wireless station has to undergo either re-authentication or re-association based on state of wireless station. By default, it is enabled.	60-604800	28800
Inactivity Timeout	Inactivity timer triggers whenever there is no communication between cnPilot device and wireless station associated to cnPilot device. Once the timer reaches the configured Inactivity timeout value, APs sends a de-authentication to that wireless station. By default, it is enabled.	60-28800	1800
Drop Multicast Traffic	When enabled, will drop all multicast flowing in or out of that WLAN.	–	Disabled

To configure the above parameters, navigate to the **Configure > WLAN > Basic** tab and provide the details as given below:

1. Select the **Enable** checkbox to enable a particular WLAN.
2. Select the operating parameters from the **Mesh** drop-down list.

3. Enter the SSID name for this WLAN in the **SSID** textbox.
4. Enter the default VLAN assigned to the clients on this WLAN in the **VLAN** textbox.
5. Select **Security** type from the drop-down list.
6. Enter WPA2 Pre-shared security passphrase or key in the **Passphrase** textbox.
7. Select the radio type (2.4GHz, 5GHz) on which the WLAN should be supported from the **Radios** drop-down list.
8. Select the required **VLAN Pooling** parameters from the drop-down list.
9. Select **Max Clients** parameter value from the drop-down list.
10. Select the required **Client Isolation** parameter from the drop-down list.
11. Enable **cnMaestro Managed Roaming** checkbox for layer2/layer 3 roaming.
12. Enable **Hide SSID** checkbox.
13. Enter the session timeout value in the **Session Timeout** textbox.
14. Enter the inactivity timeout value in the **Inactivity timeout** textbox.
15. Select **Drop Multicast Traffic** checkbox to enable dropping multicast traffic.
16. Click **Save**.

Table 16 WLAN (Max Clients) parameters

Number of Clients	2.4GHz	5GHz
e600 and e700	512	512
e410 and e430	256	256
E400 and E500	256	128

Figure 23 Configure: WLAN > Basic parameter

Basic

Enable
 Mesh Off *Mesh Base/Client/Recovery mode*
 SSID *The SSID of this WLAN (upto 32 characters)*
 VLAN *Default VLAN assigned to clients on this WLAN. (1-4094)*
 Security *Set Authentication and encryption type*
 Passphrase *WPA2 Pre-shared Security passphrase or key*
 Radios *Define radio types (2.4GHz, 5GHz) on which this WLAN should be supported*
 VLAN Pooling *Configure VLAN pooling*
 Max Clients *Default maximum Client assigned to this WLAN. (1-256)*
 Client Isolation *When selected, it allows wireless clients connected to the same AP or different APs to communicate with each other in the same VLAN*
 cnMaestro Managed Roaming *Enable centralized management of roaming for wireless clients through cnMaestro*
 Hide SSID *Do not broadcast SSID in beacons*
 Session Timeout *Session time in seconds (60 to 604800)*
 Inactivity Timeout *Inactivity time in seconds (60 to 28800)*
 Drop Multicast Traffic *Drop the send/receive of multicast traffic*

Table 17 Configure: WLAN > Advanced parameters

Parameters	Description	Range	Default																														
WLAN > Advanced																																	
UAPSD	<p>When enabled, cnPilot devices support WMM Power Save / UAPSD. This is required where applications such as VOIP Calls, Live Video streaming etc. is in use. This feature helps to prioritize traffic. Below is the default traffic priority followed by cnPilot device.</p> <table border="1"> <thead> <tr> <th>Priority</th> <th>802.1D Priority (= UP)</th> <th>802.1D Designation</th> <th>Access Category</th> <th>WMM Designation</th> </tr> </thead> <tbody> <tr> <td rowspan="7"> lowest ↓ highest </td> <td>1</td> <td>BK</td> <td rowspan="2">AC_BK</td> <td rowspan="2">Background</td> </tr> <tr> <td>2</td> <td>-</td> </tr> <tr> <td>0</td> <td>BE</td> <td rowspan="2">AC_BE</td> <td rowspan="2">Best Effort</td> </tr> <tr> <td>3</td> <td>EE</td> </tr> <tr> <td>4</td> <td>CL</td> <td rowspan="2">AC_VI</td> <td rowspan="2">Video</td> </tr> <tr> <td>5</td> <td>VI</td> </tr> <tr> <td>6</td> <td>VO</td> <td rowspan="2">AC_VO</td> <td rowspan="2">Voice</td> </tr> <tr> <td>7</td> <td>NC</td> </tr> </tbody> </table>	Priority	802.1D Priority (= UP)	802.1D Designation	Access Category	WMM Designation	lowest ↓ highest	1	BK	AC_BK	Background	2	-	0	BE	AC_BE	Best Effort	3	EE	4	CL	AC_VI	Video	5	VI	6	VO	AC_VO	Voice	7	NC	-	Disabled
Priority	802.1D Priority (= UP)	802.1D Designation	Access Category	WMM Designation																													
lowest ↓ highest	1	BK	AC_BK	Background																													
	2	-																															
	0	BE	AC_BE	Best Effort																													
	3	EE																															
	4	CL	AC_VI	Video																													
	5	VI																															
	6	VO	AC_VO	Voice																													
7	NC																																
QBSS	<p>When enabled, appends QBSS IE in Management frames. This IE provides information of channel usage by AP, so that smart wireless station can decide better AP for connectivity. Station count, Channel utilization and</p>	-	Disabled																														

Parameters	Description	Range	Default
	Available admission capacity are the information available in this IE.		
DTIM interval	This parameter plays a key role when power save supported mobile stations are part of infrastructure. This field when enabled controls the transmission of Broadcast and Multicast frames.	1-255	1
Monitored Host			
Host	This feature is required where there is interrupted backbone network. cnPilot device monitors the reachability of hostname/IP configured in this parameter and modifies the state of WLAN.	–	Disabled
Interval	The frequency of monitoring the network health based on the status of keep-alive mechanism w.r.t configured monitored host.	60-3600 Sec	300
Attempts	The number of packets in the keep-alive mechanism to determine the status.	1-20	1
DNS Logging Host	This feature is required when an Administrator requires to monitor the websites accessed by wireless stations connected to WLAN profile.	–	Disabled
Connection Logging Host	When enabled provides information of all TCP connections accessed by a wireless station that is associated to WLAN.	–	Disabled
Band Steering	This feature when enabled, steers wireless stations to connect to 5GHz. There are three modes supported by cnPilot device. The mode can be selected based on either deployment or wireless station type. Below is the order of modes, which forces wireless station to connect to 5GHz band. <ul style="list-style-type: none"> • Low • Normal • Aggressive 	–	Disabled
Proxy ARP	Provision to avoid ARP flood in wireless network. When enabled, AP responds to ARP requests for the wireless stations connected to that AP. This is for IPv4 infrastructure.	–	Enabled
Proxy ND	Provision to avoid ARP flood in wireless network. When enabled, AP responds to ARP requests for the wireless	–	Disabled

Parameters	Description	Range	Default
	stations connected to that AP. This is for IPv6 infrastructure.		
Unicast DHCP	Provision to transmit DHCP offer and ACK/NACK packets as Unicast packets to wireless stations.	–	Enabled
Insert DHCP Option 82	<p>When enabled, DHCP packets generated from wireless stations that are associated to APs are appended with Option 82 parameters. Option 82 provides provision to append Circuit ID and Remote ID. Following parameters can be selected in both Circuit ID and Remote ID:</p> <ul style="list-style-type: none"> • Hostname • AP MAC • BSSID • SSID • VLAN ID • Site ID • Custom • All 	–	Disabled
Tunnel Mode	This option is enabled when user traffic is tunneled to DMZ network either using L2TP or L2GRE.	–	Disabled
Fast-Roaming Protocol	<p>One of the important aspects to support voice applications on Wi-Fi network (apart from QoS) is how quickly a client can move its connection from one AP to another. This should be less than 150 msec to avoid any call drop. This is easily achievable when WPA2-PSK security mechanism is in use. However, in enterprise environments there is a need for more robust security (the one provided by WPA2-Enterprise). With WPA2-Enterprise, the client exchanges multiple frames with AAA server and hence depending on the location of AAA server the roaming-time will be above 700 msec.</p> <p>Select any one of the following:</p> <ol style="list-style-type: none"> 1. OKC This roaming method is a proprietary solution to bring scalability to the roaming problem. This method avoids the need to authenticate with AAA server every time a client moves to new AP. 2. 802.11r This is the IEEE standard for fast roaming, introduces a new concept of roaming where the initial handshake 	–	Disabled

Parameters	Description	Range	Default
	with the new AP is done even before the client roams to the target AP, which is called Fast Transition (FT).		
RRM (802.11k)	AP sends the SSID name of the neighbor APs (SSID configured on multiple APs) to 11k clients. Following parameters needs to be enabled: <ul style="list-style-type: none"> • Enable OCS • Enable RRM • Support for WPA2 authentication method 	–	Disabled
PMF (802.11w)	802.11w, also termed as Protected Management Frames (PMF) Service, defines encryption for management frames. Unencrypted management frames makes wireless connection vulnerable to DoS attacks as well as they cannot protect important information exchanged using management frames from eavesdroppers.	<ul style="list-style-type: none"> • Optional • Mandatory • Disabled 	–
SA Query Retry Time	The legitimate 802.11w client must respond with a Security Association (SA) Query Response frame within a pre-defined amount of time (milliseconds) called the SA Query Retry time.	100-500	100ms
Association Comeback Time	This value is included in the Association Response as an Association Comeback Time information element. AP will deny association for the configured interval.	1-20	1 Sec

To configure the above parameters, navigate to the **Configure > WLAN > Basic** tab and provide the details as given below:

1. Select the **UAPSD** checkbox to enable UAPSD.
2. Select the **QBSS** checkbox to enable QBSS.
3. Enter the value in the **DTIM interval** textbox to configure DTIM interval.
4. Enter IP address or Hostname in **Host** textbox.
5. Enter **Interval** time duration in the textbox.
6. Select number of attempts to check the reachability of monitored hoist in the **Attempts** drop-down list.
7. Enter an IP Address or Hostname in the **Monitored Host** textbox.
8. Enter the FQDN or IP address of the Server where all the client DNS requests will be logged in the **DNS Logging Host** server along with customized port number in the textbox. If the port number is not entered, AP will take default value as 514.
9. Enter the FQDN or IP address of the Server where all wireless client connectivity events/logs will be displayed in the configured **Connection Logging Host** server along with customized port number in the textbox. If the port number is not entered, AP will take default value as 514.
10. Select **Band Steering** parameter for 5GHz band from the drop-down list.

11. Enable **Proxy ARP** checkbox to avoid ARP flood in wireless network.
12. Enable **Proxy ND** checkbox to avoid ARP flood in wireless network.
13. Enable **Unicast DHCP** checkbox to Convert DHCP-OFFER and DHCP-ACK to unicast before forwarding to clients.
14. Enable **Insert DHCP Option 82** checkbox.
15. Select **Option 82 Circuit ID** to enable DHCP Option-82 from the drop-down list.
16. Select **Option 82 Remote ID** to choose the MAC address of the AP from the drop-down list.
17. Select **Tunnel Mode** checkbox to enable tunnelling of WLAN traffic over configured tunnel.
18. Enable the required **OKC or 802.11r** configure roaming protocol in the **Fast-Roaming Protocol** checkbox.
19. Enable **RRM (802.11k)** checkbox.
20. Select **PMF (802.11w)** parameter from the drop-down list.
 - a. Enter **SQ Query Retry Time** in the textbox.
 - b. Enter **Association Comeback Time** in the textbox.
21. Click **Save**.

Figure 24 Configure: WLAN > Advanced parameter

Advanced

UAPSD Enable UAPSD

QBSS Enable QBSS load element

DTIM interval Number of beacons (1-255)

Monitored Host

Host IP Address or Hostname that should be reachable for this WLAN to be active

Interval Duration in seconds (60-3600)

Attempts Number of attempts to check the reachability of monitored host (1-20)

DNS Logging Host Port Syslog server where all client DNS requests will be logged

Connection Logging Host Port Syslog server where all client connection requests will be logged

Band Steering Steer dual-band capable clients towards 5GHz radio

Proxy ARP Respond to ARP requests automatically on behalf of clients

Proxy ND Respond to ipv6 ND requests automatically on behalf of clients

Unicast DHCP Convert DHCP-OFFER and DHCP-ACK to unicast before forwarding to clients

Insert DHCP Option 82 Enable DHCP Option 82

Tunnel Mode Enable tunnelling of WLAN traffic over configured tunnel

Fast-Roaming Protocol OKC 802.11r Configure roaming protocol

RRM (802.11k) Enable Radio Resource Measurements (802.11k)

PMF (802.11w)

Table 18 Configure: WLAN > Radius Server parameters

Parameters	Description	Range	Default
Authentication Server	Provision to configure RADIUS Authentication server details such as Hostname, Shared Secret, Port Number and Realm. Maximum of three RADIUS server can be configured.	–	Disabled
Accounting Server	Provision to configure Accounting server details such as Hostname, Shared Secret, Port Number. Maximum of three RADIUS server can be configured.	–	Disabled
Timeout	Wait time period for response from AAA server.	1-30	3
Attempts	Parameter to configure number of attempts that a device should send AAA request to server if no response is received within configured timeout period.	1-3	1
Accounting Mode	This field is enabled based on customer requirement. Accounting packet is transmitted based on mode selected. <ol style="list-style-type: none"> Start-Stop Accounting packets are transmitted by AP to AAA server when a wireless station is connected and then disconnects. Start-Interim-Stop Accounting packets are transmitted by AP to AAA server when a wireless station connects and then at regular intervals of configured Interim Update Interval and then when it disconnects. 	–	Disabled
Accounting Packet	When enabled, Accounting-On is sent for every client when connected.	–	Disabled
Sync Accounting Records	When enabled, will share the accounting records when wireless stations move across different AP that are Layer 2 connected.	–	Disabled
Server Pool Mode	User can configure multiple Authorization and Accounting servers. Based on number of wireless stations, user can choose either Failover or Load Balance mode. <ol style="list-style-type: none"> Load Balance AP communicates with multiple servers and ensures that authorization and accounting are equally shared across configured servers. 	–	Load Balance

Parameters	Description	Range	Default
	<p>2. Failover</p> <p>AP selects the RADIUS server which is up and running based on the order of configuration.</p>		
NAS Identifier	This is configurable parameter and is appended in RADIUS request packet.	–	Hostname/ System Name
Interim Update Interval	This field is used when RADIUS accounting is enabled and mode selected as Start-Interim-Stop.	10-65535	1800
Dynamic Authorization	This option is required, where there is a CoA requests from AAA/RADIUS server.	–	Disabled
Dynamic VLAN	When enabled, AP honors the VLAN information provided in RADIUS transaction. Wireless station requests IP address from the same VLAN learnt through RADIUS.	–	Enabled
Proxy through cnMaestro	This option is enabled, whenever cnMaestro is required to act as proxy server to RADIUS authentication requests coming from cnPilot devices that are connected to cnMaestro.	–	Disabled

To configure the above parameters, navigate to the **Configure > WLAN** tab and select **Radius Server** tab and provide the details as given below:

1. Enter the RADIUS Authentication server details such as Hostname/Shared Secret/Port Number/Realm in the **Authentication Server 1** textbox.
2. Enter the time in seconds of each request attempt in **Timeout** textbox.
3. Enter the number of attempts before a request is given up in the **Attempts** textbox.
4. Select the configuring **Accounting Mode** from the drop-down list.
5. Enable **Accounting Packet** checkbox.
6. Enable **Sync Accounting Records** checkbox to enable sync accounting records configuration.
7. Enable **Load Balance/Failover** in the **Server Pool Mode** checkbox.
8. Enter the **NAS Identifier** parameter in the textbox.
9. Enter the **Interim Update Interval** parameter value in the textbox.
10. Enable **Dynamic Authorization** checkbox to configure dynamic authorization for wireless clients.
11. Enable **Dynamic VLAN** checkbox.
12. Enable **Proxy through cnMaestro** checkbox.
13. Click **Save**.

Figure 25 Configure: WLAN > Radius Server parameter

Table 19 Configure: WLAN > Guest Access > Internal Access Point parameters

Parameters	Description	Range	Default
WLAN > Guest Access > Internal Access Point			
Enable	Enables the Guest Access feature.	–	Disabled
Access Policy	<p>There are four types of access types provided for the user:</p> <ol style="list-style-type: none"> Clickthrough This mode allows the users to get access data without any authentication mechanism. User can access internet as soon as he is connected and accepts Terms and Conditions. RADIUS This mode when selected, user has to provide username and password, which is then redirected to RADIUS server for authentication. If successful, user is provided with data access. 	–	Clickthrough

Parameters	Description	Range	Default
	<p>3. LDAP</p> <p>This mode when selected, user has to provide username and password, which is then redirected to LDAP server for authentication. If successful, user is provided with data access.</p> <p>4. Local Guest Account</p> <p>User has to configure username and password on device, which has to be provided in the redirection page for successful authentication and data access.</p>		
Redirect Mode	<p>This option helps the user to configure the HTTP or HTTPS mode of redirection URL.</p> <p>1. HTTP</p> <p>AP sends a HTTP POSTURL to the associated client, which will be <a href="http://<Pre-defined-URL>">http://<Pre-defined-URL>.</p> <p>2. HTTPS</p> <p>AP sends HTTPS POSTURL to the successful associated client, which will be <a href="https://<Pre-defined-URL>">https://<Pre-defined-URL>.</p>	–	HTTP
Redirect Hostname	<p>User can configure a friendly hostname, which is added in DNS server and is resolvable to cnPilot IP address. This parameter once configured will be replaced with IP address in the redirection URL provided to wireless stations.</p>	–	–
Title	<p>User can configure a Title to the splash page. Configured text in this parameter will be displayed in the redirection page. This text is usually Bold.</p>	Up to 255 characters	Welcome To Cambium Powered Hotspot
Contents	<p>User can configure the contents of Splash page using this field. Displays the text configured under the Title section of redirection page.</p>	Up to 255 characters	Please enter username and password to get Web Access
Terms	<p>Splash page displays the text configured when user accepts Terms and Agreement.</p>	Up to 255 characters	–
Logo	<p>Displays the logo image updated in URL <a href="http(s)://<ipaddress>/logo.png">http(s)://<ipaddress>/logo.png. Either PNG or JPEG format of logo are supported.</p>	–	–

Parameters	Description	Range	Default
Background Image	Displays the background image updated in URL <a href="http(s)://<ipaddress>/backgroundimage.png">http(s)://<ipaddress>/backgroundimage.png . Either PNG or JPEG format of logo are supported.	–	–
Success Action	Provision to configure redirection URL after successful login to captive portal services. User can configure three modes of redirection URL: <ol style="list-style-type: none"> Internal Logout Page After successful login, wireless client is redirected to logout page hosted on AP. Redirect user to External URL Here users will be redirected to URL which is configured on device in Redirection URL configurable parameter. Redirect user to Original URL Here users will be redirected to URL that is accessed by user before successful captive portal authentication. 	–	Internal Logout page
Redirect user to External URL	Provision to configure re-direction URL after successful login and an additional information of AP and wireless station information can be appended in the URL. <ul style="list-style-type: none"> Prefix Query Strings in Redirect URL This option is selected by default. Following information is appended in the redirection URL: <ul style="list-style-type: none"> ○ SSID ○ AP MAC ○ NAS ID ○ AP IP ○ Client MAC ○ Redirection URL ○ User can provide either HTTP or HTTPS URL 	–	–
Redirection user to Original URL	Users will be redirected to URL that is accessed by user before successful captive portal authentication. There is additional parameter Prefix Query Strings in Redirection URL that is enabled by default and details given below: <ul style="list-style-type: none"> Prefix Query Strings in Redirect URL This option is selected by default. Following information is appended in the redirection URL: 	–	–

Parameters	Description	Range	Default
	<ul style="list-style-type: none"> ○ SSID ○ AP MAC ○ NAS ID ○ AP IP ○ Client MAC 		
Success message	Provision to configure text to display upon successful Guest Access authentication. This is applicable only when Success Action mode is Internal Logout Page.	–	–
Redirect	<ul style="list-style-type: none"> • If enabled, only HTTP URLs will be redirected to Guest Access login page. • If disabled, both HTTP and HTTPS URLs will be redirected to Guest Access login page. 	–	Enabled
Redirect User Page	IP address configured in this field is used as logout URL for Guest Access sessions. IP address configured should be not reachable to internet.	–	1.1.1.1
Proxy Redirection Port	Proxy port can be configured with which proxy server is enabled. This allows URL's accessed with proxy port to be redirected to login page.	1 - 65535	–
Session Timeout	This is the duration of time, client will be allowed to access internet if quota persists, after which AP sends de-authentication. Wireless station has to undergo Guest Access authentication after session timeout.	60 - 2592000	28800
Inactivity Timeout	Provision to configure timeout period to disconnect wireless stations that are associated but no data traffic. AP starts timer when there is no data received from a wireless station and disconnects when timer reaches 0.	60 - 2592000	1800
MAC Authentication Fallback	It's a mechanism in which wireless stations will be redirected to Guest Access login page after any supported type of MAC address authentication fails.	–	Disabled
Extend Interface	Provision to support Guest Access on Ethernet interface.	–	Disabled
Whitelist	Provision to configure either IPs or URLs to bypass traffic, therefor user can access those IPs or URLs without Guest Access authentication.	–	–

Parameters	Description	Range	Default
Captive Portal bypass User Agent	Provision to limit the auto-popup to a certain browser as configured based on User-agent of browsers.	–	–

To configure the above parameters, navigate to the **Configure > WLAN > Guest Access** tab and provide the details as given below:

1. Select **Enable** checkbox to enable the Guest Access feature.
2. Enable **Internal Access Point** checkbox.
3. Enable the required access types from the **Access Policy** checkbox.
4. Enable **HTTP** or **HTTPS** from the **Redirect Mode** checkbox.
5. Enter **Redirect Hostname** in the textbox.
6. Enter the title to appear in the splash page in the **Title** textbox.
7. Enter the content to appear in the splash page in the **Contents** textbox.
8. Enter the terms and conditions to appear in the splash page in the **Terms** textbox.
9. Enter the logo to be displayed in the **Logo** textbox.
10. Select the **Background Image** to be displayed on the splash page in the textbox.
11. Enable configured modes of redirection URL in **Success Action** checkbox.
12. Enter **Success message** to appear in the textbox.
13. Enable **Redirect** checkbox for HTTP packets.
14. Enter configuring IP address in the **Redirect User Page** textbox.
15. Enter Port number in the **Proxy Redirection Port** textbox.
16. Enter the session timeout in seconds in the **Session Timeout** textbox.
17. Enter the inactivity timeout in seconds in the **Inactivity Timeout** textbox.
18. Enable **MAC Authentication Fallback** checkbox if guest-access is used only as fallback for clients failing MAC-authentication.
19. Enter the name of the interface that is extended for guest access in the **Extend Interface** textbox.
20. Click **Save**.

To configure **Whitelist** parameter:

1. Enter the IP address or the domain name of the permitted domain in the **IP Address** or **Domain Name** textbox.
2. Click **Save**.

To configure the **Captive Portal bypass User Agent** parameter:

1. Select **Index** parameter value from the drop-down list.
2. Enter **User Agent String** parameter in the textbox.
3. Select **Status Code** from the drop-down list.

4. Enter **HTML Response** in the textbox.
5. Click **Save**.

Figure 26 Configure: WLAN > Guest Access > Internal Access Point parameter

Basic
Radius Server
Guest Access
Usage Limits
Scheduled Access
Access
Passpoint

Enable

Portal Mode Internal Access Point External Hotspot cnMaestro

Access Policy Clickthrough *Splash-page where users accept terms & conditions to get on the network*
 Radius *Splash-page with username & password, authenticated with a RADIUS server*
 LDAP *Redirect users to a login page for authentication by a LDAP server*
 Local Guest Account *Redirect users to a login page for authentication by local guest user account*

Redirect Mode HTTP *Use HTTP URLs for redirection*
 HTTPS *Use HTTPS URLs for redirection*

Redirect Hostname
Redirect Hostname for the splash page (up to 255 chars)

Title
Title text in splash page (up to 255 chars)

Contents
Main contents of the splash page (up to 255 chars)

Terms
Terms & conditions displayed in the splash page (up to 255 chars)

Logo
Logo to be displayed on the splash page

Background Image
Background image to be displayed on the splash page

Success Action Internal Logout Page Redirect user to External URL Redirect user to Original URL

Success message

Redirect HTTP-only *Enable redirection for HTTP packets only*

Redirect User Page
Configure IP address for redirecting user to guest portal splash page

Proxy Redirection Port
Port number(1 to 65535)

Session Timeout *Session time in seconds (60 to 2592000)*

Inactivity Timeout *Inactivity time in seconds (60 to 2592000)*

MAC Authentication Fallback *Use guest-access only as fallback for clients failing MAC-authentication*

Extend Interface
Configure the interface which is extended for guest access

Add Whitelist
Captive Portal bypass User Agent

IP Address or Domain Name

IP Address Domain Name	Action
No white list available	

1 / 1 items per page

Table 20 Configure: WLAN > Guest Access > External Hotspot parameters

Parameters	Description	Range	Default
WLAN > Guest Access > External Hotspot			
Access Policy	<p>There are four types of access types provided for the end user:</p> <ol style="list-style-type: none"> Clickthrough This mode allows users to get access data without any authentication mechanism. User can access internet as soon as he is connected and accepts Terms and Conditions. RADIUS User has to provide username and password, which is then redirected to RADIUS server for authentication. If successful, user is provided with data access. LDAP User has to provide username and password, which is then redirected to LDAP server for authentication. If successful, user is provided with data access. Local Guest Account User has to configure username and password on device, which has to be provided in the redirection page for successful authentication and data access. 	–	Clickthrough
LDAP Server baseDN	Provision to configure the point from where the server will search for users.	–	–
LDAP Server adminDN	Provision to configure the Admin Domain which binds with LDAP server for successful search of LDAP/AD server.	–	–
LDAP Server Admin Password	Provision to configure Admin password of LDAP/AD server to search all organizational unit defined in a Domain component.	–	–
Redirect Mode	<p>Provision to configure the HTTP or HTTPS mode of redirection URL.</p> <ol style="list-style-type: none"> HTTP AP sends a HTTP POSTURL to the associated client, which will be <a href="http://<Pre-defined-URL>">http://<Pre-defined-URL>. HTTPS 	–	HTTP

Parameters	Description	Range	Default
	AP sends HTTPS POSTURL to the successful associated client, which will be <a href="https://<Pre-defined-URL>">https://<Pre-defined-URL> .		
Redirect Hostname	User can configure a friendly hostname, which is added in DNS server and is resolvable to cnPilot IP address. This parameter once configured will be replaced with IP address in the redirection URL provided to wireless stations.	–	–
WISPr Clients External Server Login	Provision to enable re-direction of guest access portal URL obtained through WISPr.	–	Disabled
External Page URL	User can configure landing/login page which is posted to wireless stations that are not Guest Access authenticated.	–	–
External Portal Post Through cnMaestro	This is required when HTTPS is only supported by external guest access portal. This option when enabled minimizes certification. Certificate is required to install only in cnMaestro On-Premises.	–	Disabled
External Portal Type	Two modes of portal types are supported by cnPilot products. 1. Standard This mode is selected, for all third-party vendors whose Guest Access services is certified and integrated with cnPilot products. 2. XWF This mode is selected for Facebook Express Wi-Fi deployment.	–	Standard
XWF Key	This is applicable when XWF portal mode is selected.	–	–
XWF Authentication API URL	This is applicable when XWF portal mode is selected. Provision to configure XWF Authentication API URL.	–	–
XWF Accounting API URL	This is applicable when XWF portal mode is selected. Provision to configure XWF Accounting API URL.	–	–
XWF Dynamic Authentication API URL	This is applicable when XWF portal mode is selected. Provision to configure XWF Dynamic Authentication API URL.	–	–

Parameters	Description	Range	Default
XWF SSE Server API URL	This is applicable when XWF portal mode is selected. Provision to configure XWF SSE Server API URL.	–	–
XWF SSE Server Timeout	This is applicable when XWF portal mode is selected. Provision to configure XWF SSE Server Timeout.	5-1800	60
Success Action	<p>Provision to configure redirection URL after successful login to captive portal services. User can configure three modes of redirection URL:</p> <ol style="list-style-type: none"> Internal Logout Page After successful login, Wireless client is redirected to logout page hosted on AP. Redirect user to External URL Here users will be redirected to URL which is configured on device in Redirection URL configurable parameter. Redirect user to Original URL Here users will be redirected to URL that is accessed by user before successful captive portal authentication. 	–	Internal Logout Page
Redirect user to External URL	<p>Provision to configure re-direction URL after successful login and an additional information of AP and wireless station information can be appended in the URL.</p> <ul style="list-style-type: none"> Prefix Query Strings in Redirect URL This option is selected by default. Following information is appended in the redirection URL: <ul style="list-style-type: none"> ○ SSID ○ AP MAC ○ NAS ID ○ AP IP ○ Client MAC ○ Redirection URL <p>User can provide either HTTP or HTTPS URL.</p>	–	–
Redirection user to Original URL	Users will be redirected to URL that is accessed by user before successful captive portal authentication. There is additional parameter Prefix Query Strings in Redirection URL that is enabled by default and details given below:	–	–

Parameters	Description	Range	Default
	<ul style="list-style-type: none"> Prefix Query Strings in Redirect URL <p>This option is selected by default. Following information is appended in the redirection URL:</p> <ul style="list-style-type: none"> o SSID o AP MAC o NAS ID o AP IP o Client MAC 		
Success message	Provision to configure text to display upon successful Guest Access authentication. This is applicable only when Success Action mode is Internal Logout Page.	–	–
Redirection URL Query String	<p>Following information is appended in the redirection URL, if “Prefix Query Strings in Redirect URL” is enabled.</p> <ul style="list-style-type: none"> • Client IP • RSSI • AP Location 	–	Disabled
Redirect	<ul style="list-style-type: none"> • If enabled, only HTTP URLs will be redirected to Guest Access login page. • If disabled, both HTTP and HTTPS URLs will be redirected to Guest Access login page. 	–	Enabled
Redirect User Page	IP address configured in this field is used as logout/disconnect/redirect to captive portal URL for Guest Access sessions. IP address configured should not be reachable to internet.	–	1.1.1.1
Proxy Redirection Port	Proxy port can be configured with which proxy server is enabled. This allows URL’s accessed with proxy port to be redirected to login page.	1 - 65535	–
Session Timeout	This is the duration of time, client will be allowed to access internet if quota persists, after which AP sends de-authentication. Wireless station has to undergo Guest Access authentication after session timeout.	60 - 2592000	28800
Inactivity Timeout	Provision to configure timeout period to disconnect wireless stations that are associated but no data traffic. AP starts timer when there is no data received from a wireless station and disconnects when timer reaches 0.	60 - 2592000	1800

Parameters	Description	Range	Default
MAC Authentication Fallback	It's a mechanism in which wireless stations will be redirected to Guest Access login page after any supported type of MAC address authentication failures.	–	Disabled
Extend Interface	Provision to support Guest Access on Ethernet interface.	–	Disabled
Traffic Class 1	This is exclusively applicable for XWF portal type. This traffic class includes IP and URLs related to XWF for successful re-direction, login and payments.	–	–
Traffic Class 2	This is exclusively applicable for XWF portal type. This traffic class includes whitelist IP/URLs that can be accessed without Guest Access authentication.	–	–
Internet	This is exclusively applicable for XWF portal type. This traffic class includes whitelist IP/URLs that can be accessed after successful Guest Access authentication.	–	–
Whitelist	Provision to configure either IPs or URLs to bypass traffic, such that user can access those IPs or URLs without Guest Access authentication. This parameter is valid for standard portal type.	–	–
Captive Portal bypass User Agent	Provision to limit the auto-popup to a certain browser as configured based on User-agent of browsers. This is valid for standard portal type.	–	–

To configure the above parameters, navigate to the **Configure > WLAN > Guest Access** tab and provide the details as given below:

1. Enable the required access types from the **Access Policy** checkbox.
2. Enable **HTTP** or **HTTPS** from the **Redirect Mode** checkbox.
3. Enter **Redirect Hostname** in the textbox.
4. Enable **WISPr Clients External Server Login** checkbox.
5. Enter **External Page URL** in the textbox.
6. Enable **External Portal Post Through cnMaestro** checkbox.
7. Select **External Portal Type** from the drop-down list.
8. Enable configured modes of redirection URL in **Success Action** checkbox.
9. Enter **Success message** to appear in the textbox.
10. Enable the required **Redirection URL Query String** checkbox.
11. Enable **Redirect** checkbox for HTTP packets.
12. Enter configuring IP address in the **Redirect User Page** textbox.

13. Enter Port number in the **Proxy Redirection Port** textbox.
14. Enter the session timeout in seconds in the **Session Timeout** textbox.
15. Enter the inactivity timeout in seconds in the **Inactivity Timeout** textbox.
16. Select the **MAC Authentication Fallback** checkbox if guest-access is used only as fallback for clients failing MAC-authentication.
17. Enter the name of the interface that is extended for guest access in the **Extend Interface** textbox.
18. Click **Save**.
19. Select **Traffic Class 1** and **Traffic Class 2** tabs and enter the following:
 1. Enter **Name** in the textbox.
 2. Enter **Policy** in the textbox.
 3. Click **Save**.
20. Select **Internet** tab and enter **Name** in the textbox.
 1. Click **Save**.

To configure **Whitelist**:

1. Enter the IP address or the domain name of the permitted domain in the **IP Address or Domain Name** textbox.
2. Click **Save**.

To configure **Captive Portal bypass User Agent**:

1. Select **Index** parameter value from the drop-down list.
2. Enter **User Agent String** parameter in the textbox.
3. Select **Status Code** from the drop-down list.
4. Enter **HTML Response** in the textbox.
5. Click **Save**.

Figure 27 Configure: WLAN > Guest Access > External Hotspot (Standard) parameter

The screenshot displays the configuration page for 'External Hotspot (Standard)' under the 'Guest Access' tab. The 'External Portal Type' dropdown menu is highlighted with a red box and set to 'Standard'. Below this, there are sections for 'Success Action', 'Redirection URL Query String', and 'Redirect' settings. At the bottom of the main configuration area are 'Save' and 'Cancel' buttons.

Below the main configuration area, there are two smaller panels:

- Traffic Class 1:** Shows 'Traffic Class 1 not available' in a table with columns for IP Address, Subnet, Domain Name, and Action.
- Add Whitelist:** Shows 'No white list available' in a table with columns for IP Address, Domain Name, and Action.

Figure 28 Configure: WLAN > Guest Access > External Hotspot (XWF) parameter

The screenshot shows the configuration page for External Hotspot (XWF) parameters. The 'External Portal Type' dropdown menu is highlighted with a red box and is set to 'XWF'. Other visible parameters include 'Enable', 'Portal Mode', 'Access Policy', 'Redirect Mode', 'Redirect Hostname', 'WISPr Clients External Server Login', 'External Page URL', 'XWF Key', 'XWF Authentication API URL', 'XWF Accounting API URL', 'XWF Dynamic Authentication API URL', 'XWF SSE Server API URL', 'XWF SSE Server Timeout', 'Success Action', 'Success message', 'Redirection URL Query String', 'Redirect', 'Redirect User Page', 'Proxy Redirection Port', 'Session Timeout', 'Inactivity Timeout', and 'MAC Authentication Fallback'. At the bottom, there are two smaller panels: 'Traffic Class 1' and 'Add Whitelist', both showing 'not available' or 'No white list available'.

Table 21 Configure: WLAN > Guest Access > cnMaestro parameters

Parameters	Description	Range	Default
WLAN > Guest Access > cnMaestro			
Guest Portal Name	Provision to configure the name of the Guest Access profile which is hosted on CnMaestro.	—	—

Parameters	Description	Range	Default
Redirect	<ul style="list-style-type: none"> If enabled, only HTTP URLs will be redirected to Guest Access login page. If disabled, both HTTP and HTTPS URLs will be redirected to Guest Access login page. 	–	Enabled
Redirect User Page	IP address configured in this field is used as logout URL for Guest Access sessions. IP address configured should be not reachable to internet.	–	1.1.1.1
Proxy Redirection Port	Proxy port can be configured with which proxy server is enabled. This allows URL's accessed with proxy port to be redirected to login page.	1 - 65535	–
Inactivity Timeout	Provision to configure timeout period to disconnect wireless stations that are associated but no data traffic. AP starts timer when there is no data received from a wireless station and disconnects when timer reaches 0.	60 - 2592000	1800
MAC Authentication Fallback	It's a mechanism in which wireless stations will be redirected to Guest Access login page after any supported type of MAC address authentication fails.	–	Disabled
Extend Interface	Provision to support Guest Access on Ethernet interface.	–	Disabled
Whitelist	Provision to configure either IPs or URLs to bypass traffic, such that user can access those IPs or URLs without Guest Access authentication.	–	–
Captive Portal bypass User Agent	Provision to limit the auto-popup to a certain browser as configured based on User-agent of browsers.	–	–

To configure the above parameters, navigate to the **Configure > WLAN > cnMaestro** tab and provide the details as given below:

1. Enter **Guest Portal Name** which is hosted on cnMaestro in the textbox.
2. Enable **Redirect** checkbox for HTTP packets.
3. Enter configuring IP address in the **Redirect User Page** textbox.
4. Enter Port number in the **Proxy Redirection Port** textbox.
5. Enter the inactivity timeout in seconds in the **Inactivity Timeout** textbox.
6. Select the **MAC Authentication Fallback** checkbox if guest-access is used only as fallback for clients failing MAC-authentication.
7. Enter the name of the interface that is extended for guest access in the **Extend Interface** textbox.
8. Click **Save**.

To configure the Whitelist parameter:

1. Enter the IP address or the domain name of the permitted domain in the **IP Address or Domain Name** textbox.
2. Click **Save**.

To configure the **Captive Portal bypass User Agent** parameter:

1. Select **Index** parameter value from the drop-down list.
2. Enter **User Agent String** parameter in the textbox.
3. Select **Status Code** from the drop-down list.
4. Enter **HTML Response** in the textbox.
5. Click **Save**.

Figure 29 Configure: WLAN > Guest Access > cnMaestro parameter

The screenshot displays the configuration page for 'Guest Access > cnMaestro'. The top navigation bar includes tabs for 'Basic', 'Radius Server', 'Guest Access', 'Usage Limits', 'Scheduled Access', 'Access', and 'Passpoint'. The main configuration area contains the following settings:

- Enable:**
- Portal Mode:** Internal Access Point External Hotspot cnMaestro
- Guest Portal Name:** SIT_GuestAccess (Guest Portal Name which is hosted on cnMaestro)
- Redirect:** HTTP-only (Enable redirection for HTTP packets only)
- Redirect User Page:** 1.1.1.1 (Configure IP address for redirecting user to guest portal splash page)
- Proxy Redirection Port:** (Port number(1 to 65535))
- Inactivity Timeout:** 1800 (Inactivity time in seconds (60 to 2592000))
- MAC Authentication Fallback:** Use guest-access only as fallback for clients failing MAC-authentication
- Extend Interface:** (Configure the interface which is extended for guest access)

At the bottom, there are 'Save' and 'Cancel' buttons. Below the main configuration is a section for 'Add Whitelist' and 'Captive Portal bypass User Agent'. It features a text input for 'IP Address or Domain Name' with a 'Save' button. Below this is a table with columns 'IP Address | Domain Name' and 'Action'. The table is currently empty, displaying 'No white list available'. At the bottom right of the table, there are navigation controls and a dropdown for '10 items per page'.

Table 22 Configure: WLAN > Usage Limits parameters

Parameters	Description	Range	Default
Rate Limit per Client	Provision to limit throughput per client. Default allowed throughput per client is unlimited. i.e., maximum allowed by 802.11 protocols. The traffic from/to each client on a SSID can be rate-limited in either direction by configuring Client rate limit available in usage-limits inside the WLAN Configuration. This is useful in deployments like public hotspots where the backhaul is limited and the network administrator would like to ensure that one client does not monopolize all available bandwidth.	–	0 [Unlimited]
Rate Limit per WLAN	Provision to limit throughout across WLAN irrespective of number of associated wireless stations to WLAN. All upstream/downstream traffic on an SSID (aggregated across all wireless clients) can be rate-limited in either direction by configuring usage-limits inside the WLAN Configuration section of the GUI. This is useful in cases where multiple SSIDs are being used and say one is for corporate use, and another for guests. The network administrator can ensure that the guest VLAN traffic is always throttled, so it will not affect the corporate WLAN.	–	0 [Unlimited]

To configure the above parameters, navigate to the **Configure > WLAN > Usage Limits** tab and provide the details as given below:

1. Enter **Upstream** and **Downstream** parameters in the **Rate Limit per Client** textbox.
2. Enter **Upstream** and **Downstream** parameters in the **Rate Limit per WLAN** textbox.
3. Click **Save**.

Figure 30 Configure: WLAN > Usage Limits parameters

The screenshot shows the configuration interface for WLAN Usage Limits. At the top, there are tabs for 'Basic', 'Radius Server', 'Guest Access', 'Usage Limits' (which is active), 'Scheduled Access', 'Access', and 'Passpoint'. Below the tabs, there are two main sections:

- Rate Limit per Client:** Contains two input fields. The 'Upstream' field is labeled 'Upstream:' and has a value of '0' with 'Kbps' below it. The 'Downstream' field is labeled 'Downstream:' and also has a value of '0' with 'Kbps' below it.
- Rate Limit per WLAN:** Contains two input fields. The 'Upstream' field is labeled 'Upstream:' and has a value of '0' with 'Kbps' below it. The 'Downstream' field is labeled 'Downstream:' and also has a value of '0' with 'Kbps' below it.

At the bottom right of the configuration area, there are two buttons: 'Save' and 'Cancel'.

Table 23 Configure: WLAN > Scheduled Access parameters

Parameters	Description	Range	Default
Scheduled Access	Provision to configure the availability of Wi-Fi services for a selected time duration. cnPilot has capability of configuring the availability of Wi-Fi services on all days or on specific day (s) of a week. Time format is in Hours.	00:00 Hrs. - 23:59 Hrs.	Disabled

To configure the above parameter, navigate to the **Configure > WLAN > Scheduled Access** tab and provide the details as given below:

1. Enter the start and end time to enable the Wi-Fi access in the respective textboxes.
2. Click **Save**.

Figure 31 Configure: WLAN > Scheduled Access parameters

Table 24 Configure: WLAN > Access parameters

Parameters	Description	Range	Default
ACL			
Precedence	Provision to configure index of ACL rule. Packets are validated and processed based on precedence value configured.	1-256	1
Policy	Provision to configure whether to allow or deny traffic.	Allow/deny	Deny
Direction	Provision to apply the ACLs rules configured either in any direction or specific direction.	–	–

Parameters	Description	Range	Default
Type	<p>cnPilot devices support three layers of ACLs. A rule can be configured as below:</p> <ul style="list-style-type: none"> • MAC • IP • Proto 	–	IP
Source IP/Mask	This option is available when ACL type is configured to an IP address. This field helps user to configure if rule needs to be applied for a single IP address or range of IP addresses.	–	–
Destination IP/Mask	This option is available when ACL type is configured to an IP address. This field helps user to configure if rule needs to be applied for a single IP address or range of IP addresses.	–	–
Source MAC/Mask	This option is available when ACL type is configured to a MAC address. This field helps user to configure if rule needs to be applied for a single device MAC address or range of MAC addresses.	–	–
Destination MAC/Mask	This option is available when ACL type is configured to MAC address. This field helps user to configure if rule needs to be applied for a single device MAC address or range of MAC addresses.	–	–
Protocol	<p>This option is available when user selects ACL type as proto. User can select following protocols:</p> <ul style="list-style-type: none"> • TCP • UDP • ICMP • Any 	–	TCP
Source Port	Provision to apply ACL with combination of protocol and port.	–	–
Destination Port	Provision to apply ACL with combination of protocol and port.	–	–
Description	To make administrator easy to understand, a text string can be added for each ACL rule.	–	–
DNS-ACL			

Parameters	Description	Range	Default
Precedence	Provision to configure index of ACL rule. Packets are validated and processed based on Precedence value configured.	–	1
Action	Provision to configure whether to allow or deny traffic.	–	Deny
Domain	Provision to configure domain names and rules are applied based on Action configured.	–	–
MAC Authentication			
MAC Authentication Policy	<p>cnPilot supports multiple methods of MAC authentication. Following are details of each mode:</p> <ol style="list-style-type: none"> Permit Wireless station MAC addresses listed will be allowed to associate to AP. Deny When user configures a MAC address, those wireless station shall be denied to associate and the non-listed MAC address will be allowed. Radius For every wireless authentication, cnPilot sends a radius request and if radius accept is received, then wireless station is allowed to associate. cnMaestro This option is preferable when administrator prefers centralized MAC authentication policy. For every wireless authentication, AP sends query to cnMaestro if it allowed or disallowed to connect. Based on the configuration, wireless stations are either allowed or denied. 	–	Deny

To configure the above parameter, navigate to the **Configure > WLAN > Access** tab and provide the details as given below:

To configure **ACL**:

1. Select **Precedence** from the drop-down list.
2. Select type of **Policy** from drop-down list.
3. Select **Direction** from the drop-down list.
4. Select **Type** from the drop-down list.
5. Enter IP address of source in the **Source IP/Mask** textbox.
6. Enter IP address of destination in the **Destination IP/Mask** textbox.

7. Enter **Description** in the textbox.
8. Click **Save**.

To configure **DNS ACL**:

1. Select **Precedence** from the drop-down list.
2. Select type of action from **Action** drop-down list.
3. Enter domain name in the **Domain** textbox.
4. Click **Save**.

To configure **MAC Authentication**:

1. Select **MAC Authentication Policy** from the drop-down list.
2. Enter **MAC** in the textbox.
3. Enter **Description** in the textbox.
4. Click **Save**.

Figure 32 Configure: WLAN > Access parameters

Table 25 Configure: WLAN > Passpoint parameters

Parameters	Description	Range	Default
Configuration > Hotspot2.0 / Passpoint			
Enable	Passpoint (Release 2) enables a secure hotspot network access, online sign up and Policy Provisioning.	–	Disabled

Parameters	Description	Range	Default
DGAF	Downstream Group Addressed Forwarding, when enabled the WLAN doesn't transmit any multicast and broadcast packets.	–	Disabled
ANQP Domain ID	ANQP domain identifier included when the HS 2.0 indication element is in Beacon and Probe Response frames.	0-65535	0
Comeback Delay	Comeback Delay in milliseconds.	100-2000	0
Access Network Type	The configured Access Network Type is advertised to STAs. Following are the different network types supported: <ul style="list-style-type: none"> • Private • Chargeable Public • Emergency Services • Free Public • Personal Device • Private with Guest • Test • Wildcard 	–	Private
ASRA	Indicates that the network requires a further step for access.	–	Disabled
Internet	The network provides connectivity to the Internet if not specified.	–	Disabled
HESSID	Configures the desired specific HESSID network identifier or the wildcard network identifier.	–	–
Venue Info	Configure venue group and venue type.	–	–
Roaming Consortium	The roaming consortium and/or SSP whose security credentials can be used to authenticate with the AP.	–	–
ANQP Elements	Select any one of the following: <ul style="list-style-type: none"> • 3GPP Cellular Network Information • Connection Capability • Domain Name List • Icons 	–	–

Parameters	Description	Range	Default
	<ul style="list-style-type: none"> • IP Address Type information • NAI Realm List • Network Authentication Type • Operating Class Indication • Operator Friendly Names • OSU Provider List • Venue Name Information • WAN Metrics 		

To configure the above parameter, navigate to the **Configure > WLAN > Passpoint** tab and provide the details as given below:

1. Select **Enable** checkbox to enable passpoint functionality.
2. Select **DGAF** checkbox to enable Downstream Group Addressed Forwarding functionality.
3. Enter the domain identifier value in **ANQP Domain ID** textbox.
4. Enter **Comeback Delay** in milliseconds in the textbox.
5. Choose the **Access Network Type** value from the drop-down list.
6. Enable **ASRA** checkbox if the network requires additional steps for access.
7. Enable **Internet** checkbox for the network to provide connectivity to the Internet.
8. Enter the **HESSID** to configure the desired specific HESSID network identifier or the wildcard network identifier.
9. Select **Venue Info** from the drop-down list.
10. To add **Roaming Consortium** value, enter the value in the textbox and click **Add**. To delete a **Roaming Consortium** value, select from the drop-down list and click **Delete**.
11. Click **Save**.

Figure 33 Configure: WLAN > Passpoint parameters

Basic Radius Server Guest Access Usage Limits Scheduled Access Access **Passpoint** Delete

Configuration

Hotspot2.0 / Passpoint

Enable *Passpoint (Release 2) enables a secure hotspot network access, online sign up and Policy Provisioning*

DGAF *Downstream Group Addressed Forwarding. When enabled the WLAN doesn't transmit any multicast and broadcast packets*

ANQP Domain ID *ANQP domain identifier (0-65535) included when the HS 2.0 indication element is in Beacon and Probe Response frames*

Comeback Delay *Comeback delay in milliseconds. Supported range is 100-2000 ms, use 0 to disable*

Access Network Type *The configured Access Network Type is advertised to STAs.*

ASRA *Additional Step Required for Access, indicate that the network requires a further step for access*

Internet *The network provides connectivity to the Internet, Otherwise unspecified*

HESSID *Configure the desired specific HESSID network identifier or the wildcard network identifier*

Venue Info *Configure Venue group and Venue type*

Roaming Consortium *The roaming consortium and/or SSP whose security credentials can be used to authenticate with the AP*

ANQP Elements (Access Network Query Protocol)

ANQP

Summary

Hotspot2.0 / Passpoint

Status	Disable	DGAF	Disable	Domain ID	0
Access Network Type	Private	ASRA	No	Internet	Not Available
HESSID					

Chapter 9: Configuration - Network

This chapter describes the following topics:

- [Overview](#)
- [Configuring Network parameters](#)

Overview

This chapter gives an overview of cnPilot configurable parameters related to LAN, VLAN, Routes, DHCP server, Tunnel, ACL and Firewall.

Configuring Network parameters

cnPilot network configuration parameters are segregated into following sections:

- VLAN
- Routes
- Ethernet Ports
- Security
- DHCP
- Tunnel
- PPPoE
- VLAN Pool

Table 26 Configure: Network > VLAN parameters

Parameters	Description	Range	Default
VLAN			
Edit	Provision to select the VLAN interface that user is intended to view/update configuration.	–	VLAN 1
IP Address	Provision to configure mode of IP address configuration for an interface selected. Two modes are supported: <ol style="list-style-type: none"> DHCP This is the default mode in which cnPilot device tries to obtain IP address from DHCP server. Static User has to explicitly configure IP address and Netmask for a VLAN selected. 	–	DHCP

Parameters	Description	Range	Default
NAT	This option is preferable when you defined local DHCP servers. This option when selected, traffic from wireless stations are NAT'ed to the default gateway interface IP.		Disabled
Zeroconf IP	Zeroconf IP is recommended to be enabled. This interface is available only on VLAN1 configuration section. If VLAN 1 is not allowed in Ethernet interfaces, this IP will not be accessible.	–	Enabled
Management Access	Provision to restrict the access of device either using CLI or UI and to restrict SNMP access. User can configure restriction of device access as follows: <ul style="list-style-type: none"> • Block • Allow from Wired • Allow from both wired and wireless 	–	Allow from both Wired and Wireless
DHCP Relay Agent	This option is enabled when DHCP server is hosted on a VLAN which is not same as client that is requesting for DHCP IP. Enabling this appends Option 82 in the DHCP packets. Following information is allowed to configure: <ol style="list-style-type: none"> 1. DHCP Option 82 Circuit ID Configurable parameters under this option are as follows: <ul style="list-style-type: none"> • Hostname • APMAC • BSSID • SSID • Custom 2. DHCP Option 82 Remote ID Configurable parameters under this option are as follows: <ul style="list-style-type: none"> • Hostname • APMAC • BSSID • SSID • Custom 	–	Disabled
Request Option All	This configuration decides the interface on which cnPilot AP will learn the following:	–	Enabled on VLAN1

Parameters	Description	Range	Default
	<ul style="list-style-type: none"> IP default gateway DHCP client options like Option 43 (Controller discovery like controller host name / IP address) DNS Servers Domain Name 		
Routing & DNS			
Default Gateway	Provision to configure default gateway. If this is provided, cnPilot device installs this gateway as this is the highest priority.	–	–
Domain Name	Provision to configure Domain Name. If this is provided, cnPilot device installs this Domain Name as this is highest priority.	–	–
DNS Server	Provision to configure Static DNS server on cnPilot device. Maximum of two DNS servers can be configured.	–	–
DNS Proxy	cnPilot device can acts as DNS proxy server when this parameter is enabled.	–	Disabled

To configure the above parameter, navigate to the **Configure > Network > VLAN** tab and provide the details as given below:

To configure **VLAN**:

1. Select **Edit** checkbox to enable VLAN1 functionality.
2. Enable **DHCP** or **Static IP** mode of IP address configuration from the **IP Address** checkbox.
3. Enable **NAT** checkbox.
4. Enable **Zeroconf IP** checkbox.
5. Select **Management Access** to configure restriction of device from the drop-down list.
6. Enter **DHCP Relay Agent** parameter in the textbox.
7. Select **DHCP Option 82 Circuit ID** from the drop-down list.
8. Select **DHCP Option 82 Remote ID** from the drop-down list.
9. Enable **Request Option All** checkbox.

To configure **Routing & DNS**:

1. Enter **Default Gateway** IP address in the textbox.
2. Enter **Domain Name** in the textbox.
3. Enter primary domain server name in the **DNS Server 1** textbox.
4. Enter secondary domain server name in the **DNS Server 2** textbox.

5. Enable **DNS Proxy** checkbox.
6. Click **Save**.

Figure 34 Configure: Network > VLAN parameters

VLAN

Edit VLAN 1 Delete this interface

IP Address DHCP Static IP **Network Mask**

NAT When NAT is enabled, IP addresses under this SVI are hidden

Zeroconf IP Support 169.254.x.x local IP address

Management Access Allow from both Wired & Wireless CLI/GUI/SNMP access via this interface

DHCP Relay Agent Enables relay agent and assign DHCP server to it

DHCP Option 82 Circuit ID None

DHCP Option 82 Remote ID None

Request Option All Use Gateway, DNS, Dhcp options received on this interface

Routing & DNS

Default Gateway IP address of default gateway

Domain Name Domain name

DNS Server 1 Primary Domain Name Server

2 Secondary Domain Name Server

DNS Proxy DNS Proxy

Save Cancel

Table 27 Configure: Network > Routes parameters

Parameters	Description	Range	Default
Gateway Source Precedence	Provision to prioritize default gateway and DNS servers when cnPilot device has learnt from multiple ways. Default order is Static, DHCP and PPPoE.	—	Static
Add Multiple Route Entries	User has provision to configure static Routes. Parameters that are required to configure static Routes are as follows: <ul style="list-style-type: none"> • Destination IP • Mask • Gateway 	—	—
Port Forwarding	This feature is required when wireless stations are behind NAT. User can access the services hosted on wireless stations using this feature. Following configurable parameters are required to gain the access of services hosted on wireless stations which are behind: <ul style="list-style-type: none"> • Port 	—	—

Parameters	Description	Range	Default
	<ul style="list-style-type: none"> IP Address Type 		

To configure the above parameter, navigate to the **Configure > Network > Routes** tab and provide the details as given below:

To configure **Gateway Source Precedence**:

1. Select **STATIC**, **DHCPC** or **PPPoE** from the **Gateway Source Precedence** checkbox.
2. Click **Save**.

To configure **Add Multiple Route Entries**:

1. Enter **Destination IP** address in the textbox.
2. Enter **Mask IP** address in the textbox.
3. Enter **Gateway IP** address in the textbox.
4. Click **Save**.

To configure **Port Forwarding**:

1. Enter **Port** in the textbox.
2. Enter **IP Address** in the textbox.
3. Select **Type** from the drop-down list.
4. Click **Save**.

Figure 35 Configure: Network > Routes parameters

The screenshot displays the configuration interface for Network > Routes parameters, divided into three main sections:

- Gateway Source Precedence:** A dropdown menu is set to 'STATIC'. Below it is a 'Save' button.
- Add Multiple Route Entries:** This section contains three input fields: 'Destination IP' (with placeholder 'xxx.xxx.xxx.xxx'), 'Mask' (with placeholder 'xxx.xxx.xxx.xxx'), and 'Gateway' (with placeholder 'xxx.xxx.xxx.xxx'). A 'Save' button is to the right. Below these is a table with columns for 'Destination IP', 'Mask', 'Gateway', and 'Action'. The table is currently empty, displaying 'No routes available'. At the bottom right, there are navigation controls and a '10 items per page' indicator.
- Port Forwarding:** This section contains three input fields: 'Port', 'IP Address', and 'Type' (set to 'TCP'). A 'Save' button is to the right. Below these is a table with columns for 'Port', 'IP Address', 'Protocol', and 'Action'. The table is currently empty, displaying 'No rules available'. At the bottom right, there are navigation controls and a '10 items per page' indicator.

Table 28 Configure: Network > Ethernet Ports parameters

Parameters	Description	Range	Default
Ethernet	<p>cnPilot devices Ethernet port is provisioned to operate in following modes:</p> <ol style="list-style-type: none"> Access Single VLAN Single VLAN traffic is allowed in this mode. Trunk Multiple VLANs Multiple VLANs are supported in this mode. 	—	Access
ACL			
Precedence	Provision to configure index of ACL rule. Packets are validated and processed based on precedence value configured.	1-256	1
Policy	Provision to configure whether to allow or deny traffic.	Allow/deny	Deny

Parameters	Description	Range	Default
Direction	Provision to apply the ACLs rules configured either in any direction or specific direction.	–	–
Type	cnPilot devices support three layers of ACLs. A rule can be configured as below: <ul style="list-style-type: none"> • IP • MAC • Proto 	–	IP
Source IP/Mask	This option is available when ACL type is configured to an IP address. This field helps user to configure if rule needs to be applied for a single IP address or range of IP addresses.	–	–
Destination IP/Mask	This option is available when ACL type is configured to an IP address. This field helps user to configure if rule needs to be applied for a single IP address or range of IP addresses.	–	–
Source MAC/Mask	This option is available when ACL type is configured to a MAC address. This field helps user to configure if rule needs to be applied for a single device MAC address or range of MAC addresses.	–	–
Destination MAC/Mask	This option is available when ACL type is configured to MAC address. This field helps user to configure if rule needs to be applied for a single device MAC address or range of MAC addresses.	–	–
Protocol	This option is available when user selects ACL type as proto. User can select following protocols: <ul style="list-style-type: none"> • TCP • UDP • ICMP • Any 	–	TCP
Source Port	Provision to apply ACL with combination of protocol and port.	–	–
Destination Port	Provision to apply ACL with combination of protocol and port.	–	–
Description	To make administrator easy to understand, a text string can be added for each ACL rule.	–	–

To configure the above parameter, navigate to the **Configure > Network > Ethernet Ports** tab and provide the details as given below:

1. Select **Access Single VLAN** or **Trunk Multiple VLANs** from the **ETH1** drop-down list.
2. Enter **Access Mode** in the textbox.
3. Click **Save**.

To configure **ACL**:

1. Select **Precedence** from the drop-down list.
2. Select type of **Policy** from the drop-down list.
3. Select **Direction** from the drop-down list.
4. Select **Type** from the drop-down list.
5. Enter IP address of source in the **Source IP/Mask** textbox.
6. Enter IP address of destination in the **Destination IP/Mask** textbox.
7. Enter **Description** in the textbox.
8. Click **Save**.

Figure 36 Configure: Network > Ethernet Ports parameters

The screenshot shows the configuration page for Ethernet Ports. The top section, labeled 'ETH1', contains a dropdown menu for 'ETH1' with 'Access Single VLAN' selected, and a text input for 'Access Mode' with 'VLAN' selected and '1' entered. Below this is a 'Save' button and a 'Cancel' button. The bottom section, labeled 'ACL', contains several dropdown menus: 'Precedence' (1), 'Policy' (Deny), 'Direction' (In), 'Type' (IP), 'Source IP/Mask', and 'Destination IP/Mask'. There is also a 'Description' text input field. Below these fields is a table with columns for 'Precedence', 'Policy', 'Direction', 'Type', 'Rule', 'Description', and 'Action'. The table is currently empty, displaying 'No Rules available'. At the bottom right of the table, there is a 'Save' button and a pagination control showing '1' of '1' items and '10' items per page.

Table 29 Configure: Network > Security parameters

Parameters	Description	Range	Default
DoS Protection	<p>cnPilot devices has inbuilt capability of detecting DoS attacks on wired network. Following are the attacks that are detected by cnPilot devices:</p> <ul style="list-style-type: none"> • IP Spoof • Smurf Attack • IP Spoof Log • ICMP Fragment 	–	Disabled
Rogue AP			
Detection	<p>cnPilot devices in association with cnMaestro has capability of detecting Rogue APs. On enabling this all neighbor information is shared to cnMaestro and reports Rogue APs in the networks.</p>	–	Disabled

To configure the above parameter, navigate to the **Configure > Network > Security** tab and provide the details as given below:

1. Select any of the following from **DoS Protection** checkbox
 - a. IP Spoof
 - b. Smurf Attack
 - c. IP Spoof Log
 - d. ICMP Fragment
2. Enable **Detection** checkbox.
3. Click **Save**.

Figure 37 Configure: Network > Security parameters

DoS Protection

- IP Spoof *Enable IP spoof attack protection(Checks whether spoofed IP address is reachable before accept)*
- Smurf Attack *Enable SMURF attack protection(Do not respond to broadcast ICMP)*
- IP Spoof Log *Enable IP spoof log messages(Log unroutable source addresses)*
- ICMP Fragment *Enable fragmented ping attack protection(Drop fragmented ICMP packets)*

Rogue AP

Detection *Enable rogue AP detection*

Save **Cancel**

Table 30 Configure: Network > DHCP parameters

Parameters	Description	Range	Default
Edit	Provision to select DHCP Pool if multiple Pools are defined on cnPilot device.	–	–
Address Range	User can configure start and end addresses for a DHCP Pool selected from the drop-down box.	–	–
Default Router	Provision to configure next hop for a DHCP pool selected from drop-down box.	–	–
Domain Name	Provision to configure domain name for a DHCP pool selected from drop-down box.	–	–
DNS Address	Provision to configure DNS server for a DHCP pool selected from drop-down box.	–	–
Network	Provision to configure Network ID for a DHCP pool selected from drop-down box.	–	–
Lease	Provision to configure lease for a DHCP pool selected from drop-down box.	–	–
Add Bind List			
	For every DHCP pool configured, user can bind MAC and IP from the address pool defined, so that wireless station gets same IP address every time they connect. Following parameters are required to bind IP address: <ul style="list-style-type: none"> • MAC Address • IP Address 	–	–

To configure the above parameter, navigate to the **Configure > Network > DHCP** tab and provide the details as given below:

1. Select DHCP pool from the **Edit** drop-down list.
2. Enter start and end IP addresses for a DHCP Pool selected from the **Address Range** textbox.
3. Enter **Default Router** IP address in the textbox.
4. Enter **Domain Name** for a DHCP pool selected in the textbox.
5. Enter **DNS Address** for a DHCP pool selected in the textbox.
6. Enter **Network** ID for a DHCP pool selected in the textbox.
7. Enter **Lease** for a DHCP pool selected in the textbox.
8. Click **Save**.

To configure **Add Bind List**:

1. Enter **MAC Address** for a DHCP pool selected in the textbox.
2. Enter **IP Address** for a DHCP pool selected in the textbox.
3. Click **Save**.

Figure 38 Configure: Network > DHCP parameters

The screenshot shows the 'Configure: Network > DHCP parameters' interface. At the top, there are 'Edit' and 'Delete this Pool' buttons, and a 'Create Pool' button on the right. The main configuration area contains several groups of fields:

- Address Range:** 'Start' and 'End' textboxes with a note 'IP address range to be assigned to clients'.
- Default Router:** A single textbox with a note 'Default router IP'.
- Domain Name:** A single textbox with a note 'Domain Name'.
- DNS Address:** 'Primary' and 'Secondary' textboxes with a note 'Domain name for the client'.
- Network:** 'IP' and 'Mask' textboxes with a note 'Subnet number and mask of the DHCP address pool'.
- Lease:** '1' in a textbox, 'Hours' and 'Minutes' textboxes, and a note 'Lease time (days hours minutes)'.

 Below the configuration fields are 'Save' and 'Cancel' buttons. The 'Add Bind List' section has two input fields: 'MAC Address' (with placeholder 'xx:xx:xx:xx:xx:xx') and 'IP Address' (with placeholder 'xxx.xxx.xxx.xxx'), followed by a 'Save' button. Below these is a table with columns 'MAC Address', 'IP Address', and 'Action'. The table content is empty, with the text 'No bind list available' centered in the table area. At the bottom right of the table area, there are navigation controls and a 'Items per page' dropdown set to '10'.

Table 31 Configure: Network > Tunnel parameters

Parameters	Description	Range	Default
Tunnel Encapsulation	Provision to enable tunnel type. Following tunnel types are supported by cnPilot devices: <ul style="list-style-type: none"> • L2TP • L2GRE 	—	Disabled
L2TP			
Remote Host	Configure L2TP end point. Either IP or hostname of endpoint is supported.	—	—
Authentication Info	Provision to configure credentials required for L2TP authentication.	—	—
Auth Type	Provision to select the PPP authentication method. Following are the options available: <ul style="list-style-type: none"> • Auto • CHAP • MS-CHAP 	—	Auto

Parameters	Description	Range	Default
	<ul style="list-style-type: none"> MS-CHAP v2 PAP 		
TCP MSS	Provision to configure TCP Maximum Segment Size.	–	1400
PMTU Discovery	Provision to enable to discover PMTU in network.	–	Disabled
L2GRE			
Remote Host	Configure L2GRE end point. Either IP address or hostname of endpoint is supported.	–	–
DSCP	User can configure priority of GRE packets.	–	0
TCP MSS	Configure L2TP end point. Either IP address or hostname of endpoint is supported.	–	1410
PMTU Discovery	Provision to enable to discover PMTU in network.	–	Disabled
MTU	Maximum Transmission Unit.	–	1500

To configure the above parameter, navigate to the **Configure > Network > Tunnel** tab and provide the details as given below:

1. Select Tunnel type from the **Tunnel Encapsulation** drop-down list.

To configure **L2TP**:

1. Enter IP address or domain name in the **Remote Host** textbox.
2. Enter credentials required for L2TP authentication in the **Authentication Info** textbox.
3. Select authentication type from the **Auth Type** drop-down list.
4. Enter TCP Maximum Segment Size in the **TCP MSS** textbox.
5. Enable **PMTU Discovery** checkbox.
6. Enter Maximum Transmission Unit in the **MTU** textbox.
7. Click **Save**.

To configure **L2GRE**:

1. Enter IP address or domain name in the **Remote Host** textbox.
2. Enter **DSCP** in the **textbox**.
3. Enter TCP Maximum Segment Size in the **TCP MSS** textbox.
4. Enable **PMTU Discovery** checkbox.
5. Enter Maximum Transmission Unit in the **MTU** textbox.
6. Click **Save**.

Figure 39 Configure: Network > Tunnel parameters

The screenshot displays the 'Tunnel' configuration interface. At the top, there are navigation tabs: VLAN, Routes, Ethernet Ports, Security, DHCP, Tunnel (selected), PPPoE, VLAN Pool, and WWAN. Below the tabs, the 'Tunnel Encapsulation' is set to 'L2GRE'. The interface is divided into two main sections: 'L2TP' and 'L2GRE'.
 In the 'L2TP' section:
 - Remote Host: 0.0.0.0 (IP address or domain)
 - Authentication Info: admin (Max 64 characters)
 - Auth Type: DEFAULT (MS-CHAPv2, MS-CHAP, CHAP, PAP)
 - TCP MSS: 1400 (TCP Maximum Segment Size (422-1410 bytes))
 - PMTU Discovery: (Path MTU Discovery)
 In the 'L2GRE' section:
 - Remote Host: 10.110.219.62 (IP address or domain)
 - DSCP: 0 (Differentiated Service Code Point)
 - TCP MSS: 1410 (TCP Maximum Segment Size (472-1460 bytes))
 - PMTU Discovery: (Path MTU Discovery)
 - MTU: 1500 (Configure MTU for L2GRE tunnel (1400-1500 bytes))
 At the bottom, there are 'Save' and 'Cancel' buttons.

Table 32 Configure: Network > PPPoE parameters

Parameters	Description	Range	Default
Enable	Provision to enable PPPoE client.	–	Disable
VLAN	User can configure VLAN ID where PPPoE client should obtain IP address.	–	–
Service Name	Configure PPPoE service name	–	–
Authentication Info	Provision to configure credentials required for PPPoE authentication.	–	–
MTU	Maximum Transmission Unit.	500-1492	1430
TCP MSS Clamping	Configure PPPoE end point. Either IP or hostname of endpoint is supported.	–	Enabled
Management Access	If enabled, user can access device either using UI or SSH with PPPoE IP.	–	Disabled

To configure the above parameter, navigate to the **Configure > Network > PPPoE** tab and provide the details as given below:

1. Select **Enable** checkbox to enable PPPoE functionality.

2. Enter the VLAN ID assigned to the PPPoE in the VLAN textbox.
3. Enter **Service Name** in the textbox.
4. Enter the username and password for the device in the **Authentication Info** textbox.
5. Enter the MTU value PPPoE connection in the **MTU** textbox.
6. Enable the TCP MSS clamping for the PPPoE connection in the **TCP-MSS Clamping** textbox.
7. Enable **Management Access** in the textbox.
8. Click **Save**.

Figure 40 Configure: Network > PPPoE parameters

The screenshot shows the configuration page for PPPoE parameters. At the top, there is an 'Enable' checkbox which is currently unchecked. Below it are several rows of configuration options:

- VLAN:** A text box containing the number '1'. To its right is the text 'Vlan ID assigned to PPPoE'.
- Service Name:** An empty text box. To its right is the text 'Configure pppoe serve-name parameters'.
- Authentication Info:** Two text boxes. The first contains 'admin'. The second contains six dots '.....'. To the right of the second box is the text 'Max 64 characters'.
- MTU:** A text box containing '1430'. To its right is the text 'Configure mtu for pppoe connection (500-1492 bytes)'.
- TCP-MSS Clamping:** A checked checkbox followed by the text 'Enable tcp mss clamping for pppoe connection'.
- Management Access:** An unchecked checkbox followed by the text 'Enable CLI/GUI/SNMP access via this interface'.

At the bottom of the form, there are two buttons: 'Save' (highlighted in blue) and 'Cancel'.

Table 33 Configure: Network > VLAN Pool parameters

Parameters	Description	Range	Default
VLAN Pool Name	Provision to configure user friendly name to a list of VLANs.	–	–
VLAN ID List	List of VLAN IDs for each VLAN Pool name. User can configure either single VLAN ID or multiple VLAN ID. Multiple VLAN IDs can be configured either separated by comma or hyphen.	–	–

To configure the above parameter, navigate to the **Configure > Network > VLAN Pool** tab and provide the details as given below:

1. Enter the name of the VLAN pool in the **VLAN Pool Name** textbox.
2. Enter the VLAN ID in the **VLAN ID List** textbox.
3. Click **Save**.

Figure 41 Configure: Network > VLAN Pool parameters

Table 34 Configure: Network > WWAN parameters

Parameters	Description	Range	Default
WWAN	Enables wireless WAN using a USB cellular dongle for Internet access.	-	Disabled
Failover Only	Enables to use WWAN as backhaul only when failover is triggered.	-	Disabled
APN	Provision to configure network provider APN address.	-	-
Authentication	Provision to configure authentication parameters.	-	-
Monitor Host	Provision to configure as server to monitor with ping to decide for internet failover.	-	-

To configure the above parameter, navigate to the **Configure > Network > WWAN** tab and provide the details as given below:

1. Enable **WWAN** checkbox.
2. Enable **Failover Only** checkbox.
3. Enter **APN** address in the textbox.
4. Enter username and password in the **Authentication** textbox.
5. Enter **Monitor Hoist** parameter in the textbox.
6. Click **Save**.

Figure 42 Configure: Network > WWAN parameters

VLAN Routes Ethernet Ports Security DHCP Tunnel PPPoE VLAN Pool **WWAN**

WWAN Enable Wireless WAN using a USB cellular dongle for Internet access

Failover Only Use WWAN as backhaul only when failover is triggered

APN Configure network provider APN address

Authentication username max 32 char password max 32 char [Configure authentication parameters](#)

Monitor Host Host to monitor in order to trigger WWAN failover

Chapter 10: Configuration - Services

This chapter describes the following topics:

- [Overview](#)
- [Configuring Services](#)

Overview

This chapter gives an overview of cnPilot configurable parameters related to LDAP, NAT Logging, Location API, Speed Test and DHCP Option 82.

Configuring Services

This section provides information on how to configure the following services on cnPilot AP.

- [LDAP](#)
- [NAT Logging](#)
- [Location API](#)
- [Speed Test](#)
- [DHCP Option 82](#)

LDAP

Table 35 lists the fields that are displayed in the **Configuration > Services > LDAP** tab:

Table 35 Configure: Services > LDAP parameters

Parameters	Description	Range	Default
Server Host	Provision to configure IP/Hostname of LDAP server.	–	–
Server Port	Provision to configure custom port number for LDAP services.	–	–

To configure the above parameter, navigate to the **Configure > Services > LDAP** tab and provide the details as given below:

1. Enter the IP address of the LDAP server in the **Server Host** textbox.
2. Enter the Port address of the LDAP server in the **Server Port** textbox.
3. Click **Save**.

Figure 43 Configure: Services > LDAP parameters

LDAP

Server Host Configure LDAP server IP address

Server Port Configure LDAP server port address

NAT Logging

NAT logging is same as the internet access log that is generated when NAT is enabled on AP. Each internet access log PDU consists of one or more internet access log data in TLV format. The packet format for the internet access log PDU is defined as below:

Table 36 PDU type code: 0x82

Type	Mandatory	Length	Default Value
0x01	N	32 Bytes	Includes IPv4 internet access log data structure.

Type 0x01 TLV includes the internet access log data structure as below:

Table 37 NAT Logging Packet Structure

Length	Description
4 Bytes	NAT records UNIX time stamp which generates time in seconds from 1970-01-01 (00:00:00 GMT until now).
6 Bytes	The MAC address of the client.
1 Bytes	Reserved for future use.
1 Bytes	The protocol type. The supported protocol types are: <ul style="list-style-type: none"> • 0x06 TCP • 0x11 UDP
2 Bytes	The VLAN ID where the client is connected. If there is no VLAN ID, the value will be 0.
4 Bytes	The client internal or the private IP address.
2 Bytes	The internal port of the client.
4 Bytes	The Internet IP address which is translated by NAT.
2 Bytes	The Internet port which is translated by NAT.
4 Bytes	The IP address of the visited server.
2 Bytes	The port address of the visited server.

Table 37 lists the fields that are displayed in **Configuration > Services > NAT Logging** tab:

Table 38 Configure: Services > NAT Logging parameters

Parameters	Description	Range	Default
Enable	Provision to enable/disable NAT logging services.	–	–
Server IP	Provision to configure IP/Hostname of NAT logging server.	–	–
Server Port	Provision to configure custom port number for NAT Logging services.	–	–
Interval	Provision to configure frequency of logging.	5-3600	–

To configure the above parameter, navigate to the **Configure > Services > NAT Logging** tab and provide the details as given below:

1. Select the **Enable** checkbox to enable NAT Logging.
2. Enter the IP address of the server for NAT Logging in the **Server IP** textbox.
3. Enter the IP address of the server port for NAT Logging in the **Server Port** textbox.
4. Enter the interval for NAT Logging in the **Interval** textbox.
5. Click **Save**.

Figure 44 Configure: Services > NAT Logging parameters

Location API

Location API is a method to send the discovered (Probed) clients list to a specified server address. The reports are sent as HTTP Post to the HTTP server every interval. Discovered client entries are deleted from the list if the entry is aged out. Age timeout is five minutes. If there are no new probe requests for the client within 5 minutes, entry is deleted.

Table 39 lists the fields that are displayed in **Configuration > Services > Location API** tab:

Table 39 Configure: Services > Location API parameters

Parameters	Description	Range	Default
Enable	Provision to enable/disable Location API services.	–	–

Parameters	Description	Range	Default
Server	Provision to configure HTTP/HTTPs server to send report with the pot number.	–	–
Interval	Provision to configure custom frequency of information to be shared to server.	5-3600	–
MAC Anonymization	Provision to detect fake clients and avoid populating it in Location API client list.	–	–

To configure the above parameter, navigate to the **Configure > Services > Location API** tab and provide the details as given below:

1. Select the **Enable** checkbox to enable Location API.
2. Enter the HTTP/HTTPs server and port number in the **Server** textbox.
3. Enter the interval for Location API in the **Interval** textbox.
4. Enable **MAC Anonymization** checkbox.
5. Click **Save**.

Figure 45 Configure: Services > Location API parameters



Speed Test

Wifiperf is a speed test service available on cnPilot devices. This tool is interoperable with open source zapwireless tool (<https://code.google.com/archive/p/zapwireless/>)

The wifiperf speed test can be triggered by using zapwireless tool between two cnPilot APs or between cnPilot AP and with other third-party devices (or PC) that is having zapwireless endpoint running.

Refer <https://code.google.com/archive/p/zapwireless/> to download the zapwireless tool to generate zapwireless endpoint for third party device (or PC) and zap CLI to perform the test.

In this case, wifiperf endpoint should be enabled in cnPilot AP through UI shown below.

Table 40 lists the fields that are displayed in the **Configuration > Services > Speed Test** tab:

Table 40 Configure: Services > Speed Test parameters

Parameters	Description	Range	Default
wifiperf	Provision to enable wifiperf functionality.	–	Disabled

To configure the above parameter, navigate to the **Configure > Services > Speed Test** tab. Select **Wifiperf** checkbox to enable this functionality.

Figure 46 Configure: Services > Speed Test parameters



DHCP Option 82

Global parameter to configure DHCP Option 82 parameters that will be appended to DHCP packets when a device is connected either from wireless or wired to a cnPilot device. This parameter is given first precedence and overwrites any configuration defined in VLAN or WLAN profiles.

Table 41 lists the fields that are displayed in the **Configuration > Services > DHCP Option 82** tab:

Table 41 Configure: Services > DHCP Option 82 parameters

Parameters	Description	Range	Default
Enable	Provision to enable/disable DHCP Option 82 as global services.	–	–
Option 82 Circuit ID	When enabled, DHCP packets generated from wireless stations that are associated to APs are appended with Option 82 parameters. Option 82 provides provision to append Circuit ID and Remote ID. Following parameters can be selected in both Circuit ID and Remote ID: <ul style="list-style-type: none"> • Hostname • APMAC • BSSID • SSID • VLAN ID • SITEID • Custom • All 	–	None
Option 82 Remote ID	When enabled, DHCP packets generated from wireless stations that are associated to APs are appended with Option 82 parameters. Option 82 provides provision to append Circuit ID and Remote ID. Following parameters can be selected in both Circuit ID and Remote ID: <ul style="list-style-type: none"> • Hostname • APMAC 	–	None

Parameters	Description	Range	Default
	<ul style="list-style-type: none"> BSSID SSID VLAN ID SITEID Custom All 		
VLAN ID	User can configure VLAN IDs where DHCP Option 82 has to be enabled.	–	–

To configure the above parameter, navigate to the **Configure > Services** tab and select **DHCP Option 82** tab and provide the details as given below:

1. Select the **Enable** checkbox to enable DHCP Option 82.
2. Select **Option 82 Circuit ID** to enable DHCP Option-82 circuit ID information from the drop-down list.
3. Select **Option 82 Remote ID** to enable DHCP Option-82 remote ID information from the drop-down list.
4. Enter **VLAN ID** parameter to configure VLAN to have DHCP Option 82.
5. Click **Save**.

Figure 47 Configure: Services > DHCP Option 82 parameters

DHCP Option 82

Enable *Insert DHCP Option 82 for all wireless and guest enabled wired clients*

Option 82 Circuit ID *Insert DHCP option 82 circuitID information*

Option 82 Remote ID *Insert DHCP option-82 remoteID information*

VLAN ID *Configure vlan to have DHCP Option-82 (1-4094)*

Chapter 11: Operations

This chapter describes the following topics:

- [Overview](#)
- [Firmware update](#)
- [System](#)
- [Configuration](#)

Overview

This chapter gives an overview of cnPilot administrative functionalities such as Firmware update, System and Configuration.

Firmware update

The running software on the cnPilot Enterprise AP can be upgraded to newer firmware. When upgrading from the UI the user can upload the firmware file from the browser. The same process can be followed to downgrade the AP to a previous firmware version if required. Configuration is maintained across the firmware upgrade process.



Note Once a firmware upgrade has been initiated, the AP should not be rebooted or power cycled until the process completes, as this might leave the AP inoperable.

Table 42 lists the fields that are displayed in the **Operations > Firmware update** tab:

Table 42 Configure: Operations > Firmware update parameters


Parameters	Description	Range	Default
Choose File	Provisions to select upgrade file.	–	–
Upgrade Firmware	Provision to initiate upgrade once file is selected.	–	–

To configure the above parameter, navigate to **Operations > Firmware update** tab and provide the details as given below:

1. Click **Choose File** and select the downloaded image file to upgrade the firmware manually.
2. Click **Upgrade Firmware** and select the downloaded image file to upgrade the firmware automatically.

You can view the status of upgrade in the **Upgrade Status** field.

Figure 48 Configure: Operations > Firmware update parameters



System

This section provides multiple troubleshooting tools provided by cnPilot Enterprises.

Table 43 lists the fields that are displayed in the **Operations > System** tab:


Table 43 Configure: Operations > System parameters

Parameters	Description	Range	Default
Reboot	User will be prompted with Reboot pop-up requesting for reboot. If Yes, device will go for reboot.	–	–
Download Tech Support	User will be prompted with permission to download tech-support from AP. If yes, file will be saved in your default download path configured on your system.	–	–
Disconnect All Clients	All clients connected to both the radios will be terminated by sending de-authentication packet to each client connected to radios.	–	–
Flash LEDs	LEDs on the device will toggle for configured time period.	1-120	10
Factory Default	A pop-up window appears requesting confirmation for factory defaults. If yes, device will delete all configuration to factory reset and reboots.	–	–

To configure the above parameter, navigate to **Operations > System** tab and provide the details as given below:

1. Click **Reboot** for rebooting the device.
2. Click **Download Tech Support** to generate a techsupport from the device and save it locally.
3. Click **Disconnect All Clients** to disconnect all wireless clients.
4. Select **Flash LEDs** value from the drop-down list to flash LEDs for the given duration of time.
5. Click **Factory Default** to delete all configuration on the device.

Figure 49 Configure: Operations > System parameters



Configuration

The device configuration can either be exported from the device as a text file or imported into the device from a previous backup. Ensure that when a configuration file is imported onto the device, a reboot is necessary to activate that new configuration.

Table 44 lists the fields that are displayed in the **Operations > Configuration** tab:


Table 44 Configure: Operations > Configuration parameters

Parameters	Description	Range	Default
Export	Provision to export configuration of device to default download path configured on system.	–	–
Import	Provision to import configuration of device.	–	–

To configure the above parameter, navigate to **Operations > Configuration** tab and provide the details as given below:

1. Click **Export** to export device configuration and save locally to the device.
2. Click **Import** to import device configuration to the device.

Figure 50 Configure: Operations > Configuration parameters



Chapter 12: Troubleshoot

This section provides detailed information about troubleshooting methods supported by cnPilot enterprise devices. Troubleshooting methods supported by cnPilot devices are categorized as below:

- **Logging**
 - Events
 - Debug Logs
- **RF**
 - Wi-Fi Analyzer
 - Spectrum Analyzer
 - Unconnected Clients
- **Packet Capture**
- **Performance**
 - Wi-Fi Perf Speed Test
 - Connectivity

Logging

cnPilot devices supports multi-level logging, which will ease to debug issues.

Events


cnPilot devices generates events that are necessary for troubleshooting across various modules. Below is the list of modules, cnPilot device generates events for troubleshoot.

- Wireless station
 - Connectivity
- Configuration updates
- LDAP
 - Authentication
- RADIUS
 - Authentication
 - Accounting
 - CoA
- Mesh
- Roaming
 - Enhanced roaming
- Auto-RF

- Channel change
- Tunnel state
- Reboot
- Guest Access
- Autopilot

Events are available at **Troubleshoot > Logs > Events**.

Figure 51 Troubleshoot > Logs > Events




Debug Logs

cnPilot provisions enhanced debugging of each module as events generated by system and scope of debugging is limited. Debug logs can be triggered when user click **Start Logs** and can be terminated when clicked on **Stop Logs**. By default, debug logs auto terminate after 1 minute when clicked on **Start Logs**.

Debug logs are available at **Troubleshoot > Logs > Debug Logs**.

Figure 52 Troubleshoot > Logs > Debug Logs



RF

Wi-Fi Analyzer

This tool provisions customer to scan the channels supported as per regulatory domain and provides information related to AP's presence in each channel. Wi-Fi analyzer graphs are available in two modes:

- Interference

This tool shares more information of each channel as below:

- Noise
- Interference measured in RSSI
- List of top 64 neighbor APs


- Number of APs

This tool shares more information of each channel as below:

- Noise
- Number of neighbor APs
- List of top 64 neighbor APs

Channel analyzer is available at **Troubleshoot > Wi-Fi Analyzer > Interference Mode.**

Figure 53 Troubleshoot > Wi-Fi Analyzer > Interference Mode



Channel analyzer is available at **Troubleshoot > Wi-Fi Analyzer > Number of APs Mode:**

Figure 54 Troubleshoot > Wi-Fi Analyzer > Number of APs Mode



Spectrum analyzer

Due to heavy commercialization of Wi-Fi devices and wide range of non-Wi-Fi devices operating in the ISM band, interference in the ISM bands is unavoidable and imminent. The Wi-Fi performance can quickly degrade with the presence of these wide range of devices in the vicinity. The Wi-Fi network deployment is in need of more robust tools for RF spectrum analysis for determining potential Wi-Fi (and non-Wi-Fi) interferers for efficient planning of the network deployment.

Given the wide range deployment of high capacity Wi-Fi networks, it is inevitable that the devices come ready with automatic interference detection and mitigation. The spectral scan feature on cnPilot is the first step towards achieving the same.

Spectral analyzer is triggered on demand. Following options are required to trigger spectrum analyzer:

- Band**
 This feature is available on both 2.4GHz and 5GHz. At an instance, any one band can be selected
- Continuous scan**
 If user is looking for continuous scan until stopped, this field has to be enabled.
- Scanning**
 Option to start and stop the scan process.

Spectrum analyzer is available at **Troubleshoot > Spectrum Analyzer**.

Figure 55 Troubleshoot > Spectrum Analyzer




Unconnected clients

Provides a list of clients that could not connect properly due to various reasons with the APs. Currently the following failures are tracked:

- Invalid pre-shared key
- EAP authentication failure
- Denied due to MAC ACL
- Client disconnected by enhanced-roaming

Figure 56 Unconnected clients



Packet capture

Allows the administrator to capture all packets on a specified interface. A decode of the packet indicating the network addresses, protocol types etc is displayed. The administrator can filter the packets being captured by specifying a particular MAC address, IP address, port number etc. The number of packets that are captured can also be capped, so the console or system is not overwhelmed. Packets captured on the ETH interfaces are packets that are being transmitted or received on the physical interface of the device.

cnPilot device allows packet capture on following interfaces:

- WLAN
- Ethernet
- VLAN
- SSID

Multiple options of filtering are provided and is available **Troubleshoot > Packet Capture page**:

Figure 57 Troubleshoot > Packet Capture page

Performance

Wi-Fi Perf speed test

The Wi-Fi Perf Speed Test feature helps to measure the bandwidth from AP to an end point. You can measure both TCP and UDP with variable payloads. To configure this feature:

1. Navigate to **Troubleshoot > Wi-Fi Perf Speed Test** page in the UI.
2. Provide the following details:
 - Select the duration from the **Duration** drop-down list.
 - Select the Protocol as **UDP** or **TCP**.
 - Enter the length of the payload in the **Payload Length** textbox.
 - Enter the IP of the payload length in the **Wi-FiPerf Endpoint** textbox.

- Select **Downlink** or **Uplink** Radio button.
- Click on **Start Test**.

Figure 58 Troubleshoot > Wi-Fi Perf Speed Test

The screenshot displays the web interface for a Cambium Networks cnPilot E400 - E400-AFA308 device. The left sidebar contains navigation options: Dashboard, Monitor, Configure, Operations, Troubleshoot, WiFi Analyzer, Spectrum Analyzer, WiFi Perf Speed Test (highlighted), Connectivity, Packet Capture, Logs, and Unconnected Clients. The main content area is titled 'Troubleshoot / Speed Test' and features the following configuration fields:

- Duration: 10 sec
- Protocol: TCP
- Payload Length: optional (64 to 65505)
- WiFiPerf Endpoint: Please select
- Downlink:
- Uplink:

A blue 'Start Test' button is located below the radio buttons. Below the configuration fields is a large empty box labeled 'Test Result'.

Connectivity

This tool helps to check the accessibility of remote hosts from cnPilot device. Three types of tools are supported under this category:

- Ping
- DNS Lookup
- Traceroute

Chapter 13: Management Access

This chapter describes different methods of authenticating users to access device UI. Following are the authentication methods supported by cnPilot devices:

- **Local authentication**
- **SSH-Key authentication**
- **RADIUS authentication**

Local authentication

This is the default authentication mode enabled on device. Only one username is supported which is “admin”. Default password for “admin” username is “admin”. User has provision to configure/update password.

Device configuration

Figure 59 shows how to configure/update default password of admin user.

1. Under Management, enter **Admin Password**.
2. Click **Save**.

Figure 59 configure/update default password of admin user

The screenshot shows the configuration page for a Cambium Networks cnPilot E400 - E400-AFA308 device. The page is divided into two main sections: System and Management.

System Section:

- Name:** E400-AFA308 (Hostname of the device (max 64 characters))
- Location:** (Location where this device is placed (max 64 characters))
- Contact:** (Contact information for the device (max 64 characters))
- Country-Code:** India (For appropriate regulatory configuration)
- Placement:** Indoor (selected), Outdoor (Configure the AP placement details)
- LED:** Whether the device LEDs should be ON during operation
- LLDP:** Whether the AP should transmit LLDP packets

Management Section:

- Admin Password:** (Configure password for authentication of GUI and CLI sessions)
- Autopilot:** Default (Autopilot Management of APs)
- Telnet:** Enable Telnet access to the device CLI
- SSH:** Enable SSH access to the device CLI
- SSH Key:** (Use SSH keys instead of password for authentication)
- HTTP:** Enable HTTP access to the device GUI
- HTTP Port:** 80 (Port No for HTTP access to the device GUI(1-65535))

SSH-Key authentication

SSH keys are also used to connect remote machines securely. They are based on the SSH cryptographic network protocol, which is responsible for the encryption of the information stream between two machines. Ultimately, using SSH keys user can connect to remote devices without even entering a password and much more securely too. SSH works based on “public-key cryptography”. For simplicity,

let us consider that SSH keys come in pairs. There is a **private key**, that is safely stored to the home machine of the user and a **public key**, which is stored to any remote machine (AP) the user wants to connect. So, whenever a user initiates an SSH connection with a remote machine, SSH first checks if the user has a private key that matches any of the public keys in the remote machine and if not, it prompts the user for password.

Device configuration

SSH Key based access method can be configured on device using standalone AP or from cnMaestro. Navigate to **System > Management** and configure the following:

1. Enable **SSH** checkbox.
2. Provide Public key generated from steps described in **SSH Key Generation** section.

Figure 60 System > Management

The screenshot shows the configuration interface for a Cambium Networks cnPilot E400 - E400-AFA308 device. The left sidebar contains navigation options: Dashboard, Monitor, Configure, System (selected), Radio, WLAN, Network, Services, Operations, and Troubleshoot. The main content area is divided into two sections: System and Management.

System Section:

- Name:** E400-AFA308 (Hostname of the device (max 64 characters))
- Location:** (Location where this device is placed (max 64 characters))
- Contact:** (Contact information for the device (max 64 characters))
- Country-Code:** India (For appropriate regulatory configuration)
- Placement:** Indoor (selected), Outdoor (Configure the AP placement details)
- LED:** Whether the device LEDs should be ON during operation
- LLDP:** Whether the AP should transmit LLDP packets

Management Section:

- Admin Password:** (Configure password for authentication of GUI and CLI sessions)
- Autopilot:** Default (Autopilot Management of APs)
- Telnet:** Enable Telnet access to the device CLI
- SSH:** Enable SSH access to the device CLI
- SSH Key:** (Use SSH keys instead of password for authentication)
- HTTP:** Enable HTTP access to the device GUI
- HTTP Port:** 80 (Port No for HTTP access to the device GUI(1-65535))
- HTTPS:** Enable HTTPS access to the device GUI
- HTTPS Port:** 443 (Port No for HTTPS access to the device GUI(1-65535))


SSH Key Generation

Windows

PUTTY tool can be used to generate both Public and Private Key. Below is a sample demonstration of configuring cnPilot device and logging using SSH Key via UI.


1. Generate a key pair in PUTTY Key Generator (**Figure 61**) and save private and public key as shown in **Figure 62**.

Figure 61 Generating public/private Key



2. Save the Public key and Private key once key pair is generated as shown in **Figure 62**.

Figure 62 Public and Private Key



3. Save the Public key generated in step above as described in **Device configuration** section.
4. Login to device using Private key generated above with username as “admin”.

Linux

If using a Linux PC and SSH from the Linux host, then you can generate the keys with the following steps:

1. Generate key pair executing below command on Linux console as shown in **Figure 63**.

Figure 63 Public Key location path

```
saidell@saidell-Vostro-15-3568:~$ ssh-keygen -t rsa
Generating public/private rsa key pair.
Enter file in which to save the key (/home/saidell/.ssh/id_rsa):
Created directory '/home/saidell/.ssh'.
Enter passphrase (empty for no passphrase):
Enter same passphrase again:
Your identification has been saved in /home/saidell/.ssh/id_rsa.
Your public key has been saved in /home/saidell/.ssh/id_rsa.pub.
The key fingerprint is:
SHA256:VRR4qleviI2zqqXDFe5fCgR/SwCX7vDfzT65jNbKio8 saidell@saidell-Vostro-15-3568
The key's randomart image is:
+---[RSA 2048]-----+
|
|  . . . . .
|  o. . . +
|  .. . .o
|  .oo. . .
|  =o.o S.
|  .o . . .
|  . oo..o.= o
|  oo.++B++* .
|  ooE+0*0=+
+---[SHA256]-----+
saidell@saidell-Vostro-15-3568:~$
```

2. The Public key is now located in PATH mentioned in **Figure 63**.
 - PATH = “Enter the file to which to save the key”
3. The private key (identification) is now saved in PATH as mentioned in **Figure 64**.
 - PATH = “Your identification has saved in <>”

Figure 64 Private Key saved path

```
saidell@saidell-Vostro-15-3568:~$ cat /home/saidell/.ssh/id_rsa.pub
ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQDg/1dsGYP4rFOKH8UnyjHgCHgzLl4quxd2ak2oQ4Us+qGRQLQNB1UDBJh6Zh9pESMcJTa8x1G2g0n33b1WpUlnEtxKY9pvC77ccQYn0u
sLClq157svTnBbXyn+7BgQ7+AUGG+WFucDmhrh05LuchJJP5XAtcwwLQ8pXmzsTy0JeZmkbnESV08+rFnM4/bIPDdzfp6pLc68lnotZQ3h/FTHUOXLTMOX3g87vMQlhy6WtnzYLT2Pw
I9o8A5WwVd1QW0Inbse57z7n6exs+/eQd81FTN+IyEuphxFZVDECLznBFFwSAT8FKCkRrQq4MxRnIM43n3V+zhwYH saidell@saidell-Vostro-15-3568
saidell@saidell-Vostro-15-3568:~$
```

4. Save the Public key generated in step above as described in **Device configuration** section.
5. Login to device using Private key generated above with username as “admin”.

RADIUS authentication

Device management access using RADIUS authentication allows multiple users to access using unique credentials and is secured.


Device configuration

Management access using RADIUS authentication method can be configured on device using standalone AP or from cnMaestro. Navigate to **System > Management** and configure the following:

1. Enable **RADIUS Mgmt Auth** checkbox.

2. Configure RADIUS IP/Hostname and shared secret in **RADIUS Server** and **RADIUS Secret** parameters respectively.
3. Click **Save**.

Figure 65 System > Management: RADIUS Server and RADIUS Secret parameters



4. Login to device using appropriate credentials as shown in **Figure 66**.

Figure 66 UI Login page



Chapter 14: Mesh

cnPilot Enterprise series Wi-Fi APs support wireless mesh allowing the user to easily extend the range of their network and to cover areas where a cable run might be hard to do. Mesh support was added in software version 2.0.

cnPilot devices support mesh connections between radios. Mesh links can form between radios which are operating in the same band. Given the larger set of available channels and typically cleaner RF environment Cambium recommend using the 5GHz radio for mesh backhaul.

For a stable mesh link to be established, cnPilot mesh operates in three modes of operation:

1. Mesh Base (MB)

cnPilot device that operates in MB mode is the key to Mesh topology. MB is usually connected to the wired network. The radio setup for MB will select a channel and start transmitting beacons as soon as the AP comes up.

2. Mesh Client (MC)

cnPilot device that operates in MC mode, scans all available channels supported as per regulatory domain and establishes a link with MB.

3. Mesh Recovery (MR)

This mode when enabled helps to maintain mesh link if there is a disruption in backhaul link established with MB and MC. Mesh link disruption can cause due to PSK mismatch or due to asynchronous configurations on MB and MC. This mode needs to be exclusively enabled on MB device.

This mode can also help in Zero Touch Configuration of cnPilot device.

Mesh configurable parameters

Table 45 lists the configurable parameters that are exclusive to mesh:

Table 45 Configure: WLAN > Mesh parameters

Parameters	Description	Range	Default
Enable	Option to enable a WLAN profile. Once enabled, a Beacon is broadcasted with SSID and respective configured parameters in a WLAN profile.	–	–
Mesh	This parameter is required when a WDS connection is established with cnPilot devices. Four options are available under this parameter: <ol style="list-style-type: none"> Base A WLAN profile configured with mesh-base will operate like a normal AP. Its radio will beacon on startup so its SSID can be seen by radios configured as mesh-clients. 	–	Off

Parameters	Description	Range	Default
	<p>2. Client</p> <p>A WLAN profile configured with mesh-client will scan all available channels on startup, looking for a mesh-based AP to connect.</p> <p>3. Recovery</p> <p>A WLAN profile configured as mesh-recovery will broadcast pre-configured SSID upon detection of mesh link failure after a successful connection. This needs to be exclusively configured on mesh-base device. Mesh-client will auto scan for mesh-recovery SSID upon failure of mesh link.</p> <p>4. Off</p> <p>Mesh support disable on WLAN profile.</p>		
SSID	SSID is the unique network name to which MC connects and establishes mesh link.	–	–
VLAN	Management VLAN to access all devices in mesh topology.	1-4094	1
Security	<p>This parameter determines key values that is encrypted based on selected algorithm. Following security methods are supported by cnPilot devices:</p> <p>1. Open</p> <p>This method is preferred when Layer 2 authentication is built in the network. With this configured on cnPilot device, any mesh link can be established.</p> <p>2. WPA2-Pre-Shared Keys</p> <p>This mode is supported with AES encryption.</p> <p>3. WPA2 Enterprise</p> <p>This security type uses 802.1x authentication to associate mesh devices. This is a centralized system of authentication method.</p>	–	Open
Passphrase	String that is a key value to generate keys based on security method configured.	–	12345678
Radios	<p>Each SSID can be configured to be transmitted as per the deployment requirement. For a mesh WLAN profile, options available to configure band:</p> <ul style="list-style-type: none"> • 2.4GHz • 5GHz 	–	2.4GHz

Parameters	Description	Range	Default
Max Clients	This specifies the maximum number of mesh clients that can be associated to a mesh WLAN profile. This varies based on cnPilot device model number. Refer Table 16 for more details.	1-512 (Refer Table 16)	128
Client Isolation	<p>This feature needs to be enabled when there is a need for prohibition of inter mesh devices communication either over the network or on an AP. Three options are available to configure based on requirement:</p> <ol style="list-style-type: none"> Disable This option when selected disables client isolation feature. i.e. Inter Mesh client communication is allowed. Local This options when selected enables client isolation feature. This option prevents inter mesh client communications connected to same device. Network Wide This option when selected enables network wide client isolation feature. It prevents mesh client communications connected to different AP deployed in same network. 	–	Disabled
Hide SSID	This is the basic security mode of a Wi-Fi device. This parameter when enabled, will not broadcast SSID.	–	Disabled
Mesh Vlan Tagging	Enable the VLAN tagging over mesh link. This is applicable only for Cambium mesh topology.	–	Enabled
Mesh Auto Detect Backhaul	<ol style="list-style-type: none"> Single Hop MC is configured on MB with same WLAN parameters. When enabled, this feature triggers when a MB losses Ethernet connectivity. MB profile will get disabled and MC profile will get enable and establishes mesh link with nearest MB. For MB profile to get auto disabled, uncheck Mesh Multi Hop. Multi Hop MC is configured on MB with same WLAN parameters. When enabled, this feature triggers when a MB losses Ethernet connectivity. MB profile and MC profile will get enable and establishes mesh link with nearest MB. 	–	Disabled
Drop Multicast Traffic	When enabled, will drop all multicast flowing in or out of that WLAN.	–	Disabled

Parameters	Description	Range	Default
Insert DHCP Option 82	<p>Enabling this option appends Option 82 in the DHCP packets. Following information is allowed to configure:</p> <ol style="list-style-type: none"> DHCP Option 82 Circuit ID Configurable parameters under this option are as follows: <ul style="list-style-type: none"> • Hostname • APMAC • Site ID • BSSID • SSID • Custom DHCP Option 82 Remote ID Configurable parameters under this option are as follows: <ul style="list-style-type: none"> • Hostname • APMAC • Site ID • BSSID • SSID • Custom 		Disabled
Tunnel Mode	This option is enabled when user traffic is tunneled to central network either using L2TP or L2GRE.	–	Disabled
Mesh Monitored Host	This parameter is exclusive to MC device. Configure IP or Hostname to check the link status.	–	–
Mesh Monitor Duration	Configure the interval at which the ping is sent for the configured mesh monitored host.	5-60 Min	30
Mesh Recovery Interval	Configure the interval for the consecutive ping loss seen after which the mesh link is considered to be down and a reconnect is attempted. One can configure the duration and interval both to be the same at which case the first ping loss itself will result in triggering the reconnect.	5-30 Min	30

To configure the above parameters, navigate to the **Configure > WLAN > Basic** tab and provide the details as given below:

1. Select the **Enable** checkbox to enable the operations of this WLAN.

2. Select the operating parameters **Base/Client/Recovery** from the **Mesh** drop-down list.
3. Enter a name that uniquely identifies a wireless network in the **SSID** textbox.
4. Enter the **VLAN** parameter value in the textbox.
5. Select **Security** type from the drop-down list.
6. Enter WPA2 Pre-shared security passphrase or key in the **Passphrase** textbox.
7. Select the radio type (2.4GHz, 5GHz) on which the WLAN should be supported from the **Radios** drop-down list.
8. Select **Max Clients** parameter value from the drop-down list.
9. Select the required **Client Isolation** parameter from the drop-down list.
10. Enable **Hide SSID** checkbox.
11. Enable **Mesh Vlan Tagging** checkbox.
12. Enable **Mesh Auto Detect Backhaul** checkbox.
13. Enable **Drop Multicast Traffic** checkbox.
14. Enable **Insert DHCP Option 82** checkbox.
15. Select **Tunnel Mode** checkbox to enable tunnelling of WLAN traffic over configured tunnel.
16. Enter the IP or hostname name in the **Mesh Monitored Host** textbox.
17. Select the **Mesh monitor duration** time from the drop-down list.
18. Select the **Mesh recovery interval** time from the drop-down list.
19. Click **Save**.

Figure 67 Configure > Mesh > Base parameters

Basic

Enable	<input checked="" type="checkbox"/>	
Mesh	Base	<small>Mesh Base/Client/Recovery mode</small>
SSID	HSTSK_WLAN_Free\$II	<small>The SSID of this WLAN (upto 32 characters)</small>
VLAN	1	<small>Default VLAN assigned to clients on this WLAN. (1-4094)</small>
Security	WPA2 Pre-shared Keys	<small>Set Authentication and encryption type</small>
Passphrase	*****	<small>WPA2 Pre-shared Security passphrase or key</small>
Radios	2.4GHz	<small>Define radio types (2.4GHz, 5GHz) on which this WLAN should be supported</small>
Max Clients	128	<small>Default maximum Client assigned to this WLAN. (1-256)</small>
Client Isolation	Disable	<small>When selected, it allows wireless clients connected to the same AP or different APs to communicate with each other in the same VLAN</small>
Hide SSID	<input type="checkbox"/> Do not broadcast SSID in beacons	
Mesh Vlan Tagging	<input checked="" type="checkbox"/> Enable the vlan tagging over mesh link	
Mesh Auto Detect Backhaul	<input type="checkbox"/> Enable the ethernet link status detection and try to connect over mesh link	
Drop Multicast Traffic	<input type="checkbox"/> Drop the send/receive of multicast traffic	

Advanced

Insert DHCP Option 82	<input type="checkbox"/> Enable DHCP Option 82
Tunnel Mode	<input type="checkbox"/> Enable tunnelling of WLAN traffic over configured tunnel

Figure 68 Configure > Mesh > Client parameters

Basic

Enable

Mesh Client Mesh Base/Client/Recovery mode

SSID H\$TSK_WLAN_Free\$!! The SSID of this WLAN (upto 32 characters)

VLAN 1 Default VLAN assigned to clients on this WLAN. (1-4094)

Security open Set Authentication and encryption type

Radios 5GHz Define radio types (2.4GHz, 5GHz) on which this WLAN should be supported

Mesh Vlan Tagging Enable the vlan tagging over mesh link

Advanced

Mesh Monitored Host IP or hostname that if not reachable a mesh recovery is attempted

Mesh monitor duration 30 Duration in minutes (5-60)

Mesh recovery interval 30 Interval in minutes after which a full recovery is attempted if the mesh base is not reachable (5-30)

Save
Cancel

Mesh link

This section briefs about configuration of device to get mesh link established with different deployment scenarios.

VLAN 1 as management interface

Follow the below steps to establish mesh link with VLAN 1 as management interface:

1. On MB, configure MB and MR. Follow the below steps to configure MB:
 - a. WLAN Profile

Figure 69 Mesh Base configuration with native VLAN 1

Cambridge Networks cnPilot E400 - E400-AFA308 Reboot Logout

Configure / Wlan

Add WLAN

Edit WLAN

H\$TSK_WLAN_...

Basic Radius Server Guest Access Usage Limits Access Delete

Basic

Enable

Mesh Base Mesh Base/Client/Recovery mode

SSID CAMBIUM_MESH_BASE The SSID of this WLAN (upto 32 characters)

VLAN 1 Default VLAN assigned to clients on this WLAN. (1-4094)

Security open Set Authentication and encryption type

Radios 2.4GHz Define radio types (2.4GHz, 5GHz) on which this WLAN should be supported

Max Clients 128 Default maximum Client assigned to this WLAN. (1-256)

Client Isolation Disable When selected, it allows wireless clients connected to the same AP or different APs to communicate with each other in the same VLAN

Hide SSID Do not broadcast SSID in beacons

Mesh Vlan Tagging Enable the vlan tagging over mesh link

Mesh Auto Detect Backhaul Enable the ethernet link status detection and try to connect over mesh link

Drop Multicast Traffic Drop the send/receive of multicast traffic

Advanced


Insert DHCP Option 82 Enable DHCP Option 82

Tunnel Mode Enable tunneling of WLAN traffic over configured tunnel

Save
Cancel


- b. Management VLAN Interface

Figure 70 Mesh Base configuration > Management VLAN 1




c. Ethernet Interface

Figure 71 Mesh Base Ethernet configuration > Access VLAN 1




- 2. Configure MC as below:
 - a. WLAN Profile

Figure 72 Mesh Client configuration with VLAN 1




b. Management Interface

Figure 73 Mesh Client configuration > Management VLAN 1




c. Ethernet Interface

Figure 74 Mesh Client Ethernet configuration > Access VLAN 1



3. Configure MR on MB device as follows on any WLAN profile:
 - a. WLAN Profile

Figure 75 Configure > WLAN > Mesh Recovery




Non-VLAN 1 as management interface

Follow the below steps to establish mesh link with Non-VLAN 1 as management interface:


1. On MB, configure MB and MR. Following are the steps to configure MB:
 - a. WLAN Profile

Figure 76 Mesh Base configuration with non-VLAN 1




b. Management VLAN Interface

Figure 77 Mesh Base configuration > Management non-VLAN 1




c. Ethernet Interface

Figure 78 Mesh Base Ethernet configuration > Access non-VLAN 1




2. Configure MC as below:
 - a. WLAN Profile

Figure 79 Mesh Client configuration with non-VLAN 1




- b. Management Interface

Figure 80 Mesh Client configuration > Management non-VLAN 1



c. Ethernet Interface


Figure 81 Mesh Client Ethernet configuration > Access non-VLAN 1



3. Configure MR on MB device on any WLAN profile as follows:

a. WLAN Profile

Figure 82 Configure > WLAN > Mesh Recovery



Chapter 15: Autopilot

Autopilot is a feature on Cambium Enterprise Wi-Fi APs that allows one AP to be a controller of other APs in a network to manage:

- [Configuration and Onboarding](#)
- [Manage Autopilot](#)
- [Dashboard](#)
- [Insight](#)

Configuration and Onboarding

This section provides required information to:

- [Configure member AP to Autopilot master](#)
- [Configuring WLAN in default WLAN Group](#)
- [Configuring WLANs with user created WLAN Group](#)
- [WLAN Group override](#)
- [Configuring WPA2-Enterprise WLAN](#)
- [Onboard member APs to Autopilot master](#)
- [Connect clients to the WLANs and check statistics](#)

Configure member AP to Autopilot master

To configure member APs to a Master:

1. Open a web browser and browse the IP address of an AP in the network and access the AP's UI page.



Note The AP needs to be upgraded with autopilot firmware.

2. Go to **Configure > System > Management > Autopilot** and select the AP as Master.

Figure 83 Configure > System > Management > Autopilot

The screenshot shows the configuration page for a Cambium Networks cnPilot E500 - E500-B99DDC device. The interface is split into two main sections: System and Management.

System Configuration:

- Name:** E500-B99DDC (Hostname of the device (max 64 characters))
- Location:** Cambium_Lab (Location where this device is placed (max 64 characters))
- Contact:** Automation_Team (Contact information for the device (max 64 characters))
- Country-Code:** India (For appropriate regulatory configuration)
- Placement:** Indoor (Configure the AP placement details)
- PoE Output:** Off (Enable Power-over-Ethernet to an auxiliary device connected to ETH2)
- LED:** Whether the device LEDs should be ON during operation
- LLDP:** Whether the AP should transmit LLDP packets

Management Configuration:

- Admin Password:** [Redacted] (Configure password for authentication of GUI and CLI sessions)
- Autopilot:** Default (Autopilot Management of APs)
- Teinet:** Master
- SSH:** Enable SSH access to the device CLI

3. Click **Save**.
4. Refresh the web page and AP brings up the Autopilot UI.

The configured Master AP can perform the following:

- Act as a controller and manage other member APs
- Configure approved APs
- Upgrade firmware
- Display combined statistics and events

Cambium Enterprise AP can be configured the following ways:


- [Configuring an AP with Internal DHCP server](#)
- [Configuring an AP with External DHCP Server](#)

Configuring an AP with Internal DHCP server

Network Topology

The initial network for installments with external NAT device and VLAN segregation (having two VLANs for the network) is shown in [Figure 84](#).

Figure 84 Configuring an AP with Internal DHCP server



Configure an AP with default WLAN group

To configure an AP with default WLAN group:

1. Connect all the APs to the native VLAN; for example, VLAN 1 as shown above.
2. Configure all the ports of the switch as trunk with the native VLAN 1 where,
 - a. Allowed VLAN: 10, 20
 - b. Native VLAN: 1

To configure the Master AP:

1. Go to **CONFIGURE > System** and configure **Country Code** and **NTP Servers**.

Figure 85 Configure > Systems




Figure 86 Configure > Ethernet Ports

The screenshot displays the 'Configure > Ethernet Ports' page in the cnPilot Enterprise AP web interface. The top navigation bar includes 'Cambium Networks', 'DASHBOARD', 'INSIGHT', 'CONFIGURE', 'MANAGE', and 'LOGOUT'. The left sidebar shows a 'Configuration' menu with options like System, Management, Wireless LANs, Radios, MASTER-AP CONFIG, IP Settings, Networks, NETWORK, Ethernet Ports (highlighted), Firewall, Tunnels, OVERRIDES, Access Point Settings, and CLI Overrides. The main content area is titled 'Ethernet Ports' and contains a 'PORT CONFIGURATION' section with tabs for 'ETH 1' and 'ETH 2'. The configuration fields are as follows:

Field	Value
Port Mode	Trunk - Multiple VLANs
Native VLAN	1
Allowed VLANs	1,15,25,50
Native Tagged	<input type="checkbox"/> Native VLAN tagged
Port Speed	Auto
Port Duplex	Full Duplex

At the bottom right of the configuration area, there are 'Cancel' and 'Save' buttons.

2. Go to **CONFIGURE > MASTER AP CONFIG > Networks** and configure the **Static IP Address** and the **DHCP Server** for VLAN 1 (native VLAN).
3. Enable DHCP Server and provide range of IP addresses. For example, when starting address range is give as 10.10.10.20 to 10.10.10.200, IP addresses can be assigned from 10.10.10.20 to 10.10.10.200 range.

Figure 87 Configure > Networks


The screenshot shows the 'Edit Interface - VLAN 50' configuration page. The left sidebar contains a navigation menu with 'Networks' selected. The main content area is divided into three sections:

- IP CONFIGURATION:**
 - VLAN ID: 10
 - Address Mode: Static
 - Available in member APs: Enable this VLAN on all member Access Points
 - Static IP Address: 10.10.10.10
 - Network Mask: 255.255.255.0
 - Enable Nat: When NAT is enabled, IP addresses under this SVI are hidden
 - Enable DHCP Server: Enable DHCP server for this interface. **Enable this option to configure DHCP**
- DHCP SERVER CONFIGURATION:**
 - Starting Address Range: 10.10.10.20
 - Ending Address Range: 10.10.10.200
 - Network IP Address: 10.10.10.0
 - Network Mask: 255.255.255.0
- ROUTING AND DNS:**
 - Default gateway: 10.10.10.1. **This should be the IP address of NAT device in your network**
 - Domain Name: CAMNWK
 - Primary DNS server: 208.69.38.205. **Edit these fields as per the DNS server of ISP**
 - secondary DNS server: 4.2.2.2. **Edit these fields as per the DNS server of ISP**

Buttons for 'Cancel' and 'Save' are located at the bottom right of the configuration area.


4. DHCP pool is used to provide IP addresses to all devices on VLAN 1. Add L3 interface of VLAN 10 and 20 under **CONFIGURE > Networks**.
 - a. Enable **NAT** in this L3 interface.
 - b. Enable **DHCP server** for this VLAN L3 interface.
 - c. Default gateway needs to be Static IP Address of the L3 interface.

Figure 88 Configure > Networks > VLAN 10



5. Add L3 interface of VLAN 20 and enable DHCP server and NAT as shown in Figure 89.

Figure 89 Configure > Networks > VLAN 20




Configuring an AP with External DHCP Server

Network Topology

Initial network installments with external DHCP server and NAT box. The complete network is connected to VLAN 1.

Figure 90 Configuring an AP with External DHCP server




All the member APs are connected to ports of Switch. All the ports are mapped to VLAN 1.

To configure Master AP:


1. Configure country code, ntp server in master AP under **System**.

Figure 91 Configure > Systems



2. Configure static IP on Master.

Figure 92 Configure > IP Settings




3. Refresh the page after saving with newly configured Ip address. In this example, open URL in browser <http://10.10.10.25>.

Configuring WLAN in default WLAN Group

To configure WLAN in default WLAN group:


1. Add a **Wireless LAN**.

Figure 93 Configure > Wireless LANs




2. Enter **SSID** and password in respective fields.
3. Configure **VLAN** as 10 and click **Save**.

Figure 94 Configure > Wireless LANs > VLAN 10




4. Add another WLAN with VLAN 20. Enter **SSID** and password as required.
5. Configure VLAN as 20 and click **Save**.

Figure 95 Configure > Wireless LANs > VLAN 20




6. Check the configured WLANs.

Figure 96 Configure > Wireless LANs > VLAN 10 and 20



7. Connect member APs to the Switch. The connected member APs receive IP from IP address from Master AP on VLAN 1. Once the member APs connect to the Master AP and they are approved, the configured WLANs are pushed to all the approved member APs and Master AP.

Figure 97 Dashboard




Configuring WLANs with user created WLAN Group

User can group one or multiple WLANs under a WLAN group and push the configuration to specific APs. WLAN group is used to push specific WLANs to specific selected APs.


1. Create a WLAN group.

Figure 98 Create a WLAN group




2. Configure a new WLAN Group.

Figure 99 Configure a new WLAN Group



3. Configure WLAN under the newly created WLAN Group.

Figure 100 Configure WLAN under the newly created WLAN Group




WLAN group override

This section is to describe how user can select device and configure user configured WLAN-group. By selecting device and overriding their WLAN-group, specific WLANs can be pushed to selected devices.


- 1. Select the device and click **Edit** button.

Figure 101 Configure > Access Point settings



2. Choose the WLAN-group you had configured from the drop-down list and click **Save** button. This will push the WLANs configured under **group1** to the selected AP.


Figure 102 Configure > Access Point settings > WLAN Group



Configuring WPA2-Enterprise WLAN

Follow the below steps to create a WLAN with Enterprise security under **user created WLAN Group**.

Figure 103 Configure > Access Point settings > user created WLAN Group



1. Enter details in the **WLAN** page.


2. Select **Security** as **WPA2-Enterprise** from the drop-down list.
3. Keep **VLAN** as 1.
4. Do not press **Save** button before configuring Radius configurations for authentication.

Figure 104 Configure > Wireless LANs > Security

The screenshot displays the 'Wireless LANs' configuration page for 'Auto_pilot_8'. The interface includes a navigation menu on the left with options like System, Management, Wireless LANs, Radios, and more. The main content area shows the 'Basic' tab with fields for Name / SSID (Auto_pilot_8), Enable (checked), Band (2.4GHz & 5GHz), Security (WPA2 Enterprise), and VLAN. There are also 'Cancel' and 'Save' buttons at the bottom right.

5. Configure **Radius Server** details for Authentication and for Accounting if applicable. Authentication server details has to be filled before saving the WLAN configuration.

Figure 105 Configure > Wireless LANs > Radius Server




Onboard member APs to Autopilot master

To onboard other member APs to Autopilot Master:

1. Access the Autopilot Master AP via web browser.
2. Login with the below credentials:
 - Username: **admin**
 - Password: **admin**

Figure 106 Login page




- Go to the **DASHBOARD** tab of the Master AP which displays the list of member APs those have discovered the Master AP.



Note The member AP needs to be upgraded with autopilot firmware.

- Click **APPROVE** to approve and manage the desired member AP or click **APPROVE ALL** to approve and manage all the listed APs.

Figure 107 Dashboard > Overview



- The approved member APs are listed under **DASHBOARD > ACCESS POINTS** tab.

Figure 108 Dashboard > Access points

The screenshot shows the 'Dashboard > Access points' page. A red arrow points to the 'Approved APs are listed here.' text above a table. The table lists various APs with their MAC, IP, Model, Clients, Power, Channel, and State.

NAME	MAC	IP ADDRESS	MODEL	CLIENTS	POWER	CHANNEL	STATE
E400-B5AD58	00-04-56-B5-AD-58	10.10.10.169	cnPilot E400	0	25, 20 dBm	1, 100	ON, ON
E400-AF0782	00-04-56-AF-07-82	10.10.10.141	cnPilot E400	0	25, 24 dBm	1, 144	ON, ON
E500-917722	00-04-56-91-77-22	10.10.10.165	cnPilot E500	2	29, 24 dBm	1, 48	ON, ON
E400-B5B05A	00-04-56-B5-B0-5A	10.10.10.166	cnPilot E400	0	25, 14 dBm	1, 44	ON, ON
E400-B5AD58	00-04-56-B1-6C-D0	10.10.10.41	cnPilot E400	0	25, 24 dBm	1, 100	ON, DFS
E400-B5AEFC	00-04-56-B5-AE-FC	10.10.10.167	cnPilot E400	0	25, 14 dBm	6, 48	ON, ON
E410-93F1AD	00-04-56-93-F1-AD	10.10.10.138	cnPilot E410	0	dBm		

Connect clients to the WLANs and check statistics

- Go to **DASHBOARD > WIRELESS CLIENTS**.
- Connect the listed clients to the configured WLANs and check statistics.

Figure 109 Dashboard > Wireless clients

The screenshot shows the 'Wireless Clients' dashboard. At the top, there is a navigation bar with 'Overview' selected. Below it, a table lists wireless clients with columns for Name, MAC, IP, AP, Vendor, Username, Device Type, WLAN, and VLAN. Two clients are visible: 'android-777' and 'ipad-766'. A search bar is located at the top right, and a pagination control shows '1' of 1 items.

NAME	MAC	IP	AP	VENDOR	USERNAME	DEVICE TYPE	WLAN	VLAN
android-777	78-7B-8A-9A-9E-77	192.168.10.10	E400-AF0782	Apple		Motorola	member-10	10
ipad-766	80-00-6E-2E-59-3F	192.168.20.10	E400-AF0782	Motorola		iphone	member-20	20

Manage Autopilot

The Manage tab of Autopilot UI manages firmware upgrades, configuration file updates, and technical assistance of the master and member APs. Data is distributed in the following sub-sections:

- **Firmware**
- **System**
- **Tools**

Figure 110 Manage > Firmware

The screenshot shows the 'Manage > Firmware' dashboard. The navigation bar at the top has 'MANAGE' selected. Below it, there are three sub-section tabs: 'FIRMWARE', 'SYSTEM', and 'TOOLS'. The 'FIRMWARE' tab is currently active.

Firmware

This section supports uploading required firmware to master AP, and from master AP to the member APs.

To configure firmware:

1. Go to **Manage > Firmware** tab.
2. Click the **Browse** button to browse the firmware file.


Figure 111 Manage > Upload Firmware

The screenshot shows the 'Upload Firmware' interface. It features a file upload form with a 'Choose File' button and an 'Upload Firmware' button. Below the form is a table titled 'Access Point Firmware Upgrade' with columns for Name, MAC, IP, Model, Active, Backup, Status, and Actions. One entry is visible for 'cnPilot E500'.

NAME	MAC	IP	MODEL	ACTIVE	BACKUP	STATUS	ACTIONS
E500-9F33F0	00-04-56-9F-33-F0	10.10.0.7	cnPilot E500	3.11-b11	3.11-b9		INSTALL REBOOT

3. Select the required firmware file and click **Open**. For example, firmware file: E400_E50X-3.4.2-b27.img.

Figure 112 To open required Firmware



4. Click **Upload Firmware** button and wait for upload.

Figure 113 Upload firmware on Master AP




5. By clicking on **Upgrade All Devices** button, the firmware can be upgraded on all APs simultaneously or can be upgraded on each AP separately by clicking on **Install** button provided for every AP on the list.

Figure 114 To upgrade firmware in all devices



Once step 5 is done, the following statuses during the Firmware upgrade can be seen in **Figure 115**.

Figure 115 Firmware upgraded sequence



6. Different statuses of the firmware upgrade can be seen in Figure 116.

Figure 116 Firmware upgraded status

NAME	MAC	IP	MODEL	ACTIVE	BACKUP	STATUS	ACTIONS
E500-BEA714	00-04-56-BE-A7-14	10.10.10.153	cnPilot E500	3.4.2-b27	3.4.2-b27	File downloaded. Starting upgrade	INSTALL REBOOT
E500-914ED0	00-04-56-91-4E-D0	10.10.10.157	cnPilot E500	3.4.2-b27	3.4.2-b27	File downloaded. Starting upgrade	INSTALL REBOOT
E500-BEA758	00-04-56-BE-A7-58	10.10.10.120	cnPilot E500	3.4.2-b27	3.4.2-b27	File downloaded. Starting upgrade	INSTALL REBOOT
E400-B16CD0	00-04-56-B1-6C-D0	10.10.10.40	cnPilot E400	3.4.2-b27	3.4.2-b27	Starting upgrade	INSTALL REBOOT
E500-917722	00-04-56-91-77-22	10.10.10.165	cnPilot E500	3.4.2-b27	3.4.2-b27	File downloaded. Starting upgrade	INSTALL REBOOT
E400-AF0782	00-04-56-B5-5D-8A	10.10.10.197	cnPilot E400	3.4.2-b27	3.4.2-b27	Queued. Starting in 10 seconds	INSTALL REBOOT
E410-93F1AD	00-04-56-93-F1-AD	10.10.10.138	cnPilot E410	3.4.2-b27	3.4.2-b20	firmware verification failed	INSTALL REBOOT
E500-BEA54A	00-04-56-BE-A5-4A	10.10.10.161	cnPilot E500	3.4.2-b27	3.4.2-b27	File downloaded. Starting upgrade	INSTALL REBOOT
E500-BEA650	00-04-56-BE-A6-50	10.10.10.109	cnPilot E500	3.4.2-b27	3.4.2-b27	Queued. Starting in 20 seconds	INSTALL REBOOT
E400-AF0782	00-04-56-AF-07-82	10.10.10.198	cnPilot E400	3.4.2-b27	3.4.2-b27	Queued. Starting in 5 seconds	INSTALL REBOOT
E500-914F3C	00-04-56-91-4F-3C	10.10.10.152	cnPilot E500	3.4.2-b27	3.4.2-b27	File downloaded. Starting upgrade	INSTALL REBOOT
E500-BEA588	00-04-56-BE-A5-88	10.10.10.92	cnPilot E500	3.4.2-b27	3.4.2-b27	File downloaded. Starting upgrade	INSTALL REBOOT
E400-B5B05A	00-04-56-B5-B0-5A	10.10.10.166	cnPilot E400	3.4.2-b27	3.4.2-b27	Queued. Starting in 15 seconds	INSTALL REBOOT

NAME	MAC	IP	MODEL	ACTIVE	BACKUP	STATUS	ACTIONS
E500-BEA714	00-04-56-BE-A7-14	10.10.10.153	cnPilot E500	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT
E500-914ED0	00-04-56-91-4E-D0	10.10.10.157	cnPilot E500	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT
E500-BEA758	00-04-56-BE-A7-58	10.10.10.120	cnPilot E500	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT
E400-B16CD0	00-04-56-B1-6C-D0	10.10.10.40	cnPilot E400	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT
E500-917722	00-04-56-91-77-22	10.10.10.165	cnPilot E500	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT
E400-AF0782	00-04-56-B5-5D-8A	10.10.10.197	cnPilot E400	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT
E410-93F1AD	00-04-56-93-F1-AD	10.10.10.138	cnPilot E410	3.4.2-b27	3.4.2-b20	firmware verification failed	INSTALL REBOOT
E500-BEA54A	00-04-56-BE-A5-4A	10.10.10.161	cnPilot E500	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT
E500-BEA650	00-04-56-BE-A6-50	10.10.10.109	cnPilot E500	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT



Note

In case of any error/failure in upgrade status such as **Firmware verification failed** is shown in status column:

1. APs can be rebooted individually by using **Reboot** option.
2. All the APs can be rebooted simultaneously using **Reboot All Devices** option.
3. The loaded firmware can be deleted from the master AP using **Delete Firmware** option.

NAME	MAC	IP	MODEL	ACTIVE	BACKUP	STATUS	ACTIONS
E500-BEA714	00-04-56-BE-A7-14	10.10.10.153	cnPilot E500	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT
E500-914ED0	00-04-56-91-4E-D0	10.10.10.157	cnPilot E500	3.4.2-b27	3.4.2-b27	Upgraded successfully to 3.4.2-b27	INSTALL REBOOT

System

This section provides the following options:

- **Reboot All:** This option is used to reboot all the APs including the master AP simultaneously.
- **Disable Autopilot:** This button is used to disable Autopilot and the entire network of master AP.

Figure 117 System

- **Import Configuration:** This button is used to load any essential configuration and configure Autopilot. Configuration files are stored in .json format.
- **Export configuration:** This button is used to export any new or essential configuration from Autopilot setup and store in .json format for future use.

Figure 118 System > Import/Export Configuration

Access Point Management

This section provides the following options:

- **LED:** This button triggers the LED light on the AP (Hardware) for easy identification.
- **Reboot:** This button is used to individually reboot APs in Autopilot network.
- **Default:** This button is used to set the APs to their default configuration.
- **Delete:** This button is used to delete member APs from the Autopilot network.


Figure 119 Access Point management



Tools

This section supports downloading technical support file for troubleshooting and viewing User Interfaces of APs.

Figure 120 Tools > Troubleshoot




Dashboard

The Dashboard of Autopilot UI provides excellent monitoring capability of the complete setup.

Various graphs and statistics of events, performance, and system information of clients and application is evidently made available to the user. It comprises of following components through which the data is available for monitoring.

Figure 121 Dashboard



Overview

The Dashboard tab comprises of data and various graphs as follows:


- **Site information**
- **Discovered devices**
- **Events**
- **Clients**
- **Throughput**
- **Top AP**
- **Top clients**
- **Clients by Band/Radio type**

- Channel distribution
- Clients by WLAN
- Clients by device type

Site information

This section provides the information of number of configured APs, online APs, and number of clients provided.

Figure 122 Dashboard > Overview > Site information



Discovered devices

This table lists all the discovered devices with their names, IP addresses, and actions performed over them. Every device discovered and displayed here should be **APPROVED** for it to be connected to APs network and ready for configuration.


Figure 123 Dashboard > Overview > Discovered devices

DISCOVERED DEVICES			Approve All
NAME	IP	ACTIONS	
E410-93F17C	10.10.10.119	✓ APPROVE	
mesh-base1-E410-93F185	10.10.10.137	✓ APPROVE	

Events

This section continuously streams all the events occurring on the network of AP both graphically and digitally. Graphical spikes can be helpful in representing the network to know how the network is behaving. Any configuration error is also displayed as an event with the reasons mentioned due to which the application of respective configuration failed. For example, check the highlighted event in the below figure.


Figure 124 Dashboard > Overview > Events



Clients

This section graphically streams information about the number of clients connected to specific frequency (2.4 Hz or 5 Hz) and total number of clients at a given time on the present day.


Figure 125 Dashboard > Overview > Clients



Throughput


This section graphically represents the TX, RX of each client and total Throughput of all clients against each channel. User can hover over the graph and get more granular details.

Figure 126 Dashboard > Overview > Throughput



Top APs


This section graphically displays the top five APs connected to Autopilot’s network along with numbers of clients and traffic in respective frequencies (2.4hz or 5hz).



Top clients


This section graphically represents the top five clients connected to APs with highest traffic flow.

Figure 128 Dashboard > Overview > Top clients



Clients by Band/Radio type


This section provides pie chart representation of the radio types of clients. This shows pie chart based on the percentage of 2.4 GHz and 5 GHz clients connected to Autopilot network. Another pie chart is plotted based on types of clients such as 802.11a, 802.11b/g/n, 802.11ac.



Channel distribution

This section plots and displays the channel distribution between master and member APs as shown below. This helps to know which channels are being used and how many APs are using the channels.


Figure 130 Dashboard > Overview > Channel distribution



Clients by WLANs

This section provides a pie chart representation of all the Clients and WLANs. This helps to instantly know the load on the WLANs.


Figure 131 Dashboard > Overview > Clients by WLANs



Clients by device type

This section provides a pie chart representation of device type (Respective Platforms) of the Clients. This classifies the clients based on type such as Android, Windows clients, Linux, IPad, iPhone clients, and so on.

Figure 132 Dashboard > Overview > Clients by device type



Access Points

This tab contains details such as Performance, System details, Client details, and so on of all the APs connected to Autopilot. Under Access Point tab, there are four tabs which are as follows:

Overview

This tab provides information such as Name, MAC address, IP Address, Model, number of Clients, Power, Channels, and State of radio of all the APs'.

Performance

This tab displays MAC, IP, Link speed, Total TX (Transmit from APS), and Total RX (Received to APS). For example, if AP transmits data at the speed of 10Mbps, then its TX is equal to 10Mbps.

Figure 133 Dashboard > Access Points > Performance

NAME	IP ADDRESS	MAC	LINK SPEED	TOTAL TX	TOTAL RX
E500-9F33F0	10.10.0.7	00-04-56-9F-33-F0	1000M	1.2 Kbps	0 bps
E400-B16F48	192.168.15.10	00-04-56-B1-6F-48	1000M	0 bps	0 bps
E400-B558D2	10.10.0.5	00-04-56-B5-58-D2	1000M	0 bps	0 bps

System

This tab displays name, IP address, model, firmware, backup, CPU usage, memory, uptime, and synced configurations of all APs. This helps to know the performance of the APs. Config synced option lets a user to know whether the configuration of an AP is synced with the configuration done on Master. If there is any config sync issue, a red x is displayed as shown in Figure 134.

Figure 134 Dashboard > Access Points > System

NAME	IP ADDRESS	MODEL	FIRMWARE	BACKUP	CPU	MEMORY	UPTIME	CONFIG SYNCED
E500-9F33F0	10.10.0.7	cnPilot E500	3.11-b11	3.11-b9	10 %	48 %	16 hours	✓
E400-B16F48	192.168.15.10	cnPilot E400	3.11-b11	3.11-b9	10 %	45 %	16 hours	✓
E400-B558D2	10.10.0.5	cnPilot E400	3.11-b11	3.11-b9	10 %	45 %	16 hours	✓
E410-93F1AD	10.10.10.138	cnPilot E400	3.11-b11	3.11-b9	0%	0%	16 hours	✗
E400-AF0782	10.10.10.25	cnPilot E400	3.11-b11	3.11-b9	0%	0%	16 hours	✗

RF stats

This tab displays the number of 2.4G Clients, 5G Clients, TX to 2.4G clients, TX to 5G clients, RX from 2.4G clients, RX from 5G clients. Tx statistic signifies the downlink data speed to the client and Rx signifies uplink data speed from the client.

Figure 135 Dashboard > Access Points > RF Status

NAME	IP ADDRESS	MAC	2.4G CLIENTS	5G CLIENTS	2.4G TX	2.4G RX	5G TX	5G RX
E500-9F33F0	10.10.0.7	00-04-56-9F-33-F0	0	1	0 bps	0 bps	1.3 Kbps	0 bps
E400-B16F48	192.168.15.10	00-04-56-B1-6F-48	0	0	0 bps	0 bps	0 bps	0 bps
E400-B558D2	10.10.0.5	00-04-56-B5-58-D2	0	0	0 bps	0 bps	0 bps	0 bps

Wireless clients

This tab represents details of wireless clients such as vendor type, WLANs, VLANs, RF Stats, and so on.

Overview

The details in this tab include Name, MAC, IP, Vendor type of clients, Usernames (WPA2 enterprise and guest access), Device type (Platform) of Clients, list of WLANs to which clients are connected, and VLAN information of respective WLANs.

Figure 136 Dashboard > Wireless clients

NAME	MAC	IP	AP	VENDOR	USERNAME	DEVICE TYPE	WLAN	VLAN
	02-00-46-00-00-01	10.10.10.155	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-02	10.10.10.122	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-03	10.10.10.153	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-04	10.10.10.158	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-05	10.10.10.120	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-06	10.10.10.100	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-07	10.10.10.154	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-08	10.10.10.159	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-09	10.10.10.156	E400-B16CD0	[Local MAC]		Linux	beta-test	1
	02-00-46-00-00-0A	10.10.10.55	E400-B16CD0	[Local MAC]		Linux	beta-test	1

RF Stats

This tab includes details such as frequency type, radio type, signal, Signal to Noise (SNR), physical rate, TX and RX of clients along with names, MAC, and IP addresses of clients.



Note Less the number in signal better is the signal. For example, -20 is better signal than -70. Similarly, more the SNR better is the signal quality.

Figure 137 Dashboard > Wireless clients > RF status

Cambium Networks									
DASHBOARD INSIGHT CONFIGURE MANAGE LOGOUT									
OVERVIEW ACCESS POINTS WIRELESS CLIENTS WIRELESS LANS									
Overview RF Stats Search									
NAME	MAC	IP	TYPE	RADIO	SIGNAL	SNR	PHY RATE	TX	RX
	02-00-46-00-00-01	10.10.10.155	5GHz	ac	-39 dBm	56 dB	780 M	885.1 Kbps	6.9 Kbps
	02-00-46-00-00-02	10.10.10.122	5GHz	ac	-38 dBm	57 dB	780 M	900.2 Kbps	7 Kbps
	02-00-46-00-00-03	10.10.10.153	5GHz	ac	-39 dBm	56 dB	780 M	872.6 Kbps	6.6 Kbps
	02-00-46-00-00-04	10.10.10.158	5GHz	ac	-39 dBm	56 dB	780 M	863 Kbps	6.7 Kbps
	02-00-46-00-00-05	10.10.10.120	5GHz	ac	-39 dBm	56 dB	780 M	895.2 Kbps	7 Kbps
	02-00-46-00-00-06	10.10.10.100	5GHz	ac	-39 dBm	56 dB	780 M	876.3 Kbps	6.7 Kbps
	02-00-46-00-00-07	10.10.10.154	5GHz	ac	-39 dBm	56 dB	780 M	865.1 Kbps	6.8 Kbps
	02-00-46-00-00-08	10.10.10.159	5GHz	ac	-39 dBm	56 dB	780 M	885.4 Kbps	6.8 Kbps
	02-00-46-00-00-09	10.10.10.156	5GHz	ac	-39 dBm	56 dB	780 M	864.4 Kbps	6.6 Kbps
	02-00-46-00-00-0A	10.10.10.55	5GHz	ac	-39 dBm	56 dB	780 M	884.2 Kbps	6.8 Kbps

Displaying 1-10 of 18 items. Items per page: 10

Wireless LANs

This tab provides details of all the configured WLANs as follows:

- **GROUP:** Name of the group under which the WLAN is created. WLAN group is used to club single or multiple WLANs and then push the WLAN configurations to selected APs.
- **SSID:** SSID of the WLAN.
- **SECURITY:** Security of the WLAN which can be WPA2-PSK, WPA2-Enterprise, or Open.
- **Tx:** The actual data speed of downlink data. AP to clients.
- **Rx:** The actual data speed of uplink data. Clients to AP.

Figure 138 Dashboard > Wireless LANs

GROUP	SSID	SECURITY	CLIENTS	TX	RX
Default	Auto_pilot_8	open	0	0 bps	0 bps
diva1	diva_wlan1	open	0	0 bps	0 bps
Default	Auto_pilot_4	open	1	74 bps	140 bps
Default	Auto_pilot_1	wpa2-enterprise	0	0 bps	0 bps

Displaying 1-4 of 4 items. Items per page: 25

Insight

Insight option of Autopilot UI provides accurate insights on an AP anomalies which are distributed on the sub tabs as follows:

- **Pulse**
- **Timeview**
- **Events**

On the top left corner of the page the master and the member APs can be selected from the drop-down list. Site default gives overall details.

Figure 139 Insight > Pulse

ACCESS POINT ANOMALIES

- High CPU Usage** (0): Tracks Access Points which use very high CPU. Threshold is currently configured at 90%.
- High Memory Usage** (0): Tracks Access Points which use very high memory. Threshold is currently configured at 90%.
- No WLANs Mapped** (0): Tracks Access Points which do not have any wireless lans configured.
- No Clients** (2): Tracks Access Points which do not have any clients associated.
- No Gigabit Ethernet** (0): Tracks Access Points which did not auto-neg Gigabit network speed.
- Less uptime** (0): Tracks Access Points which came up within the last 30 minutes.
- Client overload** (0): Tracks Access Points which have more than 100 clients.
- Mismatched Firmware** (0): Tracks Access Points which do not have the latest firmware.

Site: Default

Select Site / AP

- Site : Default
- AP : E500-9F33F0
- AP : E400-B16F48
- AP : E400-B558D2

Pulse

This tab provides the detailed information of the following:

- **High CPU usage:** On clicking, this option leads to **TIMEVIEW** page of Insight tab and tracks the CPU usage of all APs graphically.

- **No WLANs mapped:** This option leads to APs page of Dashboard tab and tracks number of APs without wireless LANs configured.
- **No Gigabit ethernet:** This option leads to APs page of Dashboard tab and tracks APs which do not auto negotiate Gigabit network speed.
- **Client overload:** This option leads to AP page of Dashboard and gives the number of clients connected to every AP and also points the AP connected by highest number of clients.
- **High memory usage:** Tracks the memory usage of all APs and the highest memory usage and leads to **TIMEVIEW** page of the Insight tab, when clicked upon.
- **No clients:** Tracks the APs which do not have any clients connected to them along with their details like IP Address, Mac Address, and Model etc. On clicking leads to APs page on Dashboard.
- **Less uptime:** Lists all the APs which were activated within the last 30 minutes along with their details and leads to Overview page on Dashboard.
- **Mismatched firmware:** Provides information related to mismatch of software with respect to Master device.




Note In current version not all of these options are supported.

Timeview

This tab provides the graphical interpretation of CPU usage, Memory Usage, Clients, Overall Throughput, and Throughput by frequencies and Events. Also, the maximum (Graphical Peaks) and minimum values of all the mentioned components can be tracked accurately.

Figure 140 Insight > Timeview



Events

This tab provides the list of all the latest events of master and member APs. Events can be filtered for specific APs based on their event name, content, Mac or IP address. All the old events can be cleared to start afresh.

Figure 141 Insight > Unfiltered Events

The screenshot shows the 'Insight > Unfiltered Events' page. At the top, there is a navigation bar with 'Camblum Networks', 'DASHBOARD', 'INSIGHT', 'CONFIGURE', 'MANAGE', and 'LOGOUT'. Below the navigation bar, there are tabs for 'PULSE', 'TIMEVIEW', and 'EVENTS'. A search filter is present: 'Filter text : Can include event name, content, IP or MAC'. There are 'Filter Events' and 'Clear Events' buttons. The main content area is titled 'Events' and contains a list of events. A red box highlights the following events:

- WIFI-AUTORF-CHANNEL-SWITCH: Channel switched from [1] to [6] on [2.4GHz] radio, [High Intf on channel]
- WIFI-AUTORF-CHANNEL-SWITCH: Channel switched from [6] to [11] on [2.4GHz] radio, [High Intf on channel]
- WIFI-AUTORF-CHANNEL-SWITCH: Channel switched from [11] to [6] on [2.4GHz] radio, [High Intf on channel]
- WIFI-AUTORF-CHANNEL-SWITCH: Channel switched from [100] to [116] on [5GHz] radio, [High Intf on channel]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [59] secs roamed [yes] tbytes [0] rxbytes [0] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-CONNECTED: Client [78-7B-8A-9A-9E-77] connected to wireless lan [Auto_pilot_4]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [13759] secs roamed [yes] tbytes [114047] rxbytes [219436] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-CONNECTED: Client [78-7B-8A-9A-9E-77] connected to wireless lan [Auto_pilot_4]
- DHCPSRVR-IP-ASSIGNED: Client [78-7B-8A-9A-9E-77], assigned [dynamic] IP [192.168.15.12] from DHCP pool [2]

Figure 142 Insight > Filtered Events

The screenshot shows the 'Insight > Filtered Events' page. The search filter is set to 'disconnect'. The list of events is filtered to show only disconnection events. A red box highlights the following events:

- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [59] secs roamed [yes] tbytes [0] rxbytes [0] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [13759] secs roamed [yes] tbytes [114047] rxbytes [219436] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [1943] secs roamed [yes] tbytes [15150] rxbytes [26173] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [1163] secs roamed [yes] tbytes [14198] rxbytes [41673] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [1654] secs roamed [yes] tbytes [14298] rxbytes [26150] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [112] secs roamed [yes] tbytes [42] rxbytes [46] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [21387] secs roamed [no] tbytes [191684] rxbytes [388282] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [99] secs roamed [yes] tbytes [42] rxbytes [46] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]
- WIFI-CLIENT-DISCONNECTED: Client [78-7B-8A-9A-9E-77] disconnected from WLAN [Auto_pilot_4] after [1] secs roamed [no] tbytes [0] rxbytes [0] avgtx [0] maxtx [0] mintx [0] avgrx [0] maxrx [0] minrx [0]

Glossary

Term	Definition
AP	Access Point Module. One module that distributes network or Internet services to subscriber modules.
ARP	Address Resolution Protocol. A protocol defined in RFC 826 to allow a network element to correlate a host IP address to the Ethernet address of the host.
BHM	Backhaul Timing Master (BHM)- a module that is used in a point to point link. This module controls the air protocol and configurations for the link.
BHS	Backhaul Timing Slave (BHS)- a module that is used in a point to point link. This module accepts configuration and timing from the master module.
DFS	See Dynamic Frequency Selection
DHCP	Dynamic Host Configuration Protocol, defined in RFC 2131. Protocol that enables a device to be assigned a new IP address and TCP/IP parameters, including a default gateway, whenever the device reboots. Thus DHCP reduces configuration time, conserves IP addresses, and allows modules to be moved to a different network within the system.
Ethernet Protocol	Any of several IEEE standards that define the contents of frames that are transferred from one network element to another through Ethernet connections.
FCC	Federal Communications Commission of the U.S.A.
GPS	Global Positioning System. A network of satellites that provides absolute time to networks on earth, which use the time signal to synchronize transmission and reception cycles (to avoid interference) and to provide reference for troubleshooting activities.
UI	User interface.
HTTP	Hypertext Transfer Protocol, used to make the Internet resources available on the World Wide Web.
HTTPS	Hypertext Transfer Protocol Secure
HT	High Throughput

Term	Definition
IP Address	32-bit binary number that identifies a network element by both network and host. See also Subnet Mask.
IPv4	Traditional version of Internet Protocol, which defines 32-bit fields for data transmission.
LUID	Logical Unit ID. The final octet of the 4-octet IP address of the module.
MAC Address	Media Access Control address. The hardware address that the factory assigns to the module for identification in the Data Link layer interface of the Open Systems Interconnection system. This address serves as an electronic serial number.
Maximum Information Rate (MIR)	The cap applied to the bandwidth of an SM or specified group of SMs. In the Cambium implementation, this is controlled by the Sustained Uplink Data Rate, Uplink Burst Allocation, Sustained Downlink Data Rate, and Downlink Burst Allocation parameters.
MIB	Management Information Base. Space that allows a program (agent) in the network to relay information to a network monitor about the status of defined variables (objects).
MIR	See Maximum Information Rate.
PPPoE	Point to Point Protocol over Ethernet. Supported on SMs for operators who use PPPoE in other parts of their network operators who want to deploy PPPoE to realize per-subscriber authentication, metrics, and usage control.
Proxy Server	Network computer that isolates another from the Internet. The proxy server communicates for the other computer, and sends replies to only the appropriate computer, which has an IP address that is not unique or not registered.
SLA	Service Level Agreement
VLAN	Virtual local area network. An association of devices through software that contains broadcast traffic, as routers would, but in the switch-level protocol.

Term	Definition
VPN	Virtual private network for communication over a public network. One typical use is to connect remote employees, who are at home or in a different city, to their corporate network over the Internet. Any of several VPN implementation schemes is possible. SMS support L2TP over IPSec (Level 2 Tunneling Protocol over IP Security) VPNs and PPTP (Point to Point Tunneling Protocol) VPNs, regardless of whether the Network Address Translation (NAT) feature enabled.
VHT	Very High Throughput